

CORPORATE HEADQUARTERS

8100 34TH AVENUE SOUTH, MINNEAPOLIS, MINNESOTA

MAILING ADDRESS • BOX 0, MINNEAPOLIS, MINNESOTA 55440

CONTROL DATA

July 15, 1975


Dear Customer:

Attached is the July 1975 Literature Catalog. Please read all instructions in the front section of this catalog before placing orders. This catalog obsoletes all previous editions.

Tranex Users Guide, Publication No. 60436500 will not be available under Kronos V2.1. This document will be available under NOS V1.0, but not until 11-15-75.

Batch Users Guide, Publication No. 60436300 will not be available until 10-22-75.

T-S Users Guide, Publication No. 60436400 will not be available until 9-15-75.



G. F. Moore, Manager
Literature & Distribution Services

GFM/sku

**CONTROL DATA CORPORATION
LITERATURE AND DISTRIBUTION SERVICES
8100 34TH AVENUE SOUTH, P.O. BOX O
MINNEAPOLIS, MINNESOTA 55440
TELEPHONE: 612-853-4157
TWX NUMBER 910-576-2978
TELEX NUMBER 290-435**



JULY 1975 EDITION

THIS CATALOG OBSOLETE
ALL PREVIOUS EDITIONS

EXTERNAL CUSTOMER CATALOG
PUBLICATION 90310500

INTRODUCTION

The Literature and Distribution Services Department of Control Data Corporation is responsible for the publishing of this catalog and the distribution of the items contained therein. The purpose of LDS is to provide a central ordering and distribution service for the external sale of literature and coding forms to Control Data customers.

The Customer Catalog will be published twice during 1975, with literature supplements published during the interim months. The monthly supplements reflect the changes which have taken place in the previous month including obsoleted publications, new publications and revision changes.

LDS solicits your comments and requests that verbal or written communication be directed to the Manager of Literature and Distribution Services.

TABLE OF CONTENTS

	<u>PAGE</u>
Manual Definition	I-1 - I-2
Procedures For Ordering Manuals	I-3 - I-5
Procedures For Ordering Coding Forms	I-5
Listing Of Coding Forms	I-6 - I-7
Accumulated Literature Change Listings	I-8 - I-27
Obsoleted Publications	I-28 - I-29
Numerical Listing Of Publications	
With Page Locations	I-30 I-38
Section I - Hardware Manuals	1-53
Listed Under Equip. Designator	
Section II - Software Manuals	54-127
Listed Under Product Number	
Section III - Software Manuals	128-155
Listed Under Operating Systems	
Table Of Software Abbreviations	129
Section IV - Miscellaneous Manuals -	156
Binders, Templates, Etc.	
Miscellaneous Manuals	157-158
Education Manuals	159
Training Manuals	159-162
Technical Reports	162-163
Video Lecture Manuals	163
SCM Publications	163-164
Hard Cover Binders	164-165
Templates	165
Motor Generator Set Manuals	165
Refrigeration Manuals	165
Power Supply Manuals	165-166
Printed Circuit Manuals	166
Site Preparation Manuals	166-167
Vendor Manuals	167-168
Long Line Transmission For 1604 Type I/O	168
Miscellaneous Equipment Modifications	168-169
QSE	169
Standard Options	169-171
Special Options	171-172
Cybernet Publications	172-179

MANUAL DEFINITION

The following general description of manuals, operator guides and handbooks is provided to allow the catalog user to more quickly identify categorically, the type of book he requires. With this information the user can then relate more easily to the section of this catalog which contains the required manual.

Hardware Reference Manual - This manual provides functional and operational descriptions and general programming capability information on Control Data hardware products and systems. This manual is written to the level of a knowledgeable prospective customer, professional programmer, and equipment operator.

Customer Engineering Manual - This manual provides the technical information necessary to maintain Control Data hardware products. Categories of information presented, in one or more volumes, are: General Description, Operation and Programming, Installation and Checkout, Theory of Operation, Diagrams, Maintenance, Maintenance Aids, Parts Data, Wire Lists, and Equation Summary (or equivalent).

Hardware Reference/Customer Engineering Manual - This combined manual, usually for less complex devices that require minimal programming information, contains the same information as that in separate Reference and Customer Engineering manuals.

Site Preparation Manual - This manual presents technical information with which to plan and prepare sites for computer installation. Three sections make up this manual:

Section I: General Information - Two Section I manuals are available: One for small systems; the other covers large and medium-scale systems.

Section II: System Information - Section II manuals cover site planning information for specific systems; e.g., 3300, 6400, etc.

Section III: Peripheral Equipment - Section III provides site planning data on all Control Data peripheral equipment.

Hardware Diagnostic Reference Manual - This manual provides a functional description and detailed operating instructions for diagnostic programs.

System Operator's Manual - This manual provides operating instructions to the system operator. Instructions in this manual normally include system start-up, message formats, error recovery procedures, and general system information. This manual is written to the level of computer operators who do not have a detailed knowledge of programming.

System Reference Manual - This manual describes the system in terms of function, applications, and capabilities. Provides a configuration of the hardware that makes up the system with a brief description of the system function of each product. May also include a description of the software available with the system. Written to the level of the prospective customer who does not have a detailed knowledge of either the hardware or software.

Software General Information Manual - This manual provides introductory descriptions of functional and operational characteristics of Control Data software products.

Software Reference Manual - This manual provides complete descriptions of external functional and operational characteristics of Control Data software products.

Software Operator's Guide - This manual provides detailed instructions for operating Control Data software systems.

Software Diagnostic Handbook - This manual provides the messages issued by all programs in a software product set, together with the recommended action.

Software Installation Handbook - This manual provides installation and modification instructions for Control Data software products.

Software User's Guide - This manual provides the layman with the instructions on how to use a software product.

Software Instant Manual - This pocket-size manual provides summary information {deck structures, etc.} for system programmers and operators of software systems.

LITERATURE ORDERING POLICY AND PROCEDURES

Please read these policies and procedures prior to ordering to avoid confusion and mistakes and also to expedite the handling of orders.

PURCHASE ORDERS - Orders directed to LDS should include, if possible, a numbered purchase order, a money order or personal check.

ORDER LEAD TIME - All customer orders received will be handled on a priority basis and normally processed within a four working day period. Please keep in mind the transit time required by your order to both get to LDS and for the order to travel to your place of business. Under normal conditions, complete turn around on orders should not exceed fourteen calendar days.

DOMESTIC ORDERS - All purchase orders from domestic customers should be forwarded directly to:

Literature & Distribution Services
Control Data Corporation HQC00C
8100 34th Avenue South, P.O. Box 0
Minneapolis, Minnesota 55440

INTERNATIONAL ORDERS - International customer orders should be directed to the nearest Control Data Sales Office. The Control Data Sales Office will then process your order through LDS.

PRICING - The prices contained in this catalog are subject to change without notice.

FOB - All prices are F.O.B. Minneapolis, Minnesota

TERMS: NET 30 DAYS

SHIPPING REQUIREMENTS - Shipping instructions as given by the customer will be followed whenever possible. However, when the instructions cannot be adhered to, LDS reserves the right to determine the mode of transportation.

PRICE QUOTES - Price quotes are available upon request and are valid for 30 days only.

TELEPHONE ORDERS - LDS will accept telephone orders but each order must reference a purchase order number. A purchase order must follow confirming the phone order, and should be marked 'confirmation, do not duplicate'.

IDENTIFICATION OF MANUALS NEEDED - When ordering, you must specify whether you require a specific revision packet to a manual or if you desire the complete manual with all applicable revision packets updating the publication to its current revision level.

LITERATURE ORDERING POLICY AND PROCEDURES {CONT.}

NOTE: In some cases, the revision packet required is not available. However, the manual itself may have been reprinted through the revision which you require. If the packet is not available and you wish LDS to send you the updated manual, please specify same on your order. If you do not give LDS specific instructions for such a possibility, LDS will return your order and will not arbitrarily send the updated manual in place of the unavailable revision packet.

BACK ORDERS - All out of stock items will be automatically backordered and routed to you upon resupply of the item to stock. Please contact LDS should you not want specific items backordered.

DISCOUNTS - Discounts are given for literature as follows:

- {1} A 10% discount is given when ordering 25 to 99 copies of a single document.
- {2} A 20% discount is given when ordering 100 or more copies of a single document.

RETURNS FOR CREDIT - LDS does not sell literature on a consignment basis but will accept returns to stock if LDS has misfilled or delayed delivery of order so that the manuals are no longer required. Manuals which customers have ordered in excess of their needs may be returned if the publications are still current. IT IS IMPORTANT THAT YOU CONTACT AND RECEIVE FROM LDS WRITTEN APPROVAL BEFORE ANY MANUALS ARE RETURNED TO LDS. The manuals must be unused, in new condition and sent freight prepaid. Complete paperwork must accompany all returns for credit. Complete paperwork would include your original order number and if possible a copy of the order, the date of order and a copy of the LDS generated order invoice. All uncleared return to stock orders which LDS receives will be returned to the originator at the originator's expense.

AUTOMATIC SOFTWARE REVISION PACKET DISTRIBUTION SERVICE - On July 1, 1972, an additional service was made available to CDC customers. This service provides for the free postpaid automatic distribution to eligible customers of software revision packets as the packets become available. The policy holds that all external customer manual orders received directly from the customer by LDS on July 1, 1972 and thereafter will be eligible for automatic revision packet distribution. The customer is requested to return a copy of the shipping document which will be provided by Literature and Distribution and indicate on the document which Software publications they wish to have placed on the A/D service. A cover memo will be sent with each shipment indicating the guidelines you must follow. The packets will then be supplied to the customer in the same quantity as the manuals purchased under the original manual purchase order. The packets will continue to be distributed as long as packets are published or until the customer notifies LDS that the distribution should stop. You must establish eligibility

LITERATURE ORDERING POLICY AND PROCEDURES {CONT.}

by the purchase of a manual as a customer will not be placed on the listing if he purchases only a revision packet. Revision packets for manuals purchased prior to July 1, 1972, must be purchased by the customer and not through a CDC Sales Office. Not all customers will want this service as some manuals are purchased for a short duration use, such as orders by educational institutions for class use. Please indicate on your order if you do not wish this automatic packet distribution service.

GENERAL REVISION PACKET PRICING - All revision packets which support manuals sold to external CDC customers by LDS after July 1, 1972, will be provided free of charge. The packets will be given in the same quantity as the original manual purchase. Software packets will be automatically distributed {see Automatic Software Revision Packet Distribution above} whereas, requests for Hardware and Miscellaneous packets to support previously purchased manuals must be made directly to LDS by the customer. Please state on your order that the packets are in support of previously ordered manuals to avoid a billing for the packets. Quantities of packets which are in excess of the total number of manuals initially purchased by the customer will be charged to the customer.

PROCEDURES FOR ORDERING CODING FORMS

All purchase orders for coding forms from International customers should be directed to the nearest Control Data Sales Office. All purchase orders from Domestic customers should be directed to:

Literature & Distribution Services
Control Data Corporation
8100 34th Avenue South, P.O. Box 0
Minneapolis, Minnesota 55440

The unit price, form number, description and sheets per pad are as shown on the following pages.

Control Data does not offer quantity discounts on Forms sales.

CODING FORMS

<u>FORM NO.</u>	<u>DESCRIPTION</u>	<u>UNIT PRICE</u>
AA0138	OSAS/OSAS-A Coding Form	\$.75/PD
*AA0193	1604 Assembly Coding Form	
*AA0235	1604 Octal Card For General Load	
*AA0236	1604 Decimal Card For General Load	
AA0252	FORTTRAN Coding Form	.84/PD
AA0323	80 Column Punched Card Layout	.90/PD
AA0366	3600 COMPASS System Coding Form	1.00/PD
AA0382	COBOL Coding Form	.86/PD
AA0382-1	COBOL Coding Form	1.00/PD
AA0383	AUTOCOMM Coding Form	.66/PD
AA0540	160/160-A Data Processor	.81/PD
*AA0543	160 G Octal/Decimal Loader Form	
AA0649	Tape Record Layout	1.02/PD
AA1030	Computer Operating Instructions	1.33/PD
AA1031	Intercom Program	.87/PD
AA1040	Report and Tape Layout	2.82/PD
AA1053	Cybernet Tape/Pkt. Lab	.06/EA
AA1084	Obsolete - Use AA5491	
AA1085	Obsolete - Use AA5492	
AA1086	Obsolete - Use AA5490	
AA1133	Obsolete - Use AA5494	
AA1283	Loadflow Program - Control Information	.73/PD
AA1284	Loadflow Program - Line & Transformer Data	1.18/PD
AA1385	Software Document	1.40/PD
AA1385-1	Software Document	2.75/PD
AA1401	Index To Data Files For System	.99/PD
AA1405	Documentation Charting Form - Large	4.17/PD
AA1457	1700 Absolute Programming Sheet	1.24/PD
AA1502	Element Values LP-DCD Linear Programming Code	.87/PD
AA1503	Row Or Column Name LP-DCD Linear Programming Code	.70/PD
AA1529	Tape Record Format	.97/PD
AA1530	Card Format {S}	.97/PD
AA1708	SIMSCRIPT Report Generator Layout Form	1.46/PD
AA1709	SIMSCRIPT Initial	1.48/PD
AA1710	SIMSCRIPT Definition Form	1.62/PD
AA1775	6600 ASCENT System Coding Form	.64/PD
AA1779	80 Column Punched Card Layout	1.20/PD
AA2142	PERT/TIME Coding Form - Type A Data	1.36/PD
AA2184	Obsolete - No Replacement	
AA2212	OSAS/OSAS-A TAS 915 Coding Form	48.60/RM
AA2364	Transfer Request	.64/PD
AA2394	Report Generator Coding Form	.90/PD
AA2422	Multiple Layout Card Form	.78/PD
AA2442	CIVCO Input Data Form	1.63/PD
AA2453	Pagination Sequence	.98/PD
AA2501	Forecasting Worksheet	1.44/PD
AA2583	Form Layout Sheet - 8 1/2 x 11 Vertical	1.57/PD
AA2583-1	Form Layout Sheet - 8 1/2 x 11 Horizontal	2.00/PD
AA2836	Sample Format and Card	.94/PD
AA2986	Eunas Data Form	1.02/PD

*PRICES AVAILABLE UPON REQUEST

CODING FORMS {CONT}

<u>FORM NO.</u>	<u>DESCRIPTION</u>	<u>UNIT PRICE</u>
AA2987	6000/7000 Compass Coding Form	\$.76/PD
AA3034	Department Data and Recaps	.84/PD
AA3034-1	Departmental Recap Names	.85/PD
AA3168	SAMIS, Pseudo Instruction Input Data-Form 1	1.02/PD
AA3169	SAMIS, Materials Tables Input Data-Form 2	1.02/PD
AA3170	SAMIS, Facet and Beam Element Input Data-Form 3	1.02/PD
AA3171	SAMIS, Matrix Input Data - Form 4	1.02/PD
AA3385	Program Trouble Sheet	.17/EA
AA3389	CDC/MACRAN Coding Form	1.02/PD
AA3422	STARDYNE Data Form, Prep Data Form 2	.87/PD
AA3423	STARDYNE Data Form, 10 Digit Decimal Data	.71/PD
AA3424	STARDYNE Data Form, Stardyne Static Loads	.93/PD
AA4173	3000L Compass System Coding Form	1.44/PD
AA4193	TELCOM User Master Corrections	.87/PD
AA4206	6000/7000 Table Form	.91/PD
AA4405	Revision Record	1.29/PD
AA4437	OPHELIE-LP MPS Data Form	.67/PD
AA5490	DC0/Tranplan Transit NE	1.12/PD
AA5491	DC0/Tranplan Transit NE	1.40/PD
AA5492	DC0/Tranplan Transp System	.88/PD
AA5493	DC0/Tranplan Transp PLA	1.29/PD
AA5494	DB0/Tranplan Transp PLA	1.53/PD
AA6036	Bridge Analysis Input Data-Card Type 1	1.62/PD
AA6037	Bridge Analysis Input Data-Card Types 2, 5, 6	1.44/PD
AA6038	Bridge Analysis Input Data-Card Type 3	1.62/PD
AA6039	Bridge Analysis Input Data-Card Type 7	1.46/PD
AA6040	Bridge Analysis Input Data-Card Type 8	1.45/PD
AA6041	Bridge Analysis Input Data-Card Type 9	1.46/PD
AA6042	Bridge Analysis Input Data-Card Type 10	1.42/PD
AA6043	Bridge Analysis Input Data-Card Type 11	1.46/PD
AA6044	Bridge Analysis Input Data-Card Type 12	1.35/PD
AA6045	Bridge Analysis Input Data-Card Type 13	1.46/PD
AA6046	Bridge Analysis Input Data-Card Type 14	1.46/PD
AA6047	Bridge Analysis Input Data-Card Type 15	1.46/PD
AA6048	Bridge Analysis Input Data-Card Type 60	1.46/PD
AA6049	Bridge Analysis Input Data-Card Type 61	1.38/PD
AA6050	Bridge Analysis Input Data-Card Type 62	1.62/PD
AA6051	Bridge Analysis Input Data-Card Type 63	1.35/PD
AA6052	Bridge Analysis Input Data-Card Type 64	1.35/PD
AA6053	Bridge Analysis Input Data-Card Type 65	1.46/PD
AA6054	Bridge Analysis Input Data-Control Cards	1.62/PD
MSC015R1	LGP 30 Coding Form Forms comprise set, must	1.16/PD
MSC016R1	LGP 30 Coding Form be sold together	1.16/PD
MSC05710	LGP 30 Work Format	.99/PD

All pads contain 50 sheets each
All reams contain 500 sheets each

ACCUMULATED LITERATURE CHANGE LISTING

This section is an accumulation of all literature revisions, additions and deletions which have taken place since the issuance of the January 1975, Literature Catalog. The manuals are listed numerically by product number.

The legend for columns one through six is as follows:

- 1-New or revised literature published since last edition.
 - A. N-New Publication
 - B. R-Revision in packet form only
 - C. RM-Revision in manual form only
 - D. RMP-Revised manual/packet available
 - E. RO-Revised publication obsoletes all previous editions.
 - 2-Publication number of literature
 - 3-The latest revision level
 - 4-Indicates size of hard cover binder that may be used for manuals
 - 5-Publication division responsible for contents of literature
- *FOR CONTROL DATA USE ONLY

1	TITLE	2	3	4	5
*N	33158 MEMORY SYSTEMS SALES REFERENCE MAN	10121100	-	--	HQW
R	FJ601-A {3316-1, 3516-1} MULTIPLEXER CON- TROLLER THEORY OF OPERATION, INSTALLA- TION/CHECKOUT, DIAGS., MAINT., MAINT. AIDS, PARTS DATA AND WIRE LISTS CE MAN	13796700	K	22	ARH
N	469 COMPUTER SYSTEM 462-01A AND 462-02A TELETYPE CONTROLLER HARDWARE REF/CE MANUAL	14060200	-	22	MSP
N	469 COMPUTER SYSTEM 461-01B/02A PUNCHED TAPE MEMORY LOADER/TAPE PUNCH HARDWARE REFERENCE/CE MANUAL	14060300	A	22	GSD
N	MP-60 COMPUTER SYSTEM COMPASS REFERENCE MAN	14061300	B	22	GSD
N	MP-60 COMPUTER SYSTEM COSY REFERENCE MANUAL	14062100	A	22	GSD
N	MP-60 COMPUTER SYSTEM PRELIB REFERENCE MAN	14062200	A	22	GSD
N	469 COMPUTER SYSTEM PROGRAMMING REF MANUAL	14065300	B	22	GSD
N	469 COMPUTER SYSTEM ASSEMBLER V 1.2 REF MAN	14077300	C	22	GSD
N	469 COMPUTER SYSTEM SIMULATOR V 1.0B REF MAN	14082100	D	22	GSD
N	469 COMPUTER SYSTEM BASIC ARITHMETIC SUB- ROUTINES REFERENCE MANUAL	14082200	B	22	GSD
RO	5600 COMPUTER SERIES MPP REFERENCE MANUAL	14232000	A	22	GSD
N	MP-60 COMPUTER SYSTEM REFERENCE MANUAL	14306500	A	22	GSD
N	33159 MONOLITHIC MAIN MEMORY SYSTEMS SALES REFERENCE GUIDE	15001100	-	--	HQW
R	6000 COMPUTER SYSTEMS CONTINUOUS SYSTEM SIMULATION LANGUAGE III USERS GUIDE VERSION I	17304400	F	22	SVL
N	6000/CYBER 70 MODELS 72/73/74 COMP SYSTEM DIGITAL DISPLAY SYSTEM {DDS} VER 3 REFERENCE MANUAL	17318900	A	22	SVL
RO	6000/CYBER 70 MODELS 72,73,74 COMP SYSTEM 777 INTERACTIVE GRAPHICS SYSTEM VER 2 OPERATORS GUIDE	17322600	B	22	SVL
RO	6000/CYBER 70 MODELS 72,73,74 LCGT/IGS VERSION 1 G.I.M.	17322700	B	3	SVL
RO	CYBER 70 COMPUTER SYSTEMS MODELS 72,73,74 LOW COST GRAPHICS TERMINAL {LCGT} INTERACTIVE GRAPHICS SYSTEM {IGS} VERSION 1.1 REFERENCE MANUAL	17322800	B	22	SVL
N	777 THREE DIMENSIONAL INTERACTIVE GRAPHICS SYSTEM {3-D IGS} VER 1 REF MAN CONTROL DATA 6000 CYBER 70 MODELS 72,73,74 COMPUTER SYSTEMS	17326500	A	22	SVL
R	6000/CYBER 70 MODELS 72,73,74 COMPUTER SYS 3000L TO CYBER 70 CONVERSION AIDS SYSTEM VER 1.0 FORTRAN CONVERSION FOR SCOPE 3.4	19980600	C	22	TT0

CONT.

1	TITLE	2	3	4	5
R	6000/CYBER 70 MODELS 72,73,74 COMPUTER SYS 3000L TO CYBER 70 CONVERSION AIDS SYSTEM VER 1.0 COBOL CONVERSION FOR SCOPE 3.4	19980700	B	22	TTO
R	6000/CYBER 70 MODELS 72,73,74 COMPUTER SYS 3000L TO CYBER 70 CONVERSION AIDS SYSTEM VER 1.0 LANGUAGE CONVERSION USERS GUIDE FOR SCOPE 3.4	19980900	B	22	TTO
RO	CYBER 170-MODELS 172/173/174 SYSTEMS DATA SITE PREPARATION MANUAL	19981400	A	22	ARH
N	CYBER 170 MODELS 172,173,174 CENTRAL PRO- CESSOR UNIT THEORY OF OPERATION, DIAGS, HARDWARE MAINT. MANUAL VOLUME 1 OF 2 {PRELIMINARY ED.}	19981800	01	22	TTO
N	CYBER 70/CYBER 170/6000 SERIES COMPUTER SYS COBOL VERSION 5.0 GIM	19984100	A	22	TTO
N	FF525 PRINTER SUBSYSTEM CENTRAL CONTROL UNIT LOGIC DIAGRAMS	22272500	A	34	PLY
N	28211-21 PRINTER SUBSYSTEM LOGIC DIAGRAMS	22273100	A-G	34	PLY
RO	1538 {FL301A} HIGH-SPEED, HIGH LEVEL ANALOG INPUT CONTROLLER	39074500	D	22	LJL
N	1700 A/Q {DC220/221-A} DSA ADAPTERS GEN DESC., OPER AND PROGRAMMING, INSTALLA- TION AND CHECKOUT, THEORY OF OPER., DIAGS, MAINT, MAINT. AIDS, PARTS DATA, WIRE LISTS, HDWE/REF/CE MANUAL	39392700	C	22	LJL
RO	1700 COMPUTER SYSTEMS MSOS 4 FILE MANAGER VERSION 1 SOFTWARE REFERENCE MANUAL	39520600	B	22	LJL
N	1700 COMPUTER SYSTEMS 1700 MSOS 4.1 FORTRAN 3.2 A/B, AND TIMESHARE 2.0 RELEASE BULLETIN	39520800	A	22	LJL
N	1700 COMPUTER SYSTEMS MSOS VERSION 4 ORDER- ING BULLETIN	39521900	B	22	LJL
RO	1700 COMPUTER SYSTEMS MSOS 4 G.I.M.	39522400	B	22	LJL
R	GH107-B/ED301-E MULTIPLEXER {MX-7A} GENERAL DESC., DIAGRAMS, WIRE LISTS, PARTS DATA CE MANUAL	39660400	B	22	LJL
N	BG504A-H DRUM MEMORY SUBSYSTEM HARDWARE REFERENCE/CE MANUAL	39731700	C	22	LJL
RO	DK605-A {1595-10/11} SERIAL I/O UNIT REF CE MANUAL	39909507	B	22	LJL
N	1590-3 {DN124-A,FJ124-A} REMOTE COMPUTER INTERFACE SUBSYSTEM HARDWARE REF/CE MANUAL	39909513	A	22	LJL
RO	BE102 {608} MAGNETIC TAPE TRANSPORT PARTS LIST CE MANUAL	40864100	G	22	VFD
R	FJ103-A/B/C/D/E {1748-2} MULTIPLEXER CON- TROLLER THEORY OF OPERATION, INSTALLA- TION CHECKOUT, DIAGS., MAINT., MAINT. AIDS, PARTS DATA CE MANUAL	41601700	J	22	ARH
RMP	DJ110-A {311-2} DATA SET ADAPTER THEORY OF OPERATION, INSTALLATION/CHECKOUT, DIAGS., MAINT., MAINT. AIDS, PARTS DATA CE MANUAL	41603200	C	22	ARH
R	FJ103-A/B/C/D/E {1748-2} MULTIPLEXER CONTROLLER CARD PLACEMENT, LOGIC WIRING, WIRE LISTS EQUATION SUMMARY CE MANUAL	41603300	E	22	ARH

CONT.

1	TITLE	2	3	4	5
R	361-5 {DJ144-A} COMMUNICATIONS ADAPTER REFERENCE MANUAL	41611800	C	22	ARH
RO	1700/SC1700 COMPUTER SYSTEMS DRAFT VERSION 5.1 OCR REFERENCE MANUAL	48143900	F	22	ROK
RO	CJ122 DIAGRAMS VOLUME 2, PART 3, CE MANUAL	48430045	B	22	ROK
RO	CJ122 PAGE AND DOCUMENT READER MODELS C-K VOLUME 1 HARDWARE MAINTENANCE MANUAL	48430080	C	22	ROK
RO	BE406 {659-1} MAGNETIC TAPE TRANSPORT GEN. DESC., THEO OF OPER., MAINT. CE MAN	49750600	G	22	VFD
N	34201 MAGNETIC TAPE TRANSPORT OPERATORS MANUAL	49752300	A	3	VFD
RO	415 CARD PUNCH DIAGRAMS, THEORY OF OPERATION, GEN. DESC., CE/REFERENCE MANUAL	49755300	C	22	VFD
RO	BE482 {9525} MAGNETIC TAPE TRANSPORT DIAGS. CE MANUAL	49755800	C	22	VFD
N	CH102-A/B CARD PUNCH PART IDENTIFICATION MANUAL	49762400	A	22	VFD
RO	BE103 {657-1} MAGNETIC TAPE TRANSPORT PARTS LIST CE MANUAL	49815000	G	22	VFD
N	3000 COMPUTER SYSTEM BROKERAGE CONTROL SYS VER 4.0 REF MAN	59159000	A	22	ARH
N	3000 COMPUTER SYSTEMS BROKERAGE CONTROL SYS VER 4.0 OPERATORS GUIDE	59159100	A	22	ARH
N	EXTENDED CORE STORAGE DATA PATH AND STACK SELECT MAINTENANCE AID CHART	59304600	-	--	ARH
N	14031 TRAIN PRINTER GEN DESC., INSTALLATION & CHECKOUT, OPER AND PROGRAMMING, PRINCIPLES OF OPERATION, MAINT, MAINT AIDS CE MANUAL VOLUME I	59708200	A-01	22	RHT
N	14031 TRAIN PRINTER DIAGRAMS & WIRE LIST CE MANUAL VOLUME 2	59708300	A-01	22	RHT
N	14031 TRAIN PRINTER VOLUME 3 PARTS DATA CE MANUAL	59708400	A-01	22	RHT
RO	SINGER BUSINESS MACHINES LINE PRINTER EQUIP- MENT MODELS 53, 54, 55 AND 56 PARTS MAN	59708700	D	3	RHT
RO	9322 SINGER FIELD SERVICE MANUAL VOLUME 2	59709000	B-01	34	RHT
R	PRINTED CIRCUIT MANUALS CORDWOOD MANUAL VOLUMES 1, 2, 3	60042700	AY	22	ARH
R	3200 COMPUTER SYSTEM CE DIAGRAMS	60049400	AY	22	ARH
R	3100/3150/3170/3200/3300/3500 COMPUTER SYS MASTER/MSOS/RTS MASS STORAGE FORTRAN VERSION 3 AND 4 REFERENCE MANUAL	60057600	G	22	ARH
R	3228-A/B MAGNETIC TAPE CONTROLLER CE MANUAL	60093700	V	22	ARH
R	6000 COMPUTER SYSTEMS REFERENCE MANUAL	60100000	AE	22	ARH
R	3104/3114-A/B COMPUTER DIAGRAMS CE MANUAL	60111100	BE	22	ARH
R	3000L SYSTEM MAINTENANCE MONITOR REF MANUAL VOLUME 1 AND 2	60118600	M	22	ARH
R	DC211-A {6684-A} DATA CHANNEL CONVERTER CE MANUAL	60125000	AZ	22	ARH
R	6411-A/6416-A AUGMENTED I/O BUFFER CONTROL DIAGRAMS AND CIRCUIT DESCRIPTION	60146200	U	22	AR
R	3104-A/B, 3114-A/B COMPUTER CARD PLACEMENT, EQUATION SUMMARY CE MANUAL	60152500	AD	22	ARH
R	3104-A/B, 3114-A/B COMPUTER WIRE LIST {TERM} CE MANUAL	60152600	AA	22	ARH
R	3458-A LINE PRINTER CONTROLLER DIAGS CIRC. DESC., MAINT AND PARTS LIST	60158200	Z	22	ARH
RO	1700 COMPUTER SYSTEM CODES	60163500	H	6	LJL

CONT.

1	TITLE	2	3	4	5
R	1706-A BUFFERED DATA CHANNEL DIAGS., CIR- CUIT DESC., MAINTENANCE, PARTS LISTS CE MANUAL	60165700	L	22	LJL
R	1700 COMPUTER SYSTEM INPUT/OUTPUT SPECIFI- CATIONS MANUAL	60165800	H	22	LJL
R	6400/6500-A/B/C CENTRAL COMPUTER CABLE TABS {FOR 6404-A, 6414/6514-A/B/C {ONLY}}	60166000	M	22	ARH
R	6400/6500-A/B/C CENTRAL COMPUTERS CHASSIS 3 CHASSIS TABS	60166300	AR	22	ARH
R	1738-A/B/C DISK DRIVE CONTROLLER CE MANUAL	60167700	U	22	LJL
R	3234-A/B MASS STORAGE CONTROLLER DIAGRAMS CE MANUAL	60167900	AD	22	ARH
R	6400/6500-A/B/C CENTRAL COMPUTERS CABLE TABS {FOR 6405-A, 6415-A/B/C ONLY}	60169700	M	22	ARH
R	6400/6500-A/B/C CENTRAL COMPUTERS MAINT. AND COMMAND TIMING	60182100	J	22	ARH
R	1716-A COUPLING DATA CHANNEL CE MANUAL	60182800	N	22	LJL
RO	1708-A {88310-A/88311-A/88312-A} STORAGE INCREMENT CE MANUAL	60182900	G	22	LJL
R	SMM17 REFERENCE MANUAL VOLUME 1 AND 2	60182000	M	22	ARH
R	FF511-A/B {1742} LINE PRINTER CONTROLLER CE MANUAL {INCLUDES PMI/PMP}	60183000	H	22	LJL
R	3300 COMPUTER SYSTEMS INSTRUCTION CODES	60186900	D	--	ARH
R	6400/6500-A/B/C CENTRAL COMPUTERS CHASSIS 8 CHASSIS TABS	60187700	V	22	ARH
R	6400/6500-A/B/C CENTRAL COMPUTER CABLE TABS {FOR 6413/6513-A/B/C ONLY}	60188900	G	22	ARH
R	3458-A LINE PRINTER CONTROLLER CARD PLACE- MENT, EQUATION SUMMARY, WIRE LIST CE MANUAL	60197000	S	22	ARH
R	3104-C/3114-C COMPUTER CARD PLACEMENT, EQUATION SUMMARY CE MANUAL	60197900	S	22	ARH
R	3104-C/3114-C COMPUTER WIRE LIST {TERM} CE MANUAL	60198000	M	22	ARH
R	6673/6674 DATA SET CONTROLLER CARD PLACEMENT EQUATION SUMMARY CE MANUAL	60201500	N	22	ARH
R	6673/6674 DATA SET CONTROLLER WIRE LISTS CE MANUAL	60205400	L	22	ARH
RM	1732-A/B MAGNETIC TAPE CONTROLLER CE MANUAL	60208200	L	22	LJL
R	88319-A {6634-C} EXTENDED CORE STORAGE ASSEMBLY DIAGRAMS, CIRC. DESC., WIRE LIST CE MANUAL	60209600	W	22	ARH
R	88313-A {3502} STORAGE MODULE CE MANUAL	60210200	AC	22	ARH
R	88323-A {6635-C} EXTENDED CORE STORAGE ASSEMBLY DIAGRAMS, CIRC. DESC., PARTS LIST, CARD PLACEMENT CE MANUAL	60212200	W	22	ARH
R	FJ411-A/B {6671} DATA SET CONTROLLER DIAGS. CIRCUIT DESC., PARTS LIST, CARD PLACE- MENT, EQUATION SUMMARY, WIRE LISTS CE MANUAL	60217400	W	22	ARH
RO	SMM17 PROGRAM LISTINGS - MEM	60220100	F	22	ARH
RO	SMM17 PROGRAM LISTINGS - COM	60220200	E	22	ARH
RO	SMM17 PROGRAM LISTINGS - PTP	60220300	E	22	ARH
RO	SMM17 PROGRAM LISTINGS - PTR	60220400	E	22	ARH
RO	SMM17 PROGRAM LISTINGS - TTY	60220500	F	22	ARH
RO	SMM17 PROGRAM LISTINGS - CR1	60220600	D	22	ARH
RO	SMM17 PROGRAM LISTINGS - MT1	60220700	E	22	ARH
RO	SMM17 PROGRAM LISTINGS - DP1	60220800	F	22	NRM

CONT.

1	TITLE	2	3	4	5
R0	SMM17 PROGRAM LISTINGS - RPT	60220900	F	22	ARH
R0	SMM17 PROGRAM LISTINGS - SC1	60221100	F	22	ARH
R0	SMM17 PROGRAM LISTINGS - LP1	60221200	F	22	ARH
R0	SMM17 PROGRAM LISTINGS - MT2	60221300	E	22	ARH
R0	SMM17 - PROGRAM LISTINGS - MT3	60221700	G	22	ARH
R0	FF516-A {1740} LINE PRINTER CONTROLLER CE MANUAL	60223800	J	22	LJL
R	BB323-A {6635-C} EXTENDED CORE STORAGE ASSEMBLY CHASSIS/CABLE TABS CE MANUAL	60230300	S	22	ARH
R	6000 COMPUTER SYSTEMS SIMULA REFERENCE MAN	60234800	F	22	SVL
R	6613-D COMPUTER SYSTEM CENTRAL MEMORY CLOCK, ECS COUPLER, POWER DIAGRAMS CE MANUAL	60246600	U	22	ARH
R	6400/6500-D CENTRAL COMPUTERS CPU, CENTRAL MEMORY, CLOCK, ECS COUPLER AND POWER DIAGRAMS	60246800	AG	22	ARH
R	6400/6500-D CENTRAL COMPUTERS CHASSIS 1 CHASSIS CABLE TABS	60246900	S	22	ARH
R	6613-D COMPUTER SYSTEM CHASSIS 4 CHASSIS/ CABLE TABS CE MANUAL	60247000	R	22	ARH
R	6613-D COMPUTER SYSTEM CHASSIS 8 CHASSIS/ CABLE TABS CE MANUAL	60247400	J	22	ARH
R	6614-D COMPUTER SYSTEM CHASSIS 9 CHASSIS/ CABLE TABS CE MANUAL	60247600	P	22	ARH
R	6400/6500-D CENTRAL COMPUTER CHASSIS 3 CHASSIS/CABLE TABS	60248500	U	22	ARH
R	6400/6500-D CENTRAL COMPUTER CHASSIS 6 CHASSIS/CABLE {FOR 6415-D ONLY}	60249000	K	22	ARH
R	6400/6500-D CENTRAL COMPUTER CHASSIS 8 CHASSIS/CABLE TABS	60249100	S	22	ARH
RMP	ACTIVE EXPERIMENT NETWORKS	60250500	C	3	CDI
N	6000 COMPUTER SYSTEMS SCOPE USERS GUIDE VERSION 3.3	60252700	C	22	CYB
R	FA704-A/B {3553-2} MASS STORAGE CONTROLLER CE MANUAL	60266000	AE	22	ARH
R	SMM17 INSTANT ERROR CODES	60266200	G		ARH
R	REFRIGERATION THEORY MAINTENANCE MANUAL	60268100	H	22	ARH
R	3234-A/B MASS STORAGE CONTROLLER WIRE LIST, EQUATION SUMMARY CE MANUAL	60268900	P	22	ARH
R	AT131-A {10169, 10173-3/4/5, 10174-1/2} CENTRAL MEMORY ACCESS PRIORITY REFER- ENCE CE MANUAL	60270900	H	22	ARH
R0	SMM17 PROGRAM LISTINGS {CRP} 1728/430 CARD READER/PUNCH CE MANUAL	60271300	F	22	ARH
R0	SMM17 PROGRAM LISTINGS {CR3} 1729-2/411 CARD READER	60271400	F	22	ARH
R0	SMM17 PROGRAM LISTINGS {CR2} 1726/405 CARD READER	60271500	E	22	ARH
R0	SMM17 PROGRAM LISTINGS - 1735/915 OCR OPTICAL CHARACTER READER CE MANUAL	60271700	F	22	ARH
R	AT129-A {10169, 10173-6/7/8/9/10} CENTRAL MEMORY ACCESS PRIORITY OPTION FOR 64/6500 A/B/C REFERENCE/CE MANUAL	60272700	G	22	ARH
R0	SMM17 DDC 1745/1746/210 DATA DISPLAY CE MAN	60273200	E	22	ARH
R	SECTION 3 PERIPHERAL EQUIPMENT DATA SITE PREPARATION MANUAL	60275300	Ob	22	ARH
R0	7700 SYSTEMS DATA SITE PREPARATION MANUAL	60277800	B	22	ARH
R	1706-A BUFFERED DATA CHANNEL CROSS TABS CE MANUAL	60284000	B	22	LJL

CONT.

1	TITLE	2	3	4	5
R	AA103-A CENTRAL COMPUTER {6414-E} PERIPHERAL PROCESSOR UNIT DIAGRAMS CE MANUAL	60284100	U	22	ARH
R	1770/SC-1700 SYSTEM CONTROLLER I/O SPECIFICATIONS	60285200	04	22	LJL
R	AA103-A CENTRAL COMPUTER {6614-E} CHASSIS 1 CHASSIS/CABLE TABS CE MANUAL	60285300	AD	22	ARH
R	AA105-A CENTRAL COMPUTER {6414-E} CHASSIS 3 CHASSIS/CABLE TABS CE MANUAL	60285500	Z	22	ARH
R	AA103-A CENTRAL COMPUTER {6614-E} CPW/FUNCTIONAL UNIT DIAGRAMS CE MANUAL	60287300	T	22	ARH
R	BB319-A {6634-C} EXTENDED CORE STORAGE ASSEMBLY, MAINTENANCE, MAINTENANCE AIDS, CE MANUAL	60289200	K	22	ARH
R	FA705-A {3553-1} MASS STORAGE CONTROLLER CE MANUAL	60290000	R	22	ARH
R	FJ427-A {6671-1} DATA SET CONTROLLER INSTALLATION/CHECKOUT, DIAGS, PARTS DATA, WIRE LISTS, EQ SUMMARY CE MANUAL	60294500	K	22	ARH
R	AA103-A CENTRAL COMPUTER {6614-E} CHASSIS 8 CHASSIS/CABLE TABS CE MANUAL	60294900	F	22	ARH
R	DT122-A {7683-1} REMOTE CHANNEL COUPLER REFERENCE/CE MANUAL	60296200	H	22	ARH
R	AA102-A {7601-1} CENTRAL COMPUTER THEORY OF OPERATION, DIAGRAMS, MAINT. AIDS	60297600	AC	22	ARH
RO	SMM3L PROGRAM LISTINGS {MM2} 3300 MEMORY	60300400	G	22	ARH
RO	SMM3L PROGRAM LISTINGS {COM}	60300600	E	22	ARH
RO	SMM3L PROGRAM LISTINGS {FPT} FLOATING POINT TEST	60300700	E	22	ARH
RO	SMM17 PROGRAM LISTINGS - CH2	60301500	G	22	ARH
RO	SMM3L PROGRAM LISTINGS {MS1}	60301900	G	22	ARH
RO	SMM3L PROGRAM LISTINGS {DVN} EXECUTIVE MODE MONITOR	60303000	F	22	ARH
RO	SMM3L PROGRAM LISTINGS 3L00 QUICK LOOK MEMORY TEST	60303700	B	22	ARH
RO	SMM3L PROGRAM LISTINGS 3L00 QUICK LOOK COMMAND TEST	60303800	C	22	ARH
RO	SMM3L PROGRAM LISTINGS 3200 EXTERNAL EQUIPMENT	60303900	E	22	ARH
RO	SMM3L PROGRAM LISTINGS - RFT	60304000	B	22	ARH
RO	SMM3L PROGRAM LISTINGS MMX INTERRUPT PROC	60304100	E	22	ARH
RO	SMM3L PROGRAM LISTINGS - SIMULATED RANDOM INSTR TEST	60304500	B	22	ARH
RO	SMM3L PROGRAM LISTINGS - 3316 CONTROLLER {CEN}	60304600	C	22	ARH
R	6000/7000/CYBER 70/CYBER 170 COMPUTER SYS FORTRAN EXTENDED REF/MANUAL VERSION 4	60305600	G	22	SVL
R	6000/7000/CYBER 70/CYBER 170 COMPUTER SYS CYBER RECORD MANAGER VERSION 1, 7000 RECORD MANAGER REFERENCE MANUAL	60307300	G	22	SVL
R	6000/CYBER 70 MODELS 72/73/74 COMPUTER SYS SCOPE INSTALLATION HANDBOOK VERSION 3.4.3	60307400	V	22	SVL
RO	SMM17 PROGRAM LISTINGS - 0C3 - FF406 TEST CE MANUAL	60309200	E	22	ARH
R	AA105-A CENTRAL COMPUTER {6414-E} DIAGRAMS CE MANUAL	60316200	Z	22	ARH
RO	SMM17 PROGRAM LISTINGS - MTS	60325800	E	22	ARH
RO	SMM17 PROGRAM LISTINGS - 0C4	60326400	D	22	ARH

CONT.

1	TITLE	2	3	4	5
R	6000/CYBER 70 MODELS 72,73,74 COMPUTER SYS SYMPL REFERENCE MANUAL VERSION 1	60328800	C	22	SVL
R	FV218-A/B {733-10} HSB SUBSYSTEM TERMINAL CONTROLLER CE MANUAL	60329700	V	22	ARH
R	1742-A/B {CL309-A/B, FF511-A/B} LINE PRINTER WITH CONTROLLER REFERENCE MANUAL	60331300	B	22	LJL
R	3248-A/B CARD READER CONTROLLER REF MANUAL	60332300	D	22	ARH
R	3458-A LINE PRINTER CONTROLLER REF MANUAL	60332800	B	22	ARH
R0	6681-B/C/D DATA CHANNEL CONVERTOR REF MANUAL	60334400	G	22	ARH
R	6673/6674 DATA SET CONTROLLER REFERENCE MAN	60334500	B	22	ARH
R	AA105-A CENTRAL COMPUTER {6414-E} CHASSIS & CHASSIS/CABLE TABS CE MANUAL	60336400	L	22	ARH
R	SMM3L PROGRAM LISTINGS - BDP TESTS 3312-A	60336500	D	22	ARH
R	SMM3L PROGRAM LISTINGS - BDP TESTS 3514	60336800	D	22	NRM
R	SMM3L PROGRAM LISTINGS - 33/3500 PAGE FILE TEST - PFT	60336900	D	22	ARH
R0	SMM3L PROGRAM LISTINGS - 3553-2/821 MS4	60337100	D	22	ARH
R0	6000/7600/CYBER 70/CYBER 170 COMPUTER SYS LOADER REF MANUAL	60344200	G	22	ARH
R0	7600/CYBER 70 MODEL 76 SCOPE 2.1 INSTANT	60344300	B	6	ARH
R	MODEL 72 SYSTEM DESCRIPTION/PROGRAMMING INFO VOLUME 1	60347000	H	22	ARH
R	MODEL 73 SYSTEM DESC/PROGRAMMING INFO VOLUME 1	60347200	E	22	ARH
R	MODEL 72/73/74 INSTRUCTION DESC VOLUME 2	60347300	J	22	ARH
R	MODEL 74 SYSTEMS DESC/PROGRAMMING INFO VOLUME 1	60347400	K	22	ARH
R0	AF104-A {1ST OP 10256} 3200 BUSINESS DATA PROCESSOR INTERFACE CE MANUAL	60347600	C	22	PLY
R0	10256 {AF101-C, AF104-A} 3200 BDP OPTION REFERENCE MANUAL	60347700	B	22	PLY
R	AC113-A CENTRAL COMPUTER THEORY OF OPERATION DIAGRAMS, MAINTENANCE CE MANUAL	60348000	AB	22	ARH
R	AC113-A CENTRAL COMPUTER LCM STACK WIRE LIST CE MANUAL	60349600	D	22	ARH
R	AA115-A {72-XX, 73-XX} BASIC UNIFIED PRO-CESSOR CHASSIS 1,3,11 WIRE LIST CE MAN	60350200	R	22	ARH
R	AA115-A {72-XX, 73-XX} BASIC UNIFIED PRO-CESSOR CHASSIS 2,6 WIRE LIST CE MANUAL	60350300	V	22	ARH
RMP	AA115-A {72-XX, 73XX} BASIC UNIFIED PRO-CESSOR CHASSIS 3 WIRE LIST CE MANUAL	60350400	L	22	ARH
R	AA115-A {72-XX, 73-XX} BASIC UNIFIED PRO-CESSOR CHASSIS 4 WIRE LIST CE MANUAL	60350500	AC	22	ARH
R	AA115-A {72-XX, 73-XX} BASIC UNIFIED PRO-CESSOR CHASSIS 7 WIRE LIST CE MANUAL	60350800	K	22	ARH
R	AA115-A {72-XX, 73-XX} BASIC UNIFIED PRO-CESSOR CHASSIS 8 WIRE LIST CE MANUAL	60350900	R	22	ARH
R	AA117-A {74-XX} PARALLEL PROCESSOR CHASSIS 12 WIRE LIST CE MANUAL	60351300	L	22	ARH
R0	PASSIVE ELECTRONICS STUDENT MANUAL	60354500	G	3	CDI
R	DK518-A {7681-1} DATA CHANNEL CONVERTER CE MANUAL	60355900	F	22	ARH
R0	6000/CYBER 70 MODELS 72,73,74 COMPUTER SYS SCOPE VERSION 3.3 TO SCOPE VERSION 3.4 CONVERSION AIDS PROGRAMMING SYSTEMS BULLETIN	60358200	D	22	SVL
R	6000/CYBER 70 MODELS 72,73,74 COMPUTER SYS DATA DESCRIPTION	60359000	B	22	SVL

CONT.

1	TITLE	2	3	4	5
RO	6000/CYBER 70 COMPUTER SYSTEMS DDL FOR THE QUERY UPDATE SUBSCHEMA {QUIDDL} REFERENCE MANUAL	60359200	C	22	SVL
R	6000/CYBER 70/CYBER 170 COMPUTER SYSTEMS & BIT SUBROUTINES REF MANUAL VER 1.0	60359400	C	22	SVL
RO	1700 COMPUTER SYSTEMS MSOS VERSION 4 REFERENCE MANUAL	60361500	D	22	LJL
R	1700 COMPUTER SYSTEMS MSOS DIAGNOSTIC HANDBOOK VERSION 4	60361800	D	--	LJL
R	1700 COMPUTER SYSTEMS 1700 MSOS 4 MS FORTRAN 3A/B REFERENCE MANUAL	60362000	D	22	LJL
R	7054-1 {DT209-C, FA710-A-F, FA719-A-D, MA710-A/B} OPERATION AND PROGRAMMING MANUAL	60363900	J	22	ARH
R	DT209-C {7054-1/2} 6000 COUPLER REF/CE MAN	60364100	R	22	ARH
RO	7054-1 {DT209-C, FA710-A/B/C/D/E/F, FA719- A/B/C/D/MA710-A/B} GEN INFO MANUAL	60364400	D	22	ARH
R	FA710-A/B/C/D {7054-1} DISK CONTROLLER HARDWARE REFERENCE MANUAL	60364500	G	22	ARH
RMP	7600/CYBER 70 MODEL 76 COMPUTER SYSTEMS HARDWARE REFERENCE MANUAL	60367200	C	22	ARH
R	GH 214-B 10-TON CONDENSING UNIT REFRIGERA- TION CE MANUAL	60367300	G	22	ARH
R	DC135-A {6642-1, 7030-XX} DISTRIBUTIVE DATA PATH CE MANUAL	60369400	D	22	ARH
R	AA115-A {72-XX, 73-XX} BASIC UNIFIED PRO- CESSOR CHASSIS 1,3,11 DIAGRAMS CE MAN	60369700	R	22	ARH
R	AA115-A {72-XX, 73-XX} BASIC UNIFIED PRO- CESSOR CHASSIS 4 DIAGRAMS CE MANUAL	60370100	Z	22	ARH
R	AA115-A {72-XX, 73-XX} BASIC UNIFIED PRO- CESSOR CHASSIS 3 DIAGRAMS CE MANUAL	60370200	M	22	ARH
R	AT145-A/B/C {10173} ADDITIONAL PPU CHASSIS FOR 6000 COMPUTERS {INCR TO 20 PPU'S} CE MANUAL	60370600	K	22	ARH
R	AA117-A {74-XX} PARALLEL PROCESSOR CHASSIS 4,5,6,7,8 DIAGRAMS MANUAL	60370800	R	22	ARH
R	AA117-A {74-XX} PARALLEL PROCESSOR CHASSIS 9 DIAGRAMS MANUAL	60370900	P	22	ARH
R	AE116-D {74-2X} SECOND CENTRAL PROCESSOR CHASSIS 2 WIRE LIST CE MANUAL	60371000	J	22	ARH
R	AA117-A {74-XX} PARALLEL PROCESSOR CHASSIS 4 WIRE LIST CE MANUAL	60371100	K	22	ARH
R	AA117-A {74-XX} PARALLEL PROCESSOR CHASSIS WIRE LIST CE MANUAL	60371200	S	22	ARH
R	3100/3150/3170/3200/3300/3500 COMPUTER SYS MASTER/MSOS ALGOL VERSION 1 REF MANUAL	60371800	C	22	ARH
RO	6000/7600/CYBER/CYBER 170 COMPUTER SYSTEMS LOADER INSTANT	60372200	B		ARH
R	SMM V 3 OPERATORS GUIDE	60373800	C	22	ARH
RO	CYBER 76 SMM V3 REFERENCE MANUAL	60373900	C	22	ARH
R	AE116-B {10174-X} SECOND CENTRAL PROCESSOR CONVERTS A 6600-A/B/C WITH SPIGOTS TO A 6700-A/B/C DIAGRAMS, WIRE LIST CE MANUAL {CH. 12}	60374800	D	22	ARH
R	AA115-A {72-XX, 73-XX} BASIC UNIFIED PRO- CESSOR CHASSIS 5 DIAGRAMS CE MANUAL	60377200	G	22	ARH
RMP	AA115-A {72-XX, 73-XX} BASIC UNIFIED PRO- CESSOR CHASSIS 8 DIAGRAMS CE MANUAL	60377300	L	22	ARH

CONT.

1	TITLE	2	3	4	5
R	3LOO SOFTWARE STUDENT MANUAL	60380400	A	3	CDI
R	AT154-A {10173-X} ADDITIONAL MEMORY ACCESS FOR 6613-A/B/C CHASSIS 5 WIRE LIST CE MANUAL	60380800	G	22	ARH
R	AA115-A {72-XX,73-XX} BASIC UNIFIED PRO- CESSOR REFRIGERATION SYSTEM CE MANUAL	60382300	C	22	ARH
R	AA117-A {74-XX} PARALLEL PROCESSOR CHASSIS 10 DIAGRAMS MANUAL	60382600	D	22	ARH
R	AA117-A {74-XX} PARALLEL PROCESSOR CHASSIS 11 DIAGRAMS MANUAL	60382700	C	22	ARH
R	AA117-A {74-XX} PARALLEL PROCESSOR CHASSIS 12 DIAGRAMS MANUAL	60382800	H	22	ARH
R	6000/7600/CYBER 70 MODELS 72,73,74,76 COM- PUTER SYSTEMS ALGOL REF MAN VER 4	60384700	C	22	SVL
R	6000/CYBER 70 MODELS 72,73,74 COMPUTER SYSTEMS QUERY UPDATE VERSION 2 REFERENCE MANUAL VOLUME 1 & 2	60384900	D	22	SVL
R	6000/CYBER 70 MODELS 72/73/74 COMPUTER SYS QUERY UPDATE MINI USER GUIDE VER 2	60385500	C	22	SVL
RO	6000/7600/CYBER 70 MODELS 72/73/74 COMPUTER SYSTEMS FORTRAN COMMON LIBRARY MATHEMATICAL ROUTINES	60387900	B	22	SVL
R	6682-A SATELLITE COUPLER CE MANUAL	60390100	E	22	ARH
R	AT153-A {10173-4/5,10174-2} ADDITIONAL CENTRAL MEMORY ACCESS FOR 6614-A/B/C COMPUTER SYSTEM CHASSIS 5 WIRE LISTS CE MANUAL	60391900	D	22	ARH
R	AT251-A {CYBER 72,73,74} EXTERNAL DATA CHANNEL	60392700	F	22	ARH
R	FA705-B {3553-1} MASS STORAGE CONTROLLER CE MANUAL	60394600	D	22	ARH
R	FA705-C {3053-2} MASS STORAGE CONTROLLER CE MANUAL	60394700	H	22	ARH
R	3234-D/E MASS STORAGE CONTROLLER CE MANUAL	60394800	D	22	ARH
R	AA121-A {7700} CENTRAL COMPUTER CHANNEL TABS WIRE LISTS CE MANUAL	60398200	B	22	ARH
R	AD102-A {7700} ADJUNCT PROCESSOR CHANNEL TABS, WIRE LISTS CE MANUAL	60399200	B	22	ARH
R	6671-3{FJ440-A} DATA SET CONTROLLER HARDWARE REFERENCE MANUAL	60399900	B	22	ARH
R	FA102-A {1733-1} DISK STORAGE CONTROLLER CE MANUAL	60400100	F	22	LJL
R	AT194-A {6500-D OR 6500-E WITH ECS. CAPABILITY FOR 6400-D WITH AT198-A CHASSIS 2,6,3,8 DIAGRAMS WIRE LIST CE MANUAL	60401200	G	22	ARH
R	FA401-A/B {7021-1} 1X8 MAG TAPE CONTROLLER CE MANUAL	60404100	G	22	ARH
R	7600/CYBER 70 MODEL 76 COMPUTER SYSTEMS SCOPE 2.1 ON-LINE MAINT PROGRAMS REFERENCE MANUAL	60406200	D	22	ARH
R	6000/CYBER 70 MODELS 72,73,74 COMPUTER SYSTEMS KRONOS 2.1 REFERENCE MANUAL	60407000	C	22	ARH
R	6000/CYBER 70 MODELS 72,73,74 COMPUTER SYS KRONOS 2.1 INSTALLATION HANDBOOK	60407500	K	22	ARH
R	6000/CYBER 70 MODELS 72,73,74 COMPUTER SYS KRONOS 2.1 TIMESHARING USERS REF MAN	60407600	C	22	ARH

CONT.

1	TITLE	2	3	4	5
R	6000/CYBER 70 MODELS 72,73,74 COMPUTER SYS KRONOS 2.1 OPERATORS GUIDE	60407700	D	22	ARH
R	3100/3150/3170/3200/3300/3500 COMPUTER SYS MSOS VERSION 5 OPERATING SYSTEM REFERENCE MANUAL	60410600	C	22	ARH
RO	3100/3150/3170/3200/3300/3500 COMPUTER SYS MSOS VERSION 5 OPERATORS GUIDE	60410700	B	22	ARH
R	3100/3150/3170/3200/3300/3500 COMPUTER SYS MSOS VERSION 5 INSTALLATION HANDBOOK	60410800	D	22	ARH
R	3100/3150/3170/3200/3300/3500 COMPUTER SYS MSOS VERSION 5 DIAGNOSTIC HANDBOOK	60410900	C	22	ARH
N	3100/3150/3170/3200/3300/3500 COMPUTER SYS MSOS VERSION 5 INSTANT	60411000	A		ARH
RO	SMM17 PROGRAM LISTINGS - DMP	60411500	C	22	ARH
RO	SMM17 PROGRAM LISTINGS - AQM	60412100	C	22	ARH
RO	SMM17 PROGRAM LISTINGS - LST	60412200	C	22	ARH
RO	SMM17 PROGRAM LISTINGS - MCC	60412400	C	22	ARH
RO	SMM17 PROGRAM LISTINGS - CDD	60412700	C	22	ARH
RO	SMM17 PROGRAM LISTINGS - DRM	60412800	D	22	ARH
RO	SMM17 PROGRAM LISTINGS - IOM	60413100	C	22	ARH
RO	SMM17 PROGRAM LISTINGS - DP3	60413900	D	22	ARH
RO	SMM17 PROGRAM LISTINGS - EDT	60414700	C	22	ARH
R	3170/3300/3500 COMPUTER SYSTEMS MASTER VERSION 4.0 INSTALLATION HANDBOOK	60415300	D	22	ARH
R	3170/3300/3500 COMPUTER SYSTEMS MASTER VERSION 4.0 REFERENCE MANUAL	60415100	C	22	ARH
R	3170/3300/3500 COMPUTER SYSTEMS MASTER VERSION 4.0 LIBRARY GENERATION AND MAINTENANCE MANUAL	60415400	C	22	ARH
R	3170/3300/3500 COMPUTER SYSTEMS MASTER VERSION 4.0 DIAGNOSTIC HANDBOOK	60415500	C	22	ARH
R	AT149-A {ST.OP.10173} ADDITIONAL MEMORY ACCESS OPTION FOR 6414-A/B/C, 6514- A/B/C CABLE TABS {AT149-A ONLY} CE MANUAL	60415800	C	22	ARH
R	AE116-D {74-2X} SECOND CENTRAL PROCESSOR CHASSIS 2 DIAGRAMS CE MANUAL	60416000	E	22	ARH
R	6500-D WITH ECS CAPABILITY AT198-A/6500-D CONVERSION AND DT143-A ECS KIT DT 205- A ECS INTERFACE LOGIC, AT194-A 6500 ECS CONVERSION THEORY OF INSTALLATION, DIAGRAMS, MAINT AIDS, WIRE LISTS CE MANUAL	60416700	G	22	ARH
N	STANDARD OPTIONS 10309-1 AND 10309-2 GO MODE SDL FOR THE AC104-A AND AC106-A/B CE MANUAL	60417600	A	34	ARH
RO	CYBER 170-MODEL 175 SYSTEMS DATA SITE PREPARATION MANUAL	60420100	A	22	ARH
N	CYBER 170 MODEL 175 CENTRAL COMPUTER AND ALL OPTIONS MAINTENANCE, PARTS DATA HARDWARE MAINTENANCE MANUAL	60420600	D1	22	ARH
N	CYBER 170 MODEL 175 POWER DISTRIBUTION AND WARNING SYSTEM GEN DESC., OPERATION, THEORY OF OPER., DIAGS, APPENDIX AND WIRE LIST HARDWARE MAINTENANCE MANUAL	60420700	A	22	ARH
R	AC113-B CENTRAL COMPUTER CHASSIS 6 WIRE LIST CE MANUAL	60421400	C	22	ARH
R	AC113-B CENTRAL COMPUTER CHASSIS 7 WIRE LIST CE MANUAL	60421500	C	22	ARH

CONT.

1	TITLE	2	3	4	5
R	AC113-B CENTRAL COMPUTER CHASSIS 8 WIRE LIST CE MANUAL	60421600	D	22	ARH
R	AC113-B CENTRAL COMPUTER CHASSIS 9 WIRE LIST CE MANUAL	60421700	B	22	ARH
R	AC113-B CENTRAL COMPUTER CHASSIS 10 WIRE LIST CE MANUAL	60421800	C	22	ARH
R	AC113-B CENTRAL COMPUTER CHASSIS 12 WIRE LIST CE MANUAL	60422000	C	22	ARH
R	AC113-B CENTRAL COMPUTER CHASSIS 13 WIRE LIST CE MANUAL	60422100	B	22	ARH
RO	SMM17 PROGRAM LISTINGS - MY2	60422300	C	22	ARH
RO	SMM17 PROGRAM LISTINGS - MY1	60422400	C	22	ARH
RO	SMM17 PROGRAM LISTINGS - DP5	60422900	C	22	ARH
R	FE202-A/B {415-30} CARD PUNCH CONTROLLER REFERENCE/CE MANUAL	60425600	C	22	ARH
N	DC145-A/B DISTRIBUTIVE DATA PATH/DT221-A REGISTER GEN DESC, OPERATION, INSTALLATION, AND CHECKOUT, THEORY OF OPERATION DIAGRAMS, MAINT., PARTS DATA, WIRE LISTS CABLE TABS HARDWARE MAINT MAN	60425800	A	22	ARH
N	CYBER 70 MODEL 76 {AA106-A} CYBER 170 MODEL 175 REFRIGERATION SYSTEM, GEN DESC., OPERATION, INSTALLATION AND CHECKOUT, THEORY OF OPERATION, DIAGRAMS, MAINT., PARTS DATA, APPENDIX, WIRE LISTS, HARDWARE MAINTENANCE MANUAL	60427800	A	22	ARH
R	FA722-A/B {7054-21/22/41/42} DISK STORAGE CONTROLLER HARDWARE MAINTENANCE MANUAL	60428500	J	22	ARH
N	AA106-A CENTRAL COMPUTER/AB101-A, AB102-A/B, AT174-A PERIPHERAL PROCESSOR UNIT MAINTENANCE CE MANUAL	60429900	A	22	ARH
N	GH506-A/B POWER DISTRIBUTION UNIT USED WITH POWER DISTRIBUTION AND WARNING SYSTEM AA106-A CENTRAL COMPUTER A/B102-A/B I/O STATION CABINET/GK171-A I/O STATION CABINET MODIFICATION KIT CE MAN	60433400	A	22	ARH
N	AA106-A {BS101/2-A, BB360-B, AT311/312-A} CENTRAL COMPUTER INSTALLATION AND CHECKOUT, THEORY OF OPERATION, DIAGS., MAINT. AIDS, PARTS DATA VOLUMES 1-3 CE MANUAL	60433600	A	22	ARH
N	AA106-A {BS101/2-A, BB360-B, AT311/312-A} CENTRAL COMPUTER CHASSIS 7 WIRE LISTS CE MANUAL	60433700	A	22	ARH
N	CHASSIS 8 WIRE LISTS CE MANUAL	60433800	A	22	ARH
N	CHASSIS 9 WIRE LISTS CE MANUAL	60433900	A	22	ARH
N	CHASSIS 2 WIRE LISTS CE MANUAL	60434700	A	22	ARH
N	CHASSIS 3 WIRE LISTS CE MANUAL	60434800	A	22	ARH
N	CHASSIS 4 WIRE LISTS CE MANUAL	60434900	A	22	ARH
N	CHASSIS 5 WIRE LISTS CE MANUAL	60435000	A	22	ARH
N	CHASSIS 6 WIRE LISTS CE MANUAL	60435100	A	22	ARH
N	6000/CYBER 70/CYBER 170/COMPUTER SYSTEMS ON LINE MAINTENANCE SOFTWARE REFERENCE MANUAL, KRONOS 2.1-X/NOS V1.0.0	60436600	A	22	ARH
N	SYSTEM 17 SERIES MINI COMPUTER SYSTEMS SITE PREPARATION MAN SECTION 1, GEN SITE REQUIREMENT	60437000	A	22	ARH

CONT.

1	TITLE	2	3	4	5
N	SYSTEM 17 SERIES MINI COMPUTER SYSTEMS SITE PREPARATION MAN SECTION 2 - SYSTEM DATA	60437100	A	22	ARH
N	SYSTEM 17 SERIES MINI COMPUTER SYSTEMS SITE PREPARATION SECTION 3 - PERIPHERAL EQUIPMENT DATA	60437200	A	22	ARH
RO	SMM17 PROGRAM LISTINGS {GT0}	60437400	B	22	ARH
RO	SMM17 PROGRAM LISTINGS {GT1}	60437500	B	22	ARH
RO	SMM17 PROGRAM LISTINGS - GT2	60437600	B	22	ARH
RO	SMM17 PROGRAM LISTINGS - GT3	60437700	B	22	ARH
RO	SMM17 PROGRAM LISTINGS - GT5	60437900	B	22	ARH
RO	SMM17 PROGRAM LISTINGS - GT6	60438000	B	22	ARH
RO	SMM17 PROGRAM LISTINGS - LP5	60438100	B	22	ARH
RO	SMM17 PROGRAM LISTINGS - KEY	60438400	B	22	ARH
N	FA444-A/B, FF445-A/B MAGNETIC TAPE CONTROLLER MB434-A CONTROLWARE INSTALLATION AND CHECKOUT, MAINTENANCE, DIAGS, GEN DESC., OPERATION, THEORY OF OPER., PARTS DATA, WIRE LISTS, LEVEL 2 HARDWARE MAINTENANCE MANUAL VOLUMES 1-3	60438500	A	22	ARH
RO	SMM17 PROGRAM LISTINGS - MDC	60438600	B	22	ARH
R	6640-D EXTENDED CORE STORAGE CONTROLLER GEN. DESC., OPER., THEORY OF OPER., INSTALLATION AND CHECKOUT, MAINT., DIAGS, PARTS DATA, APPENDIX AND WIRE LISTS CE MANUAL	60440500	B	22	ARH
N	6681-F DATA CHANNEL CONVERTER GEN DESC., OPERATION, INSTALLATION AND CHECKOUT, THEORY OF OPER., DIAGS., MAINT., PARTS DATA, WIRE LIST, CE MANUAL	60440800	A	22	ARH
N	6000/CYBER 70 MODELS 72,73,74 COMPUTER SYS AUTOMATED INTEGRATED DESIGN SYSTEM, SEMIAUTOMATIC ARTWORK GENERATION {SAAG} USERS GUIDE	60441000	A	22	ARH
N	6000/CYBER 70 MODELS 72,73,74 COMPUTER SYS AUTOMATED INTEGRATED DESIGN SYSTEM GENERAL PURPOSE WIRE WRAP {GPWW} USERS GUIDE	60443100	A	22	ARH
N	SMM17 PROGRAM LISTINGS - DPC	60446100	A	22	ARH
N	SMM17 PROGRAM LISTINGS - MTX	60446200	A	22	ARH
N	SMM17 PROGRAM LISTINGS - PET	60446300	A	22	ARH
N	SMM17 PROGRAM LISTINGS - PAD	60446400	A	22	ARH
N	SMM17 PROGRAM LISTINGS - BDL	60446500	A	22	ARH
N	SMM17 PROGRAM LISTINGS - REP	60446600	A	22	ARH
N	SMM17 PROGRAM LISTINGS - INS	60446700	A	22	ARH
N	SMM17 PROGRAM LISTINGS - CMD	60446800	A	22	ARH
N	SMM17 PROGRAM LISTINGS - CPY	60447700	A	22	ARH
RO	6000/CYBER 170/CYBER 70 MODELS 72,73,74 COMPUTER SYSTEMS CYBER RECORD MANAGER VERSION 1.1 MULTIPLE INDEX PROCESSOR PROGRAMMING SYSTEMS BULLETIN	60492900	B	22	SVL
N	6000/7600/CYBER 70/CYBER 170 COMPUTER SYS CYBER COMMON UTILITIES REF MANUAL	60493300	A	3	SVL
N	6000/CYBER 70 MODELS 72,73,74 COMPUTER SYS SCOPE INTEGRATED SCHEDULER TUNING GUIDE PROGRAMMING SYSTEMS BULLETIN	60493500	A	22	SVL
N	HOSPITAL COMMUNICATIONS SYSTEM DIGISCRIBE OPTION OPERATORS GUIDE {QSE 10892}	62995800	A-0		LJL

CONT.

1	TITLE	2	3	4	5
N	CV403-A {10892} HOSPITAL COMMUNICATIONS SYSTEM DIGISCRIBE OPTION ON-ISTE MAINTENANCE MANUAL	62995900	A-0	22	LJL
N	CV403-A DIGISCRIBE OPTION REPAIR CENTER CE MANUAL	62996000	A-0	22	LJL
N	AN/UYK-25{V} DATA PROCESSING SET INCLUDING CPL201{V}/UYK-25 {V} DIGITAL DATA COMPUTER {5601 SERIES} MU/618/UYK-25 {V} CORE MEMORY UNIT {5604 SERIES} REFERENCE MANUAL	69651800		22	MSP
RO	CJ112 PAGE READER G-H {CS/N151-200} DIAGRAMS CE MANUAL	70601700	E	22	ROK
RO	33301/33302 SUBSYSTEMS ON-LINE DIAGNOSTICS MANUAL {COLDS}	70602900	D	22	NRM
N	BR281 DISK STORAGE UNIT DIAGRAMS AND WIRE LISTS CE MANUAL	70607900	D	22	NRM
RO	33301 MULTIPLE DISK SYSTEM INSTALLATION CE MANUAL	70608100	G	22	NRM
R	33301 MULTIPLE DISK SYSTEM TROUBLESHOOTING MANUAL	70608200	C	22	NRM
R	BR1A9-B VOICE COIL DRIVE PARTS DATA B01 AND ABOVE CE MANUAL	70609300	J	22	NRM
R	BR281 DISK STORAGE UNIT MAINTENANCE MANUAL	70612500	C	3	NRM
R	TB301-A/B FIELD TEST EXERCISER MAINTENANCE MANUAL	70612800	G	3	NRM
R	FA7A4-A/B PLUG COMPATIBLE CONTROLLER MAINT CE MANUAL	70613800	G	22	NRM
R	BR2A1-D DISK STORAGE UNIT MAINTENANCE MANUAL	70616300	C	22	NRM
R	BR2A1-L DISK STORAGE UNIT DIAGRAMS CE MANUAL	70616400	F	22	NRM
R	BR1A9 DISK STORAGE UNIT DIAGRAMS, WIRE LISTS, MAINT. AIDS {MODS B03 AND ABOVE}	70617100	H	22	NRM
R	BR5A1 DISK STORAGE UNIT MAINTENANCE MANUAL	70617800	E	22	NRM
R	BR5A1 DISK STORAGE UNIT PARTS DATA CE MANUAL	70618000	P	22	NRM
R	BR1B3 DISK STORAGE UNIT PARTS DATA CE MANUAL	70620600	G	22	NRM
R	FR113-A {731-10/12-732-10/12} BUFFER CON- TROLLER MAINTENANCE CE MANUAL	70621400	F	22	NRM
R	BR2A7 DISK STORAGE UNIT DIAGRAMS AND WIRE LIST	70622200	L	22	NRM
RM	BR2A8 DISK STORAGE UNIT DIAGRAMS AND WIRE LISTS CE MANUAL	70622300	M	22	NRM
R	BR2A8 DISK STORAGE UNIT MAINTENANCE CE MAN	70622400	G	22	NRM
R	BR2A7 DISK STORAGE UNIT PARTS DATA CE MANUAL	70622500	M	22	NRM
R	BR2A6-B DISK STORAGE UNIT MAINT. CE MANUAL	70622600	H	22	NRM
R	BR2A6-B DISK STORAGE UNIT PARTS DATA CE MAN	70622800	N	22	NRM
R	BR5A2 DISK STORAGE UNIT MAINTENANCE MANUAL	70624500	G	22	NRM
R	BR5A2 DISK STORAGE UNIT PARTA DATA CE MANUAL	70624700	J	22	NRM
R	BR304 DISK STORAGE UNIT MAINTENANCE CE MAN	70627900	D	22	NRM
R	BR304 DISK STORAGE UNIT GENERAL DESCRIPTION, OPERATION, THEORY OF OPERATION, KEY TO LOGIC, INTEGRATED/DISCRETE CIRCUITS CE MANUAL	70628000	C	22	NRM
R	BR304 DISK STORAGE UNIT PARTS DATA CE MANUAL	70628100	C	22	NRM
R	BR3B4 DISK STORAGE UNIT MAINTENANCE MANUAL	70628200	L	3	NRM
R	BR3B4 DISK STORAGE UNIT MAINTENANCE MANUAL	70628400	G	3	NRM
N	BR5A3 DISK STORAGE UNIT GEN DESC., OPER., INSTALLATION/CHECKOUT, THEORY OF OPER., MAINTENANCE CE MANUAL	70628500	B	22	NRM
N	BR5A3 DISK STORAGE UNIT DIAGRAMS AND WIRE LISTS CE MANUAL	70628600	D	22	NRM

CONT.

1	TITLE	2	3	4	5
R	BR501 DISK STORAGE UNIT GENERAL DESCRIPTION, OPERATION, THEORY OF OPERATION CE MANUAL	70629200	F	22	NRM
RMP	BR501 DISK STORAGE UNIT PREVENTIVE AND CORRECTIVE MAINTENANCE DIAGRAMS AND WIRE LISTS CE MANUAL	70629300	M	22	NRM
R	BR501 DISK STORAGE UNIT PARTS DATA CE MANUAL	70629400	K	22	NRM
R	BR303 DISK STORAGE UNIT GENERAL DESCRIPTION, OPERATION, THEORY OF OPERATION CE MAN	70629500	C	22	NRM
R	BR303 DISK STORAGE UNIT INSTALLATION/CHECK-OUT, PREVENTIVE/CORRECTIVE MAINT, DIAGRAMS WIRE LIST, CE MANUAL	70629600	H	22	NRM
R	BR303 DISK STORAGE UNIT PARTS DATA CE MANUAL	70629700	J	22	NRM
N	BR3B5 DISK STORAGE UNIT PARTS DATA MANUAL	70630500	F	3	NRM
R	BJ5XX STORAGE MODULE DRIVE MAINTENANCE MAN	70630900	K	3	NRM
R	BJ5XX STORAGE MODULE DRIVE PARTS DATA CE MAN	70631100	L	3	NRM
N	BR2B2/3 DISK STORAGE UNIT GEN. DESC., MAINTENANCE CE MANUAL	70631300	D	22	NRM
R	BR2B2/3 DISK STORAGE UNIT DIAGRAMS AND WIRE LISTS CE MANUAL	70631400	F	22	NRM
R	BR2B2/3 DISK STORAGE UNIT PARTS DATA CE MAN	70631500	G	22	NRM
N	CYBER 1000 {FA101-A, DY128-A} DISK PACK CONTROLLER HARDWARE MAINTENANCE MANUAL	73361200	B	22	STA
N	CYBER 1000 MAGNETIC TAPE CONTROLLER DY120-A, FA419-A HARDWARE MAINTENANCE MANUAL	74607500		22	STA
N	CYBER 1000/3000 SERIES CONTROLLER-ADAPTER {DY122-A} HARDWARE MAINTENANCE MANUAL	74660300	A	22	STA
N	CYBER 1000 {DY127-A} HIGH-SPEED LINE CONTROLLER HARDWARE MAINTENANCE MANUAL	74664300	A	22	STA
N	CYBER 1000/1700 SERIES {DY123-A} CONTROLLER ADAPTER HARDWARE MAINTENANCE MANUAL	74675500	A	22	STA
N	DY121-A {CYBER 1000} FAST DISK CONTROLLER HARDWARE MAINTENANCE MANUAL	74691800	A	22	STA
N	DW110-A {CYBER 1000} TWO BAY EXCHANGE UNIT HARDWARE MAINTENANCE MANUAL	74717600	A	22	STA
N	DW105-A/DW111-A {CYBER 1000} THREE BAY EXCHANGE UNIT HARDWARE MAINTENANCE MAN	74720400	A	22	STA
N	DY124-A/DY129-A {CYBER 1000} CONTROLLER EXTENSION CABINETS HARDWARE MAINT MAN	74720500	A	22	STA
N	DY107-110-A {CYBER 1000} LINE MODULE EXTENSION CABINET HARDWARE MAINT MANUAL	74724500	A	22	STA
N	6000/CYBER 70 MODELS 72,73,74 COMPUTER SYSTEMS MARS VI REF MANUAL FOR PARTIAL INVERSION KRONOS 2.1 USAGE	76070100		3	CYB
N	6000 CYBER 70 MODELS 72,73,74 COMPUTER SYS TOTAL-CDC REFERENCE MANUAL VERSION 1	76070300		3	CYB
N	1FMS-INTERACTIVE FINANCIAL MODELING SYSTEM USER INFORMATION MANUAL	76070400		3	CYB
N	SYSCAP-II - SYSTEM OF CIRCUIT ANALYSIS PROGRAMS U.I.M.	76070600		3	CYB
R	CC-TEGAS3-TEST GENERATION AND SIMULATION SYSTEM USER INFORMATION MANUAL	76070700	A	3	CYB
N	SYSTEMS PROFESSIONAL PROGRAMS COST GUIDE USER COST GUIDE	76070800		3	CYB
N	ANSYS - ENGINEERING ANALYSIS SYSTEM EXAMPLES MANUAL	76070900		3	CYB
N	XEDIT-EXTENDED KRONOS TEXT EDITOR U.I.M.	76071000		3	CYB
N	FASTIME/LOADFLOW-POWER SYSTEM ANALYSIS USER INFORMATION MANUAL	76071200		3	CYB

CONT.

1	TITLE	2	3	4	5
N	ATHENA/ON-LINE INTERACTIVE RETRIEVAL UPDATE LANGUAGE USER INFORMATION MANUAL	76071400	A	3	CYB
N	CYBERNET CYBER 70/MODEL 76 {PRELIMINARY} TERMINAL USERS GUIDE	76072700		3	CYB
N	SYSTEM 2000 LEVEL 2-A MULTI-PURPOSE DATA MANAGEMENT SYSTEM USER INFORMATION MANUAL	76074000		3	CYB
N	SYSTEM 2000 LEVEL 2-A MULTI-PURPOSE DATA MANAGEMENT SYSTEM DIAGNOSTIC MESSAGE SUPPLEMENT	76074300		3	CYB
N	SYSTEM 2000 LEVEL 2-A MULTI-PURPOSE DATA MANAGEMENT SYSTEM IMMEDIATE ACCESS FEATURE SUPPLEMENT	76074400		3	CYB
N	SYSTEM 2000 LEVEL 2-A MULTI-PURPOSE DATA MANAGEMENT SYSTEM FORTRAN PROCEDURAL LANGUAGE SUPPLEMENT	76074600		3	CYB
N	SYSTEM 2000 LEVEL 2-A MULTI-PURPOSE DATA MANAGEMENT SYSTEM REPORT WRITER FEATURE SUPPLEMENT	76074700		3	CYB
R	PUNCH CARD EQUIPMENT STUDENT MANUAL	76360001	C	3	CDI
R	BR388 DISK STORAGE UNIT MAINTENANCE CE MAN	83301000	K	3	NRM
R	BR388-DISK STORAGE UNIT REFERENCE MANUAL	83301100	C	3	NRM
R	BR388 DISK STORAGE UNIT PARTS DATA CE MANUAL	83301200	K	3	NRM
R	3330/DISK MEMORY SUBSYSTEM SITE PLANNING KIT	83301400	C	22	NRM
R	33302 DISK MEMORY SUBSYSTEM REFERENCE MANUAL	83301500	B	22	NRM
R	33302 DISK MEMORY SUBSYSTEM INSTALLATION CE MANUAL	83301600	D	22	NRM
R	FA721 STORAGE CONTROL HARDWARE REFERENCE CE MANUAL	83301800	B	22	NRM
R	FA721 STORAGE CONTROL PREVENTIVE/CORRECTIVE MAINT. W/L CE MANUAL	83301900	E	22	NRM
R	FA721 STORAGE CONTROL DIAGRAMS VOLUME 2 CE MANUAL	83302000	R	22	NRM
R	FA721 STORAGE CONTROL EIGHT VOLUME CAU FUNCTIONAL MICROPROGRAM CE MANUAL	83302100	E	22	NRM
RO	BR5A5 DISK STORAGE UNIT GEN DESC., OPERATION, INSTALLATION AND CHECKOUT, THEORY OF OPERATION AND MAINTENANCE CE MANUAL	83302300	D	22	NRM
R	BR5A5 DISK STORAGE UNIT DIAGRAMS, MAINT. AIDS, WIRE LISTS CE MANUAL	83302400	C	22	NRM
RO	BR5A5 DISK STORAGE UNIT PARTS DATA CE MANUAL	83302500	E	22	NRM
R	BR502/4 DISK STORAGE UNIT PREVENTIVE CORRECTIVE MAINTENANCE, DIAGS., WIRE LIST, CE MANUAL	83302600	G	22	NRM
R	BR502/4 DISK STORAGE UNIT PARTS DATA CE MAN	83302800	F	22	NRM
R	BR305 DISK STORAGE UNIT - PREVENTIVE CORRECTIVE MAINTENANCE, DIAGS, WIRE LISTS CE MANUAL	83303100	B	22	NRM
R	BR305 DISK STORAGE UNIT PARTS DATA CE MANUAL	83303300	C	22	NRM
R	BR3D1-DISK STORAGE UNIT MAINTENANCE MANUAL	83305700	E	3	NRM
R	BR3D1-B DISK STORAGE UNIT REFERENCE MANUAL	83305800	C	3	NRM
R	BR3D1-B DISK STORAGE UNIT PARTS DATA MANUAL	83305900	E	3	NRM
N	FA721 STORAGE CONTROL PARTS DATA CE MANUAL	83306000	F	22	NRM
RO	FV605 CONTROLLER ADAPTER UNIT GEN. DESC., THEORY OF OPERATION,	83306100	B	22	NRM
RO	FV605 CONTROLLER ADAPTER UNIT PARTS DATA CE MANUAL	83306300	C	22	NRM
N	TB207-A FIELD TEST UNIT MAINTENANCE MANUAL	83307900	B	3	NRM

CONT.

1	TITLE	2	3	4	5
N	BJ7XX STORAGE MODULE DRIVE MAINTENANCE MAN	83308400	A	3	NRM
N	BJ7XX STORAGE MODULE DRIVE REFERENCE MANUAL	83308500	A	3	NRM
N	BJ7XX STORAGE MODULE DRIVE PARTS DATA MANUAL	83308600	A	3	NRM
R	BR306/7 DISK STORAGE UNIT PREVENTIVE CORRECTIVE MAINT., DIAGRAMS AND WIRE LISTS	83308700	C	22	NRM
R	BR306/7 DISK STORAGE UNIT REFERENCE MANUAL	83308800	B	22	NRM
R	BR306/7 DISK STORAGE UNIT PARTS DATA CE MAN	83308900	C	22	NRM
R	BR3C6 DISK STORAGE UNIT MAINTENANCE CE MANUAL	83309300	C	3	NRM
R	BR3C6 DISK STORAGE UNIT REFERENCE MANUAL	83309400	B	22	NRM
R	BR3C6 DISK STORAGE UNIT PARTS DATA CE MANUAL	83309500	C	3	NRM
R	BJ6XX STORAGE MODULE DRIVE MAINTENANCE MAN	83310800	C	3	NRM
R	BJ6XX STORAGE MODULE DRIVE REFERENCE MANUAL	83310900	B	3	NRM
N	BR2A1D {S/C 19 AND ABOVE} DISK STORAGE UNIT PARTS DATA CE MANUAL	83311400	A	22	NRM
N	BR3D3-A/B DISK STORAGE UNIT MAINTENANCE MAN	83311600	A	22	NRM
N	BR3D3-A/B DISK STORAGE UNIT REFERENCE MANUAL	83311700	A	3	NRM
R	FA721 STORAGE CONTROL 16 VOL CAU FUNCTIONAL MICROPROGRAM MANUAL	83311900	E	22	NRM
RO	FA721 STORAGE CONTROL IN-LINE DIAGNOSTICS MICROPROGRAM CE MANUAL	83312000	E	22	NRM
RO	FA721 STORAGE CONTROL STANDARD DIAGNOSTICS MICROPROGRAM CE MANUAL	83312100	C	22	NRM
N	TB4A1-A FIELD TEST UNIT MAINTENANCE MANUAL	83312300	A	3	NRM
N	BR3D4 DISK STORAGE UNIT MAINTENANCE MANUAL	83313100	A	3	NRM
N	BR3D4 DISK STORAGE UNIT REFERENCE MANUAL	83313200	A	3	NRM
N	BR3D4 DISK STORAGE UNIT PARTS LIST MANUAL	83313300	A	3	NRM
N	BR5A6 DISK STORAGE UNIT MAINTENANCE MANUAL	83313400	B	3	NRM
N	BR5A6 DISK STORAGE UNIT REFERENCE MANUAL	83313500	B	3	NRM
N	BR5A6 DISK STORAGE UNIT PARTS DATA MANUAL	83313600	A	3	NRM
N	BR306/BR307-D,E DISK STORAGE UNIT PREVEN- TIVE/CORRECTIVE MAINTENANCE, DIAGRAMS, AND WIRE LISTS CE MANUAL	83314000	A	22	NRM
N	FV605-D-G CONTROLLER ADAPTER UNIT PREVEN- TIVE/CORRECTIVE MAINT. DIAGRAMS, WIRE LISTS CE MANUAL	83315400	A	22	NRM
N	FA203 CONTROLLER MICRODIAGNOSTIC USERS CE MANUAL	83315600	A	22	NRM
N	FA203 CONTROLLER FLEXIBLE DISK DRIVE CE MANUAL	83315700	A	22	NRM
N	FA203 CONTROLLER MICRODIAGNOSTIC CE MANUAL	83315800	A	22	NRM
N	FA203 CONTROLLER THEORY OF OPERATION CE MAN	83316100	A	22	NRM
N	FA203 CONTROLLER PARTS DATA CE MANUAL	83316200	A	22	NRM
N	FA203 CONTROLLER HARDWARE MICROPROGRAM CE MANUAL	83316300	A	22	NRM
N	FA203 CONTROLLER DIAGNOSTIC MICROPROGRAM CE MANUAL	83316400	A	22	NRM
N	FA203 CONTROLLER DUAL ACCESS FEATURE MICRO- PROGRAM CE MANUAL	83316600	A	22	NRM
RMP	CYBERNET/KRONOS 2.1 TIME-SHARING FORTRAN REFERENCE MANUAL	84001700	B	3	CYB
R	EAC/EASE-2 USER INFORMATION/THEORETICAL MANUAL	84002700	A	3	CYB
RO	CYBERNET/PROSE SYSTEM GUIDE	84002900	A	3	CYB
RO	GPSS V/GENERAL PURPOSE SIMULATION SYSTEM V/6000 GENERAL INFORMATION MANUAL	84003900	A	3	CYB
N	MODIFIED PCA FLAT PLATE, FLAT SLAB, WAFFLE SLAB, AND FRAME ANALYSIS AND DESIGN, WORKING OR ULTIMATE STRENGTH 1971 ACI USERS GUIDE	84009400		3	CYB

CONT.

1	TITLE	2	3	4	5
N	FAAST-FLUID ANALYSIS AND SIMULATION TECHNIQUE U.I.M.	84009800		3	CYB
R	SYSTEM 2000 DATA MANAGEMENT SYSTEM USER INFORMATION MANUAL LEVEL II	86604500	J	3	CYB
RMP	CYBERNET/KRONOS LIBRARY PROGRAMS	86605900	D	3	CYB
RO	STRU-PAK PROGRAM ABSTRACTS	86608700	B	3	CYB
RO	E/CUBE ENERGY ANALYSIS CYBERNET SERVICE GUIDELINES	86608900	C	3	CYB
RO	SYSTEM 2000 LEVEL 2-A MULTI-PURPOSE DATA MANAGEMENT SYSTEM MINI MANUAL	86615600	B		CYB
RO	CYBERLOAN GENERAL INFORMATION MANUAL	86616100	A	3	CYB
R	NASTRAN APPLICATIONS MANUAL	86616700	I	3	CYB
N	CJ127 HARDWARE REFERENCE/CE MANUAL	87906700	A	22	ROK
N	CJ520 DOCUMENT READER LOGIC RACK HARDWARE MAINTENANCE MANUAL VOLUME 1	87911800	A	22	ROK
N	CJ127 OCR DOCUMENT READER DIAGRAMS VOLUME 2 HARDWARE REFERENCE/CE MANUAL	87971600		22	ROK
N	CJ127 OCR DOCUMENT READER PARTS DATA VOLUME 3 HARDWARE REFERENCE/CE MANUAL	87971700	01	22	ROK
RO	929 DRIVE 11784 COMP. SYST. 3 OCR SOFTWARE REFERENCE MANUAL	87971800	B	22	ROK
N	1700 COMPUTER SYSTEMS TOTES OPERATORS GUIDE	88818500	A	22	LJL
N	1700 COMPUTER SYSTEMS TOTES FILE MANAGER UTILITY PROGRAM REFERENCE MANUAL	88947900	A	22	LJL
N	1700 COMPUTER SYSTEMS REDUCED CORE OPERATING SYSTEM REFERENCE MANUAL V2	88948500	A	22	LJL
N	1700 COMPUTER SYSTEMS TIMESHARE 2.0 REF MAN	88964000	A	22	LJL
N	1576 {FV4A3,498} STALL ALARM UNIT HARDWARE REFERENCE/CE MANUAL	88981000	A	22	LJL
N	EB3A1-A/D FOUR CHANNEL DIGITAL-TO-ANALOG CONVERTER HARDWARE REFERENCE/CE MANUAL	88981100	A	22	LJL
N	KEY TO LOGIC SYMBOLS G.I.M.	88981500	B	22	LJL
N	6000/CYBER 170/CYBER 70 MODELS 72,73,74 C COMPUTER SYSTEMS CCP SUPPORT SOFTWARE 1 REFERENCE MANUAL	88988400	A	22	LJL
N	6000/CYBER 170/CYBER 70 MODELS 72,73,74 COMPUTER SYSTEMS CCP SUPPORT SOFTWARE PASCAL COMPILER REFERENCE MANUAL	88988500	A	22	LJL
N	6000/CYBER 170/CYBER 70 MODELS 72,73,74 COMPUTER SYSTEMS CCP SUPPORT SOFTWARE 1 GENERAL INFORMATION MANUAL	88988600	A	22	LJL
N	6000/CYBER 170/CYBER 70 MODELS 72,73,74 COMPUTER SYSTEMS CCP SUPPORT SOFTWARE 1 DIAGNOSTIC HANDBOOK	88988700	A	22	LJL
N	6000/CYBER 170/CYBER 70 MODELS 72,73,74 COMPUTER SYSTEMS CCP SUPPORT SOFTWARE 1 MICRO ASSEMBLER REFERENCE MANUAL	88988800	A	22	LJL
N	6000/CYBER 170/CYBER 70 MODELS 72,73,74 COMPUTER SYSTEMS CCP SUPPORT SOFTWARE 1 MACRO ASSEMBLER REFERENCE MANUAL	88988900	A	22	LJL
N	SYSTEM 17 INSTALLATION MANUAL	88996000	A	22	LJL
N	1700 COMPUTER SYSTEMS 1700 RCOS 2 ASSEMBLER REFERENCE MANUAL	88997600	A	22	LJL
R	1784-1/2 COMPUTER SYSTEM CE MANUAL	89633300	04	22	LJL
N	FF524-A LINE PRINTER CONTROLLER	89637300	04	22	LJL
N	FE119-A CARD READER CONTROLLER HARDWARE REFERENCE/CE MANUAL	89637500	03	22	LJL
N	1732-2 {SYSTEM 17} MAGNETIC TAPE TRANSPORT CONTROLLER REFERENCE MANUAL	89637600	03	22	LJL

CONT.

1	TITLE	2	3	4	5
N	FA442-A NRZI MAGNETIC TAPE TRANSPORT CONTROLLER GEN. DESC., OPER AND PROGRAMMING, INSTALLATION/CHECKOUT, THEORY OF OPERATION, DIAGS., MAINT., MAINT. AIDS, P/L, W/L, GLOSSARY	89637700	02	22	LJL
N	FA716-A CARTRIDGE DISK DRIVE CONTROLLER CE MANUAL	89638100	02	22	LJL
N	DJ81-A SYNCHRONOUS COMMUNICATIONS CONTROLLER AND DISTRIBUTION PANEL CE MANUAL	89638300	02	22	LJL
N	FJ606-A SYNCHRONOUS COMMUNICATIONS CONTROLLER (SCC) AND DISTRIBUTION PANEL CE MANUAL	89638500	01	22	LJL
N	SYSTEM 17 REAL TIME CLOCK PRELIMINARY REFERENCE MANUAL	89638800	01	22	LJL
R	1784 (SYSTEM 17) COMPUTER SYSTEM INPUT/OUTPUT SPECIFICATIONS	89673100	02	22	LJL
N	SYSTEM 17 KEY TO LOGIC SYMBOLS	89723700		22	LJL
N	AT310-A TTL A/Q-DSA BUS EXPANDER HARDWARE REFERENCE/CE MANUAL	89758600	01	22	LJL
N	1732-3 (SYSTEM 17) MAGNETIC TAPE TRANSPORT CONTROLLER REFERENCE MANUAL	89769400	01	22	LJL
N	FA446-A NRZI-LCTT MAGNETIC TAPE TRANSPORT CONTROLLER CE MANUAL	89769500	01	22	LJL
N	FV497-A, FV618-A PHASE ENCODING FORMATTER CE MANUAL	89796100	01	22	LJL
N	929 DOCUMENT READER OCR MEDIA MANUAL	91604300	A	22	R0K
R	955/959 PAGE AND DOCUMENT READER OCR MEDIA MANUAL	91604500	B	22	R0K
N	1700/SC1700 COMPUTER SYSTEMS ASSEMBLER OCR SOFTWARE REFERENCE MANUAL	91634000	A	22	R0K
R	595 PRINT CARTRIDGE TYPE D MANUAL	91860100	A	22	RHT
N	915/8092 COMPUTER SYSTEMS GRASP OCR SOFTWARE INSTALLATION HANDBOOK	91661300			R0K
N	CW195 OCR-B PLUGGABLE FONT OPTION GEN. DESC. INSTALLATION/CHECKOUT, DIAGRAMS HARDWARE REFERENCE/CE MANUAL	91662900	A	22	R0K
N	959 PAGE AND DOCUMENT READER SYSTEM OPERATORS GUIDE	91669100	A	22	R0K
N	915/919-1700 SERIES & 955/959 1700 SERIES COMPUTER SYSTEMS PAGE READER SETUP-SOURCE EDIT TAPE UPDATE PROGRAM OCR SOFTWARE REFERENCE MANUAL	91674400	A	22	R0K
N	8092 COMPUTER SYSTEM 921 MONITOR OCR REFERENCE MANUAL V.1	91681100	A	22	R0K
N	580 LINE PRINTER EQUIPMENT INTRODUCTION, OPERATING INSTRUCTIONS, PRINCIPLES OF OPERATION REFERENCE MANUAL	91858600	B	22	RHT
N	580 LINE PRINTER EQUIPMENT INSTALLATION/CHECKOUT/PREVENTIVE MAINTENANCE CORRECTIVE MAINT., PARTS REPLACEMENT FIELD SERVICE MANUAL VOLUME 1	91858700	B	22	RHT
NMP	580 LINE PRINTER EQUIPMENT FIELD SERVICE MANUAL VOLUME II	91858800	B-01	22	RHT
N	CW207 HANDPRINT UNIT MODEL A01 HARDWARE MAINTENANCE MANUAL VOLUME 1	91558900	A	22	R0K
N	580 PRINT CARTRIDGE GEN DESC., OPER, AND PROGRAMMING, THEORY OF OPERATION, MAINTENANCE, PARTS DATA HARDWARE REFERENCE/CE MANUAL	91559000	C	22	RHT

CONT.

1	TITLE	2	3	4	5
R0	9322 LINE PRINTER EQUIPMENT INTERCONNECTION PRINT HEAD LOGIC/CONTROLLER LOGIC/ TIMING DIAGRAMS, FSM VOLUME II	91859200	B	34	RHT
R	595 PRINT CARTRIDGE TYPE D MANUAL	91860100	A	22	RHT
N	580 LINE PRINTER EQUIPMENT CONTROLS AND INDICATORS, OPERATING PROCEDURES, OPERATOR MAINTENANCE OPERATOR HANDBOOK	91860400	B	22	RHT
N	1700 COMPUTER SYSTEM TOTES G.I.M.	96716700	A	22	LJL
R	AF107-A {ST.OPT.10287-4} 3100 ENHANCED BLOCK CONTROL AND BDP INTERFACE CE MAN	97402300	B	22	PLY
N	10287-1 {AF105-A, BT193-A, CD124-A} 3200 ENHANCED BLOCK CONTROL OPTION REF MAN	97402400	A	22	PLY
N	AF105-A {ST.OPT.10287-1} 3200 ENHANCED BLOCK CONTROL MODIFICATION CE MANUAL	97402500	A	22	PLY
N	AT146-A {10287-3} MEMORY INCREMENT 3200 CE MANUAL	97402700	A	22	PLY
*R0	MASTER OPERATING SYSTEM - DATA SHEET	10035700	-	--	ADV
*R0	9427H DOUBLE-DENSITY CART DISK DRIVE - DATA SHEET	20028300	B	--	ADV
*R0	CYBERNET: PDS/MAGEN - DATA SHEET	20032100	C	--	ADV
*R0	CYBERNET: QA-PAK-QUESTIONNAIRE	20057000	A	--	ADV
*R0	CYBERNET: PIPEFLEX - DATA SHEET	20057100	A	--	ADV
*R0	CYBERNET: SYSCAP II - DATA SHEET	20057200	B	--	ADV
*R0	CYBERNET: MAP FEB. 1975 - DATA SHEET	20059700	D	--	ADV
*R0	MILITARY DISK STORAGE UNIT - DATA SHEET	20063100	B	--	ADV
*R0	REPORT ON SOCIAL RESPONSIBILITY - BROCHURE	20067200	-	--	ADV
*R0	669 MAG TAPE TRANSPORTS - DATA SHEET	20067300	-	--	ADV
*R0	667 MAG TAPE TRANSPORTS - DATA SHEET	20067500	-	--	ADV
*R0	BRIDGE ANALYSIS & RATING SYSTEM - DATA SHEET	20070200	B	--	ADV
*R0	9760 & 9762 STORAGE MOD DRIVES - DATA SHEET	20070400	E	--	ADV
*R0	CONSULTING SERVICES FOR DATA COMM SYSTEM - BROCHURE	20071500	B	--	ADV
*R0	PERIPHERAL PRODUCTS CATALOG - BROCHURE	20083800	A	--	ADV
*R0	33158 MONOLITHIC MAIN MEMORY - DATA SHEET	20085700	-	--	ADV
*R0	MULTIPARTITION MSOS 5 - DATA SHEET	20087100	-	--	ADV
*R0	1987 CABINET - DATA SHEET	20089200	A	--	ADV
*R0	MODEL 77-2 CYBER GRAPHICS TERMINAL - DATA SHEET	20090300	-	--	ADV
*R0	844-21 MASS STORAGE SUBSYSTEM - DATA SHEET	20101200	-	--	ADV
*N	1743 COMMUNICATIONS CONTROL - DATA SHEET	20106000	-	--	ADV
*R	CYBER 170 PRESENTATION GUIDE	20106200	A	22	LDS
*R0	SYSTEM 2000 G-P DATA BASE MGMT - BROCHURE	20108400	A	--	ADV
*R0	2570-1 LINE PRINTER & 2571-1 CONTROLLER - DATA SHEET	20108500	A	--	ADV
*R0	2570-2 LINE PRINTER & 2571-1 CONTROLLER - DATA SHEET	20108600	A	--	ADV
*R0	2572-1/2572-2 CARD READER & 2571-1 CONTROLLER - DATA SHEET	20108700	A	--	ADV
*N	CYBERNATA KEY ENTRY SYSTEM - BROCHURE	20109600	-	--	ADV
*R0	COMPUTERS IN EDUCATION	20114000	A	--	ADV
*N	CORPORATE PHOTOGRAPHY CATALOG	20114600	-	22	HQN
*N	1732-3/616 MAG TAPE SUBSYSTEM - DATA SHEET	20116100	-	--	ADV
*N	1566-20/21/22/23 DIGITAL-TO-ANALOG CONVERTERS - DATA SHEET	20116500	-	--	ADV
*N	1590-3 REMOTE COMPUTER INTERFACE SUBSYSTEM SUBSYSTEM - DATA SHEET	20116000	-	--	ADV
*N	MPP/CONTROLLER FOR 9760 STORAGE MODULE DRIVE - DATA SHEET	20116700	-	--	ADV

CONT.

1	TITLE	2	3	4	5
*R0	9747 DISK STORAGE UNIT - DATA SHEET	20116900	-	--	ADV
*N	2550-100 EMULATION MODULE	20117300	-	--	ADV
*N	MU-602 {V} UYK EXTENDED CORE MEMORY UNIT - DATA SHEET	20117400	-	--	ADV
*N	MB0 SYSTEMS & SERVICES COMPANY - BROCHURE	20117800	-	--	ADV
*N	MB0 MARKETING COMPANY - BROCHURE	20117900	-	--	ADV
*N	MB0 CORPORATE STAFF - BROCHURE	20118000	-	--	ADV
*N	CYBERNET - CYBER 76 SERVICE - DATA SHEET	20118200	-	--	ADV
*N	GRAPHICALLY ORIENTED DESIGN AND ANALYSIS SYSTEM - DATA SHEET	20118300	-	--	ADV
*N	777 CYBER GRAPHICS TERMINAL - DATA SHEET	20118400	-	--	ADV
*N	FAST-TIME/LOAD FLOW - BROCHURE	20118600	-	--	ADV
*N	CYBERNET: IS/ATHENA - DATA SHEET	20118700	-	--	ADV
*N	CYBERNET: SPOTLIGHT OVERVIEW - BROCHURE	20118800	-	--	ADV
*N	882 DISK PACK - DATA SHEET	20118900	-	--	ADV
*N	469 LARGE-PLANE COMPUTER SYSTEM	20119000	-	--	ADV
*N	BUSINESS PRODUCTS - LEADERS IN THEIR FIELD	20119100	-	--	ADV
*N	94200 CORE MEMORY - DATA SHEET	20119400	-	--	ADV
*N	DATA MASS STORAGE SYSTEM FOR IBM 370 - DATA SHEET	20119800	-	--	ADV
*N	MASS STORAGE TAPE CARTRIDGE-DATA SHEET	20119900	-	--	ADV
*N	1700 REDUCED-CORE OPER. SYSTEM VER 2 - DATA SHEET	20120200	-	--	ADV
*N	1974 CCC ANNUAL REPORT	20120300	-	--	ADV
*N	CYBERNET: IFMS	20120400	-	--	ADV
*N	1700 MASS STORAGE FORTRAN V3 A/B DATA SHEET	20120500	-	--	ADV
*N	CYBERNET: FAAST - DATA SHEET	20122300	-	--	ADV
*N	CYBERNET: CC-TEGAS 3 - DATA SHEET	20122400	-	--	ADV
*N	1974 ANNUAL REPORT	20122500	-	--	ADV
*N	CYBERNET: GPSS V/6000 - DATA SHEET	20122700	-	--	ADV
*N	CYBERNET: APEX III MATH PROG SYSTEM - DATA SHEET	20122800	-	--	ADV
*N	3373 MAG CORE STORAGE MEMORY SYSTEM - DATA SHEET	20123200	-	--	ADV
*N	3000 COMPUTER SYSTEMS - BROCHURE	20123300	-	--	ADV
*N	92451 STAND-ALONE DISPLAY TERMINAL - DATA SHEET	20124000	-	--	ADV
*N	ISP 00001 SUPPORT PACKAGE - DATA SHEET	20124600	-	--	ADV
*N	ISP 00005 SUPPORT PACKAGE - DATA SHEET	20124700	-	--	ADV
*N	ISP 20002 SUPPORT PACKAGE - DATA SHEET	20124800	-	--	ADV
*N	ISP 00006 SUPPORT PACKAGE - DATA SHEET	20124900	-	--	ADV
*N	ISP 00004 SUPPORT PACKAGE - DATA SHEET	20125000	-	--	ADV
*N	ISP 20001 SUPPORT PACKAGE - DATA SHEET	20125100	-	--	ADV
*N	ISP 00002 SUPPORT PACKAGE - DATA SHEET	20125200	-	--	ADV

OBSOLETE PUBLICATIONS

This section lists publications which have become obsolete since the January 1975 Catalog. The publications which replaces the obsolete items are also shown and if no manual replaces an obsoleted item, the replacement is listed as "none".

<u>TITLE</u>	<u>PUB. NO.</u>	<u>REPLACEMENT</u>
657-1 MAG TAPE DATA SHEET	10038400	NONE
3400 DATA SHEET	10039400	NONE
3800 DATA SHEET	10039600	NONE
659-1 DATA SHEET	10042200	NONE
1700 COMP SYS BROCHURE	10042500	NONE
COMPUTER SITE ENGINEERING	10047200	NONE
1750 DCB TERMINATOR-DATA SHEET	10044200	NONE
1797 DATA SHEET	10044300	NONE
1739-1 DATA SHEET	10045800	NONE
1717-1 DATA SHEET	10050600	NONE
9280 DATA SHEET	10051900	NONE
CORPORATE PHOTOGRAPHY CATALOG	10056900	20114600
8194 DATA SHEET	10059000	NONE
DIS DATA SHEET	10063200	NONE
LOW LEVEL ANALOG - D.S.	10063300	NONE
1558 DATA SHEET	10063500	NONE
1547 EVENT COUNTER SUB SYS	10063600	NONE
DATA SHEET		
1549 DATA SHEET	10063700	NONE
1577 STALL ALARM DATA SHEET	10063800	NONE
1571 DATA SHEET	10064000	NONE
3520 DATA SHEET	10068000	NONE
9540 DATA SHEET	10071000	NONE
9525 DATA SHEET	10071200	NONE
9250 DATA SHEET	10071400	NONE
9433 DATA SHEET	10071700	NONE
9432 DATA SHEET	10071800	NONE
1581 DATA SHEET	10073000	NONE
1587 DATA SHEET	10073300	NONE
EXTERNAL REGISTER DATA SHEET	10073400	NONE
9720 DATA SHEET	10076500	NONE
9200 DATA SHEET	10076900	NONE
1534,1535 DATA SHEET	10084600	NONE
3400 BROCHURE	10089200	NONE
657-2 DATA SHEET	10091900	NONE
657-4 DATA SHEET	10092100	NONE
659-3 DATA SHEET	10092300	NONE
659-4 DATA SHEET	10092400	NONE
90100 DATA SHEET	10092800	NONE
90120 DATA SHEET	10092900	NONE
1604 BROCHURE	10093000	NONE
1572 PROG SAMPLE DATA SHEET	10093400	NONE
9486/9487 DATA SHEET	10093700	NONE
APPL. REPORT COMPUTERS BOOST	20001900	NONE
COLUMBIA RIVER POWER		
THROUGHPUT-FEEDBACK FOLDER	20006800	NONE
3400 DATA SHEET	20007600	NONE
9463 DATA SHEET	20010800	NONE
9736/9737 DATA SHEET	20012100	NONE
3200 BROCHURE	20015500	NONE
92413 CRT DISPLAY D.S.	20035500	20085600
A LEASING PROGRAM STRUCTURED	20035700	NONE
TO FIT YOUR NEEDS		
APPL. REPORT-AT DELTA AIRLINES	20040100	NONE
COMMUNICATIONS RATES SEPARATE		
COMPUTER		
3000 SERIES CASH	20040900	NONE

<u>OBSOLETE PUBLICATIONS CONT.</u>	<u>PUB. NO.</u>	<u>REPLACEMENT</u>
731 LOW SPEED TERMINAL D.S.	20041300	NONE
APPL. REPORT-VICTORIAN TAB	20044200	NONE
SUCCESSFUL IN OTB AUTOMATION		
1739-1 DATA SHEET	20045800	NONE
COMPUTER MAINT FOLDER	20049201	NONE
THE READY RESPONSE PLAN	20049300	NONE
THE TIME CRITICAL PLAN	20049400	NONE
THE DO IT YOURSELF PLAN	20049500	NONE
THE CALL US WHEN YOU NEED US PLAN	20049600	NONE
THE SPECIAL PLAN ARRANGEMENT	20049700	NONE
FLIP CHART NOTEBOOK	20049900	NONE
1971 ANNUAL REPORT	20051900	NONE
ELECTRICAL ENGINEERING BROCHURE	20057800	NONE
OPERATIONS RESEARCH BROCHURE	20058000	NONE
33145 MONOLITHIC MAIN MEMORY	20069900	NONE
TOTAL SERVICES MARKETING	20073700	NONE
CYBERNET MEMBER CERTIFICATE	20059800	NONE
1732-2/615 DATA SHEET	20081500	NONE
33145 MONOLITHIC MAIN MEMORY	20086500	NONE
APPL. REPORT-BRIEF DATA RETRIEVAL	20094300	NONE
SYSTEM SPEEDS TAX SERVICE		
COMMERCIAL TERM LEASING PLAN	20094400	NONE
APPL. BRIEF FOR SKYLAB PROJECT	20097900	NONE
CDC PIONEERS GIANT DATA STORAGE		
APPL. REPORT-AT AERONAUTICAL RADIO	20098100	NONE
ELECTRONIC SWITCHING DIRECTS		
MESSAGE TRAFFIC		
C-810 TRG SERIES D.S.	20099000	NONE
C-910 TRG SERIES DATA SHEET	20102000	NONE
9315 DATA SHEET	20105200	NONE
1973 REAL/TIME VOL 10 NO. 2	00015600	NONE
469 COMPUTER SYSTEMS CE MANUAL	14176000	NONE
EL101-A (1750-1) COMPUTER	39909501	88980100
INTERFACE UNIT REF/CE		
1576 (FV4A3/498) STALL ALARM	39909510	88981000
UNIT REF/CE MANUAL		
KEY TO LOGIC SYMBOLS G.I.M.	39909515	88981500
501 HIGH SPEED REF MANUAL	40805000	NONE
501 HIGH SPEED REF MANUAL	40815200	NONE
9464 DISK STORAGE DRIVE DIAGS. &	41248700	NONE
WIRE LIST		
PROFITS INFORMATION MANUAL	59157700	NONE
1700 MSOS 4 G.I.M.	60171400	39522400
955 PAGE AND DOCUMENT READER OCR	60216102	NONE
MEDIA MANUAL		
3000 TAPE SORT/MERGE G.I.M.	60227900	60282100
1700 COSY REFERENCE V1	60237100	60361500
PAPER TAPE EQUIPMENT TRAINING MAN	60238600	NONE
6000 SCOPE USERS GD 6000 V3.3	60252700	NONE
1700 SYSTEM CHECKOUT VI	60281800	60361500
1700 CONFIGURATOR VI	60282300	60361500
MSOS VERSION 3 REF MANUAL	60282600	60361500
LOGIC ANALYSIS STUDENT MANUAL	60313300	NONE
COBOL STUDENT MANUAL	60314600	NONE
SCIENTIFIC PROGRAMMING STUDENT MAN	60315000	NONE
6000/CYBER 70/RECORD MGR REF MAN	60385400	60307300
I/LOGIC CYBERNET U.I.M.	84000200	NONE
CSM O/P CYBERNET U.I.M.	84000300	NONE
1700 REAL/TIME MAINT SYSTEM	84542000	60361500
I/CAP CYBERNET U.I.M.	86602500	NONE
SYSTEM 2000 G.I.M.	86604400	76074100
SYSTEM 2000 U.I.M.	86604500	INDIVIDUAL MANUALS
COP U.I.M.	86605500	NONE
COP DATA CARD DIGEST	86612400	NONE
I/TRAC CYBERNET U.I.M.	86616400	NONE
APEX II USERS GUIDE	97401400	NONE
28211/14031 & 28211-21 PRINTER	97403300	22265500 (AVAILABLE
SYSTEMS OPERATING GUIDE		FROM BOB HED-PLYOPS)

PUBLICATION NUMERICAL SEQUENCE PAGE LISTING

This section contains a complete listing of all catalog publications by numerical sequence along with the page numbers on which each publication can be found. Note that some publications are found on more than one page.

PUB. NO.	PG.	PUB. NO.	PG.	PUB. NO.	PG.	PUB. NO.	PG.	PUB. NO.	PG.	PUB. NO.	PG.
AEG05571	57	13791400	87	13799800	50	17322800	145	31620099	92	36822900	112
AET01621	57	13791500	93	14060200	66		147	31620199	92	36823200	70
AET05611	167	13791600	93	14061300	130	17325100	149	31620200	92	36823300	70
AET05613	57	13791700	112	14062100	131	17326500	149	31620300	92	36823400	115
AET09611	57	13791800	112	14062200	131	19980300	145	32501300	95	36823500	114
APT45910	167	13791900	112	14065300	131	19980400	145	32503300	95	36823700	114
BER11621	57	13792000	59	14077300	131	19980600	141	35110900	89	36823800	113
BER56250	57	13792100	92	14082100	131		148	36810100	112	36824400	64
BPT36210	130	13792200	92	14082200	131	19980700	148	36810200	112	36824500	74
ESD10400	58	13792400	87	14091600	115		150	36810300	59	36824700	64
ESD10501	58	13792500	87	14091700	115	19980900	148	36810500	113	36824800	64
ESD10504	167	13792700	87	14091800	115		151	36810600	113	36825600	115
ESD10505	58	13792800	59	14091900	115	19981400	166	36810700	113	36825800	93
ESD10600	58	13792900	74	14092000	115	19981400	166	36810800	113	36825900	93
PED20030	68	13793000	74	14093500	115	19983600	56	36810900	113	36826000	93
PED20080	69	13793100	87	14094700	115	19983800	4	36811000	112	36826500	74
PED22140	69	13793200	91	14123800	157	20114600	157	36811300	114	36826600	115
PED22160	69	13793300	87	14142900	157	22003300	69	36811500	114	36826700	115
PP118100	130	13793400	87	14143700	157	22006500	159	36811600	114	36827000	85
PSBAG010	130	13793500	97	14143800	157	22006600	159	36811700	112	36827100	85
PSBAG020	130	13793600	91	14155000	157	22006700	159	36812500	115	36827800	114
PSBAG030	130	13793900	93	14163300	102	22006900	159	36812600	112	36827900	114
PSBAG040	130	13794100	92	14166700	102	22008200	159	36812700	115	36828100	93
PSBAG050	130	13794400	85	14166800	102	22261700	51	36812800	171	36828200	114
PSBAG060	130	13794600	86	14167100	102	22261900	157	36813100	115	36828300	114
PSBAG070	130	13794700	86	14232000	101	22262100	157	36813300	114	36828600	74
PSBAG090	130	13794800	86	14237500	158	22262200	157	36813700	115	36828700	74
PSBAG110	130	13794900	59	14247900	102	22263500	124	36814000	112	36828900	116
PSBAG120	130	13795000	79	14306500	130	22263600	157	36814100	115	36829000	64
SB001700	142	13795100	114	15000300	123	22263800	125	36814200	115	36829100	85
SC000100	58	13795300	114	15002900	158	22263900	124	36814300	70	36829400	158
SC057600	58	13795400	158	17302500	152	22264000	124	36814400	115	36829500	87
SC063300	58	13795500	158	17303100	151	22264500	157	36814500	115	36829600	89
SC200000	58	13795600	158		152	22264600	157	36814700	116	36829700	89
SC200100	58	13795700	158	17303600	152	22264700	157	36814800	116	36829900	108
SC400600	58	13795900	43	17304200	153	22264800	124	36815000	116	368304400	79
000000200	158	13796000	114	17304400	149	22265400	124	36816000	116	368304500	79
000002100	162	13796100	64		151	22265500	123	36816200	93	368305100	172
000004600	165	13796200	86	17305100	150	22267100	157	36816300	112	368306000	108
000006000	163	13796300	168		152	22267200	157	36816400	112	368306100	108
000006100	163	13796400	64	17307300	149	22267300	157	36816600	113	368307800	108
000006300	158	13796500	38		151	22272400	46	36816700	111	368308400	108
000007300	141	13796800	95	17308100	152	22272500	46	36817300	115	39070800	75
000007500	157	13796900	114	17308300	152	22273000	123	36817400	70	39070900	76
00015000	158	13797000	116	17309500	174	22273100	123	36817500	112	39071100	85
00015100	173	13797300	116	17309700	153	22285300	125	36817600	86	39071300	76
01306700	160	13797400	64	17310100	149	22285400	125	36817700	74	39071400	76
04036700	162	13797500	158	17311600	174	22285500	125	36817900	74	39071500	76
04256700	162	13797700	74	17311700	174	22285600	124	36818000	74	39071900	76
04266700	160	13797800	83	17313000	150	22285700	125	13618100	74	39072200	79
07046700	161	13797900	47		152	24107700	60	36818200	74	39072400	79
082966A0	161	13798100	47	17313200	147	24140300	113	36818300	58	39072500	60
083066A0	159	13798400	64		149	31600200	98	36818500	58	39072600	76
13790100	87	13798500	64	17313600	147	31600800	99	36819100	114	39072900	85
13790200	87	13798600	64	149	151	31601100	99	36819900	112	39073100	76
13790300	87	13798700	64	17317200	152	31602300	100	36820000	86	39073300	75
13790400	91	13798800	47	17317400	149	31602900	100	36820100	87	39073400	75
13790500	86	13798900	159	17318900	149	31603800	101	36820200	87	39073500	75
13790700	87	13799000	85	17321800	149	31605400	98	36820300	87	39073600	75
13790800	87	13799100	47	17322100	152	31605600	99	36820400	86	39073700	75
13791100	115	13799200	47	17322500	149	31605700	99	36820600	74	39073800	75
13791200	116	13799300	64	17322600	149	31606100	100	36822500	111	39073900	75
13791300	87	13799700	116	17322700	145	31606600	101	36822700	115	39074100	75
					147	149					

PUB. NQ. PG.	PUB. NQ. PG.	PUB. NQ. PG.	PUB. NQ. PG.	PUB. NQ. PG.	PUB. NQ. PG.
39074200 75	40807200 67	40821700 117	40862700 67	41246000 120	41610700 98
39074300 75	40807700 69	40821800 117	40862900 72	41246100 121	41610900 66
39074400 75	40807800 69	40821900 22	40863100 120	41246200 121	41611000 38
39074500 75	40707900 69	40822000 69	40863200 33	41246800 120	41611200 38
39074700 63	40808100 118	40822100 116	40863300 71	41246900 121	41611300 92
39074900 66	40808200 23	40822200 69	40863600 117	41247100 121	41611700 38
39075000 75	40808300 63	40822300 116	40863900 72	41247200 121	41611800 65
39075200 76	40808400 117	40822400 68	40864000 32	41247300 71	41611900 38
39075300 76	40808500 117	40822500 68	40864100 21	41247400 72	41612000 65
39083500 141	40808600 24	40822600 69	40864400 120	41247500 120	41612100 38
39150100 74	40809100 69	40822800 69	40864600 117	41247600 120	41612200 65
39153300 75	40809300 66	40823000 68	40864800 32	41247700 120	41612300 38
39153400 75	40809500 70	40823100 71	40864900 66	41247800 121	41612400 65
39185900 79	40809600 111	40823200 72	40865000 117	41248400 121	41612500 66
39201800 133	40810800 68	40823400 71	40865100 117	41248800 121	41612600 38
39216600 85	40811200 69	40823600 117	40865200 71	41248900 26	41612700 66
39222600 42	40811400 68	40823700 117	40865500 121	41249000 26	41612800 38
39230300 74	40811500 68	40813800 117	40865800 122	41249200 25	41613200 37
39231200 47	40811700 116	40823900 66	40866400 120	41249300 25	41613400 37
39260700 134	40811800 68	40824000 69	40866500 120	41249400 25	41614300 51
39268100 133	40811900 68	40824200 23	40867100 121	41249500 25	41614400 140
39278700 75	40812000 68	40824300 71	40867500 53	41249600 25	41614500 140
39308000 79	40812300 157	40824600 116	40867600 121	41249700 25	41614600 140
39359900 50	40812400 67	40824800 71	40867700 53	41249800 25	41614700 140
	40812500 68	40824900 72	40867800 122	41600000 134	41614800 140
39368600 49	40812600 68	40825000 71	40868100 117	41600300 95	41614900 140
39392700 37	40812700 69	40825100 71	40868400 121		41615000 140
39412900 79	40812800 59	40825200 66	40868500 121	41600500 64	41615100 140
39415100 79	40813100 65	40825400 117	40868700 22	41600600 37	41615200 140
39473200 41	40813300 117	40825600 71	40869500 166	41600700 101	41615300 140
39519800 132	40814200 69	40826200 117	40869600 26	41600900 170	44016000 159
39519900 132	40814300 70	40826300 71	40869700 22	41601000 50	44016800 159
39520200 133	40814400 59	40826400 72	40869901 22	41601500 85	44020300 159
39520500 132	40814500 70	40826500 120	41240000 21	41601600 85	44020500 159
39520600 132	40814600 70	40826600 116	41240100 69	41601700 46	44610400 153
39520900 132	40814800 68	40826700 166	41240200 172	41601800 65	44616700 152
39521700 133	40814900 116	40826800 120	41240300 121	41601900 37	44623700 158
39521900 133	40815100 68	40826900 120	41240400 121	41602200 46	44629200 153
39522400 132	40815200 67	40827000 121	41240500 121	41602400 64	44629300 152
39524000 37	40815300 67	40827300 120	41240600 53	41602500 50	44855500 34
39534900 31	40815400 68	40827500 71	41240800 117	41602600 97	44855600 35
39644500 133	40815500 68	40827600 33	41240900 71	41602700 97	44855700 34
39660400 51	40815600 68	40827900 166	41241000 72	41602800 97	44855800 67
39677500 133	40815700 117	40828200 121	41241400 33	41602900 50	44895600 34
39690100 51	40816000 70	40828700 120	41241500 31	41603000 170	44895700 34
39731700 24	40816100 111	40828900 120	41241600 120	41603100 38	44895800 34
39744900 41	40816200 158	40829000 120	41241700 25	41603200 37	44895900 119
39771300 174	40816500 68	40829100 120	41241900 33	41603300 46	44896400 114
39909502 35	40816800 68	40829300 122	41242100 22	41603500 115	44896500 89
39909503 36	40816900 120	40829400 66	41242200 24	41605200 157	44976700 34
39909504 42	40817000 116	40829700 166	41242300 24	41605300 65	44977000 119
39909505 50	40817200 69	40829900 117	41242400 24	41605400 37	
39909506 41	40817400 23	40860000 157	41243200 31	41605600 47	44977600 119
39909507 39	40818700 117	40860100 117	41243500 26	41605900 58	44977700 119
39909508 48	40818800 116	40860200 121	41243600 26	41606100 113	44978800 34
39909509 37	40818900 117	40860400 72	41243700 26	41606200 65	44980100 34
39909513 76	40819300 33	40860500 72	41243800 22	41606300 37	44980700 35
40801800 22	40819400 68	40860700 21	41243900 26	41606400 46	44980800 35
40802000 31	40819500 68	40860800 21	41244100 71	41606500 93	44980900 35
40802100 116	40819700 117	40860900 23	41244200 72	41606600 141	44981600 119
40803200 70	40819800 117	40861000 23	41244300 120	41607100 65	44982700 119
40803400 70	40819900 23	40861700 67	41244400 120	41607400 114	44983100 119
40803900 116	40820000 71	40861800 67	41244500 121	41607700 172	44983200 119
40804800 31	40820100 112	40861900 65	41244600 121	41608100 37	47500700 89
40805000 67	40820200 66	40862000 67	41244700 121	41608500 48	47966500 114
40805200 117	40820300 68	40862100 67	41245200 120	41608700 168	47966600 114
40805300 116	40820400 117	40862200 67	41245500 121	41609000 64	47966700 34
40806600 111	40820500 67	40862300 117	41245600 166	41609600 65	47967000 34
40806700 116	40820800 67	40862400 72	41245700 71	41609700 37	
40806800 117	40821000 68	40862500 71	41245800 72	41610400 39	48143900 133
40807100 117	40821200 68	40862600 69	41245900 120	41610500 66	48143910 72

PUB. NO.	PG.	PUB. NO.	PG.	PUB. NO.	PG.	PUB. NO.	PG.	PUB. NO.	PG.	PUB. NO.	PG.
48143981	35	49752300	124	59150800	146	60007200	59	60026200	60	60052900	132
48249700	158	49754900	31	59151000	146	60007300	60	60026500	60	60053300	143
48299727	158	49755100	31	59151300	146	60007400	61	60026700	73	60053400	143
48402800	165	49755200	31	59151600	146	60007500	61	60026800	60		144
48430000	134	49755300	66	59152000	146	60007600	61	60026900	60	60053500	132
48430010	134	49755400	66	59152100	146	60007700	61	60027000	61	60053900	132
48430045	33	49755500	66	59153200	140	60007800	61	60027100	73	60054000	130
48430050	74	49755600	21	59153300	140	60007900	61	60027200	78	60054100	130
48430070	74	49755700	22	59155100	134	60008300	167	60027400	73	60054200	130
48430080	33	49755800	22	59155600	134	60008400	131	60027500	73	60054400	130
48430087	33	49755900	66		141	60009800	78	60027600	78	60054500	130
48430090	33	49757500	68	59156000	158	60010200	168	60028100	77	60054600	130
48430100	133	49757600	68	59156600	146	60010600	78	60028200	95	60055000	138
48430170	72	49762400	33	59156800	151	60010700	78	60029100	60		139 140
48643305	74	49800300	23	59156900	151	60013600	168	60029200	78	60055100	138
48704601	155	49803700	52	59157000	151	60013700	73	60029300	73	60055200	135
48704702	72	49803800	52	59157900	154	60013900	61	60041400	60	137 138	139
48704800	155	49815000	21	59158000	148	60014000	60	60041600	166	60055400	138
48704810	74	49815100	22		154	60014100	60	60041700	98	60055500	141
48704850	74	49815200	24	59158100	148	60014200	60	60041800	99		142
48704901	155	49815900	23		154	60014300	60	60041900	99	60055600	142
48706101	155	49859200	23	59158200	158	60014400	62	60042000	99	60055700	141
48706201	155	49859300	23	59158300	158	60016400	77	60042100	99		142
48707800	155	49859400	22	59158800	141	60016500	77		172	60055800	137
48707900	155	49932700	23	59158900	141	60016600	77	60042200	100		139
48708000	72	49973600	31	59159000	140	60016700	77	60042300	101	60055900	142
48781100	74	50577600	118	59159100	140	60016800	73	60042400	101	60056100	132
48814000	155	50577700	35	59159400	158	60017000	73	60042500	100	60056300	135
48883700	33	50577800	118	59159600	141	60017100	73	60042600	98	137 138	139
48911900	35	50577900	118	59159700	153	60017300	73	60042700	166	60056400	143
48948100	33	50578100	34	59159800	155	60017800	78	60042800	58		144
48948200	33	50578500	34	59304600	158	60017900	78	60042900	166	60056500	144
48991800	35		120	59349900	24	60018200	132	60043000	89	60056800	140
48996300	35	50578700	168	59577900	120	60018400	59	60043300	99	60056900	140
48996600		50579100	119	59578000	120	60018500	59	60043400	98	60057100	140
	155	50579600	119	59578100	120	60018600	159	60043500	100	60057200	141
48997900	33	50580500	119	59578800	120	60018700	59	60043800	92		142
49484600	23	50580900	52	59578900	120	60018800	78	60044400	98	60057400	141
49486400	21	50581000	119	59579200	118	60018900	78	60044800	73	142 143	144
49487000	23	50581200	168	59579300	118	60019100	131	60044900	78	60057500	141
49487100	23	50581300	119	59579400	119	60019400	61	60047600	99		142 143
49487200	22	50581400	119	59579500	119	60019500	61	60047700	100	60057600	134
49487300	22	50581500	168	59707800	119	60020900	59	60047900	89	135 136	137
49487400	22	50581600	67	59708000	119	60021300	98	60048300	101	138 139	140
49487500	22	50581800	34	59708200	123	60021400	78	60048400	100	60057800	142
49487600	23	50581900	120	59708300	123	60021500	78	60048600	158	60057900	141
49487700	23	50582000	52	59708400	123	60021600	62	60048800	87	60058200	155
49487800	21	50582200	67	59708500	167	60021700	62	60048900	73	60058300	142
49487900	21	50582300	35	59708600	167	60021800	62	60049100	63	60058500	143
49488000	23	50582400	35	59708700	167	60021900	62	60049400	92		144
49488100	23	50582500	119	59709000	167	60022000	61	60049800	100	60058600	143
49488200	21	50583100	34	59709100	118	60022200	61	60050100	131		144
49488300	23	50583200	34	60001500	77		62	60050300	131	60058700	142
49488400	23	50583300	34	60001800	132	60022300	62	60050500	131	60058900	141
49488600	23	50583400	34	60002000	76	60022400	62	60050600	132		142
49591900	32	50583500	52	60002300	59	60022500	61	60050700	131	60059000	142
49592900	32	50583600	118	60002600	59	60023000	60	60050800	132		143
49593000	32	50583700	118	60003000	77	60023800	62	60050900	132	60059100	139
49593100	32	50583800	118	60003200	77	60023900	62	60051000	132		140 142
49596700	117	50583900	35		132	60024000	62	60051100	132	60059200	142
49596800	117	50584100	52	60003300	77	60024300	76	60051200	131	60059300	138
49596900	118	50584300	34	60003500	77	60024400	76	60051300	131	60059400	141
49597000	32	50584400	118	60003600	77	60024500	76	60051500	131		142
49626100	31	50584500	118	60003700	77	60024900	59	60051600	132	60059500	141
49750300	22	50584600	118	60004100	77	60025000	59	60051900	131		142
49750400	22	50583700	120	60004400	77	60025100	131	60052000	132	60059800	141
49750600	24	50584800	119	60006600	77	60025600	77	60052100	132		142
49750700	24	59150500	144	60006800	59	60025700	76	60052200	132	60059900	155
49750900	66		145	60006900	59	60025800	60	60052500	143	60060100	130
49751400	69	59150600	146	60007000	59	60026000	60		144	60060200	130
49751600	158	59150700	146	60007100	59	60026100	60	60052600	132	60060300	130

PUB. NO. PG.	PUB. NO. PG.	PUB. NO. PG.	PUB. NO. PG.	PUB. NO. PG.	PUB. NO. PG.
60060400 130	60083800 144	60100700 99	60123900 61	60134100 134	60150200 87
60060500 130	60084000 132	60100800 102	60124000 61	60134200 135	60150300 95
60060600 130	60084100 131	60100900 92	60124100 60	60134300 138	60150400 99
60060700 130	60084200 130	60101100 92	60124300 61	60134400 143	60150500 105
60060800 130	60084400 142	60101400 89	60124400 113	60134500 144	60150600 59
60061000 57	60084900 141	60101900 113	60124600 57	60134600 138	60150700 78
60061200 130	60085100 165	60102000 113	60124800 101	60134700 139	60150800 62
60061300 56	60086000 164	60102300 95	60125000 36	60134800 134	60150900 61
60061400 57	60086100 164	60102500 61	60125400 101	60134900 139	60151000 63
60061500 130	60086900 164	60103900 60	60126400 95	60135000 137	60151100 61
60061600 130	60087000 164	60104200 60	60126500 101	60135100 138	60151200 167
60061700 57	60087200 164	60104300 61	60126800 77	60135200 142	60151300 94
60061800 57	60087400 164	60104400 61	60127000 106	60135300 142	60151400 90
60061900 130	60087500 164	60104500 57	60127500 78	60135400 142	60151500 81
60062000 130	60087600 164	60104600 60	60127800 112	60135500 142	60151600 102
60062100 130	60088500 164	60104700 60	60129300 61	60135600 142	60151700 79
60062200 130	60088600 164	60104900 101	60129400 58	60135700 143	60151800 130
60062300 56	60088700 165	60105100 93	60129500 137	60135800 138	60151900 130
60062400 57	60088800 164	60105400 60	60130000 138	60135900 139	60152000 130
60062500 57	60089100 164	60107100 78	60130100 140	60136000 153	60152100 94
60062600 57	60089200 164	60107300 165	60130200 139	60136100 131	60152200 94
60062700 130	60089300 164	60107400 101	60130400 137	60136200 131	60152300 102
60062900 57	60089400 179	60108100 96	60130500 143	60136300 144	60152400 93
60063000 57	60089500 179	60108400 89	60130600 143	60136400 144	60152500 102
60063100 57	60089600 112	60108500 61	60130700 155	60136500 144	60152600 102
60063200 57	60089700 73	60108600 76	60130800 182	60136600 132	60152700 98
60063300 57	60089800 97	60108700 89	60130900 134	60136700 141	60152800 140
60063400 57	60089900 93	60108800 89	60131000 135	60136800 141	60152900 158
60063500 58	60090000 77	60108900 62	60131100 137	60136900 90	60153000 160
60063600 130	60090100 113	60109000 60	60131200 138	60137000 113	60153100 160
60063700 57	60090200 113	60109100 171	60131300 143	60137100 101	60153200 102
60063800 57	60090300 113	60109200 87	60131400 142	60137200 63	60153300 99
60063900 57	60090400 113	60109300 93	60131500 141	60137300 62	60153400 112
60064000 57	60090500 78	60109400 97	60131600 142	60137400 61	60153500 112
60064100 57	60090600 97	60109500 76	60131700 143	60137500 60	60153600 100
60064200 130	60090700 73	60109600 142	60131800 141	60137600 93	60153700 102
60064300 58	60090800 92	60109700 144	60131900 138	60137700 102	60153800 102
60064400 58	60090900 98	60109800 139	60132000 137	60137800 167	60153900 91
60064500 58	60091000 73	60109900 168	60132100 143	60137900 167	60154000 103
60064600 58	60091100 165	60110000 87	60132200 142	60138000 160	60154100 94
60064700 58	60091200 171	60110100 76	60132300 143	60138100 160	60154200 157
60064800 57	60091300 87	60110200 139	60132400 144	60138200 167	60154300 167
60064900 57	60091400 87	60110300 143	60132500 143	60138300 168	60154400 102
60065000 57	60091500 113	60110400 142	60132600 136	60138400 78	60154500 90
60065100 130	60091600 113	60110500 144	60132700 137	60138500 112	60154600 95
60065200 95	60091700 92	60110600 141	60132800 143	60138600 95	60154700 79
60065300 59	60091800 92	60110700 141	60132900 141	60138700 95	60154800 112
60065400 59	60091900 98	60110800 142	60133000 144	60138800 95	60154900 82
60065500 59	60092000 62	60110900 143	60133100 144	60138900 95	60155000 102
60065600 73	60092100 62	60111000 135	60133200 144	60139000 103	60155100 57
60065700 76	60092200 61	60111100 137	60133300 145	60139100 103	60155200 57
60065800 77	60092300 168	60111200 138	60133400 146	60139200 131	60155300 159
60065900 77	60092400 87	60111300 139	60133500 147	60139300 131	60155400 93
60066000 77	60092500 76	60111400 142	60133600 150	60139400 167	60155500 93
60066100 163	60092600 76	60111500 143	60133700 144	60139500 77	60155600 92
60066200 163	60092700 76	60111600 143	60133800 141	60139600 106	60155700 79
60066300 163	60092800 60	60111700 144	60133900 138	60139700 106	60155800 103
60066400 163	60092900 60	60111800 144	60134000 139	60139800 113	60155900 103
60066500 163	60093000 60	60111900 144	60134100 147	60139900 95	60156000 103
60066600 163	60093100 62	60112000 150	60134200 152	60140000 91	60156100 103
60066700 163	60093200 105	60112100 145	60134300 146	60140100 91	60156200 103
60066800 163	60093300 143	60112200 146	60134400 152	60140200 91	60156300 103
60066900 163	60093400 143	60112300 147	60134500 152	60140300 167	60156400 92
60067000 163	60093500 141	60112400 147	60134600 152	60140400 77	60156500 82
60067100 163	60093600 141	60112500 147	60134700 152	60140500 106	60156600 79
60067200 163	60093700 141	60112600 147	60134800 152	60140600 106	60156700 103
60067300 163	60093800 141	60112700 147	60134900 152	60140700 113	60156800 103
60067400 163	60093900 141	60112800 147	60135000 152	60140800 95	60156900 103
60067500 163	60094000 141	60112900 147	60135100 152	60140900 91	60157000 103
60067600 163	60094100 141	60113000 147	60135200 152	60141000 91	60157100 103
60067700 163	60094200 141	60113100 147	60135300 152	60141100 91	60157200 103
60067800 163	60094300 141	60113200 147	60135400 152	60141200 91	60157300 103
60067900 163	60094400 141	60113300 147	60135500 152	60141300 91	60157400 103
60068000 163	60094500 141	60113400 147	60135600 152	60141400 91	60157500 103
60068100 163	60094600 141	60113500 147	60135700 152	60141500 91	60157600 103
60068200 163	60094700 141	60113600 147	60135800 152	60141600 91	60157700 103
60068300 163	60094800 141	60113700 147	60135900 152	60141700 91	60157800 103
60068400 163	60094900 141	60113800 147	60136000 152	60141800 91	60157900 103
60068500 163	60095000 141	60113900 147	60136100 152	60141900 91	60158000 103
60068600 163	60095100 141	60114000 147	60136200 152	60142000 91	60158100 103
60068700 163	60095200 141	60114100 147	60136300 152	60142100 91	60158200 103
60068800 163	60095300 141	60114200 147	60136400 152	60142200 91	60158300 103
60068900 163	60095400 141	60114300 147	60136500 152	60142300 91	60158400 103
60069000 163	60095500 141	60114400 147	60136600 152	60142400 91	60158500 103
60069100 163	60095600 141	60114500 147	60136700 152	60142500 91	60158600 103
60069200 163	60095700 141	60114600 147	60136800 152	60142600 91	60158700 103
60069300 163	60095800 141	60114700 147	60136900 152	60142700 91	60158800 103
60069400 163	60095900 141	60114800 147	60137000 152	60142800 91	60158900 103
60069500 163	60096000 141	60114900 147	60137100 152	60142900 91	60159000 103
60069600 163	60096100 141	60115000 147	60137200 152	60143000 91	60159100 103
60069700 163	60096200 141	60115100 147	60137300 152	60143100 91	60159200 103
60069800 163	60096300 141	60115200 147	60137400 152	60143200 91	60159300 103
60069900 163	60096400 141	60115300 147	60137500 152	60143300 91	60159400 103
60070000 163	60096500 141	60115400 147	60137600 152	60143400 91	60159500 103
60070100 163	60096600 141	60115500 147	60137700 152	60143500 91	60159600 103
60070200 163	60096700 141	60115600 147	60137800 152	60143600 91	60159700 103
60070300 163	60096800 141	60115700 147	60137900 152	60143700 91	60159800 103
60070400 163	60096900 141	60115800 147	60138000 152	60143800 91	60159900 103
60070500 163	60097000 141	60115900 147	60138100 152	60143900 91	60160000 103
60070600 163	60097100 141	60116000 147	60138200 152	60144000 91	60160100 103
60070700 163	60097200 141	60116100 147	60138300 152	60144100 91	60160200 103
60070800 163	60097300 141	60116200 147	60138400 152	60144200 91	60160300 103
60070900 163	60097400 141	60116300 147	60138500 152	60144300 91	60160400 103
60071000 163	60097500 141	60116400 147	60138600 152	60144400 91	60160500 103
60071100 163	60097600 141	60116500 147	60138700 152	60144500 91	60160600 103
60071200 163	60097700 141	60116600 147	60138800 152	60144600 91	60160700 103
60071300 163	60097800 141	60116700 147	60138900 152	60144700 91	60160800 103
60071400 163	60097900 141	60116800 147	60139000 152	60144800 91	60160900 103
60071500 163	60098000 141	60116900 147	60139100 152	60144900 91	60161000 103
60071600 163	60098100 141	60117000 147	60139200 152	60145000 91	60161100 103
60071700 163	60098200 141	60117100 147	60139300 152	60145100 91	60161200 103
60071800 163	60098300 141	60117200 147	60139400 152	60145200 91	60161300 103
60071900 163	60098400 141	60117300 147	60139500 152	60145300 91	60161400 103
60072000 163	60098500 141	60117400 147	60139600 152	60145400 91	60161500 103
60072100 163	60098600 141	60117500 147	60139700 152	60145500 91	60161600 103
60072200 163	60098700 141	60117600 147	60139800 152	60145600 91	60161700 103
60072300 163	60098800 141	60117700 147	60139900 152	60145700	

PUB. NO. PG.	PUB. NO. PG.	PUB. NO. PG.	PUB. NO. PG.	PUB. NO. PG.	PUB. NO. PG.
60166400 103	60175600 162	60190500 163	60213500 135	60235300 163	60244800 164
60166700 160	60175700 162	60190900 151	60213600 136	60235400 149	60244900 164
60166800 165	60176000 137	60191100 136	60213700 137	60235900 137	60245100 164
60166900 91	60176100 137		138 139	60236000 135	60245200 164
60167000 91	60176500 132	60191300 137	60214000 136	60236100 138	60245300 164
60167100 112	60176700 135	60191500 153	60214800 143	139 140 142	60245400 164
60167200 112	137 138	60191600 138	144	60236300 141	60245500 164
60167500 84	139 140	60191900 151	60214900 142	60236400 134	60246400 106
60167700 84	60177000 143	60192000 134	60215200 142	135	60246500 104
60167900 93	60177200 144	135	60216101 74	60236500 134	60246600 107
60169100 101	60177300 143	60192100 137	60216104 72	136	60246800 104
60169500 159	60177400 137	60192400 163	60217400 46	60236600 136	60246900 104
60169600 159	138 139	60192500 145	60217600 18	60236700 137	60247000 107
60169700 103	60177700 137	151	60220100 79	138	60247100 107
60170100 141	138 139	60192600 142	60220200 79	60236800 134	60247200 107
60170200 138	60177800 144	60192700 142	60220300 79	135 136	60247300 107
60170300 143	60178000 141	60192800 137	60220400 79	138 139 140	60247400 107
144	60178600 136	60192900 143	60220500 79	60236900 134	60247500 107
60170400 143	60178800 136	60193100 148	60220600 79	136 137 135	60247600 107
144	60179000 144	151	60220700 79	60237000 138	60247700 107
60170500 141	60179500 144	60193600 142	60220800 79	60237400 153	60247800 107
142 143 144	60179700 135	60194000 133	60220900 79	60237700 45	60247900 107
60170700 133	60179800 135	60194400 102	60221000 79	60237800 84	60248000 107
60170800 143	60180000 103	60194500 81	60221100 79	60238000 6	60248100 107
144	60180100 103	60197000 97	60221200 79	60238300 162	60248200 107
60170900 141	60180200 170	60197100 103	60221300 79	60238400 159	60248300 107
142 143 144	60181200 101	60197200 103	60221400 79	60238500 159	60248500 104
60171100 131	60181300 63	60197300 100	60221500 79	60238700 161	60248600 104
141	60181400 63	60197400 172	60221600 79	60238800 162	60248700 104
60171200 139	60182000 79	60197600 95	60221700 79	60239200 160	60248800 104
140	60182100 103	60197700 102	60222100 36	60239400 162	60248900 104
60171300 143	60182400 46	60197900 90	60222200 133	60239500 160	60249000 104
60171500 141	60182800 83	60198000 90	60222400 163	60239600 161	60249100 104
142	60182900 82	60198200 90	60223100 132	60239700 160	60249400 160
60171600 132	60183000 46	60199300 102	60223300 103	60240200 165	60249900 160
133	60183300 160	60199700 160	60223800 46	60240300 164	60250000 160
60171800 139	60183400 160	60199800 169	60224000 45	60240400 159	60250100 162
60171900 141	60183900 160	60200300 97	60224100 87	60240600 159	60250200 162
142	60184500 102	60201000 166	60224200 103	60240700 161	60250300 162
60172000 140	60184900 159	60201300 172	60224800 106	60241000 159	60250400 160
60172100 146	60185500 59	60201500 108	60224900 100	60241200 161	60250500 160
148	60185600 93	60202000 159	60225100 108	60241300 160	60250600 161
60172200 144	60186000 108	60202100 169	60227300 108	60241400 159	60250700 161
60172300 133	60186100 102	60202600 91	60227400 165	60241600 161	60250800 160
60172500 138	60186700 95	60203200 169	60227500 170	60241700 161	60250900 32
60172800 135	60186900 94	60203300 101	60227600 135	60241800 161	60251200 107
137 138 139	60187200 103	60205400 108	60227700 135	60241900 164	60251300 46
60172900 137	60187500 75	60206800 136	60228300 163	60242000 163	60251900 145
60173000 137	60187600 133	60207200 137	60228500 133	60242100 164	148 150 152
60173300 141	60187700 103	60207300 136	60228700 9	60242200 164	60252300 163
142	60187800 103	137 138	60229300 135	60242300 163	60252400 163
60173400 137	60187900 104	139 140	60229500 135	60242400 164	60252500 163
138	60188600 63	60207700 167	60229700 163	60242500 163	60252600 152
60173500 145	60188800 69	60207800 91	60229900 137	60242600 164	60252700 151
146	60188900 103	60207900 159	60230200 46	60242700 164	60253000 146
150 152	60189000 138	60208200 84	60230300 19	60242800 163	151
60173600 143	60189100 140	60208600 114	60231300 98	60242900 163	60253200 107
144	60189100 149	60209600 18	60232000 45	60243000 163	60253300 107
60173700 132	151	60209800 95	60232200 44	60243100 163	60256700 162
133	60189300 153	60210200 18	60232300 44	60243300 163	60257100 162
60174100 137	60189500 145	60210300 72	60233100 6	60243400 164	60257200 160
60174200 133	149 151	60210400 24	60233500 114	60243500 164	60257600 162
60174500 146	60189600 143	60210900 43	60233700 131	60243600 163	60257700 160
148 151	144	60211400 58	141	60243800 164	60257800 160
60174700 141	60189700 137	60211500 58	60234300 132	60244000 164	60257900 159
60174800 143	60190000 133	60211600 167	60234400 163	60244100 163	60258000 160
60174900 145	60190100 143	60212200 18	60234500 133	60244200 163	60258100 160
146 149 151	60190200 137	60212800 97	60234600 151	60244300 163	60259400 134
60175000 142	138 139	60213100 94	60234700 163	60244400 163	60259500 134
60175100 139	60190300 137	60213200 94	60234800 145	60244500 164	60259700 134
60175300 143	60190400 137	60213300 106	148 150 152	60244600 163	60265500 111
144					

PUB. NO.	PG.	PUB. NO.	PG.	PUB. NO.	PG.	PUB. NO.	PG.	PUB. NO.	PG.	PUB. NO.	PG.
60266000	44	60279800	153	60291400	43	60304500	88	60316600	51	60331400	86
60266200	79		154	60292600	49	60304600	88	60317100	168	60331500	100
60266300	103	60279900	146	60292700	49	60304700	89		169	60331600	95
60266400	106	151 153	154	60293300	2	60305100	151	60317200	14	60331700	92
60266500	106	60280000	153	60293400	31	60305200	151	60317300	10	60331800	90
60267100	104	60280200	136	60293500	2	60305400	146	60317500	94	60331900	91
60267200	103	60280400	153	60293600	3		151	60317600	10	60332000	90
60267300	106	60280600	133	60293700	2	60305600	149	60317800	87	60332200	93
60267400	107	60280700	137	60293800	3	60305700	132	60318100	94	60332300	93
60268000	104	60280800	135	60293900	2		150 152	60318200	89	60332400	91
60268100	165	60281000	135	60294000	3	60305800	163	60318300	94	60332500	93
60268900	93	60281100	135	60294100	3	60305900	151	60318500	39	60332600	101
60269100	104		137	60294200	3	60306200	149	60318600	49	60332700	93
60269200	45	60281200	153	60294300	3		151	60318700	32	60332800	97
60270200	59	60281300	135	60294500	47	60307000	149	60318900	14	60332900	93
60270600	85	60281400	134	60294700	2	60307100	149	60319300	11	60333000	101
60270700	74	135 136	137	60294800	2	60307200	148	60319800	20	60333100	97
60270900	9	60281500	137	60294900	2	60307300	148	60320700	102	60333200	100
60271300	80	60281600	153	60295600	167		150	60321100	43	60333300	92
60271400	80	60281700	145	60295900	14	60307400	148	60321400	125	60333400	101
60271500	80	146 147	153	60296200	39	60307500	147	60321500	125	60333500	101
60271600	80	60281900	136	60296500	10		150	60321600	12	60333600	107
60271700	80	60282000	136	60296900	172	60307600	2	60321800	47	60333700	172
60271800	80	60282100	135	60297200	164	60307700	2	60323100	18	60333800	172
60271900	80	60282200	136	60297300	167	60307800	2	60323400	94	60334100	108
60272100	158	60282400	134	60297600	2	60307900	2	60323500	18	60334200	108
60272200	59	60282500	153	60297700	2	60308000	2	60324000	126	60334300	109
60272700	9	60282800	133	60297900	2	60308100	2	60324600	74	60334400	108
60273200	80	60282900	146	60298100	51	60308200	2	60324700	46	60334500	108
60273300	160		151	60298400	51	60308300	2	60325100	71	60334600	108
60273400	159	60283000	145	60298600	51	60308400	2	60325600	80	60335400	48
60273500	160	146 147	153	60299500	103	60308500	2	60325700	80	60336400	3
60273600	160	60283100	153	60299700	113	60308600	2	60325800	80	60336500	89
60273800	162	60283200	46	60299900	37	60308700	2	60325900	80	60336600	89
60273900	162	60283400	8	60300000	87	60308800	2	60326100	80	60336700	89
60274100	160	60283500	8	60300100	87	60308900	2	60326200	80	60336800	89
60274300	160	60283600	45	60300200	88	60309000	2	60326300	80	60336900	89
60274400	162	60283900	81	60300300	88	60309100	2	60326400	80	60337000	89
60274900	6	60284000	82	60300400	88	60309200	80	60327000	152	60337100	89
60275000	48	60284100	2	60300500	88	60309300	80	60327200	150	60337200	89
60275100	166	60285200	85	60300600	88	60309400	80	60327300	148	60341500	91
60275200	166	60285300	2	60300700	88	60309500	80	60327600	146	60341600	111
60275300	167	60285400	3	60300800	88	60309600	103		151	60342100	155
60275500	166	60285500	3	60300900	88	60309700	49	60327800	145	60342200	154
60275600	166	60285600	3	60301000	88	60309800	102	147 149	153	60342300	155
60275900	166	60285700	3	60301100	88	60310500	2	60327900	145	60342400	145
60276100	166	60286000	3	60301200	88	60311200	8	147 149	153		148 150
60276400	166		10	60301300	88	60311500	160	60328400	145	60342500	146
60276500	166	60286100	3	60301400	88	60312400	6	147 149	154	150 152	153
60276600	166		10	60301500	88	60312700	161	60328800	146	60342600	154
60277000	166	60286200	32	60301600	88	60313100	161		148 150	60342700	153
60277100	166	60286400	164	60301700	88	60313400	162	60328900	158	60342800	140
60277200	166	60286800	167	60301800	88	60313500	162	60329000	145	60343000	153
60277300	166	60287000	78	60301900	88	60313600	161		151	60343300	155
60277400	166	60287100	73	60302000	88	60314100	159	60329100	151	60343400	145
60277500	166	60287200	45	60302200	88	60314200	159	60329400	145	147 149	154
60277600	166	60287300	2	60302500	88	60314300	161		147 149	60343500	134
60277700	166	60287400	2	60302600	88	60314400	162		151 154		135
60277800	166	60287600	98	60302700	88	60314800	161	60329500	70	60343600	155
60278100	6	60288100	113	60302800	88	60314900	160	60329700	49	60343700	155
60278300	48	60288700	163	60303000	88	60315100	161	60329900	94	60343800	155
60278400	2	60289000	2	60303100	88	60315200	161	60330300	82	60343900	146
60278500	98		107	60303200	88	60315500	13	60330400	83		148 150
60278800	46	60289100	43	60303700	88	60315600	10	60330500	83	60344000	154
60279100	63	60289200	18	60303800	88	60315700	10	60330600	84	60344100	154
60279200	142	60289500	6	60303900	88	60315900	20	60330700	84	60344200	145
60279400	137	60290000	44	60304000	88	60316000	20	60330900	83		150 154
60279500	153	60290900	116	60304100	88	60316100	20	60331000	84	60344300	154
60279600	153	60291000	100	60304200	88	60316200	3	60331100	84	60344400	145
	154	60291100	8	60304300	88	60316500	47	60331200	85		148
60279700	153	60291200	8	60304400	88			60331300	85	60344700	38
	154										

PUB. NQ. PG.	PUB. NQ. PG.	PUB. NQ. PG.	PUB. NQ. PG.	PUB. NQ. PG.	PUB. NQ. PG.
60344800 14	60358500 150	60370800 5	60384700 145	60401700 48	60413800 81
60345100 153	60370900 5	60370900 5	147 148 154	60401800 48	60413900 81
60346500 20	60358700 148	60371000 8	60384900 148	60402100 48	60414000 81
60347000 55	60358800 149	60371100 5	150	60402200 48	60414100 81
60347100 56	60359000 149	60371200 5	60385200 147	60402700 48	60414200 81
60347200 55	60359200 148	60371300 5	149 150	60402900 48	60414300 81
60347300 56	150	60371400 5	60385300 150	60403900 155	60414400 81
60347600 8	60359400 146	60371800 134	60385500 148	60404000 42	60414500 81
60347700 170	148 150	135 136	150	60404100 42	60414600 81
60348000 7	60359600 150	60372200 154	60385600 150	60404500 4	60414700 81
60348200 6	60359700 150	60372300 135	152	60404800 15	60415100 134
60348300 6	152	60372500 135	60385700 150	60404900 15	60415200 134
60348400 6	60359800 150	60372600 154	60385900 150	60405100 157	60415300 134
60348500 7	152	60372700 134	60387900 145	60405200 16	60415400 134
60348600 7	60360100 155	135	147 149	60405400 16	60415500 134
60348700 7	60360200 146	60372800 134	154 155	127	60415600 103
60348800 7	148 150 153	135	60389600 21	60405500 45	60415800 11
60348900 7	60360400 155	60372900 153	60390100 109	60406000 158	60415900 11
60349000 7	60360500 155	60373100 135	60390600 16	60406100 11	60416000 8
60349100 7	60360700 154	60373400 132	60391700 11	60406300 171	60416400 45
60349200 7	60360900 145	60373500 157	60391800 11	60407000 145	60417800 14
60349300 7	147 149	60373800 154	60391900 11	60407100 144	60417000 158
60349400 7	60361000 145	60373900 56	60392000 11	60407200 145	60417300 93
60349500 7	147 149 154	60374500 12	60392100 11	60407500 145	60417600 17
60349600 7	60361100 140	60374800 8	60392300 11	60407700 145	60417800 134
60349700 7	60361200 140	60374900 5	60392400 11	60407800 145	60417900 136
60349800 7	60361500 132	60375600 16	60392600 37	60407900 146	60418000 134
60350200 4	60361600 132	60375700 16	60392700 16	148	60418200 166
60350300 4	60361700 145	60376300 108	60393700 5	60408000 146	60418500 158
60350400 4	147 149 154	60377100 4	60393800 5	148	60418900 134
60350500 4	60361800 132	60377200 4	60394600 44	60408100 158	60419500 15
60350600 4	60361900 133	60377300 4	60394700 44	60408200 145	60419600 15
60350700 5	60362000 133	60378100 161	60394800 93	60408300 158	60419700 15
60350800 4	60362100 133	60378200 161	60396300 111	60408400 145	60419900 165
60350900 4	60362300 133	60378300 161	60396400 5	60408600 146	60420000 56
60351000 5	60362400 135	60378400 161	60396500 6	60408700 50	60420100 166
60351100 5	60363300 49	60378500 162	60396600 5	60409200 47	60420600 5
60351200 5	60363900 110	60378600 160	60396700 5	60409400 18	60420700 5
60351300 5	60364000 44	60378700 162	60396800 5	60410000 45	60420800 165
60351400 2	60364100 40	60378900 161	60396900 5	60410100 127	60420900 7
60352000 31	60364200 40	60379100 161	60397000 5	60410200 127	60421000 7
60352300 40	60364400 110	60379100 162	60397100 5	60410600 136	60421100 7
60352500 56	60364500 44	60379200 161	60397200 5	60410700 136	60421200 7
60353000 162	60364600 110	60379300 162	60397300 5	60410800 136	60421300 7
60353100 161	60364700 102	60379500 162	60397400 5	60410900 136	60421400 7
60353200 162	60364800 102	60380000 161	60397500 5	60411000 136	60421500 7
60353300 162	60364900 83	60380100 161	60397600 5	60411300 80	60421600 7
60353500 161	60365100 109	60380200 162	60397700 6	60411400 80	60421700 7
60353700 161	60365200 43	60380300 162	60397800 6	60411500 80	60421800 7
60354300 162	60365700 48	60380400 159	60397900 6	60411600 80	60421900 7
60354500 162	60366600 31	60380500 159	60398000 6	60411700 80	60422000 7
60354600 159	60366700 32	60380600 12	60398100 6	60411800 80	60422100 7
60354700 161	60366800 6	60380700 12	60398200 6	60411900 80	60422200 7
60354900 161	60367200 56	60380800 12	60398300 7	60412000 80	60422300 81
60355100 162	60367300 51	60380900 12	60398400 8	60412100 80	60422400 81
60355200 162	60367400 48	60381000 12	60398500 8	60412200 80	60422500 81
60355300 162	60368000 47	60381100 12	60398600 8	60412300 80	60422600 81
60355400 162	60368500 49	60381200 12	60398700 8	60412400 80	60422700 81
60355500 161	60368600 84	60381300 12	60398800 8	60412500 80	60422800 81
60355700 161	60368700 112	60381400 12	60398900 8	60412600 80	60422900 81
60355800 161	60369400 36	60382200 4	60399000 8	60412700 80	60423000 81
60355900 39	60369700 4	60382300 4	60399100 8	60412800 80	60423100 165
60356000 111	60369800 16	60382600 5	60399200 8	60412900 80	60423500 17
60356300 39	60369900 15	60382700 5	60399400 110	60413000 80	60425000 17
60357100 5	60370000 4	60382800 5	60399500 70	60413100 80	60425100 47
60357900 147	60370100 4	60383300 87	60399900 108	60413200 80	60425300 152
149 154	60370200 4	60384100 145	60400100 42	60413300 80	60425600 45
60358200 148	60370300 15	147 149	60400300 48	60413400 80	60425700 134
60358300 149	60370400 16	60384200 154	60401200 14	60413500 80	60425800 36
153	60370500 16	60384300 147	60401500 48	60413600 80	60426000 134
60358400 149	60370600 10	60384600 150	60401600 48	60413700 81	60426500 152
152					

PUB. NQ. PG.	PUB. NQ. PG.	PUB. NQ. PG.	PUB. NQ. PG.	PUB. NQ. PG.	PUB. NQ. PG.
60427200 165	60493500 149	70603600 26	70616100 70	70631000 25	82128900 63
60427300 165	152	70603700 26	70616200 70	70631100 25	82129000 63
60427400 165	62033500 127	70603900 24	70616300 27	70631300 28	82129700 63
60427500 8	62034200 127	70604000 53	70616400 28	70631400 28	82140400 31
60427600 42	62038000 127	70604100 124	70616700 44	70631500 28	82140800 35
60427800 51	62049500 127	70604200 121	70616800 158	73361200 41	82146800 95
60427900 157	62056300 53	70604300 25	70617000 27	73443000 157	82269600 165
60428500 45	62061700 127	70604400 25	70617100 27	73443100 157	83096200 123
60429200 158	62067900 118	70604500 25	70617400 31	73933300 157	83096300 123
60429900 3	62068000 127	70604700 25	70617800 30	74606800 39	83096400 123
60430000 110	62068100 118	70605000 25	70617900 30	74607500 41	83301000 29
60433400 3	62068200 127	70605300 25	70618000 30	74660300 41	83301100 28
60433600 3	62068300 118	70605400 71	70618400 29	74664300 41	83301200 28
60433700 3	62068400 127	70605500 25	70618500 29	74675500 41	83301400 124
60433800 3	62073300 127	70605800 27	70618600 29	74691800 41	83301500 124
60433900 3	62073800 118	70605900 53	70619100 158	74717600 41	83301600 124
60434000 3	62074000 127	70606100 26	70619200 27	74720400 41	83301700 124
60434100 3	62079500 116	70606500 25	70619300 27	74720500 41	83301800 45
60434200 4	62088900 127	70606600 123	70619400 27	74724500 41	83301900 45
60434300 4	62089100 127	70606700 24	70619500 26	75365100 123	83302000 45
60434600 3	62122800 127	70606800 72	70619600 26	75365200 124	83302300 30
60434700 3	62122900 127	70606900 24	70619700 26	75368900 124	83302400 30
60434800 3	62181600 165	70607100 24	70620400 27	75369000 125	83302500 30
60434900 3	62995900 35	70607200 26	70620500 27	75369100 124	83302600 30
60435000 3	62996000 35	70607300 26	70620600 27	75369200 124	83302700 30
60435100 3	63016700 106	70607500 24	70621300 123	75369600 124	83302800 30
60435400 147	63016900 105	70607700 121	70621400 48	75369800 124	83302900 53
60435500 147	63017100 105	70607900 28	70621500 44	75372900 124	83303100 29
60435600 147	63017200 105	70608100 124	70621600 44	75373000 124	83303200 29
60435700 147	63017300 105	70608200 124	70621700 44	75385700 124	83303300 29
60435800 147	63017400 105	70609200 27	70621800 44	75387400 123	83303700 53
60435900 147	63019200 105	70609300 27	70621900 44	75387500 123	83305700 29
60436100 147	63019600 105	70609400 26	70622000 123	75391300 124	83305800 29
60436200 147	63019700 105	70609500 27	70622100 24	75400200 65	83305900 29
60436300 147	63019800 105	70609600 33	70622200 28	75401000 123	83306000 45
60436600 145	63024900 106	70609700 26	70622300 28	75401400 124	83306100 50
60437000 166	63025400 106	70609800 27	70622400 28	75401500 124	83306300 50
60437100 166	63025500 105	70609900 27	70622500 28	75401700 124	83307900 53
60437200 167	63025600 105	70610100 27	70622600 28	75401800 124	83308000 53
60437300 111	63033500 106	70610300 28	70622700 28	75402000 124	83308400 25
60437400 81	63033600 106	70610500 28	70622800 28	75402100 124	83308500 25
60437500 81	63033700 106	70611000 27	70623500 28	76070000 145	83308600 25
60437600 81	63033800 106	70611100 27	70623600 28	148	83308700 29
60437700 81	65631800 86	70611200 27	70623700 28	76070300 146	83308800 29
60437800 81	65655800 87	70611300 27	70624500 30	148 176	83308900 29
60437900 81	65690800 87	70611500 70	70624600 30	76070400 174	83309300 29
60438000 81	65692300 36	70611600 70	70624700 30	76070600 175	83309400 29
60438100 81	65714900 58	70611700 71	70626300 29	76070700 173	83309500 29
60438200 81	65715000 58	70611800 71	70626500 28	76070800 178	83310800 25
60438300 81	65715100 58	70611900 71	70627400 124	76070900 172	83310900 25
60438400 81	65724900 91	70612000 71	70627900 29	76071000 176	83311400 28
60438500 43	65727400 87	70612200 121	70628000 29	76071200 174	83311600 29
60438600 81	65739900 59	70612400 124	70628100 29	76071400 173	83311700 29
60440800 109	69651800 9	70612500 28	70628200 28	76072700 173	83311900 45
60441000 157	70601100 71	70612600 27	70628400 28	76074000 176	83312000 45
60443100 157	70601300 24	70612800 53	70628500 30	76074300 175	83312100 45
60445300 147	70601400 25	70612900 27	70628600 30	76074400 175	83312300 53
60446100 81	70601500 25	70613000 27	70629100 158	76074600 175	83313100 29
60446200 81	70601700 33	70613100 27	70629200 30	76074700 175	83313200 29
60446300 81	70601900 26	70613200 28	70629300 30	76360001 162	83313300 29
60446400 81	70602100 33	70613300 28	70629400 30	76360002 161	83313400 30
60446500 81	70602200 25	70613700 123	70629500 29	76360003 162	83313500 30
60446600 81	70602300 25	70613800 44	70629600 29	76360010 159	83313600 30
60446700 81	70602400 26	70613900 44	70629700 29	76360011 161	83314000 29
60446800 81	70602500 26	70614000 44	70629800 124	76360012 161	83315400 50
60447700 81	70602900 124	70614100 44	70629900 124	76360015 160	83315600 42
60448200 145	70603000 26	70614200 44	70630000 30	76360023 161	83315700 42
60449200 147	70603200 26	70615100 28	70630100 30	76360031 161	83315800 42
60449200 145	70603300 26	70615700 166	70630200 30	76630900 120	83316100 42
148 150	70603400 26	70615800 24	70630500 28	82115700 74	83316200 42
60493300 145	70603500 26	70615900 27	70630900 25	82128800 63	83316300 42
147					

PUB. NO. PG.	PUB. NO. PG.	PUB. NO. PG.	PUB. NO. PG.	PUB. NO. PG.
83316400 42	84007900 177	86608900 173	86618400 173	91681100 155
83316600 42	84008000 177	86609000 176	86618500 173	91858500 118
84000000 175	84008100 177	86609100 176	86618900 174	91858600 67
84000100 175	84008200 177	86609200 176	86619600 174	91858700 67
84000400 175	84008300 178	86609300 176	86619700 174	91858800 67
84000500 172	84008400 178	86609400 176	86619900 174	91859000 67
84000600 173	84008500 178	86609500 176	86811400 25	91859100 118
84000700 175	84008600 178	86609600 176	87829800 33	91859200 118
84000800 173	84008700 178	86609700 176	87900200 72	91860100 67
84000900 172	84008800 178	86609800 176	87906700 33	91860200 49
84001000 173	84008900 178	86609900 176	87911800 33	91860300 52
84001100 176	84009000 178	86610000 176	87951000 33	91860400 67
84001200 173	84009100 178	86610100 176	87971600 33	96716700 133
84001300 173	84009200 178	86610200 176	87971700 33	97400200 154
84001400 173	84009300 178	86610300 176	87976600 155	97400300 152
84001500 173	84009400 178	86610400 176	87976700 155	97401500 157
84001700 173	84009600 175	86610500 176	87976800 155	97401600 157
84001800 173	84009800 174	86610600 176	87978800 74	97401700 158
84001900 173	84009900 175	86610700 176	88762000 133	97401800 170
84002000 173	84763300 140	86610800 176	88762100 133	97401900 9
84002100 173	84781600 76	86610900 176	88762200 133	97402000 171
84002400 175	84785000 158	86611000 176	88818500 133	97402100 9
84002500 174	84797500 133	86611100 177	88947900 133	97402200 171
84002600 173	84837900 75	86611200 177	88948500 133	97402300 9
84002700 173	84851100 76	86611300 177	88964000 133	97402400 9
84002800 174	84894200 74	86611400 177	88980100 42	171
84002900 173	84937300 75	86611500 177	88981000 76	97402500 9
84003000 173	84942200 43	86611600 177	88981100 41	97402600 170
84003100 173	84970400 79	86611700 177	88981500 150	97402700 8
84003200 173	86601600 175	86611800 177	88988400 149	97403500 123
84003700 173	86601700 175	86611900 177	88988500 149	97403600 158
84003800 175	86601800 172	86612000 177	88988600 149	97404600 123
84003900 145	86602000 174	86612100 174	88988700 149	97404700 152
84004000 178	86602300 174	86612300 173	88988800 149	97404800 152
84004100 178	86602800 172	86612500 173	88988900 149	97404900 152
84004200 178	86602900 173	86612600 174	88997600 133	97405000 152
84004300 178	86603000 173	86613500 173	89633300 86	97405100 152
84004400 178	86603100 173	86613600 174	89633400 86	97405200 152
84004500 178	86603200 173	86613700 174	89637200 85	97405500 152
84004600 178	86603300 173	86613800 174	89637300 46	
84004700 178	86603500 174	86614000 177	89637400 84	
84004800 178	86603700 173	86614100 174	89637700 43	
84004900 178	86604000 175	86614200 175	89638100 44	
84005000 178	86604100 175	86614300 174	89638200 85	
84005100 178	86604200 175	86614600 177	89638300 38	
84005200 178	86604300 175	86614900 177	89638400 85	
84005300 178	86604600 174	86615000 174	89638500 47	
84005400 178	86604700 174	86615100 175	89638800 171	
84005500 178	86604800 174	86615500 175	89673100 6	
84005600 178	86604900 174	86615600 177	86	
84005700 178	86605600 173	86615700 173	89723700 158	
84005800 178	86605700 177	86615800 174	89758600 17	
84005900 178	86605900 172	86615900 176	89769400 84	
84006000 178	86606100 174	86616100 173	89769500 44	
84006200 178	86606200 175	86616300 174	89796100 49	
84006300 178	86607000 175	86616600 174	91503500 169	
84006700 174	86607100 173	86616700 174	91556200 133	
84006800 177	86607200 173	86616800 172	91558900 35	
84006900 177	86607500 175	86616900 173	91566700 72	
84007000 177	86607700 172	86617100 175	91604200 74	
84007100 177	86607800 174	86617200 175	91604300 74	
84007200 177	86607900 174	86617300 175	91604400 74	
84007300 177	86608000 175	86617400 175	91604500 74	
84007400 177	86608100 175	86617500 175	91628700 52	
84007500 177	86608400 175	86617700 175	91649500 155	
84007600 177	86608500 175	86618000 172	91661300 155	
84007700 177	86608600 176	86618200 176	91662900 35	
84007800 177	86608700 176	86618300 175	91669100 33	

SECTION 1

This section contains Hardware Manuals for individual equipments arranged in equipment designator sequence. Product numbers are included in parenthesis after the equipment designator. Additional manuals may be found in Section 2 by looking up the Product Number.

TITLE	1	2	3	4
INDIVIDUAL EQUIPMENT MANUALS				
AA101-A/R COMPUTER (USE 1704-A/B, CAT. SEC. 2)				
AA102-A (7601-1) CENTRAL COMPUTER				
PARTS DATA CE MANUAL	60297700	B	22	12.35
CHANNEL TABS WIRE LIST CE MANUAL	60351900	C	22	06.25
THEORY OF OPERATION, DIAGRAMS, MAINT. AIDS	60297600	AC	22	46.50
CHASSIS 1 WIRE LIST CE MANUAL	60307600	D	22	05.10
CHASSIS 2 WIRE LIST CE MANUAL	60307700	D	22	04.60
CHASSIS 3 WIRE LIST CE MANUAL	60307800	E	22	06.70
CHASSIS 4 WIRE LIST CE MANUAL	60307900	E	22	04.50
CHASSIS 5 WIRE LIST CE MANUAL	60308000	C	22	04.15
CHASSIS 6 WIRE LIST CE MANUAL	60308100	J	22	05.70
CHASSIS 7 WIRE LIST CE MANUAL	60308200	N	22	05.50
CHASSIS 8 WIRE LIST CE MANUAL	60308300	J	22	09.70
CHASSIS 9 WIRE LIST CE MANUAL	60308400	C	22	05.05
CHASSIS 10 WIRE LIST CE MANUAL	60308500	E	22	05.05
CHASSIS 11 WIRE LIST CE MANUAL	60308600	C	22	05.00
CHASSIS 12 WIRE LIST CE MANUAL	60308700	C	22	04.80
CHASSIS 13 WIRE LIST CE MANUAL	60308800	G	22	07.00
CHASSIS 14 WIRE LIST CE MANUAL	60308900	G	22	06.15
LGM STACK WIRE LIST CE MANUAL	60309000	D	22	03.75
POWER AND REFERENCE WIRE LISTS CE MANUAL	60309100	E	22	04.30
MAINTENANCE MANUAL	60297900	E	22	15.00
REFRIGERATION INFO (USE GH214-A/B)				
(THE FOLLOWING MANUALS FOR THE ABOVE EQUIP. ARE AVAILABLE FROM D. VESTAL, ARHOPS (X3258) H2720C, H2720D SCANNER SYSTEMS SERVICE MANUAL PRICE AVAILABLE UPON REQUEST	60298500			
AA102-C () CENTRAL COMPUTER CE INFO (USE AC113-A)				
AA103-A CENTRAL COMPUTER (6614-E)				
CPU/FUNCTIONAL UNIT DIAGRAMS CE MANUAL	60287300	T	22	13.60
DEPIPH PROC UNIT DIAGRAMS CE MANUAL	60284100	U	22	05.50
CENTRAL MEMORY, CLOCK, ECS COUPLER AND POWER DIAGRAMS CE MANUAL	60287400	L	22	09.35
MAINTENANCE AID-CLOCK TIMING	60289000	B	22	01.80
CHASSIS 1 CHASSIS/CABLE TABS CE MANUAL	60285300	AD	22	18.40
CHASSIS 4 CHASSIS/CABLE TABS CE MANUAL	60310500	J	22	19.75
CHASSIS 5 CHASSIS/CABLE TABS CE MANUAL	60293300	S	22	19.20
CHASSIS 6 CHASSIS/CABLE TABS CE MANUAL	60294700	F	22	20.60
CHASSIS 7 CHASSIS/CABLE TABS CE MANUAL	60294800	C	22	20.00
CHASSIS 8 CHASSIS/CABLE TABS CE MANUAL	60294900	F	22	21.70
CHASSIS 9 CHASSIS/CABLE TABS CE MANUAL	60278400	P	22	16.50
CHASSIS 10 CHASSIS/CABLE TABS CE MANUAL	60293500	G	22	08.75
CHASSIS 11 CHASSIS/CABLE TABS CE MANUAL	60293700	F	22	08.30
CHASSIS 12 CHASSIS/CABLE TABS CE MANUAL	60293900	H	22	09.80

1-Publication number of literature.

2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.

4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
AA104-A CENTRAL COMPUTER (6613-E)				
CPU/FUNCTIONAL UNIT DIAGRAMS (USE AA103-A)				
PERIPH PROC UNIT DIAGRAMS (USE AA103-A)				
CENTRAL MEMORY, CLOCK, ECS COUPLER, AND				
POWER DIAGRAMS (USE AA103-A)				
MAINTENANCE AID-CLOCK TIMING (USE AA103-A)				
CHASSIS 1 CHASSIS/CABLE TABS (USE AA103-A)				
CHASSIS 4 CHASSIS/CABLE TABS (USE AA103-A)				
CHASSIS 5 CHASSIS/CABLE TABS (USE AA103-A)				
CHASSIS 6 CHASSIS/CABLE TABS (USE AA103-A)				
CHASSIS 7 CHASSIS/CABLE TABS (USE AA103-A)				
CHASSIS 8 CHASSIS/CABLE TABS (USE AA103-A)				
CHASSIS 9 CHASSIS/CABLE TABS (USE AA103-A)				
CHASSIS 10 CHASSIS/CABLE TABS	60293600	F	22	09.50
CHASSIS 11 AND 15 TABS CE MANUAL	60293800	F	22	09.00
CHASSIS 12 CHASSIS/CABLE TABS CE MANUAL	60294000	E	22	08.45
CHASSIS 13 CHASSIS/CABLE TABS CE MANUAL	60294100	D	22	10.75
CHASSIS 14 CHASSIS/CABLE TABS CE MANUAL	60294200	D	22	08.50
CHASSIS 16 CHASSIS/CABLE TABS CE MANUAL	60294300	E	22	05.00
AA105-A CENTRAL COMPUTER (6414-E)				
DIAGRAMS CE MANUAL	60316200	Z	22	24.50
PERIPH PROC UNIT DIAGRAMS (USE AA103-A)				
CHASSIS 1 CHASSIS/CABLE TABS (USE AA103-A)				
CHASSIS 2 CHASSIS/CABLE TABS CE MANUAL	60285400	M	22	20.00
CHASSIS 3 CHASSIS/CABLE TABS CE MANUAL	60285500	Z	22	12.65
CHASSIS 4 CHASSIS/CABLE TABS CE MANUAL	60285600	E	22	09.85
CHASSIS 5 CHASSIS/CABLE TABS CE MANUAL	60285700	G	22	09.85
CHASSIS 8 CHASSIS/CABLE TABS CE MANUAL	60336400	L	22	13.30
AA105-A, AT141-A CHASSIS 9 AND 11 CARD PLACE-	60286000	F	22	07.95
MENT. WIRE LIST, CE MANUAL				
CHASSIS 10 AND 12 CARD PLACEMENT, WIRE LISTS	60286100	G	22	10.65
CE MANUAL				
AA106-A (76-XXX) CENTRAL COMPUTER				
INSTALLATION/CHECKOUT, THEORY OF OP,	60433600	A	22	65.00
DIAGRAMS, MAINT AIDS, PARTS DATA CE MANUAL				
POWER DISTRIBUTION/WARNING SYSTEM CE MANUAL	60433400	A	22	17.50
REFRIGERATION SYSTEM INFO (USE GH223-A)				
MAINTENANCE CE MANUAL	60429900	A	22	25.90
CHASSIS 1 WIRE LIST CE MANUAL	60434600	A	22	
CHASSIS 2 WIRE LIST CE MANUAL	60434700	A	22	23.05
CHASSIS 3 WIRE LIST CE MANUAL	60434800	A	22	26.05
CHASSIS 4 WIRE LIST CE MANUAL	60434900	A	22	19.70
CHASSIS 5 WIRE LIST CE MANUAL	60435000	A	22	20.00
CHASSIS 6 WIRE LIST CE MANUAL	60435100	A	22	23.10
CHASSIS 7 WIRE LIST CE MANUAL	60433700	A	22	22.20
CHASSIS 8 WIRE LIST CE MANUAL	60433800	A	22	24.55
CHASSIS 9 WIRE LIST CE MANUAL	60433900	A	22	22.50
CHASSIS 10 WIRE LIST CE MANUAL	60434000	A	22	
CHASSIS 11 WIRE LIST CE MANUAL	60434100	A	22	

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
CHASSIS 13 WIRE LIST CE MANUAL	60434200	A	22	
CHASSIS 14 WIRE LIST CE MANUAL	60434300	A	22	
CABLE WIRE LIST CE MANUAL	60434400	A	22	
AA107-A (172-X, 173-X, 174-X) REFRIGERATION SYST GEN. DESC., OPERATION, THEORY OF OPERATION, INSTALLATION/CHECKOUT, MAINTENANCE, PARTS DATA HARDWARE MAINTENANCE MANUAL	19983800	01	22	03.45
AA108-A CENTRAL COMPUTER (6415-E) PERIPH PROC UNIT DIAGRAMS (USE AA103-A) CHASSIS 1 CHASSIS/CABLE TABS (USE AA103-A) CHASSIS 2,3,4,5 AND 8 CHASSIS/CABLE TABS CE MANUALS (USE AA105-A)				
AA108-B (PROD 6415-9) CENTRAL COMPUTER PERIPH PROC UNIT DIAGRAMS (USE AA103-A) CHASSIS 1 CHASSIS/CABLE TABS (USE AA103-A) CHASSIS 2,3,4,5 AND 8 CHASSIS/CABLE TABS CE MANUALS (USE AA105-A) CHASSIS 11 CHASSIS/CABLE TABS (USE AA103-A)				
AA108-C (PROD 6415-8) CENTRAL COMPUTER PERIPH PROC UNIT DIAGRAMS (USE AA103-A) CHASSIS 2,3,4,5 AND 8 CHASSIS/CABLE TABS CE MANUALS (USE AA105-A)				
AA108-D (PROD 6415-7) CENTRAL COMPUTER PERIPH PROC UNIT DIAGRAMS (USE AA103-A) CHASSIS 1 CHASSIS/CABLE TABS (USE AA103-A) CHASSIS 2,3,4,5 AND 8 CHASSIS/CABLE TABS CE MANUALS (USE AA105-A)				
AA115-A (72-XX, 73-XX) BASIC UNIFIED PROCESSOR COMMAND TIMING CE MANUAL	60404500	A	22	15.15
REFRIGERATION SYSTEMS CE MANUAL	60382300	C	22	03.30
POWER DISTRIBUTION/WARNING SYSTEM CE MANUAL	60382200	F	22	04.60
CHASSIS 1,3,11 DIAGRAMS CE MANUAL	60369700	R	22	16.55
CHASSIS 2,6 DIAGRAMS CE MANUAL	60370000	T	22	10.75
CHASSIS 3 DIAGRAMS CE MANUAL	60370200	M	22	01.20
CHASSIS 4 DIAGRAMS CE MANUAL	60370100	Z	22	16.00
CHASSIS 5 DIAGRAMS CE MANUAL	60377200	G	22	02.50
CHASSIS 7 DIAGRAMS CE MANUAL	60377100	F	22	05.90
CHASSIS 8 DIAGRAMS CE MANUAL	60377300	L	22	06.70
CHASSIS 1,3,11 WIRE LIST CE MANUAL	60350200	P	22	39.50
CHASSIS 2,6 WIRE LIST CE MANUAL	60350300	V	22	34.00
CHASSIS 3 WIRE LIST CE MANUAL	60350400	L	22	26.75
CHASSIS 4 WIRE LIST CE MANUAL	60350500	AC	22	27.75
CHASSIS 5 WIRE LIST CE MANUAL	60350600	D	22	37.35
CHASSIS 7 WIRE LIST CE MANUAL	60350800	K	22	17.60
CHASSIS 8 WIRE LIST CE MANUAL	60350900	R	22	30.45
AA116-A (1714) COMPUTER 65K				

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.

4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
GEN DESC, OPER AND PROG, INSTAL, CHKOUT THEO OF OP, DIAGRAMS, MAINT CE MANUAL	60357100	C	22	09.10
PARTS DATA CE MANUAL	60393700	A	22	06.85
CROSS TABS CE MANUAL	60393800	B	22	05.30
REFRIGERATION SYSTEMS CE INFO (USE AA115-A)				
COMMAND TIMING CE MANUAL	60374900	B	22	05.50
AA117-A (74-XX) PARALLEL PROCESSOR				
POWER DIST - WARNING SYSTEM INFO (USE AA115)				
CHASSIS 1 CE INFO USE AA115-A				
CHASSIS 4 WIRE LIST CE MANUAL	60371100	K	22	27.80
CHASSIS 5 WIRE LIST CE MANUAL	60371200	S	22	32.90
CHASSIS 6 WIRE LIST CE MANUAL	60350700	E	22	27.30
CHASSIS 7 WIRE LIST CE MANUAL	60371300	E	22	32.05
CHASSIS 8 WIRE LIST CE MANUAL	60371400	E	22	31.20
CHASSIS 9 WIRE LIST CE MANUAL	60351000	P	22	20.20
CHASSIS 10 WIRE LIST CE MANUAL	60351100	D	22	19.10
CHASSIS 11 WIRE LIST CE MANUAL	60351200	F	22	20.60
CHASSIS 12 WIRE LIST CE MANUAL	60351300	L	22	20.40
CHASSIS 13 AND 15, 14 AND 16 USE AT237-A				
CHASSIS 4,5,6,7,8 DIAGRAMS MANUAL	60370800	R	22	36.70
CHASSIS 9 DIAGRAMS MANUAL	60370900	P	22	09.95
CHASSIS 10 DIAGRAMS MANUAL	60382600	D	22	03.90
CHASSIS 11 DIAGRAMS MANUAL	60382700	C	22	04.15
CHASSIS 12 DIAGRAMS MANUAL	60382800	H	22	02.35
AA119-A/B/C/D (1714) COMPUTER 65K CE INFO (USE AA116-A)				
AA120-A (175-XX) CENTRAL COMPUTER				
REFRIGERATION SYSTEM INFO (USE GH223-A)				
MAINTENANCE, PARTS DATA HOWE MAINT MANUAL (INCLUDES INFO FOR ALL OPTIONS)	60420600	01	22	08.70
POWER DISTRIBUTION/WARNING SYSTEM MANUAL	60420700	A	22	09.90
CENTRAL PROCESSOR THEORY, DIAGRAMS MANUAL	60420300		22	
CENTRAL PROCESSOR (CH 5-7) WIRE LIST MANUAL	60420400		22	
CABLE WIRE LIST MANUAL	60420200		22	
INSTALLATION/CHECKOUT MANUAL	60420500		22	
AA121-A (7700) CENTRAL COMPUTER				
INSTALLATION/CHECKOUT, THEORY OF OP, DIAGRAMS, MAINT AIDS, PARTS DATA CE MANUAL	60396400	A	22	34.10
CHASSIS 1 WIRE LISTS CE MANUAL	60396600	A	22	08.05
CHASSIS 2 WIRE LISTS CE MANUAL	60396700	A	22	07.40
CHASSIS 3 WIRE LISTS CE MANUAL	60396800	A	22	08.85
CHASSIS 4 WIRE LISTS CE MANUAL	60396900	A	22	07.80
CHASSIS 5 WIRE LISTS CE MANUAL	60397000	A	22	07.80
CHASSIS 6 WIRE LISTS CE MANUAL	60397100	A	22	05.60
CHASSIS 8 WIRE LISTS CE MANUAL	60397300	A	22	10.40
CHASSIS 7 WIRE LISTS CE MANUAL	60397200	A	22	09.60
CHASSIS 9 WIRE LISTS CE MANUAL	60397400	A	22	11.20
CHASSIS 10 WIRE LISTS CE MANUAL	60397500	A	22	11.30
CHASSIS 11 WIRE LISTS CE MANUAL	60397600	A	22	10.10

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
CHASSIS 12 WIRE LISTS CE MANUAL	60397700	A	22	08.25
CHASSIS 13 WIRE LISTS CE MANUAL	60397800	A	22	10.50
CHASSIS 14 WIRE LISTS CE MANUAL	60397900	A	22	10.25
CHASSIS 15 WIRE LISTS CE MANUAL	60398000	A	22	04.95
LCM STACK CABLES WIRE LIST C.E. MANUAL	60398100	A	22	09.65
CHANNEL TABS WIRE LISTS CE MANUAL	60398200	B	22	14.15
POWER AND REFERENCE WIRE LISTS CE MANUAL	60396500	A	22	11.10
** SEE ALSO AB101-A, AD102-A MANUALS **				
AB101-A (7601-1, 7611-1/2) PERIPHERAL PROC. THEO OF OPERATION, INSTALLATION/CHECKOUT, DIAGRAMS, MAINTENANCE AIDS, PARTS DATA. WIRE LISTS CE MANUAL	60274900	P	22	09.40
AB102-A/B (7611-1/2) PERIPHERAL PROCESSOR CAB. INSTALLATION/CHECKOUT, THEORY OF OPERATION, DIAGRAMS, MAINTENANCE AIDS, PARTS DATA, WIRE LISTS CE MANUAL (USE AB101-A) REFRIGERATION INFO (USE GH214-A IF AB102-A OR GH214-B IF AB102-B) POWER DISTRIBUTION/WARNING SYSTEM (USE GH105-A/B/C IF AB102-A OR GH105-D IF AB102B				
AB103-A (90104) COMPUTE MODULE CE MANUAL	60278100	AW	22	07.75
PARTS LIST CE MANUAL	60366800	E	22	16.20
AB107/AB108 INPUT/OUTPUT SPECIFICATIONS	89673100	01	22	04.30
AC104-A (3504-1) CENTRAL COMPUTER GENERAL DESCRIPTION, DIAGRAMS, CABLE TABS CE MANUAL	60181000	AW	34	49.00
PROCESSOR (USE 3304-B, CATALOG SECTION 2) MAINT. AIDS; COMMAND TIMING CHARTS CE MANUAL	60238000	B	22	07.85
PARTS DATA CE MANUAL	60233100	AG	22	10.80
AC105-B (3174-1/2/3/4, 3304, 3304-2/3) CENTRAL PROCESSOR (USE 3304.B, CATALOG, SECTION 2)				
AC106-A (3514-1/2/3/4) CENTRAL PROCESSOR GENERAL DESC., DIAGRAMS, CABLE TABS CE MAN	60289500	AU	34	88.60
MAINT. AIDS, COMMAND TIMING CHARTS CE MANUAL	60312400	A	22	21.90
PARTS DATA (USE AC104-A)				
AC109-A (1774-1) SYSTEM CONTROLLER CE INFO (USE AB103-A)				
AC113-A () CENTRAL COMPUTER CHASSIS 1 WIRE LIST CE MANUAL	60348200	A	22	05.70
CHASSIS 2 WIRE LIST CE MANUAL	60348300	A	22	06.45
CHASSIS 3 WIRE LIST CE MANUAL	60348400	A	22	04.30

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.

4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
CHASSIS 4 WIRE LIST CE MANUAL	60348500	C	22	06.30
CHASSIS 5 WIRE LIST CE MANUAL	60348600	B	22	06.15
CHASSIS 6 WIRE LIST CE MANUAL	60348700	H	22	06.85
CHASSIS 7 WIRE LIST CE MANUAL	60348800	H	22	07.00
CHASSIS 8 WIRE LIST CE MANUAL	60348900	C	22	06.95
CHASSIS 9 WIRE LIST CE MANUAL	60349000	B	22	06.75
CHASSIS 10 WIRE LIST CE MANUAL	60349100	B	22	07.90
CHASSIS 12 WIRE LIST CE MANUAL	60349300	B	22	06.40
CHASSIS 11 WIRE LIST CE MANUAL	60349200	B	22	06.90
CHASSIS 13 WIRE LIST CE MANUAL	60349400	E	22	06.15
CHASSIS 14 WIRE LIST CE MANUAL	60349500	C	22	05.80
THEO OF OPERATION, DIAGRAMS, MAINT. CE MAN	60348000	AB	22	29.95
LCM STACK WIRE LIST CE MANUAL	60349600	D	22	08.00
POWER AND REFERENCE WIRE LIST CE MANUAL	60349700	E	22	08.35
CHANNEL TABS WIRE LIST CE MANUAL	60349800	E	22	09.55
REFRIGERATION MANUAL (USE GH214-B)				
POWER DISTRIBUTION/WARNING SYSTEM (USE GH105-D)				
AC113-B () CENTRAL COMPUTER				
CHASSIS 1 WIRE LIST CE MANUAL	60420900	A	22	18.60
CHASSIS 2 WIRE LIST CE MANUAL	60421000	A	22	20.70
CHASSIS 3 WIRE LIST CE MANUAL	60421100	A	22	19.20
CHASSIS 4 WIRE LIST CE MANUAL	60421200	A	22	14.60
CHASSIS 5 WIRE LIST CE MANUAL	60421300	A	22	15.20
CHASSIS 6 WIRE LIST CE MANUAL	60421400	C	22	20.10
CHASSIS 7 WIRE LIST CE MANUAL	60421500	C	22	21.05
CHASSIS 8 WIRE LIST CE MANUAL	60421600	D	22	17.85
CHASSIS 9 WIRE LIST CE MANUAL	60421700	B	22	18.60
CHASSIS 10 WIRE LIST CE MANUAL	60421800	C	22	15.80
CHASSIS 11 WIRE LIST CE MANUAL	60421900	A	22	17.84
CHASSIS 12 WIRE LIST CE MANUAL	60422000	C	22	16.55
CHASSIS 13 WIRE LIST CE MANUAL	60422100	B	22	18.00
CHASSIS 14 WIRE LIST CE MANUAL	60422200	A	22	14.75
INSTALLATION/CHECKOUT, THEORY OF OP, DIAGRAMS, MAINT AIDS, PARTS DATA INFO (USE AC113-A)				
MAINTENANCE INFO (USE AA102-A)				
LCM STACK WIRE LIST INFO (USE AC113-A)				
POWER AND REFERENCE WIRE LIST INFO (USE AC113-A)				
CHANNEL TABS WIRE LIST INFO (USE AC113-A)				
REFRIGERATION INFO (USE GH214-B)				
POWER DISTRIBUTION AND WARNING SYSTEM INFO (USE GH105-D)				
AC115-A/B/C (1774-1) BASIC PROCESSOR CE INFO (USE AB103-A)				
AD102-A (7700) ADJUNCT PROCESSOR INSTALLATION/CHECKOUT, THEORY OF OPERATION, DIAGRAMS (USE AA121-A)				
CHASSIS 6 WIRE LISTS CE MANUAL	60398300	A	22	06.45

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover binder that may be used for manuals.
4-Publication division responsible for contents of literature.

TITLE	1	2	3	4
CHASSIS 7 WIRE LISTS CE MANUAL	60398400	A	22	07.20
CHASSIS 8 WIRE LISTS CE MANUAL	60398500	A	22	09.65
CHASSIS 9 WIRE LISTS CE MANUAL	60398600	A	22	10.30
CHASSIS 10 WIRE LISTS CE MANUAL	60398700	A	22	11.50
CHASSIS 11 WIRE LISTS CE MANUAL	60398800	A	22	08.80
CHASSIS 12 WIRE LISTS CE MANUAL	60398900	A	22	09.70
CHASSIS 13 WIRE LISTS CE MANUAL	60399000	A	22	08.35
CHASSIS 14 WIRE LISTS CE MANUAL	60399100	A	22	09.60
CHANNEL TABS WIRE LISTS CE MANUAL	60399200	B	22	09.80
POWER AND REFERENCE WIRE LISTS CE MANUAL	60427500	A	22	05.95
AE116-B (10174-X) SECOND CENTRAL PROCESSOR CONVERTS A 6600-A/B/C WITH SPIGOTS TO A 6700-A/B/C. DIAGRAMS, WIRE LIST CE MANUAL (CH.12) (FOR CONSOLE DISPLAY CONTROLLER DOCUMENTS USE FR114-A)	60374800	D	22	26.90
AE116-C (10174-X) SECOND CENTRAL PROCESSOR CONVERTS A 6600-D/E WITH SPIGOTS TO A 6700-D/F. DIAGRAMS, WIRE LIST INFO (CH.2) (USE AE116-B)				
AE116-D (74-2X) SECOND CENTRAL PROCESSOR CHASSIS 2 WIRE LIST CE MANUAL	60371000	J	22	26.00
CHASSIS 2 DIAGRAMS CE MANUAL	60416000	E	22	11.10
AF101-A (3304-2) BUSINESS DATA PROCESSOR (USE 3312-A, CATALOG SEC. 2)				
AF101-B (3174-3/4, 3304-3, ST.OP.10256-1/2/ 3/4) BUSINESS DATA PROCESSOR MAINTENANCE - PMI/PMP (USE 3304-A) PARTS LIST (USE 3304-A) WIRE LIST (TERM LIST, HAND TABS) CE MANUAL MAINTENANCE COMMAND TIMING CHARTS CE MANUAL EQUATION SUMMARY, CARD PLACEMENT CE MANUAL DIAGRAMS CE MANUAL	60291200	L	22	10.10
	60283500	J	22	17.30
	60291100	L	22	11.90
	60283400	M	22	06.65
AF102-A (3514-2/4) BUSINESS DATA PROCESSOR MAINT. AIDS, COMMAND TIMING CHARTS (USE AC106-A) GENERAL DESCRIPTION, DIAGRAMS, CABLE TABS CE MANUAL	60311200	P	22	08.60
AF104-A/AT146-A OR AF105-A/AT165-A 3200 ENHANCED BLOCK CONTROL MODIFICATION (OPTION 10287) AND 3200 BUSINESS DATA PROCESSOR INTERFACE (OPTION 10256) CE MANUAL	97402700	A	22	33.90
AF104-A (ST.OP.10256-1) 3200 BUSINESS DATA PROCESSOR INTERFACE CE MANUAL	60347600	C	22	19.30

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.

4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
AF104-B (ST.OP.10256-2) 3100 BDP INTERFACE OPT CE MANUAL	97401900	A	22	09.70
AF105-A (ST.OP.10287-1) 3200 ENHANCED BLOCK CONTROL MODIFICATION CE MANUAL	97402500	A	22	24.70
REF MANUAL	97402400	A	22	03.60
AF106-A (ST.OP.10287-2) 3100 ENHANCED BLOCK CONTROL MODIFICATION CE MANUAL	97402100	A	22	14.60
AF107-A (ST.OP.10287-4) 3100 ENHANCED BLOCK CONTROL AND BDP INTERFACE CE MANUAL	97402300	B	22	20.95
AN/UYS-25 (V) DATA PROCESSING SET - REF MAN	69651800		22	08.90
AT105-A (ST. OPT. 10121) ACCESS CHANNEL CE INFO (USE BB313-A)				
AT106-A (ST. OPT.10123) MEMORY PROTECT - 3100 REF/CE MANUAL	60228700	D	22	04.15
AT115-A (ST. OPT.10123) MEMORY PROTECT - 3200 (USE AT106-A)				
AT124-A (3514-3/4) RELOCATION PAGE FILE DIAGRAMS (USE AC106-A) COMMAND TIMING CHARTS (USE AC104-A)				
AT129-A (10169, 10173-6/7/8/9/10) CENTRAL MEMORY ACCESS PRIORITY OPTION FOR 64/6500-ABC REF/CE MANUAL	60272700	G	22	08.15
AT130-A (10169, 10173-3/4/5/6/7/8/10, 10174-1 CENTRAL MEMORY ACCESS CE INFO (USE AA103-A PPU DIAGRAMS AND CH.1 WIRE LISTS CE MANUALS)				
AT131-A (10169, 10173-3/4/5, 10174-1/2) CENTRAL MEMORY ACCESS PRIORITY REF/CE MANUAL	60270900	H	22	12.30
AT137-A (10173-6/7/8/9) CENTRAL MEMORY ACCESS (AT130-A MUST BE INSTALLED) FOR ADDITIONAL PPU S - APPLICABLE TO A 6413-D CENTRAL COMPUTER (USE AA105-A) REF INFO (USE 6000 COMPUTER SYSTEMS REF MAN)				
AT139-A (10173-7/9/10, 10178-2) CENTRAL MEMORY ACCESS FOR ADDITIONAL PPU S - APPLICABLE TO A				

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
6414-D CENTRAL COMPUTER (USE AA105-A) (AT130-A MUST BE INSTALLED)				
AT140-A (6413-E, ST.OP.10119) 65K MEMORY INCREMENT FOR AA105-A				
CHASSIS 9 AND 11 WIRE LIST CE MANUAL	60286000	B	22	07.95
CHASSIS 10 AND 12 WIRE LTST CE MANUAL FOR AN AA105-A/AT141-A COMPUTER SYSTEM	60286100	C	22	10.65
AT140-B (ST.OP. 10178-1) 32K MEMORY INCREMENT REFERENCE/CE MANUAL	60315600	D	22	09.50
AT140-E (ST.OP. 10119) MEMORY INCREMENT TO 131K FOR 6413-A/B/C AND 6513-A/B/C COMPUTERS (USE 6414/6514-A)				
AT140-F (PROD ST OPT 10178-1) 32K MEMORY INCR. FOR AN 6414/6514-A/B/C CENTRAL COMPUTER REFERENCE/CE MANUAL	60317300	C	22	10.35
AT140-G (10119) 65K MEMORY INCREMENT TO 131K FOR 6400/6500-D, USE 6413-D/6513-D. NOTE IF INSTALLED ON 6414-A/B/C OR 6500-A/B/C COMPUTERS ORDER ONLY THE FOLLOWING MANUALS.				
6413-D CHASSIS 9/11 CHASSIS TABS (60248800)				
6413-A/B/C CABLE TABS (60188900)				
6413-D CHASSIS 10/12 CHASSIS TABS (60248900)				
6413-D DIAGRAMS (USE ONLY CHASSIS 9 THROUGH 12 DIAGRAMS) (60246800)				
AT140-H (PROD ST OPT 10178-1) 32K MEMORY INCR FOR AN 6414/6514-D CENTRAL COMPUTER REF/CE MANUAL	60296500	B,C	22	05.05
AT141-A (6500-E) SECOND CPU FOR AA105-A USE MANUALS LISTED UNDER AA105-A UNLESS DT143-A OR AT194-A ARE INSTALLED IN WHICH CASE USE MANUALS LISTED UNDER AT194-A.				
AT142-F (PROD ST OPT 10177-1) 16K MEMORY INCR FOR A 6415-A/B/C CENTRAL COMPUTER REF/CE MANUAL	60317600	C	22	03.05
AT142-H (PROD ST OPT 10177-1) 16K MEMORY INCR FOR A 6415-D CENTRAL COMPUTER REFERENCE/CE MANUAL	60315700	B	22	02.90
AT145-A/B/C (10173) ADDITIONAL PPU CHASSIS FOR 6000 COMPUTERS (INCR TO 20 PPU S) CE MANUAL (ALSO REQUIRES AT177-A/B/C CE MANUAL)	60370600	K	22	22.50

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
AT146-A (10287-3) MEMORY INCREMENT - 3200 CE MANUAL (USE AF104-A)				
AT147-A (ST.OP. 10180) MEMORY INCREMENT 6600-A/B/C MACHINES 98K TO 131K (USE 6613-A/B/C)				
AT147-B (ST.OPT. 10180) MEMORY INCREMENT 6600-D MACHINES 98K TO 131K (USE 6613-D)				
AT147-C (ST.OPT. 10180) MEMORY INCREMENT 6600-E MACHINES 98K TO 131K (USE AA103-A)				
AT149-A (ST.OP.10173) ADDITIONAL MEMORY ACCESS OPTION FOR 6414-A/B/C, 6514-A/B/C DIAGRAMS, W/L, C/P CE MANUAL	60406100	B	22	01.80
CABLE TABS (AT149-A ONLY) CE MANUAL	60415800	C	22	18.15
ALSO REQUIRES THE FOLLOWING AA105-A MANUALS DIAGRAMS CE MANUAL 60316200 CH 2 WIRE LISTS CE MANUAL 60285400 CH 3 WIRE LISTS CE MANUAL 60285500				
AT151-A (10256-4) 3100 BDP OPTION CE INFO (USE AF107-A)				
AT152-A (ST.OP.10173) ADDITIONAL MEMORY ACCESS OPTION FOR 6413-A/B/C, 6513-A/B/C CABLE TABS CE MANUAL	60415900	C	22	30.85
DIAGRAMS, WIRE LIST INFO (USE AT149-A)				
AT153-A (10173-4/5, 10174-2) ADDITIONAL CENTRAL MEMORY ACCESS FOR 6614-A/B/C COMPUTER SYSTEMS.				
GEN.DESC. AND DIAGRAMS	60392300	E	22	03.40
CHASSIS 2 WIRE LISTS CE MANUAL	60391700	A	22	31.65
CHASSIS 3 WIRE LISTS (USE AA103-A, CH 9)				
CHASSIS 3 ECS COUPLER DIAGRAMS (USE AA103-A ECS COUPLER DIAGRAMS)				
CHASSIS 4 WIRE LISTS CE MANUAL	60391800	B	22	19.00
CHASSIS 5 WIRE LISTS CE MANUAL	60391900	D	22	31.30
CHASSIS 9 WIRE LISTS CE MANUAL	60392000	B	22	17.40
CHASSIS 10 WIRE LISTS CE MANUAL	60392100	A	22	21.25
CABLE TABS CE MANUAL	60392400	B	22	19.30
AT154-A (10173-X) ADDITIONAL MEMORY ACCESS FOR 6613-A/B/C				
DIAGRAMS (EXCEPT CH.1,3,12) CE MANUAL	60319300	P	22	04.60
CHASSTS 1 DIAGRAMS, WIRE LIST CE MANUAL (USE ONLY IF AT145-A/AT176-A IS NOT INSTALLED)	60423300		22	
DIAGRAMS, WIRE LIST CH.3 (USE AA103-A CH.9)				

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE				1	2	3	4
DIAGRAMS, WIRE LIST CH.12 (USE AE116-B)				60380600	B	22	26.50
CHASSIS 2 WIRE LIST CE MANUAL				60380700	B	22	16.25
CHASSIS 4 WIRE LIST CE MANUAL				60380800	G	22	25.90
CHASSIS 5 WIRE LIST CE MANUAL				60380900	B	22	19.70
CHASSIS 9 WIRE LIST CE MANUAL				60381000	C	22	12.10
CHASSIS 10 WIRE LIST CE MANUAL				60381100	C	22	11.30
CHASSIS 13 WIRE LIST CE MANUAL				60381200	D	22	11.25
CHASSIS 14 WIRE LIST CE MANUAL				60381300	C	22	10.35
CHASSIS 15 WIRE LIST CE MANUAL				60381400	C	22	11.80
CABLE TABS CE MANUAL				60321600	G	22	20.25
AT155-A (10173-4/5, 10174-2) ADDITIONAL MEMORY ACCESS FOR 6614-D							
CHASSIS 9 (ONLY) DIAGRAMS, W/L, C/P CE MAN.				60374500	B	22	15.10
CHASSIS NO.	USE MANUALS FOR	DIAGRAMS PUB. NO.	CHASSIS TABS PUB.NO.				
**** 1	AA103-A	*60284100	**60285300				
4	6614-D	60224800	60247000				
5	AA103-A	***60287300	60293300				
6	6614-D	60224800	60247200				
7	6614-D	60224800	60247300				
8	6614-D	60224800	60247400				
10	AA103-A	60287400	60293500				
11	AA103-A	60287400	60293700				
12	AA103-A	60287400	60293900				
* FOR 20 PPU S USE THIS MANUAL PLUS DIFFERENCE PAGES FROM AT176-A/AT145 MANUAL, PUB.NO. 60370600							
** FOR 20 PPU S COMPLETE CHASSIS 1 AND 3 TABS ARE INCLUDED IN AT176-A/AT145 MANUAL, PUB.NO. 60370600							
*** USE ONLY CHASSIS 5 PORTION OF THIS MANUAL.							
**** THIS DOCUMENTATION SHOULD BE USED INSTEAD OF 6600-D CHASSIS 1 PLUS AT130-A OPTION MANUAL WHICH IS OBSOLETE							
AT156-A (10173-3/4, 10174-1) ADDITIONAL MEMORY ACCESS FOR 6613-D							
CHASSIS 9 (USE AT155-A)							
CHASSIS NO.	USE MANUALS FOR	DIAGRAMS PUB. NO.	CHASSIS TABS PUB.NO.				
**** 1	AA104-A	*60284100	**60285300				
4	6613-D	60224800	60247000				
5	AA104-A	***60287300	60293300				

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover binder that may be used for manuals.
4-Publication division responsible for contents of literature.

TITLE				1	2	3	4
6	6613-D	60224800	60247200				
7	6613-D	60224800	60247300				
8	6613-D	60224800	60247400				
10	AA104-A	60287400	60293600				
11/15	AA104-A	60287400	60293800				
12	AA104-A	60287400	60294000				
13	AA104-A	60287400	60294100				
14	AA104-A	60287400	60294200				
16	AA104-A	60287400	60294300				
<p>* FOR 20 PPU S USE THIS MANUAL PLUS DIFFERENCE PAGES FROM AT176-A/AT145 MANUAL, PUB.NO. 60370600.</p> <p>** FOR 20 PPU S COMPLETE CHASSIS 1 AND 3 TABS ARE INCLUDED IN AT176-A/AT145 MANUAL, PUB.NO. 60370600.</p> <p>*** USE ONLY CHASSIS 5 PORTION OF THIS MANUAL.</p> <p>**** THIS DOCUMENTATION SHOULD BE USED INSTEAD OF 6600-D CHASSIS 1 PLUS AT130-A OPTION MANUAL.</p> <p>AT160-A (ST.OP.10173) REQUIRED WHEN A 6500-A/B/C HAS AN ADDITIONAL MEMORY ACCESS ADDED (AT149-A OR AT152-A) CE INFO (USE AT141-A)</p> <p>AT162-A ADDITIONAL PPU (USE AA108-A OR 6400-D MANUALS)</p> <p>AT163-A ADDITIONAL PPU (USE AA108-A OR 6400-D MANUALS)</p> <p>AT164-A ADDITIONAL PPU (USE AA108-A OR 6400-D MANUALS)</p> <p>AT165-A (10256-3) 3200 BDP OPTION CE INFO (USE AT146-A)</p> <p>AT168-A (ST.OP. 10105) MEMORY INCREMENT TO 131K FOR 6614-E/6714 COMPUTER SYSTEMS (USE AA103-A)</p> <p>AT168-B (ST.OP.10180-1) 32K MEMORY INCR TO 98K FOR AA103-A COMPUTER REFERENCE/CE MANUAL ALSO ORDER MANUALS LISTED FOR CHASSIS 10, 11,12,13,14,15,16 FOR AA104-A</p> <p>AT168-C (ST.OP. 10105) MEMORY INCREMENT TO 131K FOR 6614-A/B/C WITH AT153-A (USE AT154-A)</p>							
				60315500	A	22	07.15

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover binder that may be used for manuals.
4-Publication division responsible for contents of literature.

TITLE	1	2	3	4
AT168-F (ST.OP. 10105-A) MEMORY INCREMENT TO 131K FOR 6614-A COMPUTER SYSTEM (USE 6613-A/B/C)				
AT168-F (ST.OP. 10105-B) MEMORY INCREMENT TO 131K FOR 6614-B/C COMPUTER SYSTEM (USE 6613-A/B/C)				
AT168-G (ST.OP. 10180-1) 32K MEMORY INCREMENT FOR 6614-A/B/C REF/CE MANUAL	60317200	A	22	08.15
AT168-J (ST.OP. 10180-1) 32K MEMORY INCR TO 98K FOR 6614-D CENTRAL COMPUTER REFERENCE/CE MANUAL ALSO ORDER MANUALS LISTED FOR CHASSIS 9,	60295900	A	22	5.30
AT174-A () PERIPHERAL PROCESSOR CE INFO (USE AA106-A)				
AT176-A (10173) ADDITIONAL PPU CHASSIS FOR 6000 COMPUTERS (INCREMENT TO 20 PPU S) CE INFO (USE AT145-A/B/C)				
AT177-A/B/C (10173) EXTERNAL DATA CHANNEL CE MANUAL	60318900	F	22	16.05
AT194-A (6500-D OR 6500-E WITH ECS) ECS CAPABILITY FOR AA105-A WITH AT141-A OR ECS CAPABILITY FOR 6400-D WITH AT198-A				
FOR 6500-D CHASSIS 3 DIAGRAMS, WIRE LIST CE MANUAL CHASSIS 2 AND 6 DIAGRAMS, WIRE LIST INFO (IDENTICAL TO 6500-C WITH ECS - SEE AT195-A) CHASSIS 8 DIAGRAMS, WIRE LIST INFO (IDENTICAL TO 6500-E WITH ECS - SEE NEXT ENTRY BELOW)	60416700	G	22	04.30
FOR 6500-E CHASSIS 2/6,3,8 DIAGRAMS, WIRE LIST CE MAN	60401200	G	22	10.20
AT195-A (6500-A/B/C WITH ECS) ECS CAPABILITY FOR 6500-A/B/C CHASSIS 2,3,8 DIAGRAMS, WIRE LIST CE MANUAL	60344800	F	22	17.10
AT196-A (6500-A/B/C) SECOND CPU FOR 641X-A/B/C USE 6400-A/B/C UNLESS DT117-A OR AT195-A ARE INSTALLED IN WHICH CASE USE MANUALS LISTED UNDER AT195-A.				
AT197-A (6500-A) SECOND CPU FOR 6404-A MAKES A 6514-A (SEE AT195-A)				

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover binder that may be used for manuals.
4-Publication division responsible for contents of literature.

TITLE	1	2	3	4
AT198-A (6500-D) SECOND CPU FOR 641X-D USE 6400-D UNLESS AT194-A IS INSTALLED IN WHICH CASE USE MANUALS LISTED UNDER AT194-A.				
AT217-A (6200-E, 6014, 6015) CPU CONVERSION FOR AA108-A/B/C/D OR AA105-A DIAGRAMS, WIRE LISTS CE MANUAL (CHASSIS 8)	60404900	A	22	31.40
DIAGRAMS, WIRE LISTS CE MANUAL (CHASSIS 2)	60404800	B	22	24.65
AT217-A () CPU CONVERSION FOR 6415-D OR 6414-D DIAGRAMS CE MANUAL	60419500	D	22	15.35
CHASSIS 2 WIRE LISTS CE MANUAL	60419600	C	22	33.15
CHASSIS 8 WIRE LISTS CE MANUAL	60419700	B	22	18.20
AT219-A (CYBER 74-XX) ECS COUPLER ENABLE CE INFO (INCLUDED IN AA117-A, CHASSIS 9 MANUALS)				
AT224-A (10267-1) 64 BIT INCREMENT TO 128 BITS FOR INTERLOCK REGISTER CE INFO (USE AA115-A, CHASSIS 3)				
AT226-A (73-XX, 10270-2, 10272-1/2) SPEED INCREMENT FOR AA115-A BASIC UNIFIED PROCESSOR AND AT227-A SECOND BASIC UNIFIED PROCESSOR CHASSIS 2 AND 6 WIRE LISTS CE MANUAL	60370300	T	22	43.60
CHASSIS 2 AND 6 DIAGRAMS CE MANUAL (DIFFERENCE PAGES ONLY, ALSO ORDER AA115-A CHASSIS 2 AND 6 DIAGRAMS) COMMAND TIMING INFO (USE AA115-A)	60369900	N	22	04.20
AT227-A (72-XX, 73-XX) SECOND BASIC UNIFIED PROCESSOR (CHASSIS 6) CE INFO (USE AT226-A)				
AT231-A (72-XX, 73-XX) 16K INCREMENT TO 65K CE INFO (USE AA115-A)				
AT232-A (72-XX, 73-XX) 16K INCREMENT TO 49K CE INFO (USE AA115-A)				
AT233-A (10268-3, 10269-3) 3 PPU INCR TO 20 PPU S FOR AA115-A OR AA117-A CE INFO (USE AA115-A, CHASSIS 1)				
AT234-A () 4 PPU INCREMENT TO 14 PPU S FOR AA117-A CE INFO (USE AA115-A, CHASSIS 1)				
AT235-A (10268-2, 10269-2) 3 PPU INCR TO 17 PPU S FOR AA115-A OR AA117-A				

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
CE INFO (USE AA115-A, CHASSIS 1)				
AT236-A (72-XX, 73-XX, 74-XX, 10265-4, 10264-4 32K INCR TO 131K FOR AA115-A OR AA117-A CE INFO (USE AT237-A)				
AT237-A (72-XX, 73-XX, 74-XX, 10264-3, 10265-3) 32K INCREMENT TO 98K FOR AA115-A OR AA117-A.				
CHASSIS 13 AND 15 WIRE LISTS CE MANUAL	60370400	J	22	24.20
CHASSIS 13 AND 15 DIAGRAMS CE MANUAL	60369800	E	22	06.10
CHASSIS 14 AND 16 WIRE LISTS CE MANUAL	60370500	G	22	24.75
CHASSIS 14 AND 16 DIAGRAMS CE MANUAL	60390600	F	22	05.95
AT239-A (CYBER 74-XX) 32K TO 49K INCREMENT CE INFO (INCLUDED IN AA117-A, CHASSIS 9, 10, 11 AND 12 MANUALS)				
AT247-A (7030) ECS INTERFACE LOGIC CE INFO (USE AA115-A, CHASSIS 8)				
AT248-A (10276-1) AUTO-RESTART OPTION CE INFO (USE AA116-A)				
AT249-A (7030-XX) ECS COUPLER ENABLE DIAGRAMS INFO (USE AA117-A)				
AT250-A () 4 PPU INCREMENT TO 14 PPU S FOR AA115-A CE INFO (USE AA115-A, CHASSIS 1)				
AT251-A (CYBER 72/73/74) EXTERNAL DATA CHANNEL CE MANUAL	60392700	F	22	25.40
AT259-A () REGISTER FILE PARITY - ABNORMAL INTERRUPT EXPANSION REF/CE MANUAL	60375600	G	22	07.75
AT260-A () PAGE FILE PARITY REFERENCE/CE MANUAL	60375700	D	22	03.95
AT265-A/B () ADDITIONAL PPU CHASSIS FOR 6000 COMPUTERS (INCREMENT TO 20 PPU S) CE INFO (USE AT145-A/B/C)				
AT267-A (CYBER 72/73) COMPARE/MOVE LOGIC CE INFO (USE AA115-A, CHASSIS 4)				
AT269-A (7611-11) SERVICE STATION CLOCK CE MANUAL	60405200	A	22	03.30
AT270-A (7611-11) SERVICE STATION ENABLE CE INFO (USE AT269-A)				

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
AT271-A (7700) LCM FLAG REGISTER INCREMENT CE INFO (USE AA121-A)				
AT281-A (SP.OP. 65102) AC105/3304 BUS PARITY CE MANUAL	60425000	A	22	19.74
AT282-A (SP.OP. 65102) BDP BUS PARITY CE INFO (USE AT281-A)				
AT283-A (SP.OP. 65102) PAGE FILE BUS PARITY CE INFO (USE AT281-A)				
AT284-A (SP.OP. 65102) 3316 MULTIPLEXER BUS PARITY CE INFO (USE AT281-A)				
AT285-A (SP.OP. 65102) BB316/BB105-A/3302 BUS PARITY CE INFO (USE AT281-A)				
AT286-A (SP.OP. 65102) BB351/BB105-B BUS PARITY CE INFO (USE AT281-A)				
AT289-A (ST.OP.10309-1/2) GO MODE FROM INTERRUPT FOR THE AC104-A AND AC106-A/B C.E. MANUAL	60417600	A	34	05.10
AT292-A (ST.OP. 10308-2) GO MODE FROM INTERRUPT CE MANUAL	60423500	A	22	03.10
AT293-A (ST.OP. 10308-2) SDL EXECUTION IN PROGRAM STATE CE INFO (USE AT292-A)				
AT294-A (ST.OP.10309-1) EXECUTE SDL IN PROGRAM STATE FOR AC104-A CE INFO (USE AT289-A)				
AT295-A (ST.OP.10309-2) EXECUTE SDL IN PROGRAM STATE FOR AC106-A/B CE INFO (USE AT289-A)				
AT303-A () ADJUNCT PPU REFRIGERATION INFO (USE GH223-A)				
AT310-A TTL AQ-DSA CE MANUAL	89758600	01	22	03.40
AT311-A (76-XXX, ST.OP.10348-1) I/O MUX CHANNEL CE INFO (USE AA106-A)				
AT312-A (ST.OP.10348-2) I/O MUX CHANNEL				

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
CE INFO (USE AA106-A)				
AU102-A (7700) MEMORY SHARING UNIT CE INFO (USE AA121-A AND AD102-A)				
BB104-A () STORAGE MODULE CE MANUAL	60323500	C	22	02.00
BB105-A (3172) MAGNETIC CORE STORAGE CE INFO (USE 3304-B, CATALOG SECTION 2) CARD PLACEMENT, EQ SUM, WIRE LISTS CE MANUAL	60323100	A	22	12.00
BB106-A () STORAGE MODULE CE MANUAL OPERATION/PROGRAMMING INFO (USE 3100 COMPUTER SYSTEM REF MANUAL OR 3150 COMPUTER SYSTEM REF MANUAL OR 3200 COMPUTER SYSTEM REF MANUAL INSTALLATION/CHECKOUT INFO (USE 3000 SERIES SITE PREPARATION MANUAL)	60409400	A	22	22.00
BB107-A () STORAGE MODULE CE AND REF INFO (SEE BB106-A)				
BB201-A (7700) SCM INCREMENT CE INFO (USE AA121-A AND AD102-A)				
BB310-A (1708) STORAGE INCREMENT				
BB311-A (1708) STORAGE INCREMENT				
BB312-A (1708) STORAGE INCREMENT				
BB313-A (3502) STORAGE MODULE CE MANUAL	60210200	AC	22	22.80
BB314-A (3502) STORAGE MODULE CE INFO (USE BB313-A)				
BB316-A STORAGE MODULE (USE 3302-A, CATALOG SEC. 2)				
BB319-A (6634-C) EXTENDED CORE STORAGE ASSEMBLY DIAGRAMS, CIRC. DESC., WIRE LIST CE MANUAL	60209600	W	22	08.40
STACK ASSEMBLY-DIAGRAMS, CIRC DESC, MAINT CE MANUALS (DESCRIBES STACK ONLY)	60217600	D	22	16.05
MAINTENANCE, MAINTENANCE AIDS CE MANUAL	60289200	K	22	10.00
BB319-B (6634-D) EXTENDED CORE STORAGE ASSEMBLY (USE MANUALS UNDER BB319-A)				
BB323-A (6635-C) EXTENDED CORE STORAGE ASSEMBLY DIAGRAMS, CIRC. DESC., PARTS LIST, CARD	60212200	W	22	05.00

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
PLACEMENT CE MANUAL STACK ASSEMBLY CE MANUAL (USE MANUAL LISTED UNDER BB319-A) CHASSIS TABS, CABLE TABS CE MANUAL MAINTENANCE, MAINTENANCE AIDS (USE BB319-A)	60230300	S	22	46.15
BB323-B (6635-D) EXTEND CORE STORAGE ASSEMBLY (USE BB323-A MANUALS)				
BB324-B (6636-D) EXTENDED CORE STORAGE ASSEMBLY (USE BB323-A MANUALS)				
BB325-A (6633-C) EXTENDED CORE STORAGE ASSEMBLY (USE BB319-A MANUALS)				
BB325-B (6633-D) EXTENDED CORE STORAGE ASSEMBLY (USE BB319-A MANUALS)				
BB328-A (1772-1, 90104, 90108-2) MEM INCREMENT CE INFO (USE AB103-A)				
BB329-A (1772-2, 90104, 90108-1) MEM INCREMENT CE INFO (USE AB103-A)				
BB343-B (ST.OP. 10178) MEMORY INCREMENT 98K TO 131K FOR 6414/6514-D REFERENCE AT140-G/H 6414-D PRIOR TO OPT (USE 6413-D) NOT FOR USE WITH AT139 OR AT137 (USE BB343-C INSTEAD				
BB343-C (ST. OP. 10178) MEMORY INCREMENT 98K TO 131K FOR AT140-A/B 6414-E (INCLUDED IN AA105-A MANUALS) ALSO APPLIES TO 6414/6514-D WITH SPIGOT				
BB346-A (SP.OP. 60058-A) MEMORY INCREMENT 32K TO 65K FOR 6605/6615-A (USE 6604/14-A)				
BB349-A (ST.OP. 10177) MEMORY INCREMENT 49K TO 65K FOR 6415-C (USE 6414-A/B/C)				
BB349-B (ST.OP. 10177) MEMORY INCREMENT 49K TO 65K FOR 6415-D (USE 6414-D)				
BB349-C (ST.OP. 10177) MEMORY INCREMENT 49K TO 65K FOR 6415-E (AA108-A) (USE AA105-A)				
BB351-A () STORAGE MODULE				

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
CE MANUAL	60316100	C	22	15.10
BB353-A () STORAGE MODULE CE INFO (USE BB104-A)				
BB354-A () STORAGE INCREMENT CE INFO (USE GH408-A/B)				
BB355-A () STORAGE INCREMENT CE INFO (USE GH408-A/B)				
BB360-A () LARGE CORE MEMORY INCREMENT CE INFO (USE AC113-A)				
BB360-B (76-XXX) LARGE CORE MEMORY INCREMENT CE INFO (USE AA105-A OR AC113-A)				
BB361-A () SMALL CORE MEMORY INCREMENT CE INFO (USE AC113-A)				
BB365-A (ST.OPT. 10179-1) 16K INCREMENT TO 49K REF/CE MANUAL	60316000	B	22	06.00
BB365-B (ST. OPT. 10179-1) 16K MEMORY INCR. FOR 6615-D CENTRAL COMPUTER REFERENCE/CE MANUAL	60315900	B	22	05.65
BB366-A () 32K INCREMENT TO 65K FOR AA103-A USE AA103-A MANUALS				
BB367-A () 16K INCREMENT TO 65K FOR AA103-A USE AA103-A MANUALS				
BB370-A () MEM MODIFICATION FOR 6600 REFERENCE/CE MANUAL	60319800	B	22	06.80
BB372-A (731-XX, 732-XX, 730-100) 750 NANO- SECOND CORE STORAGE MODULE CE MANUAL	60346500	C	22	02.85
BB377-A (733-140, 10274-1) 4K INCREMENT CE INFO (USE FV156-A)				
BB381-A (1772-2, 90108-3) MEMORY INCREMENT CE INFO (USE AB103-A)				
BB382-A (1772-2, 90108-3) MEMORY MODULE CE INFO (USE AB103-A)				
BB385-A/B (1772-2) MEMORY MODULE CE INFO (USE AB103-A)				

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.

4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
BB386-A (1772-1) STORAGE INCREMENT CE INFO (USE AB103-A)				
BB387-A () MEMORY MODULE CE INFO (USE AB103-A)				
BB393-A (7030-4/8/16) EXTENDED CORE STORAGE CE INFO (USE BB323-A)				
BB394-A (7030-2) EXTENDED CORE STORAGE CE INFO (USE BB319-A)				
BB395-A (7030-1) EXTENDED CORE STORAGE CE INFO (USE BB319-A)				
BB397-A (CYBER 74-XX) 65K TO 32K DECREMENT CE INFO (INCLUDED IN AA117-A, CHASSIS 9, 10, 11 AND 12 MANUALS)				
BB399-A (10273-2) MEMORY INCREMENT MODULE CE INFO (USE AA116-A)				
BB400-A (10273-3) MEMORY INCREMENT MODULE CE INFO (USE AA116-A)				
BB402-A () CORE STORAGE MODULE CE MANUAL	60389600	A	22	02.85
BB405-A (7700) LCM INCREMENT CE INFO (USE AA121-A)				
BE1A2 (9545-14) MAGNETIC TAPE TRANSPORT PARTS LIST (A01-A02 AND ABOVE) CE MANUAL REF/CE MANUAL (EXCEPT PARTS LIST)	49487900 49487800	B A	22 22	04.00 09.40
BE1A3 (9525-14) MAGNETIC TAPE TRANSPORT PARTS LIST (A01 AND ABOVE) CE MANUAL REF/CE MANUAL (EXCEPT PARTS LIST)	49488200 49486400	C A	22 22	04.00 09.50
BE101 (604-2) MAGNETIC TAPE TRANSPORT GENERAL DESCRIPTION, DIAGRAMS CE MANUAL PARTS LIST (A04-07 B04 AND ABOVE, C02 AND ABOVE) CE MANUAL	49755600 41240000	A E	22 22	08.55 04.20
BE102 (608) MAGNETIC TAPE TRANSPORT THEORY OF OPERATION, DIAGRAMS, WIRE LIST CE MANUAL DESCRIPTION, OPERATION, INSTALLATION, CHECKOUT, MAINTENANCE CE MANUAL PARTS LIST CE MANUAL	40860800 40860700 40864100	J E G	22 22 22	01.50 04.75 02.95
BE103 (657-1) MAGNETIC TAPE TRANSPORT PARTS LIST CE MANUAL	49815000	G	22	05.70

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
GEN DESC., THEO OF OPER, MAINT. CE MANUAL	49750300	F	22	05.45
DIAGRAMS CE MANUAL	49750400	D	34	04.05
BE104 (657-2) MAGNETIC TAPE TRANSPORT CE INFO (USE BE103)				
BE2A1 (9568) MAGNETIC TAPE TRANSPORT PARTS LIST (A01 AND ABOVE) CE MANUAL	41243800	B	22	01.65
REF/CE MANUAL (EXCEPT PARTS LIST)	40869700	D	22	04.40
BE2A2 (9585-14) MAGNETIC TAPE TRANSPORT PARTS LIST (A01 AND ABOVE) CE MANUAL	49487300	B	22	04.00
REF/CE MANUAL (EXCEPT PARTS LIST)	49487200	A	22	09.60
BE2A3-A (9565-14) MAGNETIC TAPE TRANSPORT PARTS LIST (A01 AND ABOVE) CE MANUAL	49487500	C	22	04.00
REF/CE MANUAL (EXCEPT PARTS LIST)	49487400	A	22	09.60
BE222 (607-2) MAGNETIC TAPE TRANSPORT REFERENCE/CE MANUAL (INCLUDES BE423) (INCLUDES PMI/PMO) PARTS LIST CE INFO. (USE BE101)	40869901	C	22	04.60
BE223 (657-3) MAGNETIC TAPE TRANSPORT CE INFO (USE BE103) PARTS LIST CE MANUAL	49815100	F	22	02.10
BE224 (657-4) MAGNETIC TAPE TRANSPORT CE INFO (USE BE103)				
BE4A1 (9560) MAGNETIC TAPE TRANSPORT REF/CE MANUAL (EXCEPT PARTS LIST)	40868700	C	22	05.70
PARTS LIST CE MANUAL	41242100	C	22	01.70
BE4A1/RT103 (9560 WITH SP0 68024) MAGNETIC TAPE TRANSPORT CE MANUAL	49859400	A	22	10.35
BE4A2 (9565) GEN DESC. THEO OF OPER, MAINT. CE MANUAL	49755700	B	22	09.75
PARTS LIST CE INFO. (USE BE4A1)				
BE4A9 (9585) MAGNETIC TAPE TRANSPORT GEN DESC, THEO OF OPER, MAINT. CE MANUAL	49755700	B	22	09.75
PARTS LIST (A01, B01 AND ABOVE) CE MANUAL	40801800	D	22	03.90
BE4B1 (9545) MAGNETIC TAPE TRANSPORT GEN DESC, THEO OF OPER, MAINT. CE MANUAL	49755700	B	22	09.75
PARTS LIST (A02, B02 AND ABOVE) CE MANUAL	40821900	E	22	04.00
BE4B2 (9525) MAGNETIC TAPE TRANSPORT GEN DESC, THEO OF OPER, MAINT. CE MANUAL	49755700	B	22	09.75
DIAGRAMS CE MANUAL	49755800	C	22	09.00

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
BE4B3 (9540) MAGNETIC TAPE TRANSPORT PARTS LIST (A04, B04 AND ABOVE) CE INFO. (USE BE4B1) REF/CE MANUAL (EXCEPT PARTS LIST)	40817400	B	22	05.60
BE4B3/BT115 (9540 WITH SPO 68025) MAGNETIC TAPE TRANSPORT REF/CE MANUAL	49859100	A	22	09.80
BE4B4 (9580) MAGNETIC TAPE TRANSPORT REF/CE MANUAL (EXCEPT PARTS LIST) PARTS LIST CE INFO. (USE BE4A9)	40824200	A	22	12.20
BE4B4 WITH BT116 (9580 WITH SPO.68023)	49859200	B	22	10.20
BE4B5 (9520) MAGNETIC TAPE TRANSPORT PARTS LIST (A01, B01 AND ABOVE) CE INFO. (USE BE4B2) DIAGRAMS, WIRE LIST CE MANUAL REF/CE MANUAL (EXCEPT PARTS LIST) PARTS LIST	49859300 40808200 40819900	A B C	22 22 22	10.05 05.60 04.10
BE4B8 (9585-11) MAGNETIC TAPE TRANSPORT PARTS LIST (A01 AND ABOVE) CE MANUAL REF/CE MANUAL	49800300 49484600	C B	22 22	02.55 08.50
BE4B9 (9525-13) MAGNETIC TAPE TRANSPORT REF/CE MANUAL (EXCEPT PARTS LIST) PARTS LIST (A01 AND ABOVE) CE MANUAL	49488300 49488400	A C	22 22	08.90 04.00
BE4C1 (9545-13) MAGNETIC TAPE TRANSPORT REF/CE MANUAL (EXCEPT PARTS LIST) PARTS LIST CE MANUAL	49488000 49488100	A B	22 22	09.25 03.50
BE4C2 (9565-13) MAGNETIC TAPE TRANSPORT REF/CE MANUAL (EXCEPT PARTS LIST) PARTS LIST (A01 AND ABOVE) CE MANUAL	49487600 49487700	A C	22 22	09.25 03.40
BE4C3 (9585-13) MAGNETIC TAPE TRANSPORT REF/CE MANUAL (EXCEPT PARTS LIST) PARTS LIST (A01 AND ABOVE) CE MANUAL	49487000 49487100	A B	22 22	09.25 04.00
BE4C4 (9519) MAGNETIC TAPE TRANSPORT PARTS LIST CE MANUAL SPECIAL CARD MANUAL	49488600 49932700	E A	22 22	05.80 01.50
BE4D1 (609) MAGNETIC TAPE TRANSPORT THEORY OF OPERATION, DIAGRAMS, WIRE LIST CE MANUAL DESCRIPTION, OPERATION, INSTALLATION CHECKOUT, MAINTENANCE CE MANUAL PARTS LIST CE INFO. (USE BE102)	40861000 40860900	H E	22 22	02.40 05.55

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
BE406 (659-1) MAGNETIC TAPE TRANSPORT GEN DESC., THEO OF OPER, MAINT CE MANUAL DIAGRAMS OF MANUAL PARTS LIST CE MANUAL	49750600 49750700 49815200	G G H	22 34 22	09.10 04.90 02.20
BE407 (659-2) MAGNETIC TAPE TRANSPORT CE INFO (USE BE406)				
BE408 (659-3) MAGNETIC TAPE TRANSPORT CE INFO (USE BE406) PARTS LIST CE MANUAL	70603900	J	22	02.30
BE409 (659-4) MAGNETIC TAPE TRANSPORT CE INFO (USE BE406) PARTS LIST (A01, B01 AND ABOVE) CE INFO. (USE BE408)				
BE423 () NINE TRACK OPTION (SEE BE222)				
BG105-A/B DRUM STORAGE UNITS,DIAGS, CIRC DESC, MAINT,P/L,C/P, EQ SUM, W/L	60210400	C	22	13.55
BG108-C/D/863-C DRUM STORAGE UNIT CE MAN.	70606700	A	22	09.50
BG111-A/C MICRO DRUM CE MANUAL	40808600	B	22	01.30
BG111D-G MICRO DRUM GEN DESC., OPER., PARTS DATA, MAINT., THEO. OF OPER., CE MANUAL	70622100	B	22	03.25
BG113 DRUM STORAGE UNIT GEN DESC,MAINT AIDS, EQ SUM, W/L DIAGS CE MANUAL	70607500	B	22	16.25
BG504 A-H DRUM MEMORY SUBSYSTEM HARDWARE REF/CE MANUAL	39731700	C	22	03.00
BH1A9/BH2A1 DISK FILE THEORY OF DIAGRAMS, WIRE LIST CE MANUAL	70607100	A	22	07.80
BH2A1 DISK FILE SYSTEM PARTS DATA	70606900	B	22	02.30
BH405 DISK FILE CLOCK WRITER/EXERCISER CE MANUAL TROUBLESHOOTING GUIDE	70615800 59349900	B A	22 22	05.90 15.90
BH405-C DISK FILE GEN DESC.,OPER.,INSTAL., CHECKOUT, MAINTENANCE PRELIM.ED. CE MANUAL THEO OF OPER., DIAGS., WIRE LIST CE MANUAL PARTS DATA CE MANUAL	41242300 41242200 41242400	B F C	22 22 22	08.45 06.35 05.10
BH408/410 DISK FILE GENERAL DESCRIPTION	70601300	B	22	06.20

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
OPER., INSTALL. AND CHECKOUT, MAINT. CE MAN.	70601500	D	22	02.20
PARTS LIST MOD A07,A08 AND ABOVE CE MANUAL	70601400	G	22	06.20
THEORY, DIAGRAMS AND WIRE LIST MANUAL	86811400	A	22	08.80
TRUBLE SHOOTING GUIDE CE MANUAL				
BJ1A7 DISK STORAGE DRIVE--ALSO LISTED AS 9451 DIAGRAMS AND WIRE LIST CE MANUAL	41241700	B	22	06.40
BJ1A9 PARTS LIST MOD A13,B13 ABOVE CE MANUAL	70605300	C	22	02.15
BJ103 DISK STORAGE DRIVE PARTS LIST	70605000	C	22	02.85
BJ104-A/B DISK STORAGE DRIVE DIAGS AND WIRE LIST CE MANUAL	70604400	E	22	02.90
PARTS LIST MODS A13, B13 AND ABOVE	70604500	C	22	02.85
MAINTENANCE CE MANUAL	70604300	C	22	06.70
BJ2A2 DISK STORAGE DRIVE DIAGS. AND W/L MAINTENANCE MANUAL	41249700	D	22	04.55
PARTS DATA CE MANUAL	41249600	B	22	05.75
	41249800	B	22	01.80
BJ3A1 DISK STORAGE DRIVE A12 ABOVE, B12 ABOVE PARTS LIST	41249500	C	22	03.70
DIAGS, CIRC DESC., C/P, W/L, CE MANUAL	41249400	D	22	02.15
BJ3A1-A/B DISK STORAGE DRIVE MAINT.CE MANUAL	41249300	C	22	12.70
BJ3A3 DISK STORAGE DRIVE-DUAL DISK DRIVE PARTS	70606500	B	22	02.00
BJ5XX STORAGE MODULE DRIVE PARTS DATA CE MANUAL	70631100	L	3	02.80
REFERENCE MANUAL	70631000	D	3	09.35
MAINTENANCE MANUAL	70630900	K	3	09.60
BJ6XX STORAGE MODULE DRIVE MAINTENANCE MANUAL	83310800	C	3	05.70
REFERENCE MANUAL	83310900	B	3	05.40
BJ7XX STORAGE MODULE DRIVE MAINTENANCE MANUAL	83308400	A	3	10.50
REFERENCE MANUAL	83308500	A	3	12.40
PARTS DATA MANUAL	83308600	A	3	04.10
BK3A1 DUAL DISK DRIVE PARTS LIST CE MANUAL	70604700	D	22	03.45
BM1A1/BM1A3 MULTIPLE DISK DRIVE DIAGS, W/L CE	41249200	A	22	07.20
BM1A1,2,3,4 PARTS DATA CE MANUAL	70605500	D	22	06.10
BM1A2-A/B/BM1A4-A/B MULTIPLE DISK DRIVE DIAGS, WIRE LIST CE MANUAL	70602300	A	22	07.10
MAINTENANCE CE MANUAL	70602200	A	22	03.65

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
BM1A5/BM1A6 MULT. DISK DR MOD B01/ABOVE PARTS	70601900	K	22	05.95
BM1A5/BM1A7 MULTIPLE DISK DRIVE THEORY OF OPER DIAGRAMS, MAINTENANCE AIDS, WIRE LISTS	70602500	H	22	08.20
GENERAL DESCRIPTION, OPERATION, INSTALLATION AND CHECKOUT, MAINTENANCE CE MANUAL	70602400	G	22	08.00
BM1A6/BM1A8 MULTIPLE DISK DR. GEN. DESC., OPER. INST.CHKOUT,MAINT, CE MAN	41243900	E	22	03.80
BM1B1/3-A/B GENERAL DESCRIPTION MANUAL OP., DIAGRAMS, MAINT.	70603300	G	22	05.10
THEORY OF OPER. DIAGS, MAINT AIDS, WIRE LIST CE MANUAL	70603400	H	22	11.40
BM1B1,2,3,4 AND A02,B02 AND ABOVE, MULT DK DR	70603500	H	22	03.90
BM1B2-A/B, BM1B4-A/B MULT. DISK DR GEN DESC. OPER., INST., AND CHKOUT MAINT. MAN.	70603600	D	22	03.70
THEO OF OP,DIAG,MAINT AIDS,WIRE LIST CE MAN	70603700	D	22	20.15
BM1B5-B/BM1B6-B GEN DESC.,OPER.,INST. AND CHECKOUT, MAINT. CE MANUAL PARTS LIST	40869600	J	22	02.00
BM1B7 MULTIPLE DISK DRIVE PARTS LIST CE MANUAL	70603200	A	22	02.10
BM1B7-A MULTIPLE DISK DRIVE MAINTENANCE CE	70603000	A	22	03.60
BM1B8-B/BM1B9-B MULT. DISK DRIVE MAINT., GEN. DESC., CE MANUAL	70607300	E	22	01.00
DIAG, WIRE LIST, MAINT, CE MANUAL	70607200	G	22	05.90
BM1C1-B/BM1C2-B MULTIPLE DISK DRIVE GEN DESC. THEORY OF OPER, CE MANUAL	70619500	C	22	04.95
DIAGRAMS CE MANUAL	70619600	R	22	11.80
PARTS DATA CE MANUAL	70619700	C	22	04.30
BM101/103 MULTIPLE DISK DRIVE GEN DESC., OPER., INSTAL. CKOUT., MAINT. CE MAN	41248900	J	22	02.95
THEO OF OPER., DIAGRAMS, MAINT. AIDS CE LISTS CE MANUAL	41249000	J	22	07.70
PARTS DATA CE MANUAL	41243700	L	22	16.90
BM102/104-A/B MULTIPLE DISK DRIVE GEN. DESC., OPER.,INSTL.CHKOUT,MAINT. CE MANUAL	41243500	H	22	04.35
THEO OF OPER., DIAGRAMS, MAINT AIDS, WIRE LISTS CE MAN.	41243600	J	22	22.10
PARTS DATA INFO (USE BM101/103)				
BM2A2/4 MULTIPLE DISK DRIVE MAINT, CE MANUAL	70606100	B	22	04.35
BM2A7/8 MULTIPLE DISK DRIVE MAINT. CE MANUAL	70609400	B	22	04.80
PARTS DATA CE MANUAL	70609700	F	22	04.30

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
THEORY OF OPER, DIAGRAMS, W/L, MAINT.AIDS CE	70609500	B	22	09.80
BM2B1 MULTIPLE DISK DRIVE				
GEN DESC, CHKOUT, MAINT. CE MANUAL	70611000	A	22	04.00
THEO OF OPER, MAINT AIDS, DIAGRAMS, W/L CE	70611100	B	22	14.90
BM2B2 MULTIPLE DISK DRIVE				
GEN DESC, CHECKOUT, MAINTENANCE CE MANUAL	70611300	D	22	09.25
PARTS DATA CE MANUAL	70611200	H	22	03.05
BM2B2-C/D MULTIPLE DISK DRIVE				
DIAGRAMS CE MANUAL	70615900	D	22	07.70
BM3A2 MULTIPLE DISK DRIVE PARTS DATA CE MAN	70609200	D	22	02.10
BP2A3 DISK STORAGE UNIT A01 ABOVE PARTS DATA	70605800	B	22	02.20
CE MANUAL				
BR1A1 DISK STORAGE UNIT				
GEN DESC, OPER, INSTAL/CHECKOUT, THEORY OF	70609800	D	22	14.00
DIAGRAMS, MAINT AIDS, WIRE LISTS CE MANUAL	70609900	C	22	02.50
PARTS DATA CE MANUAL	70610100	J	22	01.50
DIAGRAMS, MAINT. AIDS, WIRE LIST CE MANUAL	70617000	L	22	12.35
(MODS A03, B03 AND C03 AND ABOVE)				
BR1A1-E DISK STORAGE UNIT				
MAINTENANCE MANUAL	70619200	F	22	12.25
DIAGRAMS AND WIRE LIST	70619300	H	22	10.50
PARTS DATA CE MANUAL	70619400	H	22	02.10
BR1A3 DISK STORAGE UNIT				
PARTS DATA CE MANUAL	70613100	B	22	03.10
GEN DESC, OPER, INS0ALLATION/CHECKOUT, THEO	70612900	A	22	04.90
OF OP, MAINT CE MANUAL				
DIAGRAMS CE MANUAL	70613000	B	22	05.35
BR1A9 DISK STORAGE UNIT				
DIAGS, W/L, MAINT AIDS (MODS B03 AND ABOVE)	70617100	H	22	04.50
CE MANUAL				
BR1A9-B VOICE COIL DRIVE				
PARTS DATA(B01 AND ABOVE) CE MANUAL	70609300	J	22	03.80
BR1B3 DISK STORAGE UNIT DIAGRAMS AND WIRE LIST	70620500	F	22	02.85
CE MANUAL				
GEN DESC., THEORY OF OPER., INSTL/CHECKOUT,	70620400	C	22	06.15
MAINTENANCE CE MANUAL				
PARTS DATA CE MANUAL	70620600	G	22	02.25
BR2A1-D DISK STORAGE UNIT				
MAINTENANCE MANUAL	70616300	C	22	04.30
PARTS DATA CE MANUAL	70612600	C	22	01.65

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
BR2A1-D (SC19 AND ABOVE) DISK STORAGE UNIT PARTS DATA CE MANUAL	83311400	A	22	05.05
BR2A1-1 DISK STORAGE UNIT DIAGRAMS CE MANUAL	70616400	F	22	07.20
BR2A3 DISK STORAGE UNIT PARTS DATA CE MANUAL	70615100	A	22	04.15
BR2A6-B DISK STORAGE UNIT DIAGRAMS AND W/L PARTS DATA CE MANUAL	70622700	K	22	03.55
MAINTENANCE CE MANUAL	70622800	N	22	03.15
	70622600	H	22	05.30
BR2A7 DISK STORAGE UNIT DIAGRAMS AND WIRE LIST PARTS DATA CE MANUAL	70622200	L	22	03.45
	70622500	M	22	07.65
BR2A8 DISK STORAGE UNIT DIAGRAMS AND WIRE LISTS CE MANUAL	70622300	M	22	06.10
MAINTENANCE CE MANUAL	70622400	G	22	05.05
BR2B1 DISK STORAGE UNIT MAINTENANCE MANUAL	70612500	C	22	13.40
DIAGRAMS AND WIRE LISTS	70607900	D	22	07.60
BR2B2/3 DISK STORAGE UNIT GENERAL DESCRIPTION, MAINTENANCE CE MANUAL	70631300	D	22	08.45
DIAGRAMS, WIRE LISTS CE MANUAL	70631400	F	22	06.30
PARTS DATA CE MANUAL	70631500	G	22	04.35
BR3A1-G DISK STORAGE UNIT MAINTENANCE AIDS DIAGRAMS AND WIRE LIST CE MANUAL	70613300	F	22	06.50
MAINTENANCE CE MANUAL	70613200	F	22	10.30
PARTS DATA (SC 07 AND ABOVE)	70626500	C	22	04.50
BR3A4 DISK STORAGE UNIT GEN DESC., THEO OF OPER., MAINTENANCE CE MANUAL	70610300	D	22	12.75
DIAGRAMS CE MANUAL	70610500	F	22	06.25
BR3A5 DISK STORAGE UNIT PARTS DATA CE MANUAL DIAGRAMS AND WIRE LIST CE MANUAL	70623700	B	22	03.40
MAINTENANCE CE MANUAL	70623600	C	22	06.10
	70623500	A	22	07.60
BR3B4 DISK STORAGE UNIT MAINTENANCE MANUAL PARTS DATA MANUAL	70628200	L	3	05.80
	70628400	G	3	02.35
BR3B5 DISK STORAGE UNIT PARTS DATA MANUAL	70630500	F	3	05.90
BR3B8 DISK STORAGE UNIT PARTS DATA CE MANUAL	83301200	K	3	03.85
REFERENCE MANUAL	83301100	C	3	04.90

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.

4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
MAINTENANCE CE MANUAL	83301000	K	3	07.90
BR306 DISK STORAGE UNIT REFERENCE MANUAL	83309400	B	3	07.05
MAINTENANCE CE MANUAL	83309300	C	3	08.70
PARTS DATA	83309500	C	3	04.85
BR301R DISK STORAGE UNIT				
MAINTENANCE MANUAL	83305700	E	3	10.20
REFERENCE MANUAL	83305800	C	3	05.75
PARTS DATA MANUAL	83305900	E	3	03.00
BR303-A/B DISK STORAGE UNIT				
MAINTENANCE MANUAL	83311600	A	22	16.90
REFERENCE MANUAL	83311700	A	3	10.00
BR304 DISK STORAGE UNIT				
MAINTENANCE MANUAL	83313100	A	3	20.30
REFERENCE MANUAL	83313200	A	3	17.55
PARTS LIST	83313300	A	3	04.65
BR302 DISK STORAGE UNIT				
DIAGRAMS AND WIRE LIST CE MANUAL	70618500	J	22	05.70
MAINTENANCE CE MANUAL	70618400	F	22	24.25
PARTS DATA CE MANUAL	70618600	E	22	02.95
PARTS DATA CE MANUAL (S/C 09 AND ABOVE)	70626300	D	22	03.40
BR303 DISK STORAGE UNIT				
INSTALLATION/CHECKOUT, PREVENTIVE/CORRECTIVE	70629600	H	22	07.10
MAINTENANCE, DIAGRAMS, W/L, CE MANUAL				
PARTS DATA CE MANUAL	70629700	J	22	03.30
GEN DESC., OPER., THEORY OF OPERATION CE MAN	70629500	C	22	03.45
BR304 DISK STORAGE UNIT				
PARTS DATA CE MANUAL	70628100	C	22	01.95
MAINTENANCE CE MANUAL	70627900	D	22	11.30
GENERAL DESCRIPTION, OPERATION, THEORY OF	70628000	C	22	06.90
OPERATION, KEY TO LOGIC, INTEGRATED CIRCUIT				
DISCRETE CIRCUITS CE MANUAL				
BR305 DISK STORAGE UNIT				
PARTS DATA CE MANUAL	83303300	C	22	04.50
REFERENCE MANUAL	83303200	A	22	06.90
PREVENTIVE/CORRECTIVE MAINTENANCE, DIAGRAMS,	83303100	B	22	20.05
WIRE LISTS CE MANUAL				
BR306/7 DISK STORAGE UNIT				
PARTS DATA CE MANUAL	83308900	C	22	04.60
PREVENTIVE/CORRECTIVE MAINT., DIAGS, W/L	83308700	C	22	18.55
REFERENCE MANUAL	83308800	B	22	14.50
BR306/7-D/E DISK STORAGE UNIT				
PREVENTIVE/CORRECTIVE MAINTENANCE, DIAGRAMS,	83314000	A	22	13.05
WIRE LISTS CE MANUAL				

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
BR5A1 DISK STORAGE UNIT MAINTENANCE MANUAL	70617800	E	22	04.50
PARTS DATA CE MANUAL	70618000	P	22	02.50
DIAGRAMS AND WIRE LIST CE MANUAL	70617900	J	22	03.45
BR5A2 DISK STORAGE UNIT MAINTENANCE MANUAL	70624500	G	22	05.90
DIAGRAMS CE MANUAL	70624600	J	22	04.45
PARTS DATA MANUAL	70624700	J	22	02.85
BR5A3 DISK STORAGE UNIT GEN. DESC., OPER., INSTALLATION AND CHECKOUT THEORY OF OPERATION, MAINTENANCE CE MANUAL	70628500	B	22	06.25
DIAGRAMS AND WIRE LISTS CE MANUAL	70628600	D	22	05.40
BR5A4 DISK STORAGE UNIT MAINTENANCE MANUAL	70630000	B	3	18.75
PARTS DATA CE MANUAL	70630200	C	3	07.80
DIAGRAMS CE MANUAL	70630100	C	22	10.90
BR5A5 DISK STORAGE UNIT GEN. DESC., OPERATION, INSTALLATION/CHECKOUT THEORY OF OPERATION AND MAINT CE MANUAL	83302300	D	22	11.05
DIAGRAMS, MAINT. AIDS, WIRE LIST CE MANUAL	83302400	C	22	08.40
PARTS DATA CE MANUAL	83302500	E	22	05.35
BR5A6 DISK STORAGE UNIT MAINTENANCE MANUAL	83313400	B	3	10.50
REFERENCE MANUAL	83313500	B	3	12.20
PARTS DATA MANUAL	83313600	A	3	03.75
BR501 DISK STORAGE UNIT PREVENTIVE AND CORRECTIVE MAINTENANCE, DIAGRAMS, WIRE LISTS, CE MANUAL	70629300	M	22	09.75
GENERAL DESCRIPTION, OPERATION, THEORY OF OPERATION CE MANUAL	70629200	F	22	03.70
PARTS DATA CE MANUAL	70629400	K	22	04.60
BR502/4 DISK STORAGE UNIT REFERENCE MANUAL	83302700	D	22	06.25
PARTS DATA CE MANUAL	83302800	F	22	02.65
PREVENTIVE/CORRECTIVE MAINTENANCE, DIAGRAMS, WIRE LIST CE MANUAL	83302600	G	22	07.95
BS101-A (76-XXX) CENTRAL MEMORY INCREMENTS CE INFO (USE AA106-A)				
BS102-A (76-XXX) CENTRAL MEMORY INCREMENT CE INFO (USE AA106-A)				
BT116 (SP0 63023) DUAL MODE OPTION (SEE BF4R4)				

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
BT118 (SPO 68106) NINE TRACK OPTION (SEE BE101)				
BT128-A () STORAGE MODULE CE INFO (USE B8351-A)				
BT150-A/B (1714) MEMORY EXPANSION MODULE CE INFO (USE AA116-A)				
BU104 MAGNETIC TAPE CERTIFIER PARTS DATA CE MANUAL	70617400	A	22	04.80
CA101-A, CA102-A HDWR REF/CE MAN	82140400	A00	22	01.25
CC514-A/B (7601-1) STATION CONSOLE				
CC521-A () SECOND CONSOLE DISPLAY FOR 6000-D/E COMPUTER SYSTEMS (USE 6602/6612)				
CC533-A DATA ACQUISITION/CONTROLLER CONSOLE GEN DESC., DIAGS, W/L, MAINT CE MANUAL	39534900	A	22	02.30
CE1A5 (9200) CARD READER REF/CE MANUAL (EXCEPT PARTS LIST)	49626100	D	22	10.70
CE120 (1729-2) CARD READER PARTS LIST (A01, B01 AND ABOVE) CE MANUAL REF/CE MANUAL (EXCEPT PARTS LIST)	40804800 40802000	A C	22 22	01.85 05.30
CE123-A/B PARTS LIST CE MANUAL DIAGRAMS, WIRE LIST, MAINTENANCE CE MANUAL	49755100 49755200	02 B	22 22	01.45 14.95
CE124 (410) PL10 CARD READER GEN DESC., DIAGS, THEORY OF OPERATION REF/CE MANUAL	49754900	B	22	06.70
CE149 (407) CARD READER REF/CE MANUAL (EXCEPT PARTS LIST)	49973600	B	22	11.00
CE152 (224) CARD READER REF/CE INFO (USE CE1A5) PARTS DATA CE MANUAL	60352000	D	22	01.05
CE155-A/B () CARD READER REFERENCE/CE MANUAL	60366600	A	22	16.65
CE304 (224-2) CARD READER REF/CE MANUAL (EXCEPT PARTS LIST) PARTS LIST CE MANUAL	41243200 41241500	D H	22 22	03.55 02.50
CE305-A/B (1777-1/2, 90121-1, 90122-1) PAPER TAPE READER CE MANUAL	60293400	N	22	03.40

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
** REFER ALSO TO CATALOG SEC. 2 FOR 370 PAPER TAPE READER MANUALS				
CE306 (224-2A) CARD READER REF/CE MANUAL (EXCEPT PARTS LIST)	49593000	C	22	06.40
PARTS LIST (A01/B01 AND ABOVE) CE MANUAL	49593100	C	22	02.95
CE601-A (SP. OPT. 60031) 3447 CARD READER MODIF REFERENCE/CE MANUAL (45 COLUMN CARDS)	60250900	A	22	03.15
CE602-A (SP. OPT. 60031) 3649 CARD READER MODIF REF/CE INFO (USE CE601-A) (45 COLUMN CARDS) CE601-A				
CF104-A (1777-1/2, 90123-1, 90124-1) PAPER TAPE PUNCH - STEEL CE INFO (USE CE305-A/B) ** REFER ALSO TO VENDOR MANUALS, CATALOG SEC. 4 FOR NCR EM-B3 MANUALS				
CF105 (226-1) CARD PUNCH REF/CE MANUAL (EXCEPT PARTS LIST)	49591900	D	22	10.80
PARTS LIST CE MANUAL	49592900	C	22	06.65
CF106-A (90123-2, 90124-2) PAPER TAPE PUNCH - TUNGSTEN CARBIDE CE INFO (USE CE305-A/B) ** REFER ALSO TO VENDOR MANUALS, CATALOG SEC. 4 FOR NCR EM-B3 MANUALS				
CF109-A/B () CARD PUNCH CE MANUAL	60366700	01	22	11.70
CF5A5-A/B/C (90125-1) PAPER TAPE STATION - COMMON CONTROL				
CF504 (430) CARD READER/PUNCH REF/CE MANUAL (EXCEPT PARTS LIST) (INCLUDES PMT/PMP) PARTS LIST CE MANUAL	40864000	G	22	07.35
	40864800	E	22	05.95
CF507-A/B (9290) CARD READER/PUNCH REF/CE MANUAL (EXCEPT PARTS LIST) VOLS I-II PARTS LIST CE MANUAL	60286200	F	22	12.05
	49597000	E	22	10.95
CF508-A/B/C (1777-1/2) COMMON CONTROL CE INFO (USE CE305-A/B)				
CF511-A/B CARD READER/PUNCH CE MANUAL	60318700	A	22	16.85
CF8A1-A (90126-1) ENCLOSURE KIT				

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
CF801-A () PAPER TAPE PUNCH - TUNGSTEN CARBIDE OPTION CE INFO (USE CE305-A/B)				
CH102-A/B CARD PUNCH PART IDENTIFICATION MANUAL	49762400	A	22	12.35
CJ1A5 OCR DOCUMENT READER DIAGRAMS VOL 2 HARDWARE REF/CE MANUAL	87951000		22	04.80
CJ103-A/CW146-A OCR DOCUMENT READER WIRE LIST CE MANUAL (CJ103-A ONLY)	70609600	A	22	21.80
GEN.DESC., OPER., MAINT., MAINT. AIDS	40827600	A	22	06.55
THEORY OF OPERATION DIAGRAMS CE MANUAL	41241900	B	3	14.70
PARTS DATA CE MANUAL	40963200	B	22	04.15
CJ112 PAGE READER G-H (CS/N151-200) PARTS LIST CE MANUAL	41241400	B	3	10.35
DIAGRAMS CE MANUAL	70601700	E	22	17.85
PAGE READER REFERENCE CE MANUAL	40819300	A	22	10.35
WIRE LISTS (LOGIC W/L) VOL.4 CE MANUAL	70602100	C	22	20.90
CJ115, CJ1A4 OCR DOCUMENT READER GEN DESC., OPER, THEO OF OPER., MAINTENANCE CE MANUAL	48883700	A	3	15.90
CJ119 PAGE READER DIAGRAMS VOL 2 HARD.REF/CE	48997900	B	22	07.15
CJ122 MAINTENANCE CE MANUAL	48430080	C	3	21.30
DIAGRAMS VOLUME 2, PART 3, CE MANUAL	48430045	B	22	18.30
PARTS DATA VOLUME 3 CE MANUAL	48430090	B	3	06.60
PARTS DATA S/N 103-129 VOL 38 REF/CE MANUAL	48430087	D	3	08.55
PAGE READER VOL 2 CE MANUAL	48948100	B	3	19.95
959 PAGE AND DOCUMENT READER SYST. OP. GUIDE	91669100	A	22	02.75
CJ122 PAGE AND DOCUMENT READER (S/N 151-175) DIAGRAMS, RECOGNITION RACK, HARDWARE REF/ CE MANUAL (VOL II, PART II)	48948200	B	3	05.20
CJ127 OCR DOCUMENT READER DIAGS. HR/CE MAN V2	87971600	01	22	02.75
PARTS DATA HARDWARE/CE MANUAL VOL 3	87971700	01	22	02.65
HARDWARE REFERENCE/C.E.MANUAL	87906700	A	22	01.90
SYSTEMS OPERATORS GUIDE (SEE 929 DOC. READER				
CJ508-A ANST OCR-A AND E13-B CHARACTER SET OPT RECOGNITION LOGIC, DIAGRAMS, ASSERT-NEGATE DIAGRAMS AND PARTS DATA CE MANUAL	87829800	A	3	05.50
CJ520 OCR DOCUMENT READER LOGIC RACK HARDWARE MAINTENANCE MANUAL VOL I	87911800	A	22	13.30
CK501-A/B (1711-3, 90111-1) TELETYPEWRITER				

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
CE INFO (USE AB103-A) ** REFER ALSO TO VENDOR MANUALS, CATALOG SEC. 4 FOR TELETYPE MANUALS (35KSR)				
CK502-A/B (1713-3, 90113-1) TELETYPEWRITER CE INFO (USE AB103-A) ** REFER ALSO TO VENDOR MANUALS, CATALOG SEC. 4 FOR TELETYPE MANUALS (35ASR)				
CL106A/B ELECTRONICS EQUIP., CL107A/B PRINT HEAD EQUIPMENT	44976700	B	22	02.00
CL308A/B LINE PRINTER EQUIP PARTS DATA CE MAN. PRINTER EQUIPMENT CE MANUAL	44895600 47967000	A F	22 22	02.45 08.25
CL309 A/B LINE PRINTER EQUIP PARTS DATA PRINTER EQUIPMENT CE MAN. (USE CL308-A/B)	44895700	A	22	02.70
CL320 MEDIUM SPEED BATCH TERMINAL LINE PRINTER EQUIPMENT OPERATION REFERENCE MANUAL	50583100	A	22	01.55
DIAGRAMS AND WIRE LIST FIELD SERVICE MANUAL	50583200	B	22	04.35
PARTS IDENTIFICATION MANUAL	50584300	B	22	03.55
CL4B4-A/B/C/D USE 9322 LINE PRINTER				
CL401-A/B, CL402-A/B (222) LINE PRINTER CONTROLLER				
REF/CE MANUAL	47966700	E	22	04.95
PARTS DATA CE MANUAL	44895800	A	22	02.00
PRINTER EQUIPMENT CE MAN. (USE CL308-A/B)				
CL403A/B AND CL4044/B LINE PRINTER CONT EQ MAN PRINTER EQUIPMENT CE MAN. (USE CL308-A/B)	44978800	A	22	03.10
CL408-A/B USE 9322 LINE PRINTER				
CL503 LINE PRINTER EQUIPMENT HSRT PARTS IDENTIFICATION MANUAL	50583400	01	22	05.40
GENERAL DESCRIPTION, INSTALLATION AND CHECKOUT, MAINT./MAINT AIDS REF MANUAL	50581800	01	22	05.10
DIAGRAMS AND WIRE LIST VOL II CE MANUAL	50583300	01	22	04.35
CL6A1 (9360) LINE PRINTER PARTS DATA CE INFO - SERIES A/C23-A/C28	50578500	A	22	05.00
CL601 (512) LINE PRINTER EQUIPMENT REF/CE MANUAL	44980100	D	22	01.70
DIAGRAMS AND WIRE LIST - SERIES A23-A28, B23-B28, C23-C28, D23-D28	50578100	A		03.45
CL601, CL6A1A LINE PRINTER EQUIP DIAGRAM AND WIRE LIST	44855700	C	22	02.50
DIAGRAMS, WIRE LIST MOD A01-A07 CE MANUAL	44855500	D	22	05.80

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.

4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
PARTS DATA CE MANUAL - SERIES A08-A22	44855600	C	22	04.35
PARTS DATA CE MANUAL - SERIES A/D23-A/D28	50577700	A	22	10.10
CL835 LINE PRINTER EQUIP. PARTS DATA CE MAN. REF/CE MANUAL	44980900 44980700	C C	22 22	03.40 03.00
CL835 LINE PRINTER EQUIPMENT CE MANUAL	44980800	C	22	02.25
CL896 LOW SPEED BATCH TERMINAL LINE PRINTER EQUIPMENT REFERENCE MANUAL	50582300	B	22	01.85
DIAGRAMS, WIRE LIST FIELD SERVICE MANUAL	50582400	B	22	03.15
PARTS IDENTIFICATION MANUAL	50583900	B	22	02.70
CR105-A (3504-1) DESK CONSOLE GENERAL DESCRIPTION, DIAGRAMS (USE AC104-A) MAINT. AIDS; 50-PAK STRIP TABS/MAPS (USE AC104-A) PARTS DATA (USE AC104-A)				
CR106-A (3514-1/2/3/4) DESK CONSOLE GENERAL DESCRIPTION, DIAGRAMS (USE AC106-A) PARTS DATA (USE AC104-A)				
CV403-A DIGISCRIBE OPTION (10892) REPAIR CENTER CE MANUAL ON SITE MAINTENANCE MANUAL	62996000 62995900	A-0 A-0	22 22	04.10 03.20
CW120-A/121-A LINE PRINTER ADAPTER KIT REF/CE	82140800	A01	34	03.00
CW123-A (1777-2, 90127-1) PUNCH VALIDATION FEATURE CE INFO (USE CE305-A/B)				
CW126-E/F HANDPRINT UNIT HARDWARE REF/CE MANUAL DIAGRAMS VOL 2 HARDWARE REFERENCE MANUAL DIAGRAMS VOL 2B HARDWARE REFERENCE MANUAL	48991800 48143981 48911900	A B A	3 3 3	34.80 30.15 13.80
CW140-A ISO-OCR-B NUMERICS FONT OPTION GEN.	48996300	A	3	02.95
CW195 OCR-B PLUGGABLE FONT OPTION GENERAL DESCRIPTION, INSTALLATION AND CKOUT DIAGRAMS HARDWARE REF/CE MANUAL	91662900	A	22	06.15
CW207 HANDPRINT UNIT MODEL A01 HARDWARE MAINTENANCE MANUAL VOLUME 1	91558900	A	22	44.40
DA101-A (1544-2) DIGITAL INPUT UNIT REF/CE MANUAL	39909502	B	22	03.35
DA101-B (1544-1) DIGITAL INPUT UNIT REF/CE INFO (USE DA101-A)				

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
DA401-A (1544-4) DIGITAL INPUT UNIT REF/CE INFO (USE DA101-A)				
DA401-B (1544-3) DIGITAL INPUT UNIT REF/CE INFO (USE DA101-A)				
DA502-E () DIGITAL OUTPUT UNIT REF/CE MANUAL DESC., DTAGS, W/L, PARTS DATA CE MANUAL	39909503	B	22	03.00
DC110-A (6641-A) ECS/MASS STORAGE ADAPTER CE MANUAL	60222100	K	22	06.00
DC111-A (3507-1) COMMUNICATION CHANNEL GENERAL DESCRIPTION, DIAGRAMS ** USE AC104-A IF 3504 COMPUTER SYSTEM ** USE AC106-A IF 3514 COMPUTER SYSTEM PARTS DATA (USE AC104-A) MAINT. AIDS 50-PAK STRIP TABS/MAPS (USE AC104-A)				
DC118-A (1775-1, 90105-1) A/O INTERRUPT CHAN. CE INFO (USE AB103-A)				
DC119-A (1779-1, 90109-1) CHARACTER HANDLING CE INFO (USE AB103-A)				
DC120-A (1773-1, 90106-1) DIRECT STORAGE ACCESS CHANNEL CE INFO (USE AB103-A)				
DC135-A (6642-1, 7030-XX) DISTRIBUTIVE DATA PATH CE MANUAL	60369400	D	22	11.95
DC136-A (1773-1) DIRECT STORAGE ACCESS CHANNEL CE INFO (USE AB103-A)				
DC137-A (1775-1) A/O INTERRUPT DATA CHANNEL CE INFO (USE AB103-A)				
DC145-A/B (6642-2) DISTRIBUTIVE DATA PATH HARDWARE MAINT. MANUAL	60425800	A	22	62.75
DC211-A (6684-A) DATA CHANNEL CONVERTER CE MANUAL	60125000	AZ	22	04.70
DC212-A (6684-2) CODE CONVERSION FOR 6684-1 CE INFO (USE DC211-A) REF INFO (USE 6681-R/C/D)				
DC215-A/B DATA TRANSFER BUFFER GEN.DESC,OPER AND PROG,INSTALL,CHKOUT,THEO,OF OPER,DIAGS,	65692300	A	22	06.00

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
DIAGNOSTIC, MAINT AIDS, P/L, W/L, EQ SUM, REF/CE				
DC216-A (SP. OP. 60128) DATA CHANNEL CONVERTER REF/CE MANUAL	60299902	C	22	02.20
DC220/DC221-A 1700 A/Q DSA ADAPTERS HARDWARE REFERENCE/CE MANUAL	39392700	C	22	07.30
DC401-A (SP. OP. 65075) MASS STORAGE EXTENDER CE MANUAL	60392600	C	22	08.80
DE101-A MULTIPLEX DATA CHANNEL GEN DESC, THEORY OF CP, DIAGS, MAINT CE MAN.	39524000	A	22	14.35
DF3A1-A (1555-1/4) RELAY OUTPUT UNIT REF/CE MANUAL	39909509	A	22	03.25
DJ101-A, DJ115-A DATA SET ADAPTERS CE MANUAL	41600600	B	22	02.45
DJ110-A (311-2) DATA SET ADAPTER THEORY OF OPERATION, INSTALLATION/CHECKOUT DIAGRAMS, MAINT., MAINT. AIDS, PARTS DATA, CE MANUAL	41603200	C	22	11.05
WIRE LIST, EQ SUMMARY CE MANUAL	41608100	A	22	05.85
DJ111-A (311-2) DATA SET ADAPTER CE INFO (USE DJ110-A)				
DJ112-A-B TRANSCEIVER CE MANUAL	41605400	B	22	03.30
DJ113-A/B (358-2) TRANSCEIVER CE MANUAL (INCLUDES PMI/PMP)	41606300	E	22	04.40
DJ114-A/B/C/D (358-3/4) TRANSCEIVER CE MANUAL	41601900	E	22	04.90
DJ115-A (327-2) DATA SET ADAPTER CE INFO (USE DJ101-A)				
DJ122-A (361-4) COMMUNICATIONS ADAPTER CE MANUAL	41609700	F	22	11.55
DJ130-A (792-10) AUTOMATIC CALLING ADAPTER CE INFO (USE FJ424-A/B/C)				
DJ140-A/B (124-1) SYNCHRONOUS MODEM CE MANUAL	41613400	F	22	01.50
DJ141-A (101-1) SYNCHRONOUS MODEM CE MANUAL	41613200	E	22	01.40
DJ142-A (361-1/3) COMMUNICATIONS ADAPTER REF INFO (USE 361-1)				

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
CE MANUAL	41612100	H	22	03.30
DJ143-A (361-1/2) COMMUNICATIONS ADAPTER REF INFO (USE 361-1) CE INFO (USE DJ142-A)				
DJ144-A (361-5) COMMUNICATIONS ADAPTER CE MANUAL	41611700	J	22	12.75
DJ145-A (361-6) SYNCHRONOUS COMMUNICATIONS ADAPTER CE MANUAL	41611900	M	22	05.35
DJ146-A (361-7) COMMUNICATIONS ADAPTER CE MANUAL	41612300	A	22	03.20
DJ151-A DATA SET ADAPTER REFERENCE/CE MANUAL	60344700	A	22	05.85
DJ152-A DATA SET ADAPTER REF/CE INFO (USE DJ151-A)				
DJ604-A (792-2) DATA SET ADAPTER CE INFO (USE FJ424-A/B/C)				
DJ605-A (792-3) DATA SET ADAPTER CE INFO (USE FJ424-A/B/C)				
DJ607-A (792-1) DATA SET ADAPTER CE INFO (USE FJ424-A/B/C)				
DJ805-A/B (304-1) COMMUNICATIONS MULTIPLEXER CE MANUAL	13796500	G	22	04.30
DJ808-A (364-1/2) COMMUNICATIONS MULTIPLEXER CE MANUAL	41611000	J	22	02.35
DJ813-A (364-3) COMMUNICATIONS MULTIPLEXER CE MANUAL	41612600	02	22	04.80
DJ814-A (364-4/5) COMMUNICATIONS MULTIPLEXER CE MANUAL	41612800	F	22	07.10
DJ815-A ASYNCHRONOUS COMMUNICATIONS CONTROLLER AND DISTRIBUTION PANEL CE MANUAL	89638300	02	22	05.35
DK501-A (ST. OPT. 10128) DUAL MODE OPTION CE MANUAL	41603100	D	22	03.00
DK502-A (ST. OPT. 10127) EXPANDED MEMORY OPTION CE MANUAL	41611200	D	22	03.00
DK509-A (362-1/2) TELEGRAPHIC LEVEL CONVERTER				

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
CE MANUAL	41610400	G	22	04.10
OK516-A (7700) MUX INCREMENT-1 CE INFO (USE AC113-A/B OR AA121-A AND AD102-A)				
OK518-A (7681-1) DATA CHANNEL CONVERTER CE MANUAL	60355900	F	22	06.35
OK520-A (7700) MUX INCREMENT-2 CE INFO (USE AC113-A/B OR AA121-A AND AD102-A)				
OK526-A (CYBER 1000) MEDIUM SPEED LINE CONTROLLER HARDWARE REFERENCE MANUAL	74606800	A	22	09.70
OK605-A (1595-10/11) SERIAL I/C UNIT REF/CE MANUAL	39909507	B	22	03.90
OK605-B (1595-20/21) SERIAL I/C UNIT REF/CE INFO (USE OK605-A)				
DN124-A USE 1590-3				
DT117-A (6500-A/B/C WITH ECS) ADDS ECS CAPABILITY TO 6500-A/B/C (USE AT195-A MANUAL)				
DT122-A (7683-1) REMOTE CHANNEL COUPLER REF/CE MANUAL	60296200	H	22	04.60
DT137-A (791-1/3/4) NORMAL OUTPUT CHANNEL CE INFO (USE FJ424-A/B/C)				
DT138-A (791-1/3/4) NORMAL INPUT CHANNEL CE INFO (USE FJ424-A/B/C)				
DT139-A (791-1) CHANNEL EXPANDER RECEIVERS AND TRANSMITTERS CE INFO (USE FJ424-A/B/C)				
DT141-A () 1700 A/Q COUPLER CE INFO (USE FF104-A)				
DT143-A () ADDS ECS CAPABILITY TO AA105-A OR 641X-D. (USE MANUALS UNDER AT194-A)				
DT158-A (7611-10) PL COUPLER CE MANUAL	60356300	D	22	05.00
DT160-A () TERMINAL COUPLER CE MANUAL	60318500	A	22	08.65

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
DT174-A (ST.OP.10266-1/2/3, 10280-1/2/3) DOP REGISTER INCREMENT (2,3 OR 4 PORT) CE INFO (USE DC135-A)				
DT175-A/B (7077-1) 6000 PL SAC COUPLER CE MANUAL	60352300	C	22	05.90
DT194-A (ST.OP. 10293-1) CHANNEL MODIFICATION				
DT196-A (ST.OP. 10293-1/2) CHANNEL MODIFICATON				
DT204-A (SP.OP. 60081-A) ECS INTERFACE LOGIC FOR 6400-A/B/C CENTRAL COMPUTER OR AUGMENTED I/O BUFFER AND CONTROLLER TO 6640 ECS USE 6400-A/B/C UNLESS AT197-A AND AT195-A OR AT196-A AND AT195-A ARE INSTALLED, IF SO SEE AT195-A.				
DT205-A (SP.OP. 60081-B) ECS INTERFACE LOGIC MAY BE INSTALLED IN 6400-D OR AA105. USE STANDARD MANUALS FOR THAT SYSTEM UNLESS AT194-A IS INSTALLED. IN THIS CASE SEE MANUALS LISTED UNDER AT194-A				
DT208-A (7611-10) PL COUPLER CE INFO (USE DT158-A)				
DT209-C (7054-1/2) 6000 COUPLER REF/CE MANUAL	60364100	R	22	16.10
DT209-D (7021-1/2) 6000 COUPLER				
DT210-A (7654-1) 7000 COUPLER REF/CE MANUAL	60364200	C	22	24.40
DT210-B (7622-1/2) 7000 COUPLER REF/CE INFO (USE DT210-A)				
DT220-A (7054-2, ST.OP 10285-1) DUAL ACCESS OPTION REF/CE INFO (USE DT209-C)				
DT220-B (7054-2) DUAL ACCESS OPTION REF/CE INFO (USE FA719-A/B/C/D COUPLER MAN)				
DT220-C (7054-22/42) SECOND CHANNEL FEATURE REF/CE INFO (USE FA722-A/B)				
DT221-A () REGISTER CE INFO (USE DC145-A/B)				
DT716-A (7054-41) DOUBLE DENSITY OPTION				

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
CE INFO (USE FA722-A/B)				
DW105-A (CYBER 1000) THREE-BAY EXCHANGE UNIT HARDWARE MAINTENANCE MANUAL	74720400	A	22	09.00
DW110-A (CYBER 1000) TWO-BAY EXCHANGE UNIT HARDWARE MAINTENANCE MANUAL	74717600	A	22	09.15
DW111-A USE DW105-A				
DY107/8/9/10-A (CYBER 1000) LINE MODULE EXTENSION CABINET HARDWARE MAINTENANCE MANUAL	74724500	A	22	06.40
DY120-A (CYBER 1000) MAGNETIC TAPE CONTROLLER HARDWARE MAINTENANCE MANUAL	74607500	B	22	08.95
DY121-A (CYBER 1000) FAST DISK CONTROLLER HARDWARE MAINTENANCE MANUAL	74691800	A	22	09.00
DY122-A (CYBER 1000) 3000 SERIES CONTROLLER- ADAPTER HARDWARE MAINTENANCE MANUAL	74660300	A	22	08.75
DY123-A (CYBER 1000) 1700 SERIES CONTROLLER- ADAPTER HARDWARE MAINTENANCE MANUAL	74675500	A	22	05.35
DY124-A (CYBER 1000) CONTROLLER EXTENSION CAB. HARDWARE MAINTENANCE MANUAL	74720500	A	22	05.05
DY127-A (CYBER 1000) HIGH-SPEED LINE CONTROL HARDWARE MAINTENANCE MANUAL	74664300	A	22	10.80
DY128-A (CYBER 1000) DISK PACK CONTROLLER HARDWARE MAINTENANCE MANUAL	73361200	B	22	07.15
DY129-A USE DY124-A				
EA102-A (1525-2) ANALOG TO DIGITAL CONVERTER GEN DESC, DIAGS, W/L, MAINT CE MANUAL	39473200	A	22	04.40
EA309-A (1525-3) ANALOG TO DIGITAL CONVERTER REF/CE MANUAL	39909506	B	22	04.00
EB201-A/EB202-A (DA-1) THIRTY TWO CHANNEL ELEVEN BIT DAC GEN DESC, INSTALLATION/CHECKOUT, DIAGS, W/L, MAINTENANCE, PARTS DATA, REF/CE MANUAL	39744900	A	22	03.90
EB3A1-A/D FOUR CHANNEL DIGITAL-TO-ANALOG CONVERTER GEN.DESC.,OP AND PROGRAMMING,INSTALLATION	88981100	A	22	03.90

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
AND CHECKOUT, THEORY OF OPERATIONS, DIAGRAMS, MAINTENANCE, MAINT. AIDS, PARTS DATA HARDWARE REFERENCE/CE MANUAL				
ED105-A (1501-10) ANALOG INPUT MULTIPLEXER REF/CE MANUAL	39909504	B	22	06.35
ED106-A (1501-11) ANALOG INPUT MULTIPLEXER EXPANDER REF/CE INFO (USE ED105-A)				
EE601-A TAPE CONTR AND MONITOR UNIT (TCM) HARDWARE REFERENCE/CE MANUAL	39222600	A	22	04.90
EL101-A (1750-1) COMPUTER INTERFACE UNIT REF/CE MANUAL	88980100	C	22	
EL102-A (1750-2) COMPUTER INTERFACE EXPANDER REF/CE INFO (USE EL101-A)				
FA102-A (1733-1) DISK STORAGE CONTROLLER CE MANUAL	60400100	F	22	18.10
FA103-A (7639-2) MASS STORAGE CONTROLLER HARDWARE MAINTENANCE MANUAL	60427600	B	22	47.45
FA202-A (7639-1/2) MASS STORAGE CONTROLLER HDWE MAINT INFO (USE FA103-A)				
FA203 CONTROLLER				
MICRODIAGNOSTICS USERS CE MANUAL	83315600	A	22	07.60
FLEXIBLE DISK DRIVE CE MANUAL	83315700	A	22	04.50
MICRODIAGNOSTIC DESCRIPTIONS CE MANUAL	83315800	A	22	03.85
THEORY OF OPERATION CE MANUAL	83316100	A	22	14.25
PARTS DATA CE MANUAL	83316200	A	22	08.75
HARDWARE MICROPROGRAM CE MANUAL	83316300	A	22	07.30
DIAGNOSTIC MICROPROGRAM CE MANUAL	83316400	A	22	18.70
DUAL ACCESS FEATURE MICROPROGRAM CE MANUAL	83316600	A	22	18.60
FA401-A/B (7021-1) 1X8 MAG TAPE CONTROLLER HARDWARE REFERENCE MANUAL CE MANUAL - VOL 1	60404000 60404100	C G	22 22	03.75 37.90
FA402-A/B (7021-2) 2X8 MAG TAPE CONTROLLER HARDWARE REF INFO (USE FA401-A/B)				
FA403-A/B (7622-1) 1X8 MAG TAPE CONTROLLER HARDWARE REF INFO (USE FA401-A/B)				
FA404-A/B (7622-2) 2X8 MAG TAPE CONTROLLER HARDWARE REF INFO (USE FA401-A/B)				
FA405-A/B (8194) MAGNETIC TAPE CONTROLLER				

1-Publication number of literature.

2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.

4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
CE MANUAL	13795900	G	22	05.05
FA407-A7 OR 9 TRACK MAGNETIC TAPE CONTROLLER, OPER., MAINT.INSTR. MANUAL	84942200		22	05.10
FA414-A/B (3121-A/B) MAGNETIC TAPE CONTROLLER CE MANUAL ** REFER ALSO TO CATALOG SEC. 2 FOR 609 TAPE TRANSPORT CE MANUALS	60210900	K,L	22	06.25
FA416-B (3518-1/2/3) MAG TAPE CONTROLLER CE MANUAL	60289100	BG	22	16.80
FA417-B (3518-2/3, 3528-2/3) MAGNETIC TAPE CONTROLLER CE INFO (USE FA416-B)				
FA418-A (3528-1/2/3) MAGNETIC TAPE CONTROLLER CE INFO (USE FA416-B)				
FA419-A (CYBER 1000) SEE DY120-A				
FA420-B (3518-3, 3528-3) MAG TAPE CONTROLLER CE INFO (USE FA416-B)				
FA423-A () MAGNETIC TAPE CONTROLLER REF/CE MANUAL (INCLUDES PMI/PMP) ** REFER ALSO TO CATALOG SECTION 2 FOR 604 AND 607 MAG TAPE TRANSPORT MANUALS	60291400	F	22	10.05
FA428-A (7618-1, 7629-1) 1X8 MAGNETIC TAPE CONTROLLER CE MANUAL	60321100	U	22	37.60
FA429-A (7628-1, 7629-2) 2X8 MAGNETIC TAPE CONTROLLER CE INFO (USE FA428-A)				
FA434-A/B (7622-1, 7021-1) 1X8 MAG TAPE CONTROL CE MANUAL HARDWARE REF INFO (USE FA401-A/B)	60365200	D	22	23.40
FA438-A/B (7622-2, 7021-2) 2X8 MAG TAPE CONTROL CE INFO (USE FA434-A/B) HARDWARE REF INFO (USE FA401-A/B)				
FA442 MAGNETIC TAPE CONTROLLER CE MANUAL	89637700	02	22	10.05
FA444-A/B (7021-21) MAG TAPE CONTROLLER HOWE MAINT. MANUAL	60438500	A	22	41.50

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
FA445-A/B (7021-22) MAG TAPE CONTROLLER MAINT INFO (USE FA444-A/B)				
FA446-A MTT (LCIT) CE MANUAL	89769500	01	22	06.40
FA601-A INTERIM DRUM CONTROLLER REF/CE MANUAL	60232300	B	22	05.60
FA7A3-A (OEM 9008-1) DISK CONTROLLER REF/CE INFO (USE 9008-1 CATALOG SEC 2)				
FA7A4-A/B PLUG COMPATABLE CONTROLLER MICROPROGRAM CE MANUAL	70614100	D	22	09.80
WIRE LIST CE MANUAL	70614000	E	22	11.55
DIAGRAMS CE MANUAL	70613900	H	22	05.40
THEORY OF OPERATION	70616700	A	22	04.50
MAINTENANCE CE MANUAL	70613800	G	22	05.10
FA7A4-C/D, FV1A1-A TWO CHANNEL PLUG COMPATABLE CONTROLLER CE MANUAL	70614200	B	22	06.25
FA7A5-A/B/C/D PLUG COMPATABLE CONTROLLER MICRO PROGRAM CE MANUAL	70621800	B	22	08.95
DIAGRAMS CE MANUAL (INCLUDES FV1A4-A)	70621600	G	22	07.25
THEORY OF OPERATIONS CE MANUAL	70621500	A	22	08.05
WIRE LISTS CE MANUAL	70621700	D	22	21.70
GENERAL DESCRIPTION, INSTALLATION AND CHECK- OUT THEO OF OPER., WIRE LIST CE MANUAL	70621900	A	22	15.50
FA701-A CONTROLLER 7600 INTERIM DISK FILE SYS	60232200	D	22	05.15
FA704-A/B (3553-2) MASS STORAGE CONTROLLER CE MANUAL	60266000	AE	22	20.35
FA704-C (3553-2) MASS STORAGE CONTROLLER CE MANUAL	60394700	H	22	36.50
FA705-A (3553-1) MASS STORAGE CONTROLLER CE MANUAL	60290000	R	22	12.05
FA705-B (3553-1) MASS STORAGE CONTROLLER CE MANUAL	60394600	D	22	35.95
FA710-A/B/C/D (7054-1) DISK CONTROLLER HARDWARE REFERENCE MANUAL	60364500	G	22	04.00
CE MANUAL - VOL 1 AND 2	60364000	N	22	36.15
FA710-F/F (7054-1) DISK CONTROLLER CE INFO (USE FA719-A CE MANUAL - 60405500)				
FA716 CARTRIDGE DISK CONTROLLER CE MANUAL	89638100	02	22	05.65

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
FA719-A/B/C/D (7054-1/2) DISK STORAGE CONTROLLER CE MANUAL (6000 COUPLER) CE MANUAL VOLS 1 AND 2	60416400 60405500	E G	22 22	11.50 32.60
FA720-A/B/C/D (7654-1) DISK STORAGE CONTROLLER CE MANUAL (ALSO USE FA719-A MANUAL - 60405500)	60410000	B	22	11.00
FA721 STORAGE CONTROL EIGHT VOLUME CAU FUNCTIONAL MICROPROGRAM CE MANUAL PREVENTIVE/CORRECTIVE MAINT, W/L, CE MAN V-2 DIAGRAMS VOLUME 2 CE MANUAL STANDARD DIAGNOSTICS MICROPROGRAM CE MANUAL INLINE DIAGNOSTICS MICROPROGRAM CE MANUAL 16 VOL. CAU FUNCTIONAL MICROPROGRAM MANUAL HARDWARE REFERENCE CE MANUAL PARTS DATA CE MANUAL	83302100 83301900 83302000 83312100 83312000 83311900 83301800 83306000	E E R C E E B F	22 22 22 22 22 22 22 22	18.70 07.95 27.85 25.75 18.25 18.45 06.90 03.85
FA722-A/B (7054-21/22/41/42) DISK STORAGE CONTROLLER HARDWARE MAINTENANCE MANUAL	60428500	J	22	28.00
FA802-A (7601-1, 7638-1) DISK/DRUM CONTROLLER REF INFO (USE 7638-1, CATALOG SECTION 2) CE MANUAL ** REFER ALSO TO BH405 MANUALS FOR DISK FILE DOCUMENTATION	60287200	N	22	08.80
FE107-A (1726-1) CARD READER CONTROLLER CE MANUAL	60232000	B	22	07.80
FE110-A (1729-2) CARD READER CONTROLLER CE MANUAL	60269200	G	22	04.50
FE119 CARD READER CE MANUAL	89637500	03	22	03.15
FE201-A (417-1) CARD PUNCH CONTROLLER REFERENCE/CE MANUAL	60283600	B	22	06.95
FE202-A/B (415-30) CARD PUNCH CONTROLLER REF/CE MANUAL	60425600	C	22	20.90
FE304-A (1728-A/B) CARD READER/PUNCH CONTROLLER CE MANUAL	60224000	M	22	03.75
FF103-A (1735) PAGE READER CONTROLLER CE MANUAL	60237700	H	22	08.95
FF104-A (955-1) PAGE AND DOCUMENT READER CONTROLLER				

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover binder that may be used for manuals.
4-Publication division responsible for contents of literature.

TITLE	1	2	3	4
CE MANUAL	60324700	A	22	12.10
FF307-B (3555-1) LINE PRINTER CONTROLLER CE MANUAL	60278800	S	22	20.40
FF406-A/B/C (1736-1) UNIT RECORD READER CONTROLLER CE MANUAL	60230200	06	22	08.80
GEN DESC, FLOW CHARTS, PROGRAM LISTINGS CE MANUAL	60283200	A	22	09.80
FF510-A/B (3254) LINE PRINTER CONTROLLER CE MANUAL (INCLUDES PMI-PMP)	60182400	J	22	11.00
FF511-A/B (1742) LINE PRINTER CONTROLLER CE MANUAL (INCLUDES PMI/PMP)	60183000	H	22	04.80
FF516-A (1740) LINE PRINTER CONTROLLER CE MANUAL	60223800	J	22	23.80
FF524-A LINE PRINTER CONTROLLER GEN. DESC., OPERATION AND PROGRAMMING, INSTALL- ATION AND CHECKOUT, THEORY OF OPERATION, DIAGRAMS, MAINTENANCE, PARTS DATA, WIRE LISTS CE MANUAL	89637300	04	22	03.00
FF525 PRINTER SUBSYSTEM CENTRAL CONTROL UNIT LOGIC DIAGRAMS THEORY OF OPERATIONS	22272500	A	34	09.55
	22272400	A	3	12.90
FJ101-A (1717-1) 1700 AUTODIN INTERFACE THEORY OF OPERATION, INSTALLATION/CHECKOUT DIAGRAMS, MAINT., MAINT. AIDS, PARTS DATA, CE MANUAL	41602200	B	22	03.95
CARD PLACEMENT, EXPRESSION FILE, UNIVERSAL WIRE DATA LISTS, WIRE LISTS CE MANUAL	41606400	B,C	22	04.85
FJ103-A/B/C/D/E (1748-2) MULTIPLEXER CONTROLER THEORY OF OPERATION, INSTALLATION CHECKOUT, DIAGRAMS, MAINT., MAINT. AIDS, PARTS DATA, CE MANUAL	41601700	J	22	04.35
CARD PLACEMENT, LOGIC WIRING, WIRE LISTS, EQUATION SUMMARY CE MANUAL	41603300	E	22	08.05
FJ124-A USE 1590-3				
FJ411-A/B (6671) DATA SET CONTROLLER DIAGRAMS, CIRCUIT DESCRIPTION, PARTS LIST, CARD PLACEMENT, EQUATION SUMMARY, WIRE LISTS CE MANUAL	60217400	W	22	27.00
MAINTENANCE, MAINTENANCE AIDS CE MANUAL (INCLUDES PMI/PMP)	60251300	E	22	16.25

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.

4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
FJ412-A/B/C (1747) DATA SET CONTROLLER THEORY OF OPERATION, INSTALLATION CHECKOUT DIAGRAMS, MAINTENANCE, MAINT. AIDS, PARTS DATA CE MANUAL	13799100	E	22	04.05
WIRE LISTS, EQUATION SUMMARY CE MANUAL	13799200	E	22	03.40
FJ413-A (313, 314, 317, 318) RECEIVE CONTROL UNIT REF INFO (SEE APPROPRIATE PRODUCT, CATALOG SECTION 2) CE MANUAL	13798100	G	22	03.80
FJ414-A (313, 314, 317, 318) SEND CONTROL UNIT REF INFO (SEE APPROPRIATE PRODUCT, CATALOG SECTION 2) CE INFO (USE FJ413-A) INSTRUCTION CARD	60368000	B		01.00
FJ415-A (1717-1) AUTODIN INTERFACE UNIT THEORY OF OPERATION, INSTALLATION/CHECKOUT DIAGRAMS, MAINTENANCE, MAINT. AIDS, PARTS DATA CE MANUAL	13797900	B-E	22	05.45
CARD PLACEMENT, EXPRESSION FILE, UNIVERSAL WIRE DATA LIST, WIRE LISTS CE MANUAL	41605600	C	22	10.30
FJ424-A/B/C (791-1) LOCAL COMMUNICATIONS CONTROLLER CE MANUAL	60321800	T	22	23.50
FJ427-A (6671-1) DATA SET CONTROLLER MAINTENANCE, MAINT. AIDS CE INFO (USE FJ411-A/B) INSTALLATION/CHECKOUT, DIAGRAMS, PARTS DATA, WIRE LISTS, EQ. SUMMARY CE MANUAL	60294500	K	22	11.90
FJ430-A/B (7077-1) STORAGE ACCESS CONTROLLER CE MANUAL	60316500	D	22	24.75
FJ440-A (6671-3) DATA SET CONTROLLER CE MANUAL - VOLUME 1	60409200	B	22	34.15
MAINTENANCE, MAINTENANCE AIDS CE MAN. VOL 2	60425100	A	22	18.55
FJ601-A (3316-1, 3516-1) MULTIPLEXER CONTROLLER THEORY OF OPERATION, INSTALLATION/CHECKOUT DIAGRAMS, MAINTENANCE, MAINT. AIDS, PARTS DATA, WIRE LISTS CE MANUAL	13796700	K	22	06.15
CROSS TABS, LOGIC WIRING, EQ SUMMARY CE MAN.	13798800	H	22	06.20
TEST ROUTINE CE MANUAL	41600300	A	22	01.35
FJ606-A SYNCHRONOUS COMMUNICATIONS CONTROLLER AND DISTRIBUTION PANEL CE MANUAL	89638500	01	22	04.20
FL303-A TAGGED DATA BUS OUTPUT INTERFACES TOB/	39231200	A	22	02.05

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
DSA INTERFE-TDI T03/DAC INTERFACE DAI HOWE REFEREND/CE MANUAL				
FR101-B () BUFFER CONTROLLER REFERENCE MANUAL	60275000	C	22	01.00
CE MANUAL	60278300	H	22	06.55
FR113-A (731-10/12, 732-10/12) BUFFER CONTROLLER				
CE MANUAL	60335400	M	22	08.70
DIAGNOSTIC REFERENCE MANUAL - VOLS 1/2/3	60400300	D	22	25.00
MAINTENANCE CE MANUAL	70621400	F	22	06.10
IBM 360 BUFFER CONTROLLER DIAGNOSTIC LISTING	60401600	A	22	02.80
23141/23142 MADCOP CE MANUAL				
IBM 360 BUFFER CONTROLLER DIAGNOSTIC LISTING	60401500	A	22	28.15
23141/23142 FODDER CE MANUAL				
BUFFER CONTROLLER DIAGNOSTIC LISTINGS -				
HSB 512 LINE PRINTER TEST (LP1) CE MANUAL	60401700	B	22	03.95
HSR 80X16 DRUM/DISPLAY TEST (DD2) CE MAN.	60401800	A	22	09.45
200 NSEC MEMORY TEST (MY1) CE MANUAL	60402100	A	22	01.20
200 NSEC MEMORY TEST (MY2) CE MANUAL	60402200	A	22	01.00
LSRT/MSRT DISPLAY/KEYBOARD/OPERATOR	60402700	C	22	05.65
CONSOLE TEST (DD6) CE MANUAL				
200 NSEC MEMORY TEST (BCM) CE MANUAL	60402900	A	22	01.30
FR114-A () CONSOLE DISPLAY CONTROLLER GEN DESC, DIAGRAMS, WIRE LISTS CE MANUAL	60365700	A	22	09.60
FT1A1-A (1547-1) EVENTS COUNTER UNIT REF/CE MANUAL	39909508	A	22	05.35
FT1A1-B (1547-2) EVENTS COUNTER UNIT REF/CE INFO (USE FT1A1-A)				
FT103-A/B TRANSFER SWITCH CONTROLLER REF/CE INFO (USE 8271 - CATALOG SEC 2)				
FT104-A TRANSFER SWITCH CONTROLLER REF/CE INFO (USE 8271 - CATALOG SEC 2)				
FT111-A () POWER FAULT DETECTOR CE MANUAL	60367400	A	22	05.05
FV129-A (3516-1) MULTIPLEXER CONTROLLER ADAPTER UNIT CE MANUAL	41608500	C	22	03.00
FV138-A DISPLAY STATION ADAPTER KIT (EDIT) REF/CE INFO (USE FV135-A)				
FV149-A (ST. OPT. 10194-2) ASCII HOLLERITH TO BCD CONVERSION KIT FOR THE 3447-B CARD READER CONTROLLER				

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.

4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
REF INFO (USE 3248-A REF MAN, CATALOG SEC 2) CE MANUAL	60292600	D	22	07.65
FV150-A (ST. OPT. 10194-1) INTERNAL BCD TO ASCII HOLLERITH CONVERSION KIT FOR THE 3446-A/B CARD PUNCH CONTROLLER REF INFO (USE 3446-A/B REF MAN, CAT. SEC 2) CE MANUAL	60292700	C	22	02.50
FV156-A () 4K MEMORY CE MANUAL	60309700	B-G	22	07.35
FV165-A (791-2) EXPANSION UNIT CE INFO (USE FJ424-A/B/C)				
FV216A SWITCH UNIT HARDWARE/REF CE MANUAL	39368600	A	22	05.65
FV217-A () INTERIM MEDIUM SPEED BATCH SUBSYSTEM CE INFO (USE DT160-A)				
FV218-A/B (733-10) HSB SUBSYSTEM/TERMINAL CONTROLLER CE MANUAL	60329700	V	22	23.20
FV227-A/B (1739-1) CARTRIDGE DISK DRIVE CONTROLLER CE MANUAL	60368500	B	22	07.50
FV4A3 (1576) STALL ALARM UNIT				
FV409-A (7611-10) DRUM AND DISPLAY LOGIC REFERENCE/CE MANUAL	60318600	D	22	07.30
FV410-A (7611-10) DRUM AND DISPLAY LOGIC REF/CE INFO (USE FV409-A)				
FV433-A, FV434-A, FV435-A, FV436-A DRUM AND DISPLAY LOGIC REF/CE MANUAL	60363300	L	22	05.45
FV437-A (733-1XX) HSB SUBSYSTEM/TERMINAL RECEIVER/TRANSMITTER OPTION CE INFO (USE FV218-A)				
FV444-A () POWER REGULATOR MODULE CE INFO (USE BB372-A)				
FV497-A/FV613-A PHASE ENCODING FORMATTER CE MANUAL	89796100	01	22	06.60
FV498 (1576) STALL ALARM UNIT CII PRINT CARTRIDGE HARDWARE REFERENCE MAN	91860200	A	22	01.65

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
FV605 CONTROLLER ADAPTER UNIT				
PARTS DATA CE MANUAL	83306300	C	22	03.65
GENERAL DESCRIPTION, THEORY OF OPERATION	83306100	B	22	04.95
PREVENTIVE/CORRECTIVE MAINTENANCE, DIAGRAMS, WIRE LISTS CE MANUAL	83315400	A	22	21.10
FV618-A CE INFO USE FV497				
GA103-A/B/C (ST. OPT. 10126) INTERVAL TIMER				
THEORY OF OPERATION, INSTALLATION/CHECKOUT DIAGRAMS, MAINTENANCE, MAINT. AIDS, PARTS DATA CE MANUAL	41601000	C	22	04.00
WIRE LISTS, EQUATION SUMMARY CE MANUAL	41602500	C	22	04.00
GA104-A/B (ST. OPT. 10126) TIME OF DAY CLOCK CE MANUAL	41602900	B	22	04.90
GA107 LINE SYNCHRONIZED TIMING GENERATOR HARDWARE/REFERENCE MANUAL	39359900	A	22	01.95
GA128-A (1572-1) SAMPLE TIMING UNIT REF/CE MANUAL	39909505	C	22	03.15
GD104-A (90115-1) POWER SUPPLY - 400HZ CE INFO (USE AB103-A)				
GD105-A (90115-1) POWER SUPPLY - 50HZ CE INFO (USE AB103-A)				
GD106-A (90115-1) POWER SUPPLY - 60HZ CE INFO (USE AB103-A)				
GD108-A/B (60130-1) LOOP CURRENT POWER SUPPLY REF/CE INFO (USE GH407-A/B)				
GD306-A/B (364-1/4, 10193-1) POWER SUPPLY REF/CE INFO (USE GH407-A/B)				
GE210-A/B (90115-4) FREQUENCY CONVERTER				
GE226-A (7601-1) FREQUENCY CONVERTER CE INFO (USE MOTOR GENERATOR CE MANUAL - SEE MOTOR GENERATOR SETS, CATALOG SECTION 4)				
GE232-A (7601-1, 7611-1/2) FREQUENCY CONVERTER CE INFO (USE MOTOR GENERATOR CE MANUAL - SEE MOTOR GENERATOR SETS, CATALOG SECTION 4)				
GG105-A (303-1) COMMUNICATIONS EXPANSION UNIT CE MANUAL	13799800	B	22	06.40
GH104-A (3502) POWER MODULE				

1-Publication number of literature.

2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.

4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
CE INFO (USE BB313-A)				
GH105-A/B/C (76XX) POWER DISTRIBUTION AND WARNING SYSTEM CE MANUAL	60298400	G	22	05.25
GH105-D (76XX) POWER DISTRIBUTION UNIT CE MANUAL	60298600	L	22	10.30
GH107-B/ED301-E MULTIPLEXER (MX-7A) GEN DESC, DIAGS, W/L, PARTS DATA CE MANUAL	39660400	B	22	03.30
GH107/ED301-F ANALOG MULTIPLEXER GEN DESC, W/L, PARTS DATA CE MANUAL	39690100	A	22	04.50
GH110-A/B () 2-TON CONDENSING UNIT ** REFER ALSO TO VENDOR MANUALS, CATALOG REFRIGERATION INFO (USE GH214-B)				
GH214-A (7601-1,) TEN TON REFRIGERATION UNIT (WATER COOLED) CE MANUAL	60298100	F	22	06.60
GH214-B () 10-TON CONDENSING UNIT REFRIGERATION CE MANUAL	60367300	G	22	09.35
GH216-A (7611-1/2) 2 TON REFRIGERATION UNIT (AIR COOLED) CE INFO (USE GH214-A)				
GH218-A (7611-1/2) 2 TON REFRIGERATION UNIT (WATER COOLED) CE INFO (USE GH214-A)				
GH223-A (76-XXX) CONDENSING UNIT CE MANUAL	60427800	A	22	10.30
GH401-A (90114-1) CABINETY CE INFO (USE AB103-A)				
GH407-A/B (362-1, 364-1, 364-4) GENERAL PURPOSE CABINET REFERENCE/CE MANUAL	41614300	E	22	02.85
GH408-A/B (7077-1) CENTRAL STORAGE CABINET CE MANUAL	60316600	F	22	13.45
GH417-A/B () CABINETY CE INFO (USE AB103-A)				
GH427-A/B DESK CABINET HARDWARE MAINTENANCE MANUAL	22261700	A	3	04.00

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
GH428-A (173-X,174-X) USE AA107-A				
GH432-A/B DESK CABINET HARDWARE REF/CE MANUAL	91628700	A	22	04.30
GH506-A (76-XXX) POWER DISTRIBUTION UNIT 60HZ CE INFO (USE AA106-A)				
GH506-B (76-XXX) POWER DISTRIBUTION UNIT 50HZ CE INFO (USE AA106-A)				
GJ1A1 (5560) POWERED FORMS STACKER GEN DESC., OPER, DIAGS, MAINT AIDS, PARTS DATA CE MAN.	50580900	C	3	02.55
GJ1A1-A/B-CIT POWERED FORMS STACKER REF/CE	91860300	A	22	02.35
GJ1A2 (5570) MANUAL FORMS STACKER GEN DESC., OPER, DIAGS, MAINT AIDS, PARTS DATA CE MAN.	50582000	C	22	01.00
GJ102-A (1778-1, 90122-1) PAPER TAPE READER HANDLER CE INFO (USE CE305-A/B) ** REFER ALSO TO VENDOR MANUALS, CATALOG SEC. 4 FOR REMEX TAPE SPOOLER CE MANUAL				
GJ103-A/B (1778-2, 90124-1/2) PAPER TAPE PUNCH HANDLER CE INFO (USE CE305-A/B) SEC. 4 FOR NCR EM-B3 TAPE TRANSPORT CE MANUAL				
GJ104 MANUAL FORMS STACKER GEN DESC, OPERATION DIAGRAMS, MAINTENANCE, PARTS DATA CE MAN	50584100	B	22	01.35
GJ105A/B POWERED FORMS STACKER GEN DESC., OPER, DIAGS, MAINT, MAINT AIDS, PARTS DATA CE MAN	50583500	C	22	02.95
GK102 (673) TAPE EXERCISER REF/CE MANUAL	49803700	A	22	03.40
GK111 (SP. OPT 65006) TAPE EXERCISER REF/CE MANUAL	49803800	A	22	03.30
GK153-A () DATA CHANNEL LONG LINE DRIVER CE INFO (USE AB103-A)				
GK154-A () DATA CHANNEL LONG LINE DRIVER CE INFO (USE AB103-A)				
GK181-A (76XX) I/O STATION CABINET MODIFICATION KIT CE INFO (USE GH105-D)				

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
GL102 (686) MAGNETIC TAPE CERTIFIER GENERAL DESCRIPTION, OPERATION, INSTALLATION CHECKOUT, MAINT. CE MANUAL (INCLUDES PMI/PMP)	40867500	C	22	14.40
THEORY OF OPERATION, DIAGRAMS, W/L CE MANUAL	40867700	G	22	06.45
PARTS LIST (A04, B04 AND ABOVE) CE MANUAL	41240600	C	22	02.95
OPERATORS CE MANUAL	70605900	A	22	02.10
GL112-A (90107-1) CONSOLE CE INFO (USE AB103-A)				
MB434-A CONTROLWARE (6000) (USE FA401-A/B CE MANUAL VOL 1 OR FA444-A/B)				
MB435-A CONTROLWARE (7000) (USE FA401-A/B CE MANUAL VOL 1)				
SD101 SOURCE DATA COLLECTION TERMINAL HARDWARE PROGRAMMING MANUAL	62056300	A	22	01.35
TB101 PERIPHERAL EXERCISER--LISTED AS 9910				
TB101-B/9910-B PERIPHERAL EXERCISER				
TB115-A FIELD TEST UNIT DIAGRAMS, WIRE LISTS, PARTS DATA, GEN. DESC, OPERATIONS CE MANUAL	70604000	A	22	04.90
TB204 FIELD TEST EXERCISER CE MANUAL	83302900	B	22	03.10
TB207-A FIELD TEST UNIT MAINTENANCE MANUAL	83307900	B	3	04.65
TB301-A/B FIELD TEST EXERCISER MAINT. MANUAL	70612800	G	3	05.00
TB3A1 FIELD TEST UNIT GEN DESC., INSTALLATION AND OPERATION, THEO. OF OPERATION, MAINT., DIAGRAMS AND W/L, PART DATA CE MANUAL	83303700	B	22	05.35
TB302 FIELD TEST UNIT CE MANUAL	83308000	B	22	06.75
TB4A1-A FIELD TEST UNIT MAINTENANCE MANUAL	83312300	A	3	12.15

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

SECTION 2

The manuals in this section are listed by Product or System Number. Many entries include a product to equipment cross reference; e.g. 1742 {CL309-A/B, FF511-A/B}. Since Hardware Manuals for equipment developed after November, 1967 are categorized by equipment designator, always look up the equipment designator in Section 1 as well as the Product Number.

TITLE	1	2	3	4
<p>CYBER 72/73/74</p> <p>72-12 (6681-D, AA115-A, CC538-A/B)</p> <p>72-13 (6681-D, AA115-A, AT232-A, CC538-A/B)</p> <p>72-14 (6681-D, AA115-A, AT231-A, AT232-A, CC538-A/B)</p> <p>72-16 (6681-D, AA115-A, AT231-A, AT232-A, AT237-A, CC538-A/B)</p> <p>72-18 (6681-D, AA115-A, AT231-A, AT232-A, AT236-A, AT237-A, CC538-A/B)</p> <p>72-24 (6681-D, AA115-A, AT227-A, AT231-A, AT232-A, CC538-A/B)</p> <p>72-26 (6681-D, AA115-A, AT227-A, AT231-A, AT232-A, AT237-A, CC538-A/B)</p> <p>72-28 (6681-D, AA115-A, AT227-A, AT231-A, AT232-A, AT236-A, AT237-A, CC538-A/B)</p> <p>73-12 (6681-D, AA115-A, AT226-A, CC538-A/B)</p> <p>73-13 (6681-D, AA115-A, AT226-A, AT232-A, CC538-A/B)</p> <p>73-14 (6681-D, AA115-A, AT226-A, AT231-A, AT232-A, CC538-A/B)</p> <p>73-16 (6681-D, AA115-A, AT226-A, AT231-A, AT232-A, AT237-A, CC538-A/B)</p> <p>73-18 (6681-D, AA115-A, AT226-A, AT231-A, AT232-A, AT236-A, AT237-A, CC538-A/B)</p> <p>73-24 (6681-D, AA115-A, AT226-A, AT227-A, AT231-A, AT232-A, CC538-A/B)</p> <p>73-26 (6681-D, AA115-A, AT226-A, AT227-A, AT231-A, AT232-A, AT237-A, CC538-A/B)</p> <p>73-28 (6681-D, AA115-A, AT226-A, AT227-A, AT231-A, AT232-A, AT236-A, AT237-A, CC538-A/B)</p> <p>74-12 (6681-D, AA117-A, BB397-A, CC538-A/B)</p> <p>74-13 (6681-D, AA117-A, AT239-A, BB397-A, CC538-A/B)</p> <p>74-14 (6681-D, AA117-A, CC538-A/B)</p> <p>74-16 (6681-D, AA117-A, AT237-A, CC538-A/B)</p> <p>74-18 (6681-D, AA117-A, AT236-A, AT237-A, CC538-A/B)</p> <p>74-24 (6681-D, AA117-A, AE116-D, CC538-A/B)</p> <p>74-26 (6681-D, AA117-A, AE116-D, AT237-A, CC538-A/B)</p> <p>74-28 (6681-D, AA117-A, AE116-D, AT236-A, AT237-A, CC538-A/B)</p> <p>REFERENCE MANUALS (HARDWARE)</p> <p>ORDER VOL.2 AND APPROPRIATE VOL 1 FOR A COMPLETE REFERENCE MANUAL. ORDER VOL.3 IF SYSTEM CONTAINS FCS.</p> <p>MODEL 72 SYS DESC/PROGRAMMING INFO-VOL 1</p> <p>MODEL 73 SYS DESC/PROGRAMMING INFO-VOL 1</p>				
	60347000	H	22	01.05
	60347200	E	22	01.20

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover binder that may be used for manuals.
4-Publication division responsible for contents of literature.

TITLE	1	2	3	4
MODEL 74 SYS DESC/PROGRAMMING INFO-VOL 1	60347400	K	22	02.05
MODEL 72/73/74 INSTRUCTION DESC. VOL 2	60347300	J	22	01.25
MODEL 72/73/74 ECS DESC/PROGRAMMING VOL 3	60347100	D	22	01.00
MODEL 72/73/74 INPUT/OUTPUT SPECIFICATIONS (INCLUDES 6000)	60352500	E	22	01.00
CYBER 76				
76-111 (AA106-A, AB101-A, GH506-A/B, GE226-A/B, GH214-C/D, CC522-A/B, CE149-A/B AT311-A)				
76-112 (AA106-A, AB101-A, GH506-A/B, GE226-A/B, GH214-C/D, CC522-A/B, CE149-A/B AT311-A, BB360-B)				
76-121 (AA106-A, AB101-A, GH506-A/B, GE226-A/B, GH214-C/D, CC522-A/B, CE149-A/B AT311-A, BS101-A)				
76-122 (AA106-A, AB101-A, GH506-A/B, GE226-A/B, GH214-C/D, CC522-A/B, CE149-A/B AT311-A, BS101-A, BB360-B)				
76-142 (AA106-A, AB101-A, GH506-A/B, GE226-A/B, GH223-A, CC522-A/B, CE149-A/B, BS101-A, BS102-A, BB360-B, AT311-A)				
REF MANUAL (HARDWARE)	60367200	C	22	06.70
SMMV3 REFERENCE MANUAL VOLS 1,2,3 (INC.7600)	60373900	C	22	45.00
I/O SPECIFICATIONS (INCLUDES 7600)	60408700	B	22	01.00
CYBER 172/173/174 COMPUTER SYSTEMS				
INPUT/OUTPUT SPECIFICATIONS MANUAL (INCLUDES MODEL 175)	19983600	02	22	00.70
CYBER 175				
175-4 (AA120-A, GE258-A/B, CC545-A/B, GH223-A)				
175-6 (AA120-A, GE258-A/B, CC545-A/B, GH223-A, BS110-A)				
175-8 (AA120-A, GE258-A/B, CC545-A/B, GH223-A, BS107-A)				
175-12 (AA120-A, GE258-A/B, CC545-A/B, GH223-A, BS107-A)				
175-16 (AA120-A, GE258-A/B, CC545-A/B, GH223-A, BS107-A)				
HARDWARE REFERENCE MANUAL INPUT/OUTPUT SPECS (SEE CYBER 172/173/174)	60420000	03	22	01.70
CYBER 1000 HARDWARE SEE DW105-A, DY121/122/123 124/127/129				
G-15 COMPUTER REFERENCE MANUALS				
DIGITAL COMPUTER SYSTEM MANUAL	60061300			02.00
INTERCOM 1000 INSTRUCTION CAPD (G-15)	60062300			00.50

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.

4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
OPERATION MANUAL	60062400			02.20
PA-3 GRAPH PLOTTER REFERENCE	60181800			03.00
PROGRAMMING MANUAL	60062500			07.00
REFERENCE CARD (PAPER STOCK) (G-15)	60062600			00.50
REFERENCE CARD (PLASTIC STOCK) (G15)	60062600			00.75
CUSTOMER ENGINEERING MANUALS				
PARTS MANUAL	60061400			04.30
CE DIAGRAMS	60063000	A		03.60
CA-2 CARD ACCESSORY (AET-01631)	60063100	A		08.00
AN-1 ALPHANUMERIC ACCESSORY MANUAL	60064000			03.50
DA-1 DIFFERENTIAL ANALYZER	60064800			05.00
DIAPER (DIAGNOSTIC ROUTINES)	60064900			10.00
ANC-2 ALPHANUMERIC COUPLER	60065000			03.20
PA-3 GRAPH PLOTTER	60104500			04.20
THEORY OF OPERATION AND SIMPLIFIED DRAWINGS	60121600		22	12.75
DIGITAL MAGNETIC TAPE HANDLER (POTTER MODEL MTA) (902) INSTRUCTION MANUAL INCLUDING MTA-2 PARTS LIST	60124600			01.20
MTA-2 MAGNETIC TAPE UNIT ACCESSORY	AEG05571		22	03.45
PR-2 PHOTOELECTRIC TAPE READER	AET01621	A		06.60
MTA-2 MAGNETIC TAPE ACCESSORY	AET05613			03.50
PTP-1 PAPER TAPE PUNCH	AET09611			05.40
ANC-1 (OUTLINE, DISCUSSION, INSTALLATION AND DRAWINGS)				
(THE FOLLOWING MANUALS FOR THE ABOVE G-15 COMPUTER PRODUCT LINE ARE AVAILABLE ON A SPECIAL ORDER BASIS IN MAX. QTY OF 2 COPIES. ALLOW AT LEAST 3-4 WEEKS FOR PROCESSING AND DELIVERY. PRICE AVAILABLE UPON REQUEST				
SERVICE MANUAL MTA-3 (AET-5611)	60164600			
SERVICE MANUAL MTA-4 (AET-10621)	60164700			
OPERATORS MANUAL MTA-4 (AEG-10621)	60164800			
G-20 COMPUTER REFERENCE MANUALS				
CONTROL BUFFER/MACHINE LANGUAGE (CB-11)	60061800			05.20
GENERAL REFERENCE MANUAL	60061000	A	22	08.00
OPERATING MANUAL	60061700			12.20
REFERENCE CARD (G-20)				
CUSTOMER ENGINEERING MANUALS				
88 SERVICE MANUAL	BER05625			07.00
1402 CARD READER/PUNCH REFR/INSTRUCTION	60063200			08.50
LP-12 HIGH SPEED PRINTER (INCL. DIAGRAMS)	60062900			10.00
PC-10 CARD PRINTER COUPLER SERVICE	BER11621		22	10.05
CB-11 BUFFER CONTROL CE DIAGRAMS	60063400	A	34	03.25
CB-11 CONTROL BUFFER/SERVICE MANUAL VOL 1	60063700			10.00
CB-11 CONTROL BUFFER/SERVICE MANUAL VOL 2	60063800			05.00

1-Publication number of literature.

2-The latest revision level.

3-Indicates size of hard cover binder that may be used for manuals.

4-Publication division responsible for contents of literature.

TITLE	1	2	3	4
ENGINEERING DESIGN HANDBOOK FOR THE G-20 PT-10 SERVICE MANUAL (8ER07621)	60129400 60042800		22	04.50 04.60
(THE FOLLOWING MANUALS FOR THE ABOVE G-20 COMPUTER PRODUCT LINE ARE AVAILABLE ON A SPECIAL ORDER BASIS IN MAX. QTY OF 2 COPIES. ALLOW AT LEAST 3-4 WEEKS FOR PROCESSING AND DELIVERY. PRICE AVAILABLE UPON REQUEST				
MT-10 DIAGRAMS	60063500			
MM-10 DIAGRAMS	60064400			
LP-10 DIAGRAMS	60064500			
PC-10 DIAGRAMS	60064300			
PT-10 DIAGRAMS	60064600			
CC-10 DIAGRAMS	60064700			
G-20 CENTRAL PROC. SERVICE MANUAL VOL. 1 (8ER-10622)	60211400			
G-20 CENTRAL PROC. SERVICE MANUAL VOL. 2	60211500			
LINE PRINTER EQUIPMENT (1742,3010,3254,8130 PRODUCT) CE MANUAL	47967000	F	22	08.25
LGP 21 COMPUTER SYSTEM				
MAINTENANCE AND TRAINING MANUAL (INCLUDES TALLY TAPE READER, TALLY TAPE PERFORATOR AND MODEL 101 VISUAL OSCILLOSCOPE DISPLAY)	ESD10600	-	22	07.00
PROGRAMMING MANUAL	SC200100			03.00
REFERENCE MANUAL	SC2000			02.55
LGP 30 COMPUTER SYSTEM				
MAINTENANCE MANUAL	ESD10400		3	06.35
OPERATIONS MANUAL	SC0633			01.00
PROGRAMMING CLASS NOTES	SC0001			02.00
PROGRAMMING MANUAL	SC0576			06.00
RPC 4000 MAINTENANCE AND TRAINING MANUAL MANUAL (INCLUDES RPC 4010 AND RPC 4500)	ESD10501			12.00
REFERENCE MANUAL	SC4006			12.00
RPC 4290 TRANSLATOR MAINT AND TRAINING MANUAL (INCLUDES RPC 4410,4435,4440,180 AND 891)	ESD10505			15.75
SCM-M-120 PRINTER AND 1095-D PRINTER ADAPTER REF/CE MANUAL	41605900	C	22	04.25
0101 BADGE READER AND ADAPTER REFERENCE MAN. CE DIAGRAMS	36818300 36818500	B C	22 22	01.75 02.00
0101-R/D BADGE READER 2010 BADGE READER ADAPTER DIAGRAMS	65715000	B	22	01.40
ILLUSTRATED PARTS MANUAL	65715100	B	22	01.60
MAINTENANCE MANUAL	65714900	A	22	01.80

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.

4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
0101-C/0107-B BADGE READER REFERENCE MANUAL CE MANUAL	13792800 13792000	A H	22 22	01.10 02.25
0120-C SCALE ADAPTER REFERENCE/CE MANUAL	13794900	A	22	03.50
0202 REMOTE TERMINAL HARDWARE REF/CE MANUAL	65739900	B	22	10.00
101-1 (DJ141-A) SYNCHRONOUS MODEM				
124-1 (DJ140-A/B) SYNCHRONOUS MODEM				
150-A CARD TESTER				
(THE FOLLOWING MANUAL FOR THE 150-A CARD TESTER IS AVAILABLE ON A SPECIAL ORDER BASIS IN MAX. QTY OF 2 COPIES. ALLOW AT LEAST 3-4 WEEKS FOR PROCESSING AND DELIVERY.) PRICE AVAILABLE UPON REQUEST REFERENCE/INSTRUCTION AND DIAGRAMS MANUAL	60002600			
151-A CARD TESTER INSTRUCTION MANUAL	60018400	B		15.45
152 CARD TESTER MOD A CE MAINTENANCE MANUAL ILLUSTRATED PARTS LIST, MOD A (6/65)	40814400 40812800	A	22	09.75 03.50
160-B COMPUTER (FORMERLY 160 COMPUTER) REFERENCE MAN COMPUTER SYSTEM COMPUTING CENTER OPERATION DESCRIPTION AND OPERATION VOL 1 INSTALLATION MAN INSTRUCTION CARD (PLASTIC) SATELLITE PROGRAMMING MAN	60002300 60020900 60006800 60007200 60070100 60018700	C B	 22	03.75 03.25 07.75 03.25 00.75 02.40
CUSTOMER ENGINEERING MANUALS				
CARD PLACEMENT AND EQUATION SUMMARY	60007100	C	22	04.75
CARD PLACEMENT AND EQUATIONS (SERIALS 0-33)	60185500	A	22	04.90
CE DIAGRAMS	60007000	F	34	03.00
CE DIAGRAMS (SERIALS 0-30)	60150900	A	34	02.20
VOL 2 MAINTENANCE	60006900	B		06.00
PERIPHERAL EQUIPMENT CODES	60024900			01.35
STAND ALONE DIAGNOSTIC SYSTEM REFERENCE MAN.	60270200	A	22	07.30
160-A COMPUTER PROGRAMMING PRIMER OF MESSAGE SWITCHING SYSTEMS 160-A INSTRUCTION CARDS REFERENCE MANUAL (COMPUTER) SPECIFICATION (I/O) STAND ALONE DIAGNOSTIC SYSTEM (SAD) VOLS. I, II, III REFERENCE MANUAL INSTALLATION MANUAL	36810300 60070200 60014500 60002500 60272200 60018500	 A G F A	 22 22 22	01.25 00.75 01.65 02.00 30.00 02.70

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.

4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
CUSTOMER ENGINEERING MANUALS				
160-A WIRE LISTS	24107700	E	22	07.80
160-A CHANNEL ADAPTER OPERATION AND MAINT.	39072500			01.60
BUFFER CHANNEL LONG LINE DRIVE CE MANUAL	60123600	A		01.00
CARD PLACEMENT AND EQUATION SUMMARY	60014300	L	22	05.80
CE INSTRUCTION MANUAL-PART 1, THEO OF OPER	60014000	E	22	14.10
CE DIAGRAMS	60014200	R	22	02.40
DESC, OPERATION, MAINT.(PARTS LIST) CE MAN.	60014100	D	22	03.25
MASTER CONTROL SYSTEM MAINT MONITOR VOL 1	60104600	D	22	12.00
MASTER CONTROL SYSTEM MAINT MONITOR VOL 2	60104700	C	22	04.90
MASTER CONTROL SYSTEM MAINT MONITOR PROGRAM	60112800	G	22	45.00
LISTINGS VOLS 1 AND 2				
CHECKING PULSE WIDTHS ON 160-A/169 CLOCKED	60119100			01.50
INVERTER CARDS				
161-A/B ON-LINE INPUT/OUTPUT TYPEWRITER				
REFERENCE/INSTRUCTION MANUAL	60007300	S		02.60
CARD PLACEMENT AND EQUATION SUMMARY	60103900	F,G	22	02.00
CE DIAGRAMS (WITHOUT ECN 10) MANUAL	60105400	A	22	01.00
LONG LINE DRIVERS FOR 161 TYPEWRITER	60124100	B	22	01.00
WIRE LIST	60116600	C	22	01.25
161-F ON LINE I/O FLEXOWRITER				
REFERENCE/INSTRUCTION MANUAL	60029100	C	22	02.40
CARD PLACEMENT AND EQUATION SUMMARY	60041400	B	22	02.80
161-G TYPEWRITER				
REFERENCE/INSTRUCTION MANUAL	60094800	B		03.00
(THE FOLLOWING MANUAL FOR THE 161-G IS AVAIL- ABLE ON A SPECIAL ORDER BASIS IN MAX. QTY OF 2 COPIES. ALLOW AT LEAST 3-4 WEEKS FOR PROCESSING AND DELIVERY.) PRICE AVAILABLE UPON REQUEST				
CARD PLACEMENT AND EQUATION SUMMARY	60141600	C	22	
162 MAGNETIC TAPE SYNCHRONIZERS				
REFERENCE MANUALS				
162(S) REFERENCE MANUAL	60023000			02.25
162-1/162-2 REFERENCE MANUAL	60025800	E	22	04.25
162-1B/162-2B/162-3B REF/INST MANUAL	60100200	B	22	06.25
CUSTOMER ENGINEERING MANUALS				
162(S) CE DIAGRAMS	60026000	E	34	03.00
162(S) CE MANUAL	60026500		22	03.00
162(S) CARD PLACEMENT AND EQUATION SUMMARY	60026800	E	22	03.60
162-1 DIAGRAMS	60026100	M	22	03.05
162-1-A CARD PLACEMENT AND EQUATION SUMMARY	60026900	L	22	05.25
162-1-B CE DIAGRAMS	60104200	J	34	03.00
162-2 DIAGRAMS	60026200	M	34	01.50

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
162-2 CARD PLACEMENT AND EQUATION SUMMARY	60027000	K	22	03.40
162-2-A/H WIRE LIST	60151800	G	22	05.00
162-2-B/G CE DIAGRAMS	60104300	H	34	02.10
162-1-H/162-2-H REF/CE MANUAL DESCRIPTION OPERATION, PROGRAMMING, DIAGRAMS AND P/L	60095000	K	22	08.00
162-3-B/G CE DIAGRAMS	60104400	K	34	03.85
162-1,2,3-B/G CARD PLACEMENT AND EQUATION SUMMARY	60129300	K	22	05.30
NORMAL CHANNEL LONG LINE DRIVERS	60123900	A	22	01.50
(THE FOLLOWING MANUALS FOR THE 162 PRODUCT LINE ARE AVAILABLE ON A SPECIAL ORDER BASIS IN MAX. QTY OF 2 COPIES. ALLOW AT LEAST 3-4 WEEKS FOR PROCESSING AND DELIVERY.) PRICE AVAILABLE UPON REQUEST				
162-2-H CARD PLACEMENT AND EQUATION SUMMARY	60141500	H	22	
CARD PLACEMENT AND EQUATION SUMMARY	60022200	B		
163-A MAGNETIC TAPE SYSTEM				
VOL I REFERENCE/INSTRUCTION MANUAL	60007400	C	22	07.25
163 CE DIAGRAMS	60007500	F	34	05.00
CARD PLACEMENT AND EQUATION SUMMARY	60007600	D	22	05.35
CROSS TABS	60116200		22	07.60
164-A MAGNETIC TAPE SYSTEM				
CE DIAGRAMS	60007800	C	34	04.75
VOL I DESCRIPTION, OPERATION AND MAINTENANCE	60007700	A		03.00
CARD PLACEMENT AND EQUATION SUMMARY	60007900	A	22	04.90
165/165-2 INCREMENTAL PLOTTER				
INSTRUCTION MANUAL	60013900	D		02.60
CARD PLACEMENT AND EQUATION SUMMARY	60119200	A	22	01.50
WIRE LIST, 165-B/G	60151500	C	22	03.00
165-G INCREMENTAL PLOTTER				
REFERENCE/INSTRUCTION MANUAL	60094900	B		03.80
CARD PLACEMENT AND EQUATION SUMMARY	60141400	A	22	01.70
WIRE LIST (SEE 165/165-2)				
166-2 LINE PRINTER				
NORMAL CHANNEL LONG LINE DRIVERS CE MANUAL	60124000	A	22	01.00
REFERENCE/INSTRUCTION MANUAL	60019500	F	22	10.25
CE DIAGRAMS	60022500	R	34	01.30
CARD PLACEMENT AND EQUATION SUMMARY	60102500	J	22	04.00
WIRE LISTS, CROSS TABS	60116400	C	22	03.90
H207 LINE PRINTER REFERENCE/INSTRUCTION MAN.	60109800	B	22	04.80
167-1 CARD READER REFERENCE/INSTRUCTION	60019400	E	22	04.00
167-2-A CARD READER REFERENCE/INSTRUCTION AND DIAGRAMS MANUAL	60022000	D	22	06.50
CARD READER LONG LINE DRIVERS	60124300	C	22	01.00

1-Publication number of literature.

2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.

4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
(THE FOLLOWING MANUAL FOR THE 167-2-A CARD READER IS AVAILABLE ON A SPECIAL ORDER BASIS IN MAX. QTY OF 2 COPIES. ALLOW AT LEAST 3-4 WEEKS FOR PROCESSING AND DELIVERY.) PRICE AVAILABLE UPON REQUEST CARD PLACEMENT AND EQUATION SUMMARY	60022200	B		
168-1-A AUXILIARY ARITHMETIC UNIT VOL.1, DESCRIPTION, OPERATION AND MAINTENANCE MANUAL	60021600	A		04.00
CARD PLACEMENT AND EQUATION SUMMARY	60021700	A	22	04.20
CROSS TABS	60112700		22	05.80
168-2-A AUXILIARY ARITHMETIC UNIT REFERENCE/INSTRUCTION MANUAL	60023800	D	22	03.40
VOL 2 DIAGRAMS	60023900	B	34	04.00
AUX. ARITH. UNIT CARD PLCMT. AND EQ. SUMMARY	60024000	A	22	04.50
169-A AUXILIARY MEMORY UNIT REFERENCE/INSTRUCTION MANUAL	60014400	D	22	07.00
CE DIAGRAMS	60022300	H	22	04.70
CARD PLACEMENT AND EQUATION SUMMARY	60022400	F	22	05.80
CROSS TABS	60116300	A	22	08.30
CHECKING PULSE WIDTHS ON 160-A/169 CARDS	60119100		22	01.50
EXTERNAL BUFFER CHANNEL LONG LINE DRIVERS CE MANUAL	60123800	A	22	01.00
170-A CARD PUNCH CONTROLLER REFERENCE/INSTRUCTION MANUAL	60021800	A	22	02.65
CARD PLACEMENT AND EQUATION SUMMARY	60090200	D	22	03.70
CE DIAGRAMS MANUAL	60021900	E	34	04.80
CROSS TABS, 170-B/G	60151200	D	22	03.55
(THE FOLLOWING MANUAL FOR THE 170-A CARD PUNCH CONTR. IS AVAILABLE ON A SPECIAL ORDER BASIS IN MAX. QTY OF 2 COPIES. ALLOW AT LEAST 3-4 WEEKS FOR PROCESSING AND DELIVERY) PRICE AVAILABLE UPON REQUEST CARD PUNCH CONTROLLER LONG LINE DRIVERS	60123700	A		
170-G CARD PUNCH CONTROLLER REFERENCE/INSTRUCTION MANUAL	60095400	E	22	04.00
CROSS TABS (SEE 170-A)				
(THE FOLLOWING MANUALS FOR THE ABOVE PRODUCT ARE AVAILABLE ON A SPECIAL ORDER BASIS IN MAX. QTY OF 2 COPIES. ALLOW AT LEAST 3-4 WEEKS FOR PROCESSING AND DELIVERY.) CARD PLACEMENT AND EQUATION SUMMARY	60141300	G	22	
174-G PAPER TAPE READER/PUNCH CE MANUAL	60121100	H	22	02.95
177-A/R CARD READER CONTROLLER				

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover binder that may be used for manuals.

4-Publication division responsible for contents of literature.

TITLE	1	2	3	4
REFERENCE/INSTRUCTION MANUAL	60049100	D	22	01.50
CARD PLACEMENT AND EQUATION SUMMARY	60122600	A	22	02.50
WIRE LIST AND CABLE TABS, 177-B/G	60151700	B	22	02.00
177-G CARD READER CONTROLLER				
REFERENCE INSTRUCTION MANUAL	60095200	E		04.25
WIRE LIST AND CABLE TABS (SEE 177-A/B)				
(THE FOLLOWING MANUALS FOR THE ABOVE PRODUCT				
ARE AVAILABLE ON A SPECIAL ORDER BASIS IN				
MAX. QTY OF 2 COPIES.ALLOW AT LEAST 3-4				
WEEKS FOR PROCESSING AND DELIVERY.)				
CARD PLACEMENT AND EQUATION SUMMARY	60141200	A	22	
180 DATA COLLECTOR				
DIAGRAMS AND WIRE LIST CE MANUAL	40808300		22	02.00
210 ANALOG TO DIGITAL CONVERTER				
OPERATIONS AND MAINT INSTRUCTION MANUAL	39074700		3	01.45
217-2/FC11-B				
DISPLAY STATION FOR USE WITH 217-2 EQUIPMENT	82128800	A00	22	01.00
CONTROLLER PARTS DATA BOOK (INCLUDES INFO O				
CC505-A, CC505-B)				
218-1 TYPEWRITER STATION PARTS DATA BOOK	82128900	A00	22	01.00
(INCLUDES INFO ON CK105-A AND CK105-B)				
222 (CL401-A/B, CL402-A/B) LINE PRINTER				
CONTROLLER				
224 (CE152) CARD READER				
224-2 (CE304) CARD READER				
224-2A (CE306) CARD READER				
226-1 (CF105) CARD PUNCH				
250-2 DISPLAY SUBSYSTEM HARDWARE REF. MANUAL	82129000	A00	22	03.80
252-2 DISPLAY CONSOLE (REV. 0-3)	82129700	A00		04.40
271 DIGIGRAPHICS CONTROLLER REFERENCE MANUAL	60181400			05.75
273 DIGIGRAPHIC CONSOLE REFERENCE/CE MANUAL	60188600	A	22	08.00
274 DIGIGRAPHIC CONSOLE GEN DESC, THEO OF OP,	60279100	A	22	04.95
DIAGS, MAINT, P/L REFERENCE/CE MANUAL				
275 DIGIGRAPHIC SYSTEM				
DIGIGRAPHIC MAN-MACHINE SYSTEMS 275 BUFFER	60181300	A	22	03.75

1-Publication number of literature.

2-The latest revision level.

3-Indicates size of hard cover binder that may be used for manuals.

4-Publication division responsible for contents of literature.

TITLE	1	2	3	4
MEMORY REFERENCE MANUAL				
302 COMMUNICATIONS EXPANSION MOD REF/CE MAN	13796100	A	22	02.70
303-1 (GG105-A) COMMUNICATIONS EXPANSION UNIT REFERENCE MANUAL	13797400	A	22	01.20
304-1 (DJ805-A/B) COMMUNICATIONS MULTIPLEXER REFERENCE MANUAL	13796400	D	22	01.00
311-B DATA SET ADAPTER EQUATION FILE AND WIRE LIST CE MANUAL	36824400	B	22	04.55
311-2 (DJ110-A/DJ111-A) DATA SET ADAPTER REFERENCE MANUAL	41602400	A	22	01.00
311-3 COMMUNICATIONS ADAPTER REF INFO (USE 361-5)				
312-2 DATA SET ADAPTER REFERENCE MANUAL	41609000	A	22	02.70
313 (8536-C/8537-C/FJ413-A/FJ414-A) DATA SET ADAPTER REFERENCE MANUAL	13798400	A	22	01.00
314 (8536-C/8537-C/FJ413-A/FJ414-A) DATA SET ADAPTER REFERENCE MANUAL	13798500	A	22	01.00
317 (8536-D/8537-D/FJ413-A/FJ414-A) DATA SET ADAPTER REFERENCE MANUAL	13798600	B	22	01.00
318 (8536-D/8537-D/FJ413-A/FJ414-A) DATA SET ADAPTER REFERENCE MANUAL	13798700	B	22	04.30
321 (8518-C/8519-D) TELETYPEWRITER TERMINAL UNIT REFERENCE MANUAL	13799300	A	22	03.50
323 (8518-C/8519-D) TELETYPEWRITER TERMINAL UNIT (USE 321 REFERENCE MANUAL)				
326-C TRUNK LINE ADAPTER THEORY OF OPERATION, MAINTENANCE, PROGRAMMING, CARD PLACEMENT, PARTS LISTS, DIAGRAMS REFERENCE/CE MANUAL	36829000	A	22	02.25
OPERATION, INSTALLATION, MAINTENANCE CE MAN	36824800	A	22	01.50
327 DATA SET ADAPTER CE MANUAL	36824700	A	22	07.05
327-2 (DJ101-A, DJ115-A) DATA SET ADAPTER REFERENCE MANUAL	41600500	A	22	01.00

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
330 (8536-D/8537-D) DATA SET ADAPTER REFERENCE MANUAL	13798300	B	22	01.00
331 (8536-/8537-E) DATA SET ADAPTER REFERENCE MANUAL	41607100	A	22	01.00
332-1 (8536-C/8537-C) DATA SET ADAPTER REFERENCE MANUAL	13798200	A	22	01.00
350 PAPER TAPE READER/REFERENCE MANUAL MOD C-G REFERENCE MANUAL MOD A AND B DIAGRAMS AND WIRE LIST, MOD J,K,L,M MAINTENANCE MANUAL MOD J,K,L,M,N,P,R,S,T,U PARTS LIST (MOD A THRU U)	40801200 PED 108A 40808000 40813100 40861900	A B B B	22 22 22 22 22	01.25 01.60 01.50 01.90 02.00
358-1 (DJ112-A/B) TRANSCEIVER REF MANUAL	41605300	B	22	01.00
358-2 (DJ113-A/B) TRANSCEIVER REF MANUAL	41606200	B	22	01.00
358-3 (DJ114-A/B) TRANSCEIVER REFERENCE MANUAL	41601800	C	22	01.00
360-65+/67+ MEMORY SYSTEM DIAGNOSTIC PACKAGE USERS GUIDE	75400200	A	3	17.25
358-4 (DJ114-C/D) TRANSCEIVER REF INFO (USE 358-3)				
361-1 (DJ142-A, DJ143-A) COMMUNICATIONS ADAPTER REFERENCE MANUAL	41612200	C	22	01.00
361-2 (DJ143-A) COMMUNICATIONS ADAPTER REF INFO (USE 361-1)				
361-3 (DJ142-A) COMMUNICATIONS ADAPTER REF INFO (USE 361-1)				
361-4 (DJ122-A) COMMUNICATIONS ADAPTER REFERENCE MANUAL	41609600	A	22	03.40
361-5 (DJ144-A) COMMUNICATIONS ADAPTER REFERENCE MANUAL	41611800	C	22	02.65
361-6 (DJ145-A) COMMUNICATIONS ADAPTER REFERENCE MANUAL	41612000	B	22	01.60
361-7 (DJ146-A) COMMUNICATIONS ADAPTER REFERENCE MANUAL	41612400	A	22	01.00
362-1 (GH407-A/B, DK509-A/B) TELEGRAPHIC LEVEL CONVERTER				

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
REFERENCE MANUAL	41610500	A	22	01.00
362-2 (DK509-A/B) TELEGRAPHIC LEVEL CONVERTER REF INFO (USE 362-1)				
364-1/2 (DJ808-A, GD306-A/B, GH407-A/B) COMMUNICATIONS MULTIPLEXER REFERENCE MANUAL	41610900	A	22	01.00
364-3 (DJ813-A) COMMUNICATIONS MULTIPLEXER REFERENCE MANUAL	41612500	A	22	01.00
364-4 (DJ814-A, GD306-A/B, GH407-A/B) COMMUNICATION MULTIPLEXER REFERENCE MANUAL	41612700	B	22	01.00
364-5 (DJ814-A) COMMUNICATION MULTIPLEXER REF INFO (USE 364-4)				
370 PAPER TAPE READER DIAGRAMS, C/P, W/L, MODS A01-B01 AND ABOVE MAINTENANCE MANUAL MOD A AND B (6166) PARTS LIST MOD A AND B	40864900 40823900 40829400	B A D	22 22 22	01.00 01.25 01.50
402M ANALOG MULTIPLEXER OPER AND MAINT INSTR	39074900			01.65
405 HIGH SPEED CARD READER REFERENCE MANUAL A/B APENDIX FOR C,D,J AND K PARTS LIST MOD A THRU D SUPPLEMENTAL MANUAL (MOD D)	40809300 40825200 49750900	J L B	22 22 22	02.25 03.40 02.35
405 PL-10 CARD READER CE156 PARTS DATA CE MAN	49755400	A	22	04.50
407 (CE149) CARD READER				
415 CARD PUNCH ILLUSTRATED PARTS LIST MOD A AND B DIAGRAMS, THEO OF OPER., GEN DESC CE/REF MAN	40820200 49755300	G C	22 22	02.50 11.15
415-PL-10 CARD PUNCH (CF109) PARTS DATA CE MAN	49755500	A	22	04.75
415-30 (CH102-A/B, FE202-A/B) CARD PUNCH AND CONTROLLER				
417-1 (CF108-A/B, FE201-A) CARD PUNCH WITH CONTROLLER				
430 (CF504) CARD READ-PUNCH				
430 PL-10 CARD READER-PUNCH (CF511) PARTS DATA	49755900	01	22	04.90
469 COMPUTER SYSTEM 462-01A/02A TELETYPE CONTROLLERS	14060200		22	08.60

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
501 AND 505 HIGH SPEED LINE PRINTER				
501 REFERENCE MANUAL MOD A AND B	40805000		22	02.50
ILLUSTRATED PARTS LIST (501 MODS C/D, 505 MODS A/B)	50581600	A	22	02.35
501 HIGH SPEED LINE PRINTER REFERENCE MANUAL (MOD C AND D)	40807200		22	01.45
505 HIGH SPEED LINE PRINTER REF. MOD A/B	40820800	A	22	02.50
CUSTOMER ENGINEERING MANUALS				
ILLUSTRATED PARTS LIST, MOD A AND B (501)	40815200	A	34	04.70
DIAGRAMS AND C/P (501 MOD C07-C14/D01-D08, 505 MOD A07-A14/B01-B07)	40861700	B	22	01.80
DIAGRAMS AND C/P (501 MOD C01-C06, 505 MOD A01-A06)	40861800	A		02.10
DIAGRAMS AND C/P (501 MOD A01-A07, B01-B06)	40862000	A	22	01.45
DIAGRAMS AND C/P (501 MOD A08-A09, B07 AND B08)	40862100	B	22	02.50
DIAGRAMS AND CARD PLACEMENT (501 MOD A10-A11 B09-B10)	40862200	A	22	01.40
512 (CL601) LINE PRINTER				
517 (CL835) LINE PRINTER				
580 LINE PRINTER EQUIPMENT				
INTRODUCTION, ASSEMBLY PARTS LIST, PRINTED CIRCUIT CARDS, USED-ON INDEX PART I.D. MAN.	91858900	A	22	08.10
CONTROLS AND INDICATORS, OPERATING PROCEDURE	91860400	B	22	01.55
OPERATOR MAINTENANCE OPERATORS HANDBOOK				
GEN. DESC., OPERATION AND PROGRAMMING, THEORY OF OPERATION, MAINTENANCE, PARTS DATA CE MAN	91859000	C	22	02.35
INTRODUCTION, OPERATING INSTRUCTIONS, PRINCIPLES OF OPERATIONS REFERENCE MANUAL	91858600	B	22	08.90
INSTALLATION AND CHECKOUT, PREVENTIVE/CORRECTIVE MAINTENANCE, PARTS REPLACEMENT FIELD SERVICE MANUAL VOL.1	91858700	B	22	13.35
FIELD SERVICE MANUAL VOLUME II	91858800	B01	22	
595 PRINT CARTRIDGE HARDWARE REFERENCE/CE MAN.	44855800	C	22	01.00
GEN. DESC., THEO OF OPER., MAINT., PARTS DATA CE MANUAL	50582200	D	22	01.00
TYPE D MANUAL	91860100	A	22	01.75
599 DRUM PRINTER TESTER MAINTENANCE MANUAL	40820500		22	04.05
601 MAGNETIC TAPE TRANSPORT				
DIAGRAMS AND WIRE LIST MOD A-B	40812400	B	22	02.15
MAINTENANCE MANUAL, MOD A AND B	40815300	G	22	02.40
PARTS LIST, MOD A, B AND C (4167)	40862700	A	22	01.85

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover binder that may be used for manuals.
4-Publication division responsible for contents of literature.

TITLE	1	2	3	4
602 MAGNETIC TAPE TRANSPORT				
MAINTENANCE MANUAL, MOD A AND B (11/65)	40815500	A	22	06.25
DIAGRAMS AND WIRE LIST, MOD A AND B	40815600	A	22	02.50
603 MAGNETIC TAPE TRANSPORT				
ILLUSTRATED PARTS LIST, MOD F, G, H AND J	40812700	D	22	06.80
ILLUSTRATED PARTS LIST	PED2003	A	22	05.00
MAINTENANCE MANUAL MODS A,B,C,D AND E (ECN21	40814800	C		03.60
MAINTENANCE MANUAL MOD F,G,H AND J (5165)	40812600	C	22	02.40
DIAGRAMS AND WIRE LIST, MOD A01-A04 (4/66)	40823000	B		03.00
DIAGRAMS AND WIRE LIST, MOD B-E (12/65)	40820300	B	22	02.35
DIAGRAMS AND WIRE LIST, MOD F-J (9/66)	40819400	B	22	02.80
604,606,607 MAGNETIC TAPE TRANSPORTS				
ILLUSTRATED PARTS LIST	40810800			11.20
DIAGRAMS AND WIRE LIST, MODS A,B,C,D AND E	40811500	B	22	09.60
MAINTENANCE MANUAL MODS A,B,C,D AND E	40812500	C	22	10.25
604-2 (BE101) MAGNETIC TAPE TRANSPORT				
605 MAGNETIC TAPE TRANSPORT				
MAINTENANCE MANUAL, MOD G (8/65)	40811800	1	22	04.00
ILLUSTRATED PARTS LIST MOD G	40811900		3	03.50
DIAGRAMS AND WIRE LIST, MOD G (8/65)	40815400	B	22	05.30
606 MAGNETIC TAPE TRANSPORT				
CE MAINTENANCE MANUAL, MOD G,H,J,K,L	40811400	03		01.50
DIAGRAMS AND WIRE LIST, MOD G-L	40812000	C	22	02.60
MAINTENANCE MANUAL, MOD C AND E (11/65)	40816500	1	22	03.00
MAINTENANCE MANUAL MOD B AND N (2/66)	40816800	1	22	03.00
DIAGRAMS AND WIRE LIST, MOD C-E (12/65)	40821200	B	22	04.00
DIAGRAMS AND WIRE LIST, MOD 1 AND 2 (2/66)	40822400	B	22	03.30
DIAGRAMS AND WIRE LIST, MOD N03-N05 (2/66)	40822500	B	22	03.30
607 MAGNETIC TAPE TRANSPORT				
MAINTENANCE MANUAL MODS A,B,C,D,E AND F	40815100	D	22	02.95
DIAGRAMS AND WIRE LIST MANUAL, MOD A-F	40821000	E	22	02.85
DIAGRAMS, WIRE LIST, CIRC. DESC., C/P CE MAN	49757600	A	22	01.95
607-2 (BE222) MAGNETIC TAPE TRANSPORT				
607 R MAGNETIC TAPE TRANSPORT MAINT CE MANUAL	49757500	A	22	04.00
608 (BF102) MAGNETIC TAPE TRANSPORT				
609 (BF401) MAGNETIC TAPE TRANSPORT				
612 MAGNETIC TAPE TRANSPORT				
MAINTENANCE MANUAL	40819500	1	22	04.80

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
626 MAGNETIC TAPE TRANSPORT ILLUSTRATED PARTS LIST, MOD B REFERENCE MANUAL, MOD B DIAGRAMS AND WIRE LIST MOD B,C,D,F,G (5/66)	PED2008 PED2214 40824000		3 22 22	04.50 05.00 05.00
627 MAGNETIC TAPE TRANSPORT ILLUSTRATED PARTS LIST, MOD A REFERENCE MANUAL, MOD A DIAGRAMS AND WIRE LIST MOD A01 AND ABOVE	40807700 40807800 40811200	01 3 E	3 3 22	03.50 08.00 04.00
636 COMPUTER PROGRAMMING MANUAL	22003300			04.00
657-1 (BE103) MAGNETIC TAPE TRANSPORT				
657-2 (BE104) MAGNETIC TAPE TRANSPORT				
657-3 (BE223) MAGNETIC TAPE TRANSPORT				
657-4 (BE224) MAGNETIC TAPE TRANSPORT				
659-1 (BE406) MAGNETIC TAPE TRANSPORT				
659-3 (BE408) MAGNETIC TAPE TRANSPORT				
659-4 (BE409) MAGNETIC TAPE TRANSPORT				
66X PSDG FIELD SERVICE MANUAL	49751400	E	22	11.60
671 MAGNETIC TAPE TRANSPORT EXERCISER REFERENCE MANUAL DIAGRAMS, C/P, WIRE LIST MOD A01 AND ABOVE PARTS LIST MOD A	40814200 40817200 40822000	A C A	22 22 22	01.50 01.00 01.25
673 (GK102) TAPE EXERCISER				
680 MAGNETIC TAPE CERTIFIER DIAGRAMS AND WIRE LIST MODS A,B DIAGS AND WIRE LIST MODS E-F MAINTENANCE MANUAL FOR MODS A THRU H PARTS LIST MODS A-D PARTS LIST MODS E-H	40822800 40862600 40822200 60188800 41240100	E E D B B	22 22 22 22 22	04.60 05.00 02.90 02.90 10.95
680,685,690 MAGNETIC TAPE CERTIFIERS TECHNICAL INFORMATION MANUAL	40822600			02.40
686 (GL102) TAPE CERTIFIER				
688 CLOSED LOOP AIR DUCT SYSTEM REFERENCE AND ILLUSTRATED PARTS LIST MANUAL	PED2216			04.50
689 TRANSPORT CHANNEL SWITCH/REFERENCE MOD A DIAGRAMS AND WIRE LIST, MOD A (1/65)	40807900 40809100	A A	22 22	02.00 02.00

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.

4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
690 MAGNETIC TAPE CERTIFIER TECHNICAL INFO MAN REFERENCE MANUAL, MOD B, C, D AND E	40803400			02.50
DIAGRAM AND WIRE LIST, MOD D AND E (7/65)	40816000	A	22	10.00
PARTS LIST, MODS B01-B03, C01-C03, D01-D04,	40814600	C	22	04.15
E01-E04, F01-F04, G01-G04	40814300	C	22	05.90
699 TAPE TRANSPORT EXERCISER/REFERENCE (MOD C)	40803200			04.25
DIAGRAMS AND WIRE LIST MOD A, B AND F	40809500	B	22	01.50
MAINTENANCE MANUAL MODS A, B AND F	40814500	A	22	01.00
720 DIGITAL COMMUNICATIONS TERMINAL CONTROL UNIT REFERENCE MANUAL	36814300			01.50
DIAGRAMS CE MANUAL	36823200		34	01.75
EQUATION FILE, CARD PLACEMENT, WIRE TABS, CABLE TABS, MAINTENANCE CE MANUAL	36817400	C	22	02.50
720-G DIGITAL COMMUNICATION TERMINAL CONTROL DIAGRAMS CE MANUAL	36823300		34	01.75
730-100 (BB372-A) MEMORY EXPANSION FOR MEDIUM AND SLOW SPEED BATCH STATIONS				
733-10 (CE125-A/B, CL503-A/B, DT208-A, FV218-A/B, FV433-A, FV435-A) HIGH SPEED BATCH SUBSYSTEM/TERMINAL FUNCTIONAL CHARACTERISTICS AND PROGRAMMING OPERATORS MANUAL	60329500	B	22	05.15
FOR BUFFER CONTROLLER DIAGNOSTIC LISTINGS SEE FR113-A - CATALOG SECTION 1	60399500	B	22	07.00
733-101 (CF111-A/B, FV437-A) CARD PUNCH				
733-110 (CL503-A/B, FV437-A) TERMINAL LINE PRINTER				
733-120 (CE125-A/B, FV437-A) TERMINAL CARD READER				
733-130 (DJ152-A) TERMINAL ADAPTOR				
733-140 (BB377-A) MEMORY INCREMENT				
733-150 (CA115-A, CC102-A/B, FV434-A, FV436-A) KEYBOARD-DISPLAY				
733-152 (CA115-A, CC102-A/B, FV434-A/B) KEYBOARD-DISPLAY				
781 MAGNETIC TAPE CLEANER - GEN DESC., THEORY OF OP., DIAGRAMS, MAINT. CE MANUAL	70611600	A	22	01.65
OPERATORS MANUAL	70611500	A	22	01.00
CE MANUAL	70616100	A	22	01.20
OPERATORS GUIDE	70616200	A	22	01.00

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
782 MAGNETIC TAPE CLEANER - GEN DESC., THEORY OF OP., DIAGRAMS, MAINT. CE MANUAL OPERATORS MANUAL	70611800	A	22	04.30
	70611700	A	22	01.00
783 MAGNETIC TAPE CLEANER - GEN DESC., THEORY OF OP., DIAGRAMS, MAINT. CE MANUAL OPERATORS MANUAL	70612000	A	22	02.00
	70611900	A	22	01.20
791-1 (DT137-A, DT138-A, DT139-A, FJ424-A/B/C) COMMUNICATIONS SUBSYSTEM REFERENCE MANUAL	60325100	B	22	03.35
807/808 DISK FILES--ALSO LISTED AS BH411/BH412 DIAGRAMS AND W/L MODS A01-A08, B02-B08 DIAGS AND WIRE LIST MODS A09 AND ABOVE MAINTENANCE MOD A PARTS LIST MOD A	40862500	R	22	12.90
	70605400	B	22	06.40
	40823400	D	22	09.20
	40824300	B	22	03.40
813/814 DISK FILE DIAGRAMS,C/P,WIRE LIST MODS A01-A05,B01-B05 DIAGRAMS AND WIRE LIST MODS A06, B06 MAINTENANCE MANUAL MODS A AND B PARTS LIST THEO OF OPERATION MAINTENANCE AIDS	40827500	J	22	04.10
	70601100	D	22	06.75
	40824800	E	22	07.30
	40863300	B	22	03.75
	40865200	B	22	02.50
817 DISK FILE--LISTED AS BH405				
821 DISK FILE--LISTED AS BH408 AND BH410				
828 DISK FILE CE INSTRUCTION MANUAL CE DIAGRAMS	60099400		22	05.80
	60099500		34	04.50
841 MULTIPLE DISK DRIVE REFER TO BM101, BM102, BM103, BM104				
844-2 () DISK STORAGE UNIT GENERAL INFO (USE 7054-1) OPERATION AND PROGRAMMING (USE 7054-1)				
852 DISK STORAGE DRIVE MAINTENANCE MANUAL MOD A/B PARTS LIST MOD A AND B DIAGRAMS AND WIRE LISTS MOD A AND B	40820000	B	22	06.00
	40825000	B		02.00
	40825100	H	22	05.40
853 DISK STORAGE DRIVE DIAGS AND W/L MODS A01-A09,B01-B09 DIAGS,CIR DES,C/P,W/L, MODS A10-A11,B10-B11 MAINTENANCE MANUAL MOD A,B MAINTENANCE MANUAL MODS A12, B12 AND ABOVE PARTS LIST MODS A01-A11,B01-B11 DIAGRAMS,CIRC OFSC., C/P, W/L MODS A12 PARTS LIST MODS A12 ABOVE B12 ABOVE	40825600	P	22	03.15
	41240900	F	22	02.50
	40823100	E	22	05.60
	41245700	C	22	05.50
	40826300	D	22	02.30
	41247300	E	22	02.50
	41244100	D	22	02.40

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover binder that may be used for manuals.

4-Publication division responsible for contents of literature.

TITLE	1	2	3	4
ABOVE, B12 AND ABOVE				
854 DISK STORAGE DRIVE				
DIAGRAMS AND WIRE LISTS MANUAL MODS A,B	40824900	W	22	01.95
DIAGS, CIRC., DESC. C/P, W/L MODS A10-A11, B10-B1	41241000	F	22	02.10
DIAGS, AND WIRE LIST MODS A12, B12	41247400	F	22	02.00
J12, K12				
MAINTENANCE MANUAL MODS A,B	40823200	E	22	02.10
MAINT. MAN. MOD A12, B12, AND ABOVE	41245800	E	22	03.80
PARTS LIST MOD A AND B	40826400	D	22	07.35
PARTS LIST MODS A12 AND ABOVE AND B12 ABOVE	41244200	E	22	01.80
857 DISK STORAGE DRIVE--LISTED AS BJ104				
861/863/865 DRUM STORAGE UNIT REFERENCE MANUAL (SEE 3000 PER EQUIP REF MANUAL REV J)				
861-B/863-B, 863-C/BG108-C DRUM STORAGE UNITS	60210300	D	22	10.10
DIAGS, CIRC DESC, MAINT, C/P, EQ SUMMARY W/L				
PARTS LIST	70606800	A	22	02.30
863-C DRUM STORAGE UNIT (USE BG108-C/D)				
865 DRUM STORAGE UNIT--LISTED AS BG113				
897 DISK FILE CLOCK/TRACK VERIFICATION ADDRESS WRITER GEN. DESC. INST. AND CHKOUT. OPERATION	40862400	B	22	08.40
DIAG. MAINT, MAINT P/DATA W/L CE MANUAL				
898 DISK STORAGE DRIVE EXERCISER CE MANUAL MOD A AND B	40860400	C	22	06.70
899 DISK STORAGE DR EXERCISER MAINT MANUAL	40860500	C	22	05.90
915 PAGE READER				
GRASP II (GENERALIZED READ AND SIMULATE PROGRAM) A GENERALIZED DATA CAPTURING SYS. FOR 915 OCR PAGE READING SYSTEMS OPERATOR INFORMATION MANUAL	48704702	04	3	02.35
GRASP - 8090/160-A OCR SOFTWARE REF MAN.	48996600	A	3	03.65
THEORY OF OPERATION MANUAL	48430170	A	3	01.20
PARTS LIST MODS C,D,E,F	40862900	B	22	05.00
PARTS LIST A/B SUPPLEMENT	40863900	A	22	04.00
915/919 OCR MEDIA MANUAL	91566700		3	06.50
915/1700 PAGE READER SETUP SOFTWARE REF MAN	48143910	02		01.30
921 DOCUMENT READER OCR MEDIA MANUAL	60216104	C	3	02.20
THEORY OF OPERATION	48780800	02	3	01.15
921/8092 OCR DOCUMENT READER SYSTEM OPERATING AND PROGRAMMING GUIDE	87900200			10.55

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
924-A COMPUTER REFERENCE MANUALS				
PERIPHERAL EQUIPMENT CODES	60026700			01.50
I/O SPECIFICATION AND INSTALLATION	60027100			03.00
REFERENCE MANUAL	60027400			03.75
INSTRUCTION CARD	60070300			00.75
CUSTOMER ENGINEERING MANUALS				
CE DIAGRAMS	60027500	S	34	09.60
CE INSTRUCTION MANUAL	60094100	A	22	03.30
PARTS LIST CE MANUAL	60017300		22	06.70
924-B COMPUTER REFERENCE MANUALS				
I/O SPECIFICATION AND INSTALLATION	60013700			03.75
REFERENCE MANUAL	60016800	E	22	06.00
CUSTOMER ENGINEERING MANUALS				
CE MAINT/INSTRUCTION MANUAL	60017000	B	22	08.85
CE DIAGRAMS	60017100	F	34	10.00
925-A MAGNETIC TAPE CONTROLLER REFERENCE MANUAL	60029300	B		03.00
DIAGRAMS	60048900	G,H	34	01.75
CE INSTRUCTION MANUAL	60090300	A	22	04.65
CARD PLACEMENT, EQUATION SUMMARY	60287100	B	22	08.20
(THE FOLLOWING MANUALS FOR THE ABOVE PRODUCT ARE AVAILABLE ON A SPECIAL ORDER BASIS IN MAX. QTY OF 2 COPIES. ALLOW AT LEAST 3-4 WEEKS FOR PROCESSING AND DELIVERY.)				
CARD PLACEMENT, CHASSIS 33 100	24105200	D		
CARD PLACEMENT, CHASSIS 33 200	24105300			
EQUATION SUMMARY	24106100	G		
925-S MAGNETIC TAPE SYNCHRONIZER CE INSTRUCTION AND REFERENCE MANUAL (REFER TO 925-A)				
(THE FOLLOWING MANUALS FOR THE ABOVE PRODUCT ARE AVAILABLE ON A SPECIAL ORDER BASIS IN MAX. QTY OF 2 COPIES. ALLOW AT LEAST 3-4 WEEKS FOR PROCESSING AND DELIVERY.)				
CARD PLACEMENT	24345000	A		
CE DIAGRAMS	60106300	C	34	
926-A MAGNETIC TAPE CONTROLLER PRELIMINARY REFERENCE MANUAL	60044800	A		02.80
CE DIAGRAMS	60093100	E	34	03.00

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
CE INSTRUCTION MANUAL	60094600		22	02.40
929 OCR DOCUMENT READER				
THEORY OF OPERATION	91604200			01.50
MEDIA MANUAL	91604300	A	22	03.40
SYSTEMS OPERATORS GUIDE	87978800	A	22	02.60
935 OCR DOCUMENT READER SYSTEM REF/OPERATIONS MANUAL	60270700	01	22	06.50
936 SETUP REFERENCE MANUAL	48704810	04	3	03.00
OCR MEDIA MANUAL	60216101	02	3	03.15
OCR DOCUMENT READER THEORY OF OPERATIONS	48704850	02	3	03.60
DITO (DOCUMENT IN-TAPE OUT) OCR 1700/SC1700	48781100	02	3	02.55
COMPILER SYSTEMS SOFTWARE REF MAN				
955 PAGE AND DOCUMENT READER CONTROLLER				
REFERENCE MANUAL	60324600	C	22	06.55
THEORY OF OPERATIONS	48430070	A	3	01.00
SYSTEMS OPERATORS GUIDE VOL.2	48643305	02	3	06.00
SETUP SOFTWARE REFERENCE MANUAL	48430050	03	3	01.80
955/959 PAGE AND DOCUMENT READER				
THEORY OF OPERATION	91604400			01.50
OCR MEDIA MANUAL	91604500	B	22	01.20
1010 INPUT STATION REFERENCE MANUAL	36817700	A	22	02.50
CE DIAGRAMS MANUAL	36817900	B	34	01.50
SUPPLEMENT TO DIAGRAMS MANUAL 36817900	65699100		34	01.00
ILLUSTRATED PARTS LIST	36820500		22	03.75
1020 INPUT STATION REFERENCE MANUAL	36818000	C	22	03.50
MAINTENANCE MANUAL	36818100	D	22	03.00
SUPPLEMENT I TO MAINTENANCE MAN - 36818100	36828600			01.00
DIAGRAMS	36818200	K	34	12.15
PARTS LIST	36820600	D	22	02.30
MULTI-WIRE SEARCH UNIT SUPPLEMENT	36824500		22	01.00
DIAGRAMS AND WIRE LIST SUPPLEMENT TO 1020/1021	36828700	B	34	02.85
1022/1023/2022 DATA COLLECTOR CONTR. REFERENCE	36826500		22	01.00
1025-E INPUT STATION REFERENCE MANUAL	13792900	B	22	01.00
CE MAINTENANCE CE MANUAL	13793000	D	22	03.00
ILLUSTRATED PARTS MANUAL	13797700	H	22	02.90
QSE 1257-A,B PRINTER STATION REF/CE MANUAL	82115700	800	22	01.00
1500 INPUT/OUTPUT EQUIPMENT MANUALS				
DATA AND CONTROL TERMINAL (DCT 30) HARDWARE	84894200	A	22	07.00
REFERENCE/CE MANUAL				
PERIPHERAL EQUIPMENT SITE PREPARATION MAN.	39230300	C	22	05.25
REMOTE I/O SUBSYSTEM HDWF REF/CE MANUAL	39150100		22	10.35

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover binder that may be used for manuals.
4-Publication division responsible for contents of literature.

TITLE	1	2	3	4
TELEMETRY CONTROL CHANNEL/TELEMETRY DATA FORMATTER(TCC/TDF) OPER AND MAINT INSTR MAN	84837900		22	11.50
E9306 +128V (+100V) 15- BIT MULTIPLYING DIGITAL TO ANALOG CONVERTER HARDWARE REF./CE MANUAL	84937300	A	22	04.35
ED101-A, ED102-A, ED103-A HIGH LEVEL ANALOG MULTIPLEXER HOWE REF./CE MANUAL	39278700	A	3	01.20
1500 SERIES CONFIGURATOR	60187500			01.25
1501-10 (ED105-A) ANALOG INPUT MULTIPLEXER				
1501-11 (ED106-A) ANALOG INPUT MUX EXPANDER				
1525-2 (EA102-A) ANALOG TO DIGITAL CONVERTER				
1525-3 (EA309-A) ANALOG TO DIGITAL CONVERTER				
1530 ANALOG INPUT INTERFACE HRDW/REF/CE MAN	39153300	B	22	03.50
1530/1534 ANALOG INPUT CONTROLLER OPER AND MAINTENANCE INSTRUCTION	39073900	A		02.40
1531 MERCURY-WETTED RELAY MULTIPLEXER INCLUDING 1563 SIGNAL CONDITIONER HARDWARE REFERENCE/CUSTOMER ENGINEERING MANUAL	39074100	A	22	01.85
1533/1535/1563 RELAY MULTIPLEXER AND SIGNAL CONDITIONING UNIT	39074200	A	3	08.30
1534 ANALOG INPUT INTERFACE HARDWARE/REF. CE MANUAL	39153400	B	22	10.00
1538 HIGH SPEED, HIGH LEVEL ANALOG INPUT INTERFACE OPERATION AND MAINTENANCE	39074500	D	3	13.35
1544-1 (DA101-B) DIGITAL INPUT UNIT				
1544-2 (DA101-A) DIGITAL INPUT UNIT				
1544-3 (DA401-B) DIGITAL INPUT UNIT				
1544-4 (DA401-A) DIGITAL INPUT UNIT				
1544/1545/1564 DIGITAL INPUT SUBSYSTEM OPERATION AND MAINTENANCE	39073300	D	3	09.60
1546/1547 EVENT COUNTER SUBSYSTEM OPER AND MAINT INSTRUCTION	39070800	B		03.70
1547-1 (FT1A1-A) EVENTS COUNTER UNIT				
1547-2 (FT1A1-B) EVENTS COUNTER UNIT				
1548/1549 EXTERNAL INTERRUPT SUBSYSTEM OPER AND MAINTENANCE	39073400	C	22	06.75
1553/1554 EXTERNAL REGISTER OUTPUT SUBSYSTEM OPER AND MAINTENANCE	39073500	C	3	08.80
1555 POWER DRIVE OUTPUT UNIT AND RELAY OUTPUT UNIT	39073600	B	22	02.65
1555-1 (DF3A1-A) RELAY OUTPUT UNIT				
1555-2 (DF3A1-B) RELAY OUTPUT UNIT				
1555-4 (DF3A1-A) RELAY OUTPUT UNIT				
1556 ANALOG (DAC) OUTPUT UNIT OPER AND MAINT INSTRUCTION	39074300	A	22	02.00
1558 LATCHING RELAY OUTPUT INTERFACE OPER AND MAINT. INSTRUCTION	39073700		22	06.70
1559 LATCHING RELAY CONTACT OUTPUT UNIT OPER AND MAINT INSTRUCTION	39073800	A		01.35
1560 LATCHING RELAY ANALOG (DAC) OUTPUT UNIT OPER AND MAINT INSTRUCTION	39074400		3	02.30
1561 ANALOG OUTPUT INTERFACE OPER AND MAINT INSTRUCTION	39075000	A	22	01.90

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover binder that may be used for manuals.

4-Publication division responsible for contents of literature.

TITLE	1	2	3	4
1567, ADSE 3005 AND ADSE 3014 SIMULTANEOUS SAMPLE AND HOLD MODS OPER AND MAINT INSTR	84851100		22	04.50
1567 SIMULTANEOUS SAMPLE AND HOLD UNIT OPER, MAINT INSTR MANUAL	39071400		22	01.45
1568/420C ANALOK ANALOG MEMORY OUTPUT UNITS OPER AND MAINT INSTRUCTION	39071500	A		02.65
1570 SERIES TERMINATION PANELS/OPERATION AND MAINTENANCE	39071900	C	22	06.00
1571 CHAINING BUFFER CHANNEL OPERATION AND MAINTENANCE INSTRUCTION MANUAL	39073100	B	22	18.70
1572 PROGRAMMABLE SAMPLE RATE UNIT OPERATION AND MAINT INSTRUCTION	39070900	C	22	01.55
GENERAL DESCRIPTION, OPERATION AND PROG., THEORY OF OPERATION, MAINTENANCE, DIAGRAMS PARTS LIST AND WIRE LISTS CE MANUAL	39359900	B	22	01.50
1572-1 (GA128-A) SAMPLE TIMING UNIT				
1576 (FV4A3/498) STALL ALARM UNIT REF/CE MAN	88981000	A	22	03.70
1577 STALL ALARM HARDWARE REF/CE MANUAL	84781600	B	3	05.30
1581 LOGGING TYPEWRITER INTERFACE OP/MAINT CE MANUAL	39075200	A	22	02.80
1583 I/O TYPEWRITER INTERFACE HARDWARE/REF. CE MANUAL	39075300	A	22	02.25
1585 INCREMENTAL PLOTTER CONTROLLER HARDWARE REFERENCE CE MANUAL	39072600	B	22	01.90
1587/1557 MONITOR AND CONTROL PANELS OPER AND MAINTENANCE INSTRUCTION MANUAL	39071300	B	22	02.50
1590-3 REMOTE COMPUTER INTERFACE SUBSYSTEM HARDWARE REFERENCE CE MANUAL	39909513	A	22	21.00
1595-10 (DK605-A) SERIAL I/O UNIT				
1595-11 (DK605-A) SERIAL I/O UNIT				
1595-20 (DK605-B) SERIAL I/O UNIT				
1595-21 (DK605-B) SERIAL I/O UNIT				
1604-A COMPUTER INSTALLATION MAN	60002000	E		03.00
PERIPHERAL EQUIPMENT CODES	60025700	B		01.00
PROGRAM CARD (SA185C)	60070400			.75
REFERENCE MANUAL	60024500			03.50
SPECIFICATIONS (I/O)	60024400	E		03.25
CUSTOMER ENGINEERING MANUALS				
CE DIAGRAMS	60024300	J	34	12.00
CE INSTRUCTION MANUAL PART 1, THEORY OF OPERATION	60118700	A	22	05.75
CE INSTRUCTION MANUAL PART 2, MAINTENANCE EQUATION SUMMARY	60118800	A	22	04.40
	60116000	A	34	20.00
1604-B COMPUTER REFERENCE MANUALS				
I/O SPECIFICATIONS	60110100	B	22	05.10

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
CUSTOMER ENGINEERING MANUALS				
CE DIAGRAMS (STANDARD OPTION 10003)	60090800	R	34	10.00
CE INSTRUCTION MANUAL, PART 2, MAINTENANCE	60126800		22	05.75
CHASSIS MAPS (SEE 1604-C)				
1604-C/1604-A COMPUTER (PREVIOUSLY 1604/1604-A)				
PROGRAMMING TRAINING MANUAL	60001500	A	22	10.40
REFERENCE MANUAL	60016700	F	22	04.60
SPECIFICATIONS (I/O)	60003000	C		02.00
CUSTOMER ENGINEERING MANUALS				
PRINCIPLES OF OPERATION INSTR. BOOK	60003200	B		02.00
PART 3 MAINTENANCE	60003300	B		05.80
CE DIAGRAMS	60003500	S	34	14.00
MAINTENANCE LIBRARY	60006600	A		03.70
CHASSIS MAPS, 1604-B	60025600	D	22	10.00
TROUBLE SHOOTING AIDS	60028100	B	22	02.30
EQUATION SUMMARY, PART 1	60070500	C	22	14.00
EQUATION SUMMARY, PART 2	60070600	A	22	12.50
EQUATION SUMMARY, PART 3	60070700	A	22	13.00
1605-A ADAPTER				
(THE FOLLOWING MANUALS FOR THE ABOVE PRODUCT ARE AVAILABLE ON A SPECIAL ORDER BASIS IN MAX. QTY OF 2 COPIES.ALLOW AT LEAST 3-4 WEEKS FOR PROCESSING AND DELIVERY.)				
DESCRIPTION, OPERATION AND MAINTENANCE VOL 1	60003600	B		
1606-A PRINT CONTROL UNIT				
THEO OF OPER, DIAGS, C/P, EQ SUM, W/L, WIRE TABS, CABLE TABS, REFERENCE/CE MANUAL	60004400	A	22	08.30
1607-A MAGNETIC TAPE SYSTEM (PREVIOUSLY 1607)				
DESCRIPTION, OPERATION AND MAINTENANCE	60003700	A	22	08.70
CE DIAGRAMS	60014700	S	22	02.00
EQUATION SUMMARY, CARD PLACEMENT	60014800	E	22	08.40
(THE FOLLOWING MANUALS FOR THE ABOVE PRODUCT ARE AVAILABLE ON A SPECIAL ORDER BASIS IN MAX. QTY OF 2 COPIES.ALLOW AT LEAST 3-4 WEEKS FOR PROCESSING AND DELIVERY.)				
CHARACTERISTICS	60004100	A		
1608 CONTROL UNIT				
VOL.1, DESCRIPTION, OPERATION AND MAINTENANCE	60016400			04.25
CE DIAGRAMS	60016500	A	22	01.60
CARD PLACEMENT AND EQUATION SUMMARY	60016600	A	22	07.95
WIRE LIST, WIRE TABS (1608-A)	60148500	A	22	03.40

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.

4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
1609-A CARD READ AND PUNCH UNIT				
VOL. 1, DESCRIPTION AND OPERATION	60017800			03.25
MAINTENANCE, VOLUME 2	60017900	A	22	05.60
VOL.3 DIAGRAMS CE MANUAL	60018900		34	01.65
1610-A CONTROL UNIT				
VOL 1 DESCRIPTION AND OPERATION	60010600	A		04.50
VOL. 2 MAINTENANCE	60010700	A	22	10.80
CE DIAGRAMS	60018800	A	34	07.00
1611-A LINE PRINTER CONTROLLER				
REFERENCE/CE MANUAL	60127500	F,G	22	07.60
1612-A HIGH SPEED LINE PRINTER				
OPERATION AND MAINTENANCE MANUAL	60009800	B	22	18.50
1612G LINE PRINTER CE MANUAL	60098200	H,J	22	10.50
1612-G LINE PRINTER AND OFF LINE BUFFER	60145100	D,E	22	05.00
EQUATION SUMMARY MANUAL				
1612-B CROSS TABS AND 1612-G WIRE LIST	60151000	D,E	22	04.00
1612 TESTS (REFER TO 1612-A)				
1614-A CARD READER CONTROLLER				
REFERENCE/INSTRUCTION MANUAL	60091700	D		03.75
CARD PLACEMENT AND EQUATION SUMMARY	60287000	A	22	02.00
1615/160 CHANNEL LONG LINE DRIVERS CE MANUAL	60123700	A		00.75
1615-A MAGNETIC TAPE CONTROLLER				
REFERENCE MANUAL	60027200	A	3	03.00
DIAGRAMS	60027600	E	22	03.70
PRELIMINARY CE MANUAL	60097100	A	22	05.90
1617-A CARD READER				
(THE FOLLOWING MANUALS FOR THE ABOVE PRODUCT				
ARE AVAILABLE ON A SPECIAL ORDER BASIS IN				
MAX. QTY OF 2 COPIES.ALLOW AT LEAST 3-4				
WEEKS FOR PROCESSING AND DELIVERY.)				
VOL 1 DESCRIPTION,OPERATION,PROGRAMMING	60021400	A	22	
VOL.2, MAINTENANCE PARTS LIST	60021500	B		
1619-A MAGNETIC DISK FILE CONTROLLER				
REFERENCE MANUAL	60044900			03.00
CE DIAGRAMS	60029200	C	34	03.50
CE INSTRUCTION MANUAL	60107100		22	03.90
(THE FOLLOWING MANUALS FOR THE ABOVE PRODUCT				
ARE AVAILABLE ON A SPECIAL ORDER BASIS IN				
MAX. QTY OF 2 COPIES.ALLOW AT LEAST 3-4				
WEEKS FOR PROCESSING AND DELIVERY.)				
WIRE TABS				

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
CHASSIS 1	22914000	G		
CHASSIS 2	22913900	J		
CHASSTS 3	22913800	F		
CHASSIS 2 TO 3	22913700	H		
CABLE TABS				
CHASSIS 1	22914200	J		
CHASSIS 2	22914300	F		
CHASSIS 3	22914400	K		
1631 DATA CHANNEL CONVERTER				
REFERENCE MANUAL-DESC, OPERATION, PROGRAMMING	38704400	B	22	01.55
DIAGS, P/L, C/P, EQ SUM, W/L CE MANUAL	38704500	D	22	06.00
1700 COMPUTER SYSTEM				
COMMUNICATIONS AND EQUIPMENT REFERENCE MAN.	13795000	B	22	03.10
COMPUTER SYSTEM REFERENCE MANUAL	60153100	F	22	01.50
COMPUTER SYSTEMS CODES	60163500	H	6	01.35
INPUT/OUTPUT SPECIFICATIONS MANUAL	60165800	H	22	01.35
SMM17 ERROR CODES INSTANT	60266200	G		06.00
SMM17 REFERENCE MANUAL - VOLUMES 1 AND 2	60182000	M	22	50.80
SYSTEM 17 INSTALLATION MANUAL	88996000	A	22	12.30
CUSTOMER ENGINEERING MANUALS				
6VDC POWER SUPPLY HARDWARE/REF/CE MAN	39072400			01.00
24VDC POWER SUPPLY HDWE REFERENCE/CE MANUAL	39072200		3	01.00
AT171A, B THREE-PORT A/Q AND INTERRUPT SWITCH	39412900	A	22	04.65
HDWR/REF CE				
AT172A THREE-PORT DSA SWITCH HDWR/REF MAN.	39415100	A	22	05.70
ADSE 8013 21- TRACK MAGNETIC TAPE CONTROLLER	84970400		22	17.00
(MTC) HARDWARE REF./CE MANUAL				
DC115B BUFFERED INPUT/OUTPUT INTERFACE	39308000	A	3	05.50
HARDWARE REFERENCE CE MANUAL				
SEISMIC DECOMMUTATION CHANNEL/WORD ASSEMBLY	39185900		22	05.60
CONTROL HARDWARE REFERENCE/CE MANUAL				
SMM17 PROGRAM LISTINGS - MEM	60220100	F	22	07.35
SMM17 PROGRAM LISTINGS - COM	60220200	E	22	07.10
SMM17 PROGRAM LISTINGS - PTP	60220300	E	22	07.60
SMM17 PROGRAM LISTINGS - PTR	60220400	E	22	05.10
SMM17 PROGRAM LISTINGS - TTY	60220500	F	22	04.85
SMM17 PROGRAM LISTINGS - CR1	60220600	D	22	06.20
SMM17 PROGRAM LISTINGS - MT1	60220700	E	22	08.90
SMM17 PROGRAM LISTINGS - DP1	60220800	F	22	08.90
SMM17 PROGRAM LISTINGS - RPT	60220900	F	22	01.95
SMM17 PROGRAM LISTINGS - BD1	60221000	D	22	05.90
SMM17 PROGRAM LISTINGS - SC1	60221100	F	22	10.50
SMM17 PROGRAM LISTINGS - LP1	60221200	F	22	08.05
SMM17 PROGRAM LISTINGS - MT2	60221300	E	22	06.75
SMM17 PROGRAM LISTINGS - BD2	60221400	D	22	10.60
SMM17 PROGRAM LISTINGS - BTB	60221500	C	22	03.90
SMM17 PROGRAM LISTINGS - DSC	60221600	E	22	01.70
SMM17 PROGRAM LISTINGS - MT3	60221700	G	22	09.35

1-Publication number of literature.

2-The latest revision level.

3-Indicates size of hard cover binder that may be used for manuals.

4-Publication division responsible for contents of literature.

TITLE	1	2	3	4
SMM17 PROGRAM LISTINGS - CRP 1728/430 CARD READER/PUNCH CE MANUAL	60271300	F	22	13.20
SMM17 PROGRAM LISTINGS - (CR3) 1729-2/411 CARD READER	60271400	F	22	10.65
SMM17 PROGRAM LISTINGS - (CR2)1726/405 CARD READER	60271500	E	22	08.65
SMM17 PROGRAM LISTINGS - (DS1) 1747 DATA SET CONTROLLER	60271600	D	22	04.40
SMM17 PROGRAM LISTINGS - 1735/915 OCR OPTICAL CHARACTER READER CE MANUAL	60271700	F	22	20.70
SMM17 PROGRAM LISTINGS (CLK) 10126 INTERVAL TIMER CE MANUAL	60271800	C	22	03.40
SMM17 PROGRAM LISTINGS (CTC) 1749/321-311B COMMUNICATIONS TERMINAL CONTROLLER	60271900	D	22	09.25
SMM17 DDC 1745/1746/210 DATA DISPLAY CE MAN	60273200	E	22	12.55
SMM17 PROGRAM LISTINGS - OC3 FF406 TEST CE	60309200	E	22	18.65
SMM17 PROGRAM LISTINGS (FFT) FAST FOURIER TRANSFORM	60309300	B	22	09.25
SMM17 PROGRAM LISTINGS (CR4) 405/DTB TEST	60309400	C	22	02.75
SMM17 PROGRAM LISTINGS (DAD) DUAL ACCESS DISK TEST CE MANUAL	60309500	B	22	05.45
SMM17 PROGRAM LISTINGS - CAR	60325600	C	22	01.00
SMM17 PROGRAM LISTINGS - DDT	60325700	C	22	02.80
SMM17 PROGRAM LISTINGS - MTS	60325800	E	22	04.05
SMM17 PROGRAM LISTINGS - D1G	60325900	C	22	05.20
SMM17 PROGRAM LISTINGS - OC2	60326100	C	22	05.10
SMM17 PROGRAM LISTINGS - BC1	60326200	C	22	03.70
SMM17 PROGRAM LISTING - AC4	60326300	A	22	06.20
SMM17 PROGRAM LISTINGS - OC4	60326400	D	22	13.40
SMM17 PROGRAM LISTINGS - QL	60411300	C	22	04.95
SMM17 PROGRAM LISTINGS - SMM	60411400	C	22	10.80
SMM17 PROGRAM LISTINGS - DMP	60411500	C	22	03.10
SMM17 PROGRAM LISTING - PNY	60411600	A	22	06.45
SMM17 PROGRAM LISTINGS - U03	60411700	B	22	02.05
SMM17 PROGRAM LISTINGS - RX1	60411800	C	22	05.90
SMM17 PROGRAM LISTINGS - LDR/RX3	60411900	C	22	08.40
SMM17 PROGRAM LISTINGS - RX4	60412000	C	22	10.20
SMM17 PROGRAM LISTINGS - AQM	60412100	C	22	15.25
SMM17 PROGRAM LISTINGS - LST	60412200	C	22	03.85
SMM17 PROGRAM LISTINGS - SAS	60412300	B	22	03.85
SMM17 PROGRAM LISTINGS - MCC	60412400	C	22	21.55
SMM17 PROGRAM LISTINGS - LPX	60412500	B	22	04.65
SMM17 PROGRAM LISTING - DG4	60412600	B	22	04.45
SMM17 PROGRAM LISTINGS - CDD	60412700	C	22	17.85
SMM17 PROGRAM LISTINGS - DRM	60412800	D	22	11.40
SMM17 PROGRAM LISTINGS - GTR	60412900	C	22	10.35
SMM17 PROGRAM LISTINGS - D10	60413000	B	22	02.05
SMM17 PROGRAM LISTINGS - IOM	60413100	C	22	11.65
SMM17 PROGRAM LISTING - RMT	60413200	A	22	02.70
SMM17 PROGRAM LISTING - R03	60413300	A	22	02.60
SMM17 PROGRAM LISTING - CP1	60413400	A	22	02.20
SMM17 PROGRAM LISTING - CP2	60413500	A	22	02.35
SMM17 PROGRAM LISTING - HCA	60413600	A	22	03.75

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover binder that may be used for manuals.
4-Publication division responsible for contents of literature.

TITLE	1	2	3	4
SMM17 PROGRAM LISTING - DP2	60413700	A	22	03.75
SMM17 PROGRAM LISTING - PD4	60413800	A	22	04.05
SMM17 PROGRAM LISTINGS - DP3	60413900	D	22	15.60
SMM17 PROGRAM LISTING - DP4	60414000	A	22	03.00
SMM17 PROGRAM LISTING - BD5	60414100	A	22	02.20
SMM17 PROGRAM LISTING - PLT	60414200	A	22	01.35
SMM17 PROGRAM LISTING - QOB	60414300	A	22	01.70
SMM17 PROGRAM LISTING - CTU	60414400	A	22	04.05
SMM17 PROGRAM LISTING - CTT	60414500	A	22	02.00
SMM17 PROGRAM LISTING - DDD	60414600	A	22	03.25
SMM17 PROGRAM LISTINGS - FDT	60414700	C	22	11.10
SMM17 PROGRAM LISTINGS - MYZ	60422300	C	22	08.40
SMM17 PROGRAM LISTINGS - MY1	60422400	C	22	08.70
SMM17 PROGRAM LISTINGS - UD1	60422500	B	22	02.00
SMM17 PROGRAM LISTINGS - UD2	60422600	B	22	02.05
SMM17 PROGRAM LISTINGS - RC3	60422700	B	22	11.05
SMM17 PROGRAM LISTING - RC2	60422800	B	22	19.10
SMM17 PROGRAM LISTINGS - DP5	60422900	C	22	05.65
SMM17 PROGRAM LISTING - CP4	60423000	A	22	02.75
SMM17 PROGRAM LISTINGS - GT0	60437400	B	22	09.65
SMM17 PROGRAM LISTINGS - GT1	60437500	B	22	20.65
SMM17 PROGRAM LISTINGS - GT2	60437600	B	22	19.10
SMM17 PROGRAM LISTINGS - GT3	60437700	B	22	14.10
SMM17 PROGRAM LISTING - GT4	60437800	A	22	04.05
SMM17 PROGRAM LISTINGS - GT5	60437900	B	22	10.05
SMM17 PROGRAM LISTINGS - GT6	60438000	B	22	17.75
SMM17 PROGRAM LISTINGS - LP5	60438100	B	22	16.75
SMM17 PROGRAM LISTING - HOR	60438200	A	22	10.05
SMM17 PROGRAM LISTING - VSD	60438300	A	22	02.10
SMM17 PROGRAM LISTINGS - KEY	60438400	B	22	09.55
SMM17 PROGRAM LISTINGS - MDC	60438600	B	22	23.05
SMM17 PROGRAM LISTING - DPC	60446100	A	22	04.05
SMM17 PROGRAM LISTING - MTX	60446200	A	22	13.80
SMM17 PROGRAM LISTING - PET	60446300	A	22	06.90
SMM17 PROGRAM LISTING - PAD	60446400	A	22	05.65
SMM17 PROGRAM LISTING - BDL	60446500	A	22	06.10
SMM17 PROGRAM LISTING - REP	60446600	A	22	08.20
SMM17 PROGRAM LISTING - INS	60446700	A	22	06.65
SMM17 PROGRAM LISTING - CMD	60446800	A	22	05.70
SMM17 PROGRAM LISTING - CPY	60447700	A	22	02.25
1703-A STORAGE INCREMENT REF INFO (USE 1700 COMPUTER SYSTEM REF MAN.) MAINT., PARTS LIST (USE 1704-A/B) DIAGRAMS, CIRCUIT DESC., C/P (USE 1704-A/B)				
1704-A/B COMPUTER REF INFO (USE 1700 COMPUTER SYSTEM REF MAN.) DIAGRAMS, CIRCUIT DESCRIPTION, CARD PLACEMENT OF MANUAL (INCLUDES PMI/PMP) MAINTENANCE, PARTS LIST OF MANUAL MAINTENANCE, COMMAND TIMING CHARTS OF MANUAL CROSS TABS OF MANUAL	60152700 60160400 60194500 60283900	AV J-K D C	22 22 22 22	12.70 03.40 03.70 02.45

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
1705-A INTERRUPT DATA CHANNEL REF INFO (USE 1700 COMPUTER SYSTEM REF MAN.) DIAGRAMS, CIRCUIT DESCRIPTION, CARD PLACEMENT (USE 1704-A/B) MAINTENANCE, PARTS LIST (USE 1704-A/B)				
1706-A BUFFERED DATA CHANNEL REFERENCE MANUAL	60330300	C	22	01.00
DIAGRAMS, CIRCUIT DESCRIPTION, MAINTENANCE, PARTS LIST CE MANUAL	60165700	L	22	02.00
CROSS TABS CE MANUAL	60284000	B	22	03.10
1708-A/BB310-A/BB311-A/BB312-A STORAGE INCREMENT REF INFO (USE 1700 COMPUTER SYSTEM REF MAN.) DIAGRAMS, CIRCUIT DESCRIPTION, CARD PLACEMENT (USE 1704-A/B) CE MANUAL	60182900	G	22	05.95
1709-A STORAGE INCREMENT REF INFO (USE 1700 COMPUTER SYSTEM REF MAN.) MAINTENANCE, PARTS LIST (USE 1704-A/B) DIAGRAMS, CIRCUIT DESCRIPTION, CARD PLACEMENT (USE 1704-A/B)				
1711-A/B TELETYPEWRITER REF INFO (FOR 1704-A/B USE 1700 SYSTEM REF. MANUAL) REF INFO (FOR 1714 USE 1714 SYSTEM REF. MANUAL) DIAGRAMS, CIRCUIT DESCRIPTION, MAINTENANCE PARTS LIST, C/P, WIRE LISTS CE MANUAL ** REFER TO VENDOR MANUALS SECTION FOR TELETYPE MANUALS (35KSP)	60164200	AF	22	21.75
1711-3 (CK501-A/B) TELETYPEWRITER (35KSR) REF INFO (USE 1770 REFERENCE MANUAL)				
1712-A TELETYPEWRITER REF INFO (USE 1700 COMPUTER SYSTEM REF MAN.) CE INFO (USE 1711-A/B) ** REFER TO VENDOR MANUALS SECTION FOR TELETYPE MANUALS (35KSR)				
1713-A/B TELETYPEWRITER REF INFO (USE 1700 COMPUTER SYSTEM REF MAN.) CE INFO (USE 1711-A/B) ** REFER TO VENDOR MANUALS SECTION FOR TELETYPE MANUALS (35ASR)				
1713-3 (CK502-A/B) TELETYPEWRITER (35ASR) REF INFO (USE 1770 REF MAN)				

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
1714 (AA116-A, AA119-A/B/C/D, BT150-A/B) BASIC PROCESSOR REFERENCE MANUAL	60364900	B	22	01.75
1716-A COUPLING DATA CHANNEL REFERENCE MANUAL	60330400	B	22	01.00
CE MANUAL	60182800	N	22	01.85
1717-1 (FJ101-A, FJ415-A) DATA SET CONTROLLER REFERENCE MANUAL	13797800	B	22	03.40
1718-A SATELLITE COUPLER REFERENCE MANUAL	60330500	A	22	01.00
** REFER ALSO TO 370 PAPER TAPE READER				
** REFER ALSO TO VENDOR MANUALS SECTION FOR REMEX TAPE SPOOLER CE MANUAL				
1721-A/B PAPER TAPE READER REF INFO (USE 1700 COMPUTER SYSTEM REF MAN.) CE INFO (USE 1711-A/B) ** REFER ALSO TO 350 PAPER TAPE READER FOR ADDITIONAL DOCUMENTATION				
1721-C/D PAPER TAPE READER REF INFO (USE 1700 COMPUTER SYSTEM REF MAN.) CE INFO (USE 1711-A/B) ** REFER ALSO TO 370 PAPER TAPE READER FOR ADDITIONAL DOCUMENTATION				
1722-A/B PAPER TAPE READER REF INFO (USE 1700 COMPUTER SYSTEM REF MAN.) CE INFO (USE 1711-A/B) MAINTENANCE, PARTS LIST (USE 1704-A/B)				
1723-A/B PAPER TAPE PUNCH REF INFO (USE 1700 COMPUTER SYSTEM REF MAN.) CE INFO (USE 1711-A/B) ** REFER TO VENDOR MANUALS SECTION FOR NCR EM-B1 PAPER TAPE PUNCH CE MANUAL				
1724-A/B PAPER TAPE PUNCH REF INFO (USE 1700 COMPUTER SYSTEM REF MAN.) CE INFO (USE 1711-A/B) ** REFER ALSO TO VENDOR MANUAL SECTION FOR NCR EM-B1 PAPER TAPE PUNCH AND NCR EM-B2 TAPE HANDLER CE MANUALS				
1726-1 (FE107-A) CARD READER CONTROLLER REFERENCE MANUAL	60330900	A	22	01.00
1728-A/B (CF504, FF304-A) CARD READER/PUNCH WITH CONTROLLER				

1-Publication number of literature.

2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.

4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
REFERENCE MANUAL CE INFO FOR READER/PUNCH (USE CF504) CE INFO FOR CONTROLLER (USE FE304-A, CATALOG SECTION 1)	60331000	A	22	01.25
1729-2 (CE120-A/B, FE110-A) CARD READER WITH CONTROLLER REFERENCE MANUAL	60331100	A	22	01.00
1729-3 CARD READER CONTROLLER REFERENCE MANUAL	89637400	02	22	01.15
1729-A/B CARD READER REF INFO (USE 1700 REF MAN) CE INFO (USE 1711-A/B)				
1731-A/B MAGNETIC TAPE CONTROLLER REFERENCE MANUAL CE MANUAL	60330700 60167500	A M	22 22	01.00 06.20
1732-A/B MAGNETIC TAPE CONTROLLER REFERENCE MANUAL CE MANUAL	60330800 60208200	A L	22 22	01.50 22.20
1732-2 (SYSTEM 17) MAGNETIC TAPE TRANSPORT CONTROLLER REFERENCE MANUAL	89637600	03	22	02.25
1732-3 (SYSTEM 17) MAGNETIC TAPE TRANSPORT CONTROLLER REFERENCE MANUAL	89769400	01	22	02.95
1733-1 (FA102-A) DISK STORAGE CONTROLLER REFERENCE MANUAL	60400200	A	22	01.30
1733-2 CARTRIDGE DISK DRIVE CONTROLLER REFERENCE MANUAL	89638000	03	22	01.65
1735 (FF103-A) PAGE READER CONTROLLER REFERENCE MANUAL	60237800	D	22	01.80
1736-1 (FF406-A/B/C) UNIT RECORD READER CONTROLLER REF INFO (USE 935 OCR SYSTEM REF/OPERATORS MANUAL)				
1738-A/B/C DISK DRIVE CONTROLLER REFERENCE MANUAL CE MANUAL	60330600 60167700	B U	22 22	05.10 05.35
1739-1 (BR401-A/B, FV227-A/B, GD121-A, GH421-A) CARTRIDGE DISK DRIVE REFERENCE MANUAL	60368600	B	22	03.25

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
1740 (FF516-A) LINE PRINTER CONTROLLER REFERENCE MANUAL	60331200	A	22	01.00
1742-A/B (CL309-A/B, FF511-A/B) LINE PRINTER WITH CONTROLLER REFERENCE MANUAL CE INFO FOR PRINTER (USE CL309-A/B, CATALOG SECTION 1) CE INFO FOR CONTROLLER (USE FF511-A/B)	60331300	B	22	01.40
1742-30/120 LINE PRINTER CONTROLLER REF MAN	89637200	02	22	01.10
1743-1 SYNCHRONOUS COMMUNICATION CONTROLLER AND DISTRIBUTION PANEL REFERENCE MANUAL	89638400	02	22	01.90
1743-2 ASYNCHRONOUS COMMUNICATION CONTROLLER AND DISTRIBUTION PANEL REFERENCE MANUAL	89638200	02	22	01.45
1747 (FJ412-A/B/C) DATA SET CONTROLLER REFERENCE MANUAL	13799000	C	22	01.65
1748 MULTIPLEXER CONTROLLER C/P, LOGIC WIRING, WIRE LTSTS, EQ SUM CE MAN	41601500	01	22	15.75
1748 MULTIPLEXER CONTROLLER REFERENCE MANUAL	13794400	A	22	03.90
1748-2 (FJ103-A/B) MULTIPLEXER CONTROLLER REFERENCE MANUAL	41601600	A	22	03.70
1749-A/B COMMUNICATION TERMINAL CONTROLLER REFERENCE MANUAL THEORY OF OPERATION, MAINT., INSTALLATION, PARTS LIST, DIAGRAMS, CARD PLACEMENT CE MAN WIRE LISTS, EQ SUMMARY, MAINT. AIDS CE MAN	36827100 36827000 36829100	D H G	22 22 22	01.25 02.00 09.25
1750 DATA AND CONTROL TERMINAL (DCT) OPERATION AND MAINTENANCE INSTRUCTION MANUAL	39072900	E	22	07.15
1750-1 (EL101-A) COMPUTER INTERFACE UNIT				
1750-2 (EL102-A) COMPUTER INTERFACE EXPANDER				
1751 DRUM INTERFACE AND STORAGE UNIT OPER AND INSTRUCTION MANUAL DRUM STORAGE UNIT HDR. REF./CE MANUAL	39071100 39216600	003	22 22	03.10 03.40
1770/SC-1700 SYSTEM CONTROLLER REFERENCE MANUAL COMPUTER SYSTEM CODES (USE 1700) I/O SPECIFICATIONS MANUAL	60270600 60285200	B 04	22 22	01.90 01.00
1772-1 (BB329-A) MEMORY INCREMENT MODULE REF INFO (USE 1770 REF MAN)				

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
1772-2 (BB329-A) MEMORY EXPANSION UNIT REF INFO (USE 1770 REF MAN)				
1773-1 (DC120-A) DIRECT ACCESS STORAGE MODULE REF INFO (USE 1770 REF MAN)				
1774-1 (AC109-A/B/C) COMPUTE MODULE REF INFO (USE 1770 REF MAN)				
1775-1 (DC118-A) A/O INTERRUPT DATA CHANNEL REF INFO (USE 1770 REF MAN)				
1777-1 (CE305-A/B, CF104-A, CF508-A/B) PAPER TAPE STATION REFERENCE MANUAL	60331400	B	22	01.00
1777-2 (CE305-A/B, CF104-A, CF508-A/B, CW123-A) PAPER TAPE STATION W/VALIDATION OPT. REF INFO (USE 1777-1 REF MAN)				
1778-1 (GJ102-A) PAPER TAPE READER HANDLER REF INFO (USE 1777-1 REF MAN)				
1778-2 (GJ103-A/B) PAPER TAPE PUNCH HANDLER REF INFO (USE 1777-1 REF MAN)				
1779-1 (DC119-A) CHARACTER HANDLING REF INFO (USE 1770 REF MAN)				
1784 (SYSTEM 17) COMPUTER SYSTEM INPUT/OUTPUT SPECIFICATIONS	89673100	02	22	04.40
1784-1/2 () COMPUTER SYSTEM REFERENCE MANUAL	89633400	A	22	02.25
CE MANUAL	89633300	04	22	22.50
2017-A BADGE READER ADAPTER CE/REF MANUAL	13790500	D	22	05.50
2014-A TIME EMITTER CE MANUAL VOL 2 EQ FILE AND WIRE LIST MANUAL	13794700	C	22	02.25
REFERENCE/CE MANUAL	13794600	B	22	01.70
2014-B TIME EMITTER REFERENCE/CE MANUAL	13794800	A	22	01.00
2020 COMPILER CE MANUAL - DIAGRAMS	36820000	F	22	03.05
ILLUSTRATED PARTS MANUAL (TRANSACTION SYSTEM)	65631800	A	22	01.05
TRANSACTION SYSTEM REFERENCE MANUAL	36817600	A	22	03.25
INSTALLATION MANUAL	36820400	B	22	02.00
2022-P DATA COLLECTOR CONTROLLER CE MANUAL	13796200	B		02.40

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
2025-1/2 MAGNETIC TAPE COMPILER SYSTEM USERS MANUAL	65690800	B	22	06.05
SFTWR. DESC., SYS. DESC., SYSTEM REF.MAN.	65655800	B	22	06.15
SOFTWARE INSTALLATION MANUAL	65727400	A	22	01.25
2040 AUTOMATIC SHUNT CE DIAGRAMS MANUAL	36820100	C	34	02.00
2070-A CONCENTRATOR CE DIAGRAMS MANUAL	36820200	A	34	02.75
2070-B/2075-B CONCENTRATOR CONVERTER CE MANUAL-THEO OF OPER,DIAGS,P/L,C/P,W/L	36829800	C	22	03.60
2075-A CONVERTER CE DIAGRAMS MANUAL	36820300	A	34	01.75
2077/2078/2079 CONCENTRATOR TERMINAL REF. MAN.	13790300	B	22	01.25
CE MANUAL VOL I THEO OF OPER,MAINT,DIAG, P/L	13790100	G	22	13.90
CE MANUAL VOL II OF 4 (INCL EQ FILE, W/L)	13790200	D	22	10.00
CE MANUAL VOL III EQ FILE, LOGIC WIRING,W/L	13791300	D	22	15.35
2079 CONCENTRATOR TERM. CE MANUAL VOL 4 OF 4	13791400	D	22	02.85
2085-A/2086-A TRUNK LINE CONTROLLER REF MANUAL	13790700	A		01.00
LOGIC WIRING, W/L, EQ. FILE, C/P, VOL II CE MANUAL	13790800	D	22	07.65
CE MANUAL VOL 1 AND 2	36829500	F	22	02.50
2086-B TRUNK LINE CONTROLLER REFERENCE MANUAL	13792500	D	22	01.00
OPER,MAINT,DIAGRAMS AND PARTS LIST CE MANUAL	13792400	I	22	03.40
CE MANUAL VOL 2 (INC WIRE LIST,EQ FILE)	13792700	E	22	02.85
3000 SERIES COMPUTER SYSTEM INPUT/OUT SPECIFICATIONS	60048800	M	22	02.30
INSTRUCTION CODES (3100/3200)	60150200	B		01.35
PERIPHERAL EQUIPMENT CODES	60113400	J		01.65
SITE PREPARATION AND INSTALLATION MANUAL	60110400	M-N	22	04.00
CUSTOMER ENGINEERING MANUALS				
PERIPHERAL CONTROLLER CABINETS CE MANUAL INFORMATION (1700/3000/6000) SOLID FRONT STYLE	60224100	Z	22	02.20
3000L SYSTEM MAINT. MONITOR REF MAN VOL 1+2	60118600	M	22	20.00
PM1/PMP MAINT SERIES CONTROLLER (3000)	60317800	A	22	01.00
REAL TIME SYSTEMS EXECUTIVE TEST ROUTINES (3100/3200/3300)	13793100	A	22	02.15
3100/3200/3300 COMPUTER MEMORY PATTERN TEST	13793300		22	01.00
3100/3200/3300 COMPUTER UTILITY ROUTINE	13793400		22	01.50
IBM 360/370 SMM CE MANUAL	60383300	04	22	04.70
SMM3L PROGRAM LISTINGS MONITOR	60300000	F	22	07.20
SMM3L PROGRAM LISTINGS (SPV) SERVICE ROUTINE CE MANUAL	60300100	C	22	02.10

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
SMM3L PROGRAM LISTINGS (MEM) MEMORY TEST FOR 3200	60300200	B	22	02.25
SMM3L PROGRAM LISTINGS (MM1) 2DP MEMORY CE	60300300	D	22	03.25
SMM3L PROGRAM LISTINGS (MM2) 3300 MEMORY	60300400	G	22	08.95
SMM3L PROGRAM LISTINGS (LOG) 3L00 LOGIC	60300500	E	22	05.65
SMM3L PROGRAM LISTINGS (COM)	60300600	E	22	24.95
SMM3L PROGRAM LISTINGS (FPT) FLOATING POINT TEST	60300700	E	22	07.00
SMM3L PROGRAM LISTINGS (MOE) MOVE TEST	60300800	B	22	01.00
SMM3L PROGRAM LISTINGS (RAN) RANDOM INSTR.	60300900	C	22	04.10
SMM3L PROGRAM LISTINGS 322X MAG TAPE (MT1)	60301000	C	22	04.25
SMM3L PROGRAM LISTINGS (MT6) 3127/601 MAG TAPE TEST	60301100	C	22	02.65
SMM3L PROGRAM LISTINGS (MTQ) 3600/322X/60X TAPE	60301300	E	22	04.15
SMM3L PROGRAM LISTINGS (CH1) 3207/6 CHANNEL TEST	60301400	D	22	02.40
SMM3L PROGRAM LISTINGS (CH2) CHANNEL TEST 3234 853/854, 813/814 CE MANUAL	60301500	G	22	11.30
SMM3L PROGRAM LISTINGS (LP2) 501 LINE PRINT-	60301600	B	22	01.30
SMM3L PROGRAM LISTINGS (TP1) CONSOLE TYPEWRITER	60301700	B	22	01.60
SMM3L PROGRAM LISTINGS (OP4) DISK PACK TEST	60301800	C	22	03.25
SMM3L PROGRAM LISTINGS (MS1)	60301900	G	22	21.65
SMM3L PROGRAM LISTINGS DM19DM29 3235 DRUM 3236/3237/861 DRUM CE MANUAL	60302000	C	22	02.30
SMM3L PROGRAM LISTINGS (OD5) 3290C DISPLAY	60302200	C	22	02.75
SMM3L PROGRAM LISTINGS MEMORY INTERRUPT TEST FOR 3300	60302500	B	22	01.80
SMM3L PROGRAM LISTINGS (FX2) EXECUTIVE MODE	60302600	F	22	03.05
SMM3L PROGRAM LISTINGS (SPS) 3300 SELECTIVE PROTECT SWITCH TEST	60302700	C	22	02.30
SMM3L PROGRAM LISTINGS (PF1) 3300 PAGE FILE ILLEGAL WRITE TEST	60302800	C	22	01.10
SMM3L PROGRAM LISTINGS (OVN) EXECUTIVE MODE MONITOR	60303000	F	22	09.15
SMM3L PROGRAM LISTINGS (CP4) 3446/3644 CARD PUNCH CONTROLLER	60303100	D	22	02.60
SMM3L PROGRAM LISTINGS (CR4) 3248/3447/3649 CARD READER CONTROLLER	60303200	D	22	03.55
SMM3L PROGRAM LISTINGS 3L00 QUICK LOOK MEMORY TEST	60303700	B	22	02.90
SMM3L PROGRAM LISTINGS 3L00 QUICK LOOK COMMAND TEST	60303800	C	22	08.85
SMM3L PROGRAM LISTINGS 3200 EXTERNAL EQUIP.	60303900	E	22	07.35
SMM3L PROGRAM LISTINGS - RFT	60304000	B	22	01.70
SMM3L PROGRAM LISTINGS MMX INTERRUPT PROC.	60304100	E	22	07.40
SMM3L PROGRAM LISTINGS MS3	60304200	B	22	06.00
SMM3L PROGRAM LISTINGS LOADING	60304300	B	22	04.50
SMM3L PROGRAM LISTINGS DCP 17	60304400	E	22	05.60
SMM3L PROGRAM LISTINGS SIMULATED RANDOM INSTR. TEST	60304500	B	22	12.70
SMM3L PROGRAM LISTINGS-3316 CONTROLLER CEN	60304600	C	22	21.40

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover binder that may be used for manuals.
4-Publication division responsible for contents of literature.

TITLE	1	2	3	4
SMM3L PROGRAM LISTINGS MM4	60304700	B	22	03.80
SMM3L PROGRAM LISTINGS-BDP TESTS 3312-A	60336500	D	22	17.60
SMM3L PROGRAM LISTINGS - BDP TESTS 3504	60336600	C	22	17.75
SMM3L PROGRAM LISTINGS-BDP TESTS 3312-B	60336700	C	22	14.55
SMM3L PROGRAM LISTINGS - BDP TESTS 3514	60336800	D	22	18.10
SMM3L PROGRAM LISTINGS - 3300/3500 PAGE FILE TEST - PFT	60336900	D	22	10.50
SMM3L PROGRAM LISTINGS - 3266 COMMUNICATIONS CONTROLLER (CTC)	60337000	B	22	04.30
SMM3L PROGRAM LISTINGS-3553-2/ 821 MS4	60337100	D	22	25.75
SMM3L PROGRAM LISTINGS - (PFR) PAGE READER	60337200	B	22	05.05
3010 LINE PRINTER EQUIPMENT				
CE MANUAL PARTS DATA	44896500	A	22	02.50
REFERENCE CE MANUAL	47500700	D	22	03.50
PRINTER EQUIPMENT CE MAN. (USE CL308-A/B)				
3020-A ALPHANUMERIC INPUT TERMINAL				
REFERENCE/CE MANUAL	36829600	D	22	01.95
EQUATION SUMMARY, LOGIC WIRING CE MANUAL	36829700	C	22	03.70
3100 COMPUTER SYSTEM				
REFERENCE MANUALS				
COMPUTER SYSTEM REFERENCE MANUAL	60108400	D	22	06.70
INSTRUCTION CARD (3100/3200)	60043000	B		00.75
CUSTOMER ENGINEERING MANUALS				
OPTIONAL ARITH. CIRCUIT DESC (3100/3200)	60101400	B	22	12.45
CE MANUAL				
PMI/PMP CE MANUAL	60318200	A	22	01.00
3101-A/B/C CONSOLE				
REF INFO (USE 3100 COMPUTER SYSTEM REF MAN)				
PARTS LIST (USE 3104-A/B)				
DIAGRAMS (USE 3104-A/B/C)				
** SEE 3192-A/B/C ALSO FOR TYPEWRITER MANUAL				
3103-A STORAGE MODULE				
DIAGRAMS (USE 3104-A/B)				
REF INFO (USE 3100 COMPUTER SYSTEM REF MAN)				
PARTS LIST (USE 3104-A/B)				
CARD PLACEMENT, EQ SUMMARY, WIRE LIST CE MAN (INCLUDES PREVIOUS PUB NO.S 35111000 AND 35111100) (ALSO INCLUDES 3113-A/B INFO)	35110900	C	22	08.20
3104-A/B, 3114-A/B COMPUTER				
REF INFO (USE 3100 COMPUTER SYSTEM REF MAN)				
CIRCUIT DESCRIPTION CE MANUAL	60111200	A	22	03.50
DIAGRAMS CE MANUAL	60111100	BE	22	08.00

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover binder that may be used for manuals.
4-Publication division responsible for contents of literature.

TITLE	1	2	3	4
MAINTENANCE COMMAND TIMING CHARTS CE MANUAL	60112400	A	22	05.00
PARTS LIST CE MANUAL	60157200	C	22	06.05
CARD PLACEMENT, EQUATION SUMMARY CE MANUAL	60152500	AD	22	30.00
WIRE LIST (TERM) CE MANUAL	60152600	AA	22	16.55
WIRE LIST (HAND TABS) CE MANUAL	60162600	J	22	06.30
3104-C/3114-C COMPUTER				
REF INFO (USE 3100 COMPUTER SYSTEM REF MAN)				
CIRCUIT DESCRIPTION (USE 3104-A/B)				
DIAGRAMS (USE 3104-A/B)				
MAINT. COMMAND TIMING CHARTS (USE 3104-A/B)				
PARTS LIST (USE 3104-A/B)				
CARD PLACEMENT, EQUATION SUMMARY CE MANUAL	60197900	S	22	26.00
WIRE LIST (TERM) CE MANUAL	60198000	M	22	15.10
WIRE LIST (HAND TABS) CE MANUAL	60198200	D	22	09.10
3106-A/B DATA CHANNEL				
REF INFO (USE 3100 COMPUTER SYSTEM REF MAN)				
CE INFO (USE 3104-A/B)				
3107-A/B DATA CHANNEL				
REF INFO (USE 3100 COMPUTER SYSTEM REF MAN)				
DIAGRAMS (USE 3104-A/B)				
PARTS LIST (USE 3104-A/B)				
CARD PLACEMENT, EQUATION SUMMARY				
** USE 3104-A/B FOR 3104-A/B, 3114-A/B SYSTEMS				
** USE 3104-C FOR 3104-C, 3114-C SYSTEMS				
WIRE LISTS (SAME AS CARD PLACEMENT ABOVE)				
3108-A MEMORY EXPANSION UNIT				
REF INFO (USE 3100 COMPUTER SYSTEM REF MAN)				
CE INFO (USE 3104-A/B)				
3109-A/B MEMORY MODULE				
REF INFO (USE 3100 COMPUTER SYSTEM REF MAN)				
DIAGRAMS (USE 3104-A/B)				
PARTS LIST (USE 3104-A/B)				
CARD PLACEMENT, EQ SUMMARY				
** USE 3104-A/B FOR 3104-A/B, 3114-A/B SYSTEMS				
** USE 3104-C FOR 3104-C, 3114-C SYSTEMS				
WIRE LISTS (SAME AS CARD PLACEMENT ABOVE)				
3113-A/B STORAGE MODULE				
CARD PLACEMENT, EQ SUMMARY, WIRE LISTS (USE 3103-A)				
3121-A/B (FA414-A/B) MAGNETIC TAPE CONTROLLER REFERENCE MANUAL	60332000	A	22	01.10
3127-A/B MAGNETIC TAPE CONTROLLER CE MANUAL	60140400	R	22	17.90
REFERENCE MANUAL	60331800	B	22	03.50

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover binder that may be used for manuals.
4-Publication division responsible for contents of literature.

TITLE	1	2	3	4
3127/3228/3329 MAG TAPE CONTROLLER AND 60X MAG TAPE TRANSPORT TEST ROUTINE	13790400		22	02.30
3128-A/B MAGNETIC TAPE CONTROLLER CE MANUAL	60202600	K	22	09.65
REFERENCE MANUAL	60331900	A	22	01.35
3142-A/B CARD READER AND CONTROLLER CE MANUAL	60160300	G	22	05.55
REFERENCE MANUAL	60332400	A	22	01.20
3150 DATA PROCESSING SYSTEM				
REFERENCE MANUAL	60207800	A	22	02.55
SOURCE DATA COLLECTION SYS SOFTWARE DESC.	65724900		3	01.00
3152-A/B LINE PRINTER CONTROLLER				
CIRCUIT DESCRIPTION, DIAGRAMS, MAINT, PARTS LIST, CARD PLACEMENT, EQ SUMMARY CE MANUAL	60108100	F	22	22.65
CROSS TABS OF MANUAL	60147200	B	22	04.00
TEST ROUTINE	13793200		22	01.05
3170 COMPUTER SYSTEM				
REFERENCE MANUAL				
I/O SPECIFICATIONS (USE 3000 I/O)	60341500	C	22	10.00
3172 (BB105-A) MAGNETIC CORE STORAGE				
REF INFO (USE 3170)				
3174-1 (AC105-B, 3301-A, 3311-A) BASIC PROCESSOR				
REF INFO (USE 3170)				
3174-2 (AC105-B, 3301-A, 3310-A, 3311-A) SCIENTIFIC PROCESSOR				
REF INFO (USE 3170)				
3174-3 (AC105-B, 3301-A, 3311-A, AF101-B) BUSINESS DATA PROCESSOR				
REF INFO (USE 3170)				
3174-4 (AC105-B, 3301-A, 3310-A, 3311-A, AF101-B) GENERAL PROCESSOR				
REF INFO (USE 3170)				
3177 (3306-C, 3307-A) COMMUNICATIONS CHANNEL				
REF INFO (USE 3170)				
3192-A/B/C/D ON-LINE MONITOR TYPEWRITER				
CE MANUAL	60150100	J	22	06.45
TEST ROUTINE	13793600		22	01.05
3195-A PAGE READER CONTROLLER				
REFERENCE MANUAL	60166900	D	22	02.00
CE MANUAL	60167000	D	22	08.00

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover binder that may be used for manuals.
4-Publication division responsible for contents of literature.

TITLE	1	2	3	4
3200 COMPUTER SYSTEM				
REFERENCE MANUAL COMPUTER SYSTEM	60043800	J	22	02.30
CUSTOMER ENGINEERING MANUALS (INCLUDE INFO ON 3203-A, 3204A/B, 3205A/B, 3206 3207A/B, 3209-A, 3210-A/B, 3215-A/B)				
CARD PLACEMENTS	31620199	AK	34	05.50
EQUATION SUMMARY, VOLUME 1 AND 2	31620099	Y	34	19.05
WIRE LIST, TERM LIST	31620200	AD	22	17.95
WIRE LIST, HAND TABS	31620300	P		08.25
CE DIAGRAMS	60049400	AY	22	13.40
PARTS LIST	60075400	D	22	07.45
CE MANUAL CIRC DESC., COMPUTATION SECT.	60100900	C	22	09.80
MAINTENANCE COMMAND TIMING CHARTS	60101100	B	22	15.00
3203 DISK DIAGNOSTIC TEST ROUTINE MANUAL	41611300	A	22	04.50
3216 REAL TIME COMMUNICATION MODULE				
CE MANUAL	13792100	A	22	01.20
CE DIAGRAMS MANUAL	13792200	B	34	02.00
3217 REAL TIME COMMUNICATION MODULE AND B.A.T.E. EXCHANGE TEST ROUTINES	13794100	A	22	02.85
3218-A PROGRAMMED DATA CHANNEL REF/CE MANUAL	60116100	E	22	07.00
(THE FOLLOWING MANUALS FOR THE ABOVE PRODUCT ARE AVAILABLE ON A SPECIAL ORDER BASIS IN MAX. QTY OF 2 COPIES. ALLOW AT LEAST 3-4 WEEKS FOR PROCESSING AND DELIVERY.)				
EQUATION SUMMARY	60115900			
WIRE TABS	24146700			
3228-A/B MAGNETIC TAPE CONTROLLER				
REFERENCE MANUAL	60331700	C	22	01.40
CE MANUAL	60093700	V	22	07.05
3229-A/B MAGNETIC TAPE CONTROLLER (USE 3228-A) REF INFO (USE 3228-A/B)				
3231-A DISK PACK CONTROLLER				
REFERENCE MANUAL	60110900	C	22	01.75
CE MANUAL	60111000	B	22	06.00
3232-A/B DISK DRIVE CONTROLLER				
REFERENCE MANUAL	60165300	01	22	02.50
CE MANUAL	60165400	E	22	21.60
3234-A/B MASS STORAGE CONTROLLER				
REFERENCE MANUAL	60333300	B	22	02.20

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
DIAGRAMS CE MANUAL	60167900	AD	22	08.50
WIPE LIST, EQUATION SUMMARY CE MANUAL	60268900	P	22	10.00
TEST ROUTINE	41606500	A	22	02.00
(SEE ALSO SPECIAL OPTION 60076-A)				
3234-D/E MASS STORAGE CONTROLLER CE MANUAL	60394800	D	22	12.75
3235-A DRUM STORAGE SUBSYSTEM REFERENCE MANUAL	60165100	01		02.75
CE MANUAL	60165200	01	22	09.50
3245-A CARD PUNCH CONTROLLER REFERENCE MANUAL	60332200	A	22	01.25
CE MANUAL	60105100	J, K	22	08.00
3248-A/B CARD READER CONTROLLER REFERENCE MANUAL	60332300	D	22	02.85
CE MANUAL	60100400	R	22	03.05
3248/405 TEST ROUTINE	13793800		22	01.60
3254 (CL308-A, FF510-A/B) LINE PRINTER WITH CONTROLLER				
REFERENCE MANUAL	60332900	A	22	01.00
3256-A/B/C LINE PRINTER CONTROLLER REFERENCE MANUAL	60332500	A	22	01.25
CE MANUAL	60113900	AD	22	05.70
3256/3659 TEST ROUTINE	13793900		22	01.10
3266-B COMM TERMINAL CONTROLLER THEO OF OPER INSTAL., MAINT., AND PARTS LIST	36825800	J	22	01.50
MAINTENANCE AIDS MANUAL	36825900	J	22	03.25
DIAGRAMS MANUAL	36826000	H	34	03.00
REFERENCE MANUAL	36828100	D	22	01.00
3270-A/B TRANSFER SWITCH CONTROLLER REF/CE MANUAL	60417300	A	22	09.05
3275-C DATA SET CONTROLLER REFERENCE MANUAL	13791500	A	22	01.20
CE MANUAL	13791600		22	01.00
3276 COMMUNICATION TERMINAL CONTROLLER MAINTENANCE MANUAL	36816200	A	22	03.50
3293-A/B INCREMENTAL PLOTTER REFERENCE MANUAL	60332700	B	22	01.00
CE MANUAL	60090500	N	22	03.85
3300 COMPUTER SYSTEM REFERENCE MANUAL	60157000	N	22	04.50
COMMAND TIMING CHARTS CE MANUAL	60185600	B	22	08.50

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
INSTRUCTION CODES (POCKET-SIZE) (INCLUDES 3500)	60186900	D		00.75
ON-LINE DIAGNOSTICS (33/3500 MASTER) GIM	60329900	A	22	01.00
ON-LINE DIAGNOSTICS (33/3500 MASTER) REF MAN	60323400	04	22	14.70
3301-A (3174-1/2/3/4, 3304-2/3) DESK CONSOLE REF INFO (USE 3170 OR 3300) CIRCUIT DESCRIPTION, DIAGRAMS, MAINTENANCE (USE 3304-A) MAINTENANCE - PMI/PMP (USE 3304-A) PARTS LIST (USE 3304-A)				
3302-A/BB316-A STORAGE MODULE REF INFO (USE 3300 COMPUTER SYSTEM REF MAN) CIRCUIT DESCRIPTION, DIAGRAMS, MAINTENANCE (USE 3304-A) WIRE LIST; HAND TABS (USE 3304-A) MAINTENANCE - PMI/PMP (USE 3304-A) EQUATION SUMMARY (USE 3304-A) CARD PLACEMENT (USE 3304-A) WIPE LIST (TERM LIST) (USE 3304-A) PARTS LIST (USE 3304-A)				
3304-A CENTRAL PROCESSOR CIRCUIT DESCRIPTION, DIAGRAMS, MAINT CE MAN REF INFO (USE 3300 COMPUTER SYSTEM REF MAN) WIRE LIST; HAND TABS CE MANUAL MAINTENANCE - PMI/PMP CE MANUAL EQUATION SUMMARY CE MANUAL CARD PLACEMENT CE MANUAL WIRE LIST (TERM LIST) CE MANUAL PARTS LIST CE MANUAL	60152300	DT	22	10.15
	60317500	B	22	26.00
	60318300	A	22	01.00
	60153900	BA	22	20.00
	60154000	AZ	34	06.05
	60154100	BC	22	14.95
	60160700	E	22	10.00
3304-B/AC105-B (3304, 3304-2/3) CENTRAL PROC. REF INFO (USE 3300 COMPUTER SYSTEM REF MAN) CIRCUIT DESCRIPTION, DIAGRAMS, MAINTENANCE (USE 3304-A) WIRE LIST; HAND TABS (USE 3304-A) MAINTENANCE - PMI/PMP (USE 3304-A) EQUATION SUMMARY, CARD PLACEMENT CE MANUAL ** 3304-3/AC105-B, 3310-A, STD. OPT. 10099-B ONLY. ORDER 3304-A EQUATION SUMMARY IF INFORMATION REQUIRED FOR 3311-A, 3309-A, 3302-A, 3306-A/B/C, 3307-A. WIRE LIST (TERM LIST) CE MANUAL ** 3304-3/AC105-B, 3310-A, ST.OP.10099-B ONLY. ORDER 3304-A WIRE LIST IF INFORMATION REQUIRED FOR 3311-A, 3309-A, 3302-A, 3306-A/B/C, 3307-A PARTS LIST (USE 3304-A)	60213100	H	22	23.00
	60213200	F	22	15.50
3304-2 (AC105-B, AF101-A, 3301-A) BUSINESS				

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.

4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
DATA PROCESSOR REF INFO (USE 3300 COMPUTER SYSTEM REF MAN) CE INFO (SEE APPROPRIATE EQUIPMENT)				
3304-3 (AC105-B, AF101-B, 3301-A) BUSINESS DATA PROCESSOR REF INFO (USE 3300 COMPUTER SYSTEM REF MAN) CE INFO (SEE APPROPRIATE EQUIPMENT)				
3306-A/B/C COMMUNICATION CHANNELS REF INFO (USE 3300 COMPUTER SYSTEM REF MAN) CE INFO (USE 3304-A)				
3307-A COMMUNICATION CHANNEL REF INFO (USE 3300 COMPUTER SYSTEM REF MAN) CE INFO (USE 3304-A)				
3309-A STORAGE MODULE REF INFO (USE 3300 COMPUTER SYSTEM REF MAN) CE INFO (USE 3304-A)				
3310-A (3174-2/4) FLOATING POINT MODULE REF INFO (USE 3170 OR 3300) CE INFO EXCEPT WIRE LIST, EQ SUM (USE 3304-A WIRE LIST/EQ SUMMARY (USE 3304-A OR 3304-B) FOR 3300 SYSTEMS) (USE ONLY 3304-B FOR 3170 SYSTEMS)				
3311-A (3174-2/4) MULTIPROGRAMMING MODULE REF INFO (USE 3170 OR 3300) CE INFO (USE 3304-A FOR 3300 SYSTEMS) (USE 3304-B FOR 3170 SYSTEMS)				
3312-A/AF101-A (3304-2) BUSINESS DATA PROCESSOR REF INFO (USE 3300 COMPUTER SYSTEM REF MAN) MAINTENANCE - PMI/PMP (USE 3304-A) PARTS LIST (USE 3304-A) WIRE LIST (TERM LIST, HAND TABS) CE MANUAL EQUATION SUMMARY, CARD PLACEMENT CE MANUAL DIAGRAMS CE MANUAL MAINTENANCE COMMAND TIMING CHARTS	60197600 60186700 60162900 60209800	P P T H	22 22 22 22	07.05 13.50 05.15 11.80
3312-B/AF101-B (3304-3) BUSINESS DATA PROCESSOR REF INFO (USE 3300 COMPUTER SYSTEM REF MAN)				
3316-1 (FJ601-A) MULTIPLEXER CONTROLLER REFERENCE MANUAL TEST ROUTINE MANUAL	13796800 41600300	F A	22 22	05.00 01.35
3344 DIGIGRAPHIC CONTROLLER HDWR REF/CE MAN.	82146800	A00	22	05.15

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
3400 COMPUTER SYSTEM				
INSTRUCTION CARD	60070000			00.75
INSTRUCTION CODES (3400)	60150300			00.75
REFERENCE MANUAL	60028200	P	22	02.95
CUSTOMER ENGINEERING MANUALS				
CE DIAGRAMS	60096900	AF	22	15.00
CE INST/PART 1 THEORY OF OPERATION	60097000	C	22	13.20
MAINTENANCE MONITOR (SMM34) VOLS 1 AND 2	60126400	D	22	25.00
COMMAND TIMING CHARTS	60141800	CDE	22	08.35
WIRE TABS, CABLE TABS AND CROSS TABS	60146000	K	34	22.70
(THE FOLLOWING MANUALS FOR THE ABOVE PRODUCT ARE AVAILABLE ON A SPECIAL ORDER BASIS IN MAX. QTY OF 2 COPIES.ALLOW AT LEAST 3-4 WEEKS FOR PROCESSING AND DELIVERY.)				
PARTS LIST	60149900	A	22	
3401 CONSOLF TYPEWRITER CONTROL CARD PLCMT, EQUATION SUMMARY,WIRE TABS,CABLE TABS,CROSS TABS	60145500	A	34	06.00
3404-A BASIC 16K COMPUTER CARD PLCMTS AND EQUATION SUMMARY VOL 1 AND 2	60145900	J	22	24.10
WIRE TABS, CABLE TABS AND CROSS TABS	60146000	K	22	22.70
3406-A STANDARD T/O CHANNEL CARD PLACEMENTS, EQUATION SUMMARY,WIRE TABS,CABLE TABS,CROSS	60145600	C,D	34	15.00
3409-A 32K STORAGE OPTION CARD PLACEMENTS, EQUATION SUMMARY,WIRE,CABLE AND CROSS TABS	60145700	B	22	09.30
3410-A FLOATING POINT OPTION C/P, EQ SUMMARY, WIRE LIST CE MANUAL (INCLUDES PREVIOUS PUB NO.S 32501400 AND 32501500)	32501300	B	22	06.50
3416-A STANDARD I/O CHANNEL CARD PLACEMENT, EQUATION SUMMARY, WIRE LIST CE MANUAL (INCLUDES INFO FOR PREVIOUS PUB NO.S 32503400 AND 32503500 - ALSO INCLUDES 3417-A INFO FOR PREVIOUS PUB NO.S 32503700, 32503800 AND 32503900)	32503300	E	22	28.70
3417-A DIRECT ACCESS CHANNEL CE INFO (SEE 3416-A)				
3421-A/B/3422-A/B/3423-A/B MAG TAPE CONTROLLER THEO OF OPER, MAINT, PARTS LIST, DIAGRAMS MAN REFERENCE MANUAL	60102300	U	22	06.30
	60331600	D	22	01.30
342X-A/B MAG TAPE CONTROLLER CARD PLACEMENT,	60150000	N	34	13.30

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.

4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
EQ. SUMMARY, WIRE TABS CE MANUAL				
3436-A DRUM CONTROLLER				
REFERENCE MANUAL	60333100	A	22	01.45
CE MANUAL	60114200	M, N	22	07.30
TEST ROUTINE	13793500		22	01.00
3446-A/B CARD PUNCH CONTROLLER				
REFERENCE MANUAL	60332100	B	22	01.20
CE MANUAL	60090400	Y	22	03.75
TEST ROUTINES - 3446, 3644/415/523/544	41602600	A	22	02.50
PUNCH/READER CARD PATTERNS FOR 3446-3644/ 415/523/544 CARD PUNCH TEST AND 3447-3649/ 405 CARD READER TEST	41602800		22	09.40
3447-A CARD READER CONTROLLER				
REF INFO (USE 3248-A REF MAN)				
CE MANUAL	60091800	AB	22	02.65
TEST ROUTINES - 3447, 3649/405	41602700	A	22	01.30
3447-B CARD READER CONTROLLER				
REF INFO (USE 3248-A REF MAN)				
CE MANUAL	60212800	M	22	03.60
TEST ROUTINES (USE 3447-A)				
3458-A LINE PRINTER CONTROLLER				
REFERENCE MANUAL	60332800	B	22	01.90
DIAGRAMS, CIRC. DESC., MAINT AND PARTS LIST	60158200	Z	22	07.75
CARD PLACEMENT, EQ SUMMARY, WIRE LIST CE MAN	60197000	S	22	24.50
3500 COMPUTER SYSTEM				
COMPUTER SYSTEM REFERENCE MANUAL	60200300	D	22	05.15
INSTRUCTION CODES (USE 3300)				
SMM REF INFO (USE 3300)				
HARDWARE MAINT FEATURES (3500 MASTER) GENERAL INFORMATION MANUAL (USE 3300)				
3502 (BB313-A, BB314-A, GH104-A) SYSTEM STORAGE				
REF INFO (USE 3500 REF MAN)				
3504-1 (AC104-A, CR105-A) PROCESSOR				
REF INFO (USE 3500 COMPUTER SYSTEM REF MAN.)				
3507-1 (DC111-A) DATA CHANNEL				
REF INFO (USE 3500 COMPUTER SYSTEM REF MAN.)				
3514-1 (AC106-A, CR106-A) BASIC PROCESSOR				
REF INFO (USE 3500 COMPUTER SYSTEM REF MAN)				
3514-2 (AC106-A, AF102-A, CR106-A) BUSINESS DATA PROCESSOR				
REF INFO (USE 3500 COMPUTER SYSTEM REF MAN)				

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
3514-3 (AC106-A, AT124-A, CR106-A) MULTI-PROGRAMMING PROCESSOR REF INFO (USE 3500 COMPUTER SYSTEM REF MAN)				
3514-4 (AC106-A, AF102-A, AT124-A, CR106-A) GENERAL PURPOSE PROCFSOR REF INFO (USE 3500 COMPUTER SYSTEM REF MAN)				
3516-1 (FJ601-A, FV129-A) MULTIPLEXER CONTROLLER REFERENCE MANUAL	41610700	A	22	01.00
3518 (FA416-B, FA417-B, FA420-B) MAGNETIC TAPE CONTROLLER REFERENCE MANUAL	60287600	P	22	03.80
3522 (AT122-A, AT123-A) REAL TIME INTERRUPT REF INFO (USE 3500 COMPUTER SYSTEM REF MAN.)				
3528 (FA417-B, FA418-A, FA420-B) MAGNETIC TAPE CONTROLLER REF INFO (USE 3518)				
3553-1 (FA705-A/B) MASS STORAGE CONTROLLER REFERENCE MANUAL	60278500	B	22	02.40
3553-2 (FA704-A/B/C) MASS STORAGE CONTROLLER REF INFO (USE 3553-1)				
3555-1 (FF307-B) LINE PRINTER CONTROLLER REFERENCE MANUAL	60231300	C	22	01.00
3600 COMPUTER SYSTEM REFERENCE MANUAL	60021300	N	22	03.30
INSTRUCTION CODES 3600/3800	60044400	C		03.00
CUSTOMER ENGINEERING MANUALS				
SYSTEM MAINT. MONITOR REF MANUAL	60093900	H	22	57.50
PARTS LIST	60157300	C	22	05.80
(THE FOLLOWING MANUALS FOR THE ABOVE PRODUCT ARE AVAILABLE ON A SPECIAL ORDER BASIS IN MAX. QTY OF 2 COPIES. ALLOW AT LEAST 3-4 WEEKS FOR PROCESSING AND DELIVERY.)				
CARD TESTER REFERENCE/INSTRUCTION	60096800		22	
3601 CONSOLE DIAGRAMS	60042600	J	22	06.35
CARD PLACEMENT AND EQUATION SUM. CE MANUAL	31605400	A	22	02.25
CE INSTRUCTION MANUAL	60043400	B	22	08.75
WIRE TABS	31600200	C	22	01.50
3602-A/3802-1 COMMUNICATIONS MOD CE DIAGRAMS	60041700	J	34	01.60

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
COMMUNICATION MOD INSTRUCTION/CE MANUAL C/P, EQ SUMMARY, W/L CE MANUAL (INCLUDES PREVIOUS PUB NO. 31605500)	60096700 31600500	E B	22 22	03.50 12.85
3604-A/B COMPUTATION MODULE CE DIAGRAMS VOLS 1 AND 2	60042100	AV	34	08.45
CE INSTRUCTION/CIRCUIT DESCRIPTION	60047600		22	18.00
PRELIMINARY COMMAND TIMING CHARTS	60093800		22	14.70
ARITHMETIC COMMAND TIMING CHARTS	60100700		22	06.45
CARD PLACEMENT, EQ SUMMARY CE MANUAL	31605600	S	22	42.35
WIRE LIST CE MANUAL	31600800	P	22	45.70
3604-B COMPUTATION MODULE WIRE LIST	17804500	K	22	35.00
CARD PLACEMENT AND EQUATION SUM. VOLS. 1,2	60150700	L	34	43.50
3606-A BI-DIRECTIONAL DATA CHAN CE DIAGRAMS CE INSTRUCTION MANUAL	60041800 60043300	F D	34 22	01.25 07.45
CHASSIS MAPS AND SUMMARY	31605700	D	34	05.70
WIRE TABS	31601100	D	22	03.50
3607-A 24 BIT DATA CHANNEL CE DIAGRAMS	60041900	D	34	03.30
(THE FOLLOWING MANUALS FOR THE ABOVE PRODUCT ARE AVAILABLE ON A SPECIAL ORDER BASIS IN MAX. QTY OF 2 COPIES.ALLOW AT LEAST 3-4 WEEKS FOR PROCESSING AND DELIVERY.)				
WIRE TABS	31601400			
CHASSIS MAPS AND SUMMARY	31605800			
3608-A 48 BIT DATA CHANNEL CE DIAGRAMS	60047900	C	34	03.10
(THE FOLLOWING MANUALS FOR THE ABOVE PRODUCT ARE AVAILABLE ON A SPECIAL ORDER BASIS IN MAX. QTY OF 2 COPIES.ALLOW AT LEAST 3-4 WEEKS FOR PROCESSING AND DELIVERY.)				
WIRE LIST	31601700	C		
CHASSIS MAPS AND SUMMARY	31605900	B		
3609-A STORAGE MODULE CE DIAGRAMS CE INSTRUCTION MANUAL	60042000 60095500	R E	34 22	03.75 05.95
CARD PLACEMENTS,EQ SUMMARY AND WIRE TABS	60159200	B	34	21.85
3610-A/3810-A COMMUNICATIONS MOD CE DIAGRAMS CE INSTRUCTION MANUAL	60121400 60121300	C D	22	01.00 05.00
(THE FOLLOWING MANUALS FOR THE ABOVE PRODUCT ARE AVAILABLE ON A SPECIAL ORDER BASIS IN MAX. QTY OF 2 COPIES.ALLOW AT LEAST 3-4 WEEKS FOR PROCESSING AND DELIVERY.)				
CARD PLACEMENT, EQUATION SUMMARY	31605200			
WIRE LIST	31605300			

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
3613 SIDEWAYS ALOGRITHM BOX	60047700	B	22	03.00
362X-A MAGNETIC TAPE CONTROLLER				
REFERENCE MANUAL	60331500	C	22	01.30
CE DIAGRAMS MANUAL	60042200	AF	34	10.00
REFERENCE/INSTRUCTION MANUAL	60043500	J	22	09.50
CARD PLACEMENTS AND EQUATION SUMMARY	31606100	L	34	37.00
WIRE LIST CE MANUAL	31602300	P	22	17.65
362X-B MAGNETIC TAPE CONTROLLER				
REF INFO (USE 362X-A)				
CARD PLACEMENT AND EQUATION	60159600	J	34	34.00
WIRE LISTS CE MANUAL	60159700	J	22	24.00
363X-A DTSK FILE CONTROLLER				
REFERENCE MANUAL	60333200	A	22	01.55
CIRCUIT DESC., MAINT., PARTS LIST, CARD	60099800	D	22	22.55
PLACEMENT, EQUATION SUMMARY CE MANUAL				
WIRE LISTS CE MANUAL	60197300	C	22	10.00
3637-A DRUM STORAGE CONTROLLER				
REF/CE INFO (USE 3436-A)				
3637-B/C DRUM STORAGE CONTROLLER				
CE MANUAL	60224900	H	22	07.50
3641-A CARD READER CONTROLLER				
CARD PLACEMENTS AND EQUATION SUMMARY	31606200		34	03.20
(THE FOLLOWING MANUALS FOR THE ABOVE PRODUCT				
ARE AVAILABLE ON A SPECIAL ORDER BASIS IN				
MAX. QTY OF 2 COPIES.ALLOW AT LEAST 3-4				
WEEKS FOR PROCESSING AND DELTVRY.)				
REFERENCE/INSTRUCTION MANUAL	60107200			
WIRE TABS	31602600		22	
3643 CARD READ WIRE TABS CE MANUAL	31602900			02.90
3644-A CARD PUNCH CONTROLLER				
REF INFO (USE 3446-A/B REF MAN)				
CE MANUAL	60048400	Z	22	09.50
TEST ROUTINES (USE 3446-A)				
3649-A CARD READER CONTROLLER				
REF INFO (USE 3248-A REF MAN)				
REFERENCE/INSTRUCTION MANUAL	60097900	B	22	02.50
CE MANUAL	60049800	W	22	04.30
TEST ROUTINES (USE 3447-A)				
3655-A LINE PRINTER ADAPTER EQ. SUM., CARD	60291000	A	22	03.80
PLACEMENT, WIRE LIST CE MANUAL				
CE DIAGRAMS MANUAL	60042500	E	34	03.20

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
3659-A/B/C LINE PRINTER CONTROLLER REF INFO (USE 3256-A/B/C) DIAGRAMS CE MANUAL CIRCUIT DESCRIPTION, MAINT., PARTS LIST, CARD PLACEMENT, EQ SUMMARY, WIRE LIST CE MANUAL TEST ROUTINES (USE 3256-A)	60094200 60126500	S M	22 22	02.70 10.95
3681-A DATA CHANNEL CONVERTER CE MANUAL REFERENCE MANUAL SYSTEM MAINTENANCE MONITOR REFERENCE SYSTEMS MAINT. MONITOR PROG. LISTINGS	60042300 60333400 60169100 60181200	F A B B	22 22 22 22	13.05 01.00 07.50 10.60
3682-A/B/C SATELLITE CONTROLLER CE MANUAL REFERENCE MANUAL TEST ROUTINE	60042400 60333500 41600700	H A A	22 22 22	03.00 01.00 01.00
3691-A PAPER TAPE READER/PUNCH REFERENCE MANUAL PAPER TAPE READER PUNCH WIRE TABS REFERENCE INSTRUCTION AND DIAGRAMS MANUAL	60333000 60140800 60048300	B D F	22 22 22	01.00 01.50 03.40
3691-B/C/D/E PAPER TAPE READ/PUNCH CE MANUAL REF INFO (USE 3691-A)	60124800	T	22	08.00
3692-A PROGRAM CONTROLLED I/O TYPEWRITER REFERENCE MANUAL CE DIAGRAMS WIRE TABS CHASSIS MAPS AND SUMMARY	60332600 60094400 31603800 31606600	A E C C	22 34 22 34	01.00 02.50 01.75 05.50
3694-A PAPER TAPE READER/PUNCH DIAGRAMS REFERENCE MANUAL	60104900 60107400	A A	22 22	01.30 03.80
(THE FOLLOWING MANUALS FOR THE ABOVE PRODUCT ARE AVAILABLE ON A SPECIAL ORDER BASIS IN MAX. QTY OF 2 COPIES. ALLOW AT LEAST 3-4 WEEKS FOR PROCESSING AND DELIVERY.) PRICE AVAILABLE UPON REQUEST CARD PLACEMENT EQUATION SUMMARY	31554400 31554300			
3694-C/D PAPER TAPE READER/PUNCH CE MANUAL REFERENCE MANUAL	60125400 60203300	S A	22 22	04.20 01.50
(THE FOLLOWING MANUALS FOR THE ABOVE PRODUCT ARE AVAILABLE ON A SPECIAL ORDER BASIS IN MAX. QTY OF 2 COPIES. ALLOW AT LEAST 3-4 WEEKS FOR PROCESSING AND DELIVERY.) PRICE AVAILABLE UPON REQUEST CARD PLACEMENT EQUATION SUMMARY	31646700 60149700	E M		

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
3800 COMPUTER SYSTEM REFERENCE MANUAL	60162300	C	22	04.70
CUSTOMER ENGINEERING MANUALS				
MAINTENANCE COMMAND TIMING CHARTS	60160000	A	22	22.30
CE MANUAL-POWER DIAGRAMS	60194400	A	22	01.00
PARTS LIST CE MANUAL	60197700	A	22	08.60
3801-A CONSOLE DIAGRAMS,C/P,EQ SUMMARY,W/L AND TERM LIST CIRCUIT DESCRIPTION AND MAINTENANCE	60159000 60199300	B A	 22	 02.40 07.80
3802-A COMMUNICATION MODULE (USE 3602-A MANUAL				
3803-B STORAGE MOD DIAG,CIR DES,MAINT,C/P,W/L	60184500	C	22	06.50
3804-A/3811-A COMPUTATION MOD AND RELOCATION UNIT DIAGRAMS AND CIRCUIT DESCRIPTION CARD PLACEMENT, EQUATION SUMMARY WIRE AND TERM LISTS, HAND TABS	60154500 60159900 60186100	R K J	22 34 22	17.55 30.30 19.75
3806-A DATA CHANNEL CE MANUAL CE INSTRUCTION MANUAL	60122700 60100800	D B	22 22	09.25 04.75
3810-A COMMUNICATION MODULE (USE 3610-A MANUAL				
3816 PRIORITY DATA CHANNEL CE DIAGRAM,CIRC DESC,P/L,CP,EQ SUM,W/L REFERENCE MANUAL	60153000 60157100	B A	22 22	16.05 02.20
5100 CUSTOMER ENGINEERING MANUAL VOLS. 1 AND 2 MIMIC SOFTWARE REFERENCE MANUAL COMPASS ASSEMBLER SOFTWARE REF MAN COMPASS SOFTWARE REFERENCE MANUAL PROGRAM CHECKOUT MONITOR SOFTWARE REF MAN	14163300 14166700 14196600 14166800 14167100	A A A A	22 22	12.00 01.35 03.90 04.45 01.05
5600 SERIES MPP REFERENCE MANUAL MAINTENANCE, DIAGS, WIPE LIST CE MANUAL	14232000 14247900	A A	22 22	07.85 07.45
6000 COMPUTER SYSTEMS (6014, 6015, 6200, 6400, 6500, 6600, 6700) INSTRUCTION CARD INSTRUCTION CODES INPUT/OUTPUT SPECIFICATIONS (USE CYBER 72) 73, 74 I/O SPECIFICATIONS) REFERENCE MANUAL SCOPE 3.3 ON-LINE DIAGNOSTICS GIM SCOPE 3.4 ON-LINE DIAGNOSTICS GIM SCOPE 3.3 ON-LINE DIAGNOSTICS REFERENCE MAN. SCOPE 3.4 ON-LINE DIAGNOSTICS REFERENCE MAN.	60164500 60141900 60100000 60309800 60364700 60320700 60364800	C F AE A A 02 D	 22 22 22 22 22	 00.75 01.00 03.50 01.00 01.05 02.20 03.15

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
6000/CYBER OPTIONS GENERAL INSTALLATION PROCEDURES MANUAL	60415600	A	22	03.15
CUSTOMER ENGINEERING MANUALS				
PERIPHERAL CONTROLLER CABINETS REF/CE MANUAL (1700/3000/6000)(REFER TO 3000 SERIES) REFRIGERATION MANUALS - (SEE CATALOG SEC 4)				
6014 6000 STATION (AT217-A) REF INFO (PPU AND CPU - USE 6000 SERIES REF MANUAL) (INTERFACE REF INFO - USE 6682 AND DT122-A REF OR REF/CE MANUALS)				
6015-7/8/9 6000 STATION (USE 6014)				
6400/6500-A/B/C CENTRAL COMPUTERS * THE MANUALS LISTED BELOW ARE USED * * WITH ALL 6400/6500-A/B/C COMPUTERS * * UNLESS INDICATED OTHERWISE *				
DIAGRAM MANUALS				
CPU,PPU,CENTRAL MEMORY,CLOCK,ECS COUPLER AND POWER DIAGRAMS	60146100	BL	22	15.00
MAINTENANCE MANUALS				
MAINTENANCE AND COMMAND TIMING	60182100	J	22	23.50
INSTANT SMM CODE BOOK (64/65/6600)	60299500	D		01.00
SYSTEM MAINTENANCE MONITOR REFERENCE MANUAL VOLS 1-5(AVAIL IN SETS ONLY)	60160600	18	22	31.00
MAINTENANCE PMI/PMP CE MANUAL	60309600	G	22	27.15
PARTS DATA				
PARTS LIST(6404-A,6414-A/B/C ONLY)	60187200	C	22	08.60
PARTS LIST(6404-A,6415-A/B/C ONLY)	60266300	A	22	10.85
PARTS LIST(6413-C/O ONLY)	60223300	C	22	06.00
PARTS LIST(6514-C ONLY)	60224200	B	22	04.05
PARTS LIST(6513-C/D ONLY)	60267200	A	22	09.70
WIRE LISTS				
CHASSIS 1 CHASSIS TABS (INCL 6411/16-A/B)	60166100	T	22	15.00
CHASSIS 2 CHASSIS TABS (INCL 6400/6500-D)	60166200	AA	22	25.30
CHASSIS 3 CHASSIS TABS	60166300	AR	22	16.60
CHASSIS 4 CHASSIS TABS	60180000	L	22	15.00
CHASSIS 5/7 CHASSIS TABS	60166400	M	22	10.00
CHASSIS 8 CHASSIS TABS	60187700	V	22	06.85
CHASSIS 9/11 CHASSIS TABS	60197100	C	22	10.00
CHASSIS 10/12 CHASSIS TABS	60197200	C	22	10.00
CABLE TABS(FOR 6404-A,6414/6514-A/B/C ONLY)	60166000	M	22	10.70
CABLE TABS(FOR 6405-A,6415-A/B/C ONLY)	60169700	M	22	07.50
CABLE TABS(FOR 6413/6513-A/B/C ONLY)	60188900	G	22	14.85
6411-A,6416-A AUGMENTED I/O BUFFER/CONTROL DIAGRAMS AND CIRCUIT DESCRIPTIONS	60146200	U	22	05.05
CHASSIS 1 CHASSIS TABS(SEE 64/6500-A/B/C)				
CHASSIS 3 CHASSIS TABS CE MANUAL	60180100	H	22	13.80
CHASSIS 4 CHASSIS TABS CE MANUAL	60187800	G	22	06.10

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
CABLE TABS CE MANUAL	60187900	K	22	07.10
6400/6500-D CENTRAL COMPUTER				
* THE MANUALS LISTED BELOW ARE USED *				
* WITH ALL 6400/6500-D COMPUTERS *				
* UNLESS INDICATED OTHERWISE *				
DIAGRAM MANUALS				
CPU, CENTRAL MEMORY, CLOCK, ECS COUPLER AND	60246800	AG	22	27.75
POWER DIAGRAMS				
PERIPH PROCESSING UNIT DIAGRAMS	60246500	K	22	03.05
MAINTENANCE MANUALS				
SYSTEM MAINT MONITOR REF(SEE 64/6500-A/B/C)				
MAINTENANCE-PMI/PMP (SEE 64/6500-A/B/C)				
PARTS DATA				
PARTS LIST (6414-D ONLY)	60268000	B	22	03.50
PARTS LIST(6514-D ONLY)	60267100	A	22	03.80
PARTS LIST(6415-D,6513-D,SEE 64/6500-A/B/C)				
WIRE LTSTS				
CHASSIS 1 CHASSIS/CABLE TABS	60246900	S	22	38.40
CHASSIS 2 CHASSIS TABS(SEE 64/6500-A/B/C)				
CHASSIS 3 CHASSIS/CABLE TABS	60248500	U	22	12.00
CHASSIS 4 CHASSIS/CABLE TABS	60248600	H	22	14.00
CHASSIS 5 CHASSIS/CABLE TABS CE MANUAL	60248700	C	22	13.00
CHASSIS 6 CHASSIS/CABLE (FOR 6415.D ONLY)	60249000	K	22	10.60
CHASSIS 8 CHASSIS/CABLE TABS	60249100	S	22	13.65
CHASSIS 9/11 CHASSIS/CABLE TABS	60248800	E	22	14.30
CHASSIS10/12 CHASSIS/CABLE TABS	60248900	F	22	09.20
HAND TABS,SENSE AMP WIRING(FOR 64/65/6600-D)	60269100	A	22	02.38
6413-E (AA105-A WITH AT140-A)				
6414-E (AA105-A)				
6415-E (AA103-A) CENTRAL COMPUTER				
6415-7 (AA103-D) CENTRAL COMPUTER				
6415-8 (AA103-C) CENTRAL COMPUTER				
6415-9 (AA103-B) CENTRAL COMPUTER				
6500-C USE STANDARD 6400-C MANUALS.				
IF AT196-A/B AND DT117-A OR DT204-A				
AND AT196-A AND AT195-A ARE INSTALLED				
USE MANUALS LISTED UNDER AT195-A.				
6500-C WITH ECS CAPABILITY				
USE MANUALS LISTED UNDER AT195-A				
6500-D USE STANDARD 6400-D MANUALS.				
IF AT193-A AND DT143-A OR DT205-A				
AND AT194-A AND AT198-A ARE INSTALLED				
USE MANUALS LISTED UNDER AT194-A.				

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature..

TITLE	1	2	3	4
6500-D WITH ECS CAPABILITY USE MANUALS LISTED UNDER AT194-A.				
6500-E USE STANDARD 6400-E MANUALS. IF AT141-A AND DT143-A OR AT141-A AND DT205-A AND AT194-A ARE INSTALLED USE MANUALS LIST UNDER AT194-A.				
6500-E WITH ECS CAPABILITY USE MANUALS LISTED UNDER AT194-A.				
6601-A THROUGH F CENTRAL COMPUTER(SER.1-7) DIAGRAMS AND CIRCUIT DESC(SEE 6601-H/J) CHASSIS 1,6,7,8,13,14,15 AND 16 CHASSIS TABS(SEE 6601-H/J) * THE FOLLOWING MANUALS FOR THE * * ABOVE SYSTEM ARE AVAILABLE ON A * * A SPECIAL ORDER BASIS IN MAX.QTY * * OF 2 COPIES.ALLOW AT LEAST 3-4 * * WEEKS FOR PROC.AND DELIVERY. * PRICE AVAILABLE UPON REQUEST CHASSIS 2 CHASSIS TABS(INCL 6604-B) 60161500 22 CHASSIS 3 CHASSIS TABS 60161600 22 CHASSIS 4 CHASSIS TABS 60161800 22 CHASSIS 5 CHASSIS TABS(INCL 6604-B) 60162000 22 CHASSIS 9 CHASSIS TABS 60162100 22 CHASSIS 10 CHASSIS TABS 60162200 22 CABLE TABS(SEE 6601-H/J)				
6601-H/J CENTRAL COMPUTER **DIAGRAM MANUALS** CPU, FUNCTIONAL UNIT, PERIPHERAL PROC. UNIT CLOCK,ECS COUPLER,AND POWER DIAGRAMS **MAINTENANCE AIDS** SYSTEM MAINT MON.REF(SEE 6400/6500-A/B/C) MAINTENANCE-PMI/PMP(SFE 6400/6500-A/B/C) **PARTS DATA** PARTS LIST(FOR 6601-H/J,6613-A/B/C ONLY) 60157400 D 22 17.20 **WIRE LISTS** CHASSIS 1 CHASSIS TABS 63019800 AD 22 17.35 CHASSIS 2 CHASSIS TABS 63019700 AL 22 25.55 CHASSIS 3 (FOR 6601-H/J,6613-A/B/C ONLY) 63019600 BD 22 14.30 CHASSIS 4 (FOR 6601-H/J,6613-A/B/C ONLY) 63019200 W 22 10.00 CHASSIS 5 CHASSIS TABS 60150800 BP 22 16.85 CHASSIS 6 CHASSIS TABS 63017400 Z 22 20.00 CHASSIS 7 CHASSIS TABS 63017300 P 22 21.10 CHASSIS 8 CHASSIS TABS 63017200 AF 22 21.20 CHASSIS 9 (FOR 6601-H/J,6613-A/B/C ONLY) 63017100 V 22 10.00 CHASSIS 10 (FOR 6601-H/J,6613-A/B/C ONLY) 63016900 S 22 12.30 CHASSIS 12 CHASSIS TABS(SEE 6612-B/E) CHASSIS 13 (FOR 6601-H/J,6613-A/B/C ONLY) 63025600 R 22 09.15 CHASSIS 14 (FOR 6601-H/J,6613-A/B/C ONLY) 63025500 P 22 07.80				

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
CHASSIS 15 (FOR 6601-H/J, 6613-A/B/C ONLY)	63025400	N	22	08.00
CHASSIS 16 (FOR 6601-H/J, 6613-A/B/C ONLY)	63024900	R	22	07.25
CABLE TABS (FOR 6601-H/J, 6613-A/B/C ONLY)	60148900	AJ	22	17.05
6602-A THROUGH E CONSOLE DISPLAY CONTROLLER REFERENCE MANUAL	60333900	B	22	01.00
DIAGRAMS (6602-A THRU E, 6612-A THRU E)	60389800	A	22	03.05
PARTS LIST CE MANUAL	60266400	A	22	01.00
CHASSIS/CABLE TABS CE MANUAL	63016700	N	22	32.45
6603-A/B/C DISK SYSTEM DIAGRAMS, WIRE LISTS CE MANUAL	60389900	A	22	06.30
REFERENCE MANUAL	60334000	A	22	01.00
SERVICE MANUAL-DIAGRAMS, CIRC DESCRIPTION	60127000	C	22	20.70
PARTS LIST CE MANUAL	60266500	B	22	01.20
MAINTENANCE-ELECTRONIC TEST PROCEDURES	60213300	C	22	02.40
6604-A/C CENTRAL COMPUTER DIAGRAMS (SEE 6601-H/J)				
CHASSIS 1, 2, 5, 6, 7, AND 8 CHASSIS TABS (SEE 6601-H/J)				
CHASSIS 3 (FOR 6604-A/C, 6614-A/B/C ONLY)	63033800	BG	22	17.50
CHASSIS 4 (FOR 6604-A/C, 6614-A/B/C ONLY)	63033700	Z	22	13.00
CHASSIS 9 (FOR 6604-A/C, 6614-A/B/C ONLY)	63033600	S	22	10.00
CHASSIS 10 (FOR 6604-A/C, 6614-A/B/C ONLY)	63033500	T	22	13.85
CABLE TABS (FOR 6604-A/C, 6614-A/B/C ONLY)	60149600	AG	22	11.50
PARTS LIST (FOR 6604-A/C, 6614-A/B/C ONLY)	60267300	A	22	11.00
SYSTEM MAINT MONITOR REFERENCE VOL 1-5 (SEE 6601-H/J)				
6604-B COMPUTER SYSTEM (SERIAL 1-7) DIAGRAMS AND CIRCUIT DESC (SEE 6601-H/J)				
SYST. MAINTENANCE MONITOR (SEE 6601-H/J)				
PARTS LIST (SEE 6604-A)				
CHASSIS 1, 6, 7, AND 8 (SEE 6601-H/J)				
CHASSIS 2 (SEE 6601-A THROUGH F)				
CHASSIS 5 (SEE 6601-A THROUGH F)				
CHASSIS 9 AND 10 (SEE 6604-A/C)				
6612-A THROUGH E CONSOLE DISPLAY CONTROLLER REF INFO (USE 6602-A)				
DIAGRAMS AND CIRC DESC (SEE 6602-A-E)				
PARTS LIST (SEE 6602-A-E)				
CHASSIS/CABLE TABS (SEE 6602-A-E)				
6612-F/G CONSOLE DISPLAY CONTROLLER REF INFO (USE 6602-A)				
DIAGRAMS, CIRC DESC, CARD PLACMT, WIRE LIST,	60246400	K	22	16.20
6613-A/B/C COMPUTER SYSTEM (SEE 6601-H/J)				
6613-D COMPUTER SYSTEM CPU, FUNCTIONAL UNIT CE DIAGRAMS	60224800	W	22	15.00

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
CENT.MEM,CLOCK,ECS COUPLER,POWER DIAGRAMS PERIPH PROC UNIT DIAGRAMS(SEE 6400/6500-D)	60246600	U	22	04.90
PARTS LIST CE MANUAL	60253300	C	22	08.65
MAINTENANCE-CLOCK TIMING	60289000	B	22	01.80
SYST MAINT MONITOR REF VOL 1-5(SEE 6601-H)				
CHASSIS 1 CHASSIS TABS(SEE 64/6500-D)				
CHASSIS 4 CHASSIS/CABLE TABS CE MANUAL	60247000	R	22	19.55
CHASSIS 5 CHASSIS/CABLE TABS CE MANUAL	60247100	Z	22	20.00
CHASSIS 6 CHASSIS/CABLE TABS CE MANUAL	60247200	H	22	17.40
CHASSIS 7 CHASSIS/CABLE TABS CE MANUAL	60247300	E	22	23.45
CHASSIS 8 CHASSIS/CABLE TABS CE MANUAL	60247400	J	22	26.20
CHASSIS 9 CHASSIS/CABLE TABS CE MANUAL	60247500	N	22	10.90
CHASSIS 10 CHASSIS/CABLE TABS CE MANUAL	60247700	F	22	07.60
CHASSIS 11/15 CHASSIS/CABLE TABS CE MANUAL	60247900	C	22	10.20
CHASSIS 12/16 CHASSIS/CABLE TABS CE MANUAL	60248100	D	22	12.80
CHASSIS 13/14 CHASSIS/CABLE TABS CE MANUAL	60248300	J	22	19.80
HAND TABS-MEMORY SENSE AMP W/L(SEE 6400-D)				
6613-E (AA104-A)				
6614-A/B/C COMPUTER SYSTEM(SEE 6604-A)				
6614-D COMPUTER SYSTEM DIAGRAM MANUALS(SEE 6613-D)				
PARTS LIST CE MANUAL	60267400	B	22	05.05
MAINTENANCE MANUALS(SEE 6613-D)				
CHASSIS 1 CHASSIS/CABLE(SEE 64/6500-D)				
CHASSIS 4,6,7,AND 8 TABS(SEE 6613-D)				
CHASSIS 5 CHASSIS/CABLE TABS	60251200	Y	22	17.45
CHASSIS 9 CHASSIS/CABLE TABS	60247600	P	22	14.50
CHASSIS 10 CHASSIS/CABLE TABS	60247800	D	22	07.75
CHASSIS 11 CHASSIS/CABLE TABS	60248000	E	22	08.75
CHASSIS 12 CHASSIS/CABLE TABS	60248200	D	22	12.00
HAND TABS-MEMORY SENSE AMP W/L(SEE 6400-D)				
DATA CHANNEL EQUIP CHASSTS TABS(SEE DC211-A)				
6614-E (AA103-A)				
6622-A/B MAGNETIC TAPE CONTROLLER REFERENCE MANUAL	60333600	A	22	01.10
DIAGRAMS, WIRE LIST CE MANUAL	60390000	A	22	
(THE FOLLOWING MANUALS MANUALS FOR THE ABOVE PRODUCT ON A SPECIAL ORDER BASIS IN MAX. QTY OF 2 COPIES ALLOW AT LEAST 3-4 WEEKS FOR DELIVERY)				
PARTS LIST CE MANUAL	60253200	A	22	01.70
6633-C (BB325-A) EXTENDED CORE STORAGE ASSEM.				
6633-D (BB325-B) EXTENDED CORE STORAGE ASSEM.				
6634-C (BB319-A) EXTENDED CORE STORAGE ASSEM.				
6634-D (BB319-B) EXTENDED CORE STORAGE ASSEM.				
6635-C (BB323-A) EXTENDED CORE STORAGE ASSEM.				
6635-D (BB323-B) EXTENDED CORE STORAGE ASSEM.				

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
6636-C (BB324-A) EXTENDED CORE STORAGE ASSEM. 6636-D (BB324-B) EXTENDED CORE STORAGE ASSEM. EXTENDED CORE STORAGE REFERENCE MANUAL	60225100	F,G	22	01.00
6638 DISK FILE (USE 6639)				
6639 DISK FILE SYSTEM REFERENCE MANUAL	60334100	E	22	01.00
DIAGS, CIRC DESC, MAINT, P/L, C/P, W/L, CHASSIS TABS	60227300	H	22	04.45
6640-A/B EXT. CORE STORAGE CONTROLLER DIAGRAMS CIRC. DESC., MAINT., P/L, C/P, AND W/L	60186000	AM	22	07.60
6640-D ECS CONTROLLER HOWE MAINT. MANUAL	60440500	B	22	25.20
6641-A (DC110-A) ECS MASS STORAGE CONTROLLER REFERENCE MANUAL	60334200	A	22	01.00
6642-1 (DC135-A) DISTRIBUTIVE DATA PATH OPERATION AND PROGRAMMING REFERENCE MANUAL	60376300	A	22	01.00
6671-A/B (FJ411-A/B) DATA SET CONTROLLER REFERENCE MANUAL	60334600	E	22	02.70
6671-1 (FJ427-A) DATA SET CONTROLLER REF INFO (USE 6671-A/B)				
6671-3 (FJ440-A) DATA SET CONTROLLER HARDWARE REFERENCE MANUAL	60399900	B	22	01.30
6673/6674 DATA SET CONTROLLER REFERENCE MANUAL	60334500	B	22	01.00
CIRCUIT DESCRIPTION, MAINTENANCE, PARTS LIST	60201500	N	22	04.25
CARD PLACEMENT, EQ SUMMARY CE MANUAL	60205400	L	22	02.35
WIRE LISTS CE MANUAL				
6675 DATA SET CONTROLLER CE MANUAL	38700400	D	22	01.45
6676-A TTY MULTIPLEXER REFERENCE MANUAL	38706000	C	22	01.20
CE MANUAL	38708400	K	22	10.30
6676-B/C TTY MULTIPLEXER REFERENCE MANUAL	38707800	E	22	02.90
CE MANUAL	38706100	S	22	23.95
6681-B/C/D DATA CHANNEL CONVERTER REFERENCE MANUAL	60334400	F	22	02.55
CE INFO (USE DC211-A, CATALOG SEC. 1)				
6681-F DATA CHANNEL CONVERTER				

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
CE MANUAL	60440800	A	22	17.25
6682-A SATELLITE COUPLER REFERENCE MANUAL CE MANUAL	60334300 60390100	B E	22 22	01.50 02.10
6683-A SATELLITE COUPLER REF INFO (USE 6682-A) CE INFO (USE 6682-A)				
6684-1 (DC211-A) DATA CHANNEL CONVERTER REF INFO (USE 6681-B/C/D)				
6700 DUAL CENTRAL PROCESSOR REF INFO (USE 6000) 6700-A/B/C (USE AT153-A OR AT154-A AND AE116-B) 6700-D (USE AT155-A OR AT156-A AND AE116-C) 6700-E (USE AE116-C)				
7021-1 (FA434-A/B, DT209-D OR FA401-A/B) MAGNETIC TAPE CONTROLLER GENERAL INFORMATION MANUAL	60365100	C	22	01.25
7021-2 (FA434-A/B, DT209-D OR FA402-A/B) MAGNETIC TAPE CONTROLLER REF INFO (USE 7021-1)				
7030-X ECS REF INFO FOR ECS SYSTEMS (USE CYBER 72/73/74 ECS DESCRIPTION/PROGRAMMING MANUAL - VOL.3 - PUBLICATION NUMBER 60347100) POWER DIST/WARNING SYSTEM INFO (USE AA115-A) 7030-1 (6640-B, AT247-A, BB395-A, DC135-A) ECS 125K (FOR CYBER 72 OR 73) 7030-1 (6640-B, AT249-A, BB395-A, DC135-A) ECS 125K (FOR CYBER 74) 7030-2 (6640-B, AT247-A, BB394-A, DC135-A) ECS 250K (FOR CYBER 72 OR 73) 7030-2 (6640-B, AT249-A, BB394-A, DC135-A) ECS 250K (FOR CYBER 74) 7030-4 (6640-B, AT247-A, BB393-A, DC135-A) ECS 500K (FOR CYBER 72 OR 73) 7030-4 (6640-B, AT249-A, BB393-A, DC135-A) ECS 500K (FOR CYBER 74) 7030-8 (6640-B, AT247-A, BB393-A, DC135-A) ECS 1000K (FOR CYBER 72 OR 73) 7030-8 (6640-B, AT249-A, BB393-A, DC135-A) ECS 1000K (FOR CYBER 74) 7030-16 (6640-B, AT247-A, BB393-A, DC135-A) ECS 2000K (FOR CYBER 72 OR 73)				

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
7030-16 (6640-B, AT249-A, 98393-A, DC135-A) ECS 2000K (FOR CYBER 74)				
7030-1XX (CYBER 170) EXTENDED CORE STORAGE SUBSYSTEM HARDWARE REFERENCE MANUAL	60430000	B	22	03.25
7054-1 (DT203-C, FA710-A/B/C/D/E/F, FA719-A/B/C/D, MA710-A/B) GENERAL INFORMATION MANUAL OPERATION AND PROGRAMMING MANUAL	60364400 60363900	O J	22 22	02.60 01.65
7054-2 (DT203-C, DT220-A/B/D, FA710-A/B/C/D, FA719-A/B/C/D, MA710-A, MA720-B) DISK STORAGE CONTROLLER GENERAL INFO (USE 7054-1) OPERATION AND PROGRAMMING (USE 7054-1)				
7054-21 (FA722-A/B, MA710-A) DISK STORAGE CONTROLLER REF INFO (USE 7054-1)				
7054-22 (FA722-A/B, DT220-C, MA710-A) DISK STORAGE CONTROLLER REF INFO (USE 7054-1)				
7054-41 (DT716-A, FA722-A/B, MA710-A) DISK STORAGE CONTROLLER REF INFO (USE 7054-1)				
7054-42 (DT220-C, FA722-A/B, MA710-A) DISK STORAGE CONTROLLER REF INFO (USE 7054-1)				
7077-1 (DT175-A, FJ430-A, GH408-A) COMMUNICATIONS STATION REFERENCE MANUAL	60364600	A	22	01.75
7600 COMPUTER SYSTEM REF INFO (USE CYBER 76 REFERENCE MANUAL)				
7601-1 (AA102-A, AB101-A, GH214-A, CC514-A/B, GE226-A, GE232-A) CENTRAL COMPUTER REF INFO (USE 7600 COMPUTER SYSTEM REF MAN.)				
7611-1/2 (AB101-A, AB102-A/B, GH216-A, GH218-A, GH105-A/B, GE232-A) I/O STATION				
7611-11 () PERIPHERAL COMMUNICATIONS STATION REFERENCE MANUAL	60399400	C	22	02.95

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
7618-1 (FA428-A) MAGNETIC TAPE CONTROLLER REFERENCE MANUAL	60341600	H	22	02.00
7622-1 (FA434-A/B, DT210-B OR FA403-A/B) MAGNETIC TAPE CONTROLLER REF INFO (USE 7021-1)				
7622-2 (FA438-A/B, DT210-B OR FA404-A/B) MAGNETIC TAPE CONTROLLER REF INFO (USE 7021-1)				
7628-1 (FA429-A) MAGNETIC TAPE CONTROLLER REF INFO (USE 7618-1)				
7629-1/2 (FA428-A, FA429-A) MAGNETIC TAPE CONTROLLER SUBSYSTEM REF INFO (USE 7618-1)				
7638-1 (BH405-C, FA802-A, GH217-A) DISK STORAGE SUBSYSTEM REFERENCE MANUAL CE INFO FOR CONTROLLER (USE FA802-A, CATALOG SECTION 1)	60265500	D	22	01.00
7639-1 (FA202-A) MASS STORAGE CONTROLLER HWE REFERENCE MANUAL	60437300	A	22	01.50
7639-2 (FA103-A, FA202-A) MASS STORAGE CONTROLLER REF INFO (USE 7639-1)				
7654-1 (DT210-A, FA710-A/B/C/D/E/F, FA720-A/B/C/D, MA710-A, MA720-A) DISK STORAGE CONTROLLER GENERAL INFO (USE 7054-1) OPERATION AND PROGRAMMING (USE 7054-1)				
7681 (DK518-A) DATA CHANNEL CONVERTER REFERENCE MANUAL	60356000	C	22	01.00
7683-1 (DT122-A) REMOTE CHANNEL COUPLER				
7700 () DUAL PROCESSOR COMPUTER SYSTEM HARDWARE REFERENCE MANUAL	60396300	A	22	12.90
8010 DATA COLLECTION SYSTEM OF DIAGRAMS MAN USERS MANUAL	36816700 36822500	A		03.50 01.90
8011 DATA COLLECTOR/REFERENCE MANUAL ILLUSTRATED PARTS LIST WIRE LIST MOD A	40806600 40809600 40816100		22	03.00 01.75 07.30

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
ILLUSTRATED PARTS LIST	40820100			01.75
8011-B DATA COLLECTOR DIAGRAMS AND WIRE LIST	65725100	A	22	02.70
8012 REMOTE MULTIPLEXER/8017 LINE MODULE REFERENCE/CUSTOMER ENGINEERING MANUAL	36816400	A		01.90
8013 MASTER MULTIPLEXER REFERENCE MANUAL	36816300		22	01.00
8019-1 (FF106-A) DOCUMENT READER CONTROLLER REFERENCE MANUAL	60368700	01	22	01.15
8022-A/B PAGE READER CONTROLLER REFERENCE MANUAL	60167100	F	22	06.60
CE MANUAL	60167200	J	22	03.65
8030 RECORD TRANSMISSION TERMINAL USERS MANUAL	36822900			01.75
8041-A/8042-A/8081-A/8082-A CARD PLACEMENT AND EQUATION SUMMARY	60127800	P	22	03.00
8046-A DISK PACK CONTROLLER CE MANUAL	60163900	A	22	07.70
8047-A/B DISK DRIVE CONTROLLER CE MANUAL REFERENCE MANUAL	60159400	A	22	10.40
	60159300	C	22	03.05
8050 INFORMATION CONTROL SYSTEM 160-A/8050 COMPUTER MAINTENANCE -CRUCIBLE)	36811000			12.15
DIAGRAMS (CRUCIBLE)	36811700		34	03.10
DIAGRAMS (DUPONT)	36812600			04.50
8061 DATA SET CONTROLLER REFERENCE MANUAL (REVISED)	36810100	02	22	02.40
8063 DATA SET CONTROLLER REFERENCE/CE MANUAL	36810200	D		01.75
USERS MANUAL	36817500			01.50
8066-B COMMUNICATIONS TERMINAL CONTROLLER REFERENCE MANUAL	13791700			01.00
CE MANUAL VOL. 1	13791800	D	22	01.70
CE MANUAL VOL. 2	13791900	C	22	05.20
8067 DATA SET CONTROLLER REFERENCE MANUAL	36814000	A		01.50
USERS MANUAL	36819900			01.00
8070-A/B MAG TAPE SYNCHRONIZER REF/CE MANUAL	60145300	H		07.85
8071-A/8072-A MAG TAPE SYNCH CE DIAGRAMS CARD PLACEMENT AND EQUATION SUMMARY	60091300	M	34	02.00
	60089800	K	22	04.00
NORMAL CHANNEL LONG LINE DRIVERS CE MANUAL	60123300	A	22	01.00

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
8073-A/B PAPER TAPE PUNCH REF INFO (USE 8090 REF MANUAL)				
8075 TALLY PAPER TAPE READER REFERENCE/INSTR	60116900			04.60
8076 COMMUNICATION TERMINAL CONTROLLER CE DIAGRAMS	36823800	1	34	01.80
CE MAINTENANCE MANUAL	36816600		22	01.80
8083-A ARITHMETIC UNIT CE DIAGRAMS	60091100		34	02.50
CARD PLACEMENTS AND EQUATION SUMMARY	60149800		22	03.00
LONG LINE DRIVERS CE MANUAL	60124400	A	22	01.00
8084A/8085A AUXILIARY MEMORY CE DIAGRAMS	60091200	F	34	02.60
CARD PLACEMENTS AND EQUATION SUMMARY	60140700	C	22	03.20
8090 COMPUTER SYSTEM REFERENCE MANUALS				
INPUT/OUTPUT SPECIFICATIONS REFERENCE MANUAL	60102000	B	22	01.00
	60091500	E	22	08.55
CUSTOMER ENGINEERING MANUALS				
CROSS TABS AND CABLE TABS MANUAL	24140300	V	22	03.75
CE DIAGRAMS	60091000	AC	34	14.05
CE INSTRUCTION MANUAL, PART 1	60091600	E	22	06.00
CE INSTRUCTION, PART 2 MAINTENANCE MANUAL	60101900	D	22	26.00
8090 MCSMM REFERENCE MANUAL VOL 1-2 (SEE 160A SECTION)				
8090 MCSMM PROGRAM LISTINGS, VOL 1-2 (SEE 160-A SECTION)				
8090 NORMAL CHANNEL LONG LINE DRIVERS CE MAN.	60123200	A	22	01.00
BUFFER CHANNEL LONG LINE DRIVERS CE MANUAL	60123100	A	22	01.00
COMPUTER 1/COMPUTER 2 I/O LONG LINE DRIVER CE MANUAL	60123500	A	22	01.00
8090/8084 EXTERNAL BUFFER CHANNEL LONG LINE DRIVERS CE MANUAL	60123400	A	22	01.00
8092 TELEPROGRAMMER CE MANUAL VOL II OF II, CABLE AND WIRE TABS, WIRE LIST	41606100	B	22	02.10
EQUIPMENT DIAGRAMS	36810900	J	34	03.00
INPUT/OUTPUT SPECIFICATIONS	36810500	A	22	01.70
PROGRAMMING REFERENCE MANUAL	36810700	A		02.25
MAINTENANCE, INSTALL, TIMING CHARTS, C/P, EO FILES, PARTS LIST	36810800	F	22	02.85
REFERENCE MANUAL	36810600	E	22	03.25
SYSTEM MAINT. MONITOR CE MANUAL VOLS 1-3	60288100	F	22	65.00
SMM92 INSTANT ERROR CODES	60299700	A		01.80

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
REFERENCE MANUAL (CARD READER CONTROLLER (C813-R813)	36827800	A	22	01.60
CE MANUAL (CARD READER CONTROLLER-C813)	36827900	D	22	01.40
8092-B TELEPROGRAMMER - A BASIC LIBRARY SYSTEM	36823500			01.00
8093 TAPE SYNCHRONIZER REFERENCE MANUAL	36811600			01.80
8094 PERIPHERAL EQUIPMENT ADAPTER REFERENCE MANUAL	36811300	A	22	01.40
8095 CONTROL PANEL CE MANUAL	36811500	B	22	01.55
8097 DIGITAL COMMUNICATIONS TERMINAL REFERENCE MANUAL	36813300			01.25
8097/8297 DATA SET CONTROLLER USERS MANUAL	36819100			01.30
8130 CARD READER/LINE PRINTER TERMINAL PROGRAM LISTINGS COMMAND TEST	60233500	01	22	07.85
8130 REMOTE TERMINAL REFERENCE MANUAL	36828000	B		01.80
USERS MANUAL	36829900	B		01.55
TEST ROUTINE MANUAL	13796900	A		01.00
8136 COMMUNICATIONS TERM CONTROLLER CE MANUAL	13795100	B	22	01.75
REFERENCE MANUAL	13795300	A	22	01.00
8137 COMMUNICATIONS EXPANSION UNIT REF/CE MAN.	41607400	A	22	01.00
8156 LINE PRINTER PRINTER EQUIPMENT CE MANUAL (USE CL308-A/B)				
PRINTER PARTS DATA CE MANUAL	44896400	A	22	02.00
CONTROLLER EQUIP. REF/CE MAN SERIES A06 HDWE	47966500	E	22	05.25
CONTROLLER EQUIP. REF/CE MAN SERIES A10 HDWE	47966600	A	22	03.25
8170-A/B MAG TAPE CONTROLLER REF/CE MANUAL	60208600	D	22	13.80
8193 MAG TAPE CONTROLLER REFERENCE/CE MANUAL	36823700	D	22	03.00
8194 MAG TAPE SYNCHRONIZER REFERENCE MANUAL	13796000	C	22	01.45
8197 DATA SET CONTROLLER CE MANUAL	36828200	G	22	14.25
REFERENCE MANUAL	36828300			02.00

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
8271-A/B/D TRANSFER SWITCHES AND FT103/FT104 TRANSFER SWITCH CONTROLLERS REF./CE MANUAL	36822700	G	22	14.45
8271-E CHANNEL TRANSFER SWITCH/INDICATOR REF/CE INFO (USE 3270-A/R)				
8404 CONSOLE				
(THE FOLLOWING MANUALS FOR THE ABOVE PRODUCT ARE AVAILABLE ON A SPECIAL ORDER BASIS IN MAX. QTY OF 2 COPIES.ALLOW AT LEAST 3-4 WEEKS FOR PROCESSING AND DELIVERY.) PRICE AVAILABLE UPON REQUEST REFERENCE MANUAL	36916900			
9490 COMPUTER SYSTEM REFERENCE MANUAL	14091600	B	22	04.10
DIAGRAMS AND THEORY OF OPERATION	14091700	C	22	14.30
SITE PREPARATION AND INSTALLATION MANUAL	14091800	A	22	01.90
ADSAS AND FORTRAN OPERATION REFERENCE MANUAL	14091900	A	22	02.25
MAINTENANCE AND COMMAND TIMING MANUAL	14092000	B	22	08.75
INSTRUCTION CARDS	14093500			00.75
SYSTEM MAINTENANCE MONITOR (SMM) REFERENCE/ PROGRAM LISTINGS MANUAL	14094700	A	22	11.75
8508B/8515B INPUT UNIT, 8509B/8519B OUTPUT UNIT REFERENCE/CE MANUAL	36826700	A	22	02.85
8518-C,8519-D CE MANUAL, INSTALL AND CHECKOUT, THEO OF OPEP, DIAG, MAINT AIDS, PARTS DATA W/	36826600	B	22	01.50
8527 DCU/8065 DCT/8096 INPUT/OUTPUT UNIT REFERENCE MANUAL (8527-A)	36812700	A	22	02.95
REFERENCE MANUAL (8527-B)	36823400	B	22	03.00
8528 DIGITAL COMMUNICATIONS TERMINAL CE MANUAL	36825600	A	22	04.10
DIAGRAMS MANUAL	36814200	4	34	02.25
MAINTENANCE AIDS MANUAL	36817300	7	22	08.00
REFERENCE MANUAL	36814100	A	22	01.75
8528-G DIGITAL COMMUNICATIONS TERMINAL CE DIAGRAMS	36814500	7	34	02.25
MAINTENANCE MANUAL (USE 8528)	36814400	A	22	02.85
REFERENCE MANUAL				
8529-B/C DATA SET CONTROLLER, W/L, EQ. SUMMARY	41603500	B	22	01.70
REFERENCE MANUAL	36813100			01.25
8529 DIGITAL COMMUNICATIONS TERMINAL DIAGRAM VOLUME	36813700		34	01.50
CUSTOMER ENGINEERING MANUAL	36912500		22	02.00
8529-B/C DATA SET CONTROLLER REFERENCE MAN	13791100	A	22	01.00

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.

4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
CE MANUAL VOL. I OF II	13791200	C	22	02.40
CE MANUAL				
8536-C/D, 8537-C/D INPUT/OUTPUT UNITS CE MANUAL	13797000	E	22	07.35
8601 POWER SUPPLY REFERENCE MANUAL	36814800			01.25
8606 POWER SUPPLY REFERENCE MANUAL	36815000			01.30
8615 DUAL POWER SUPPLY REFERENCE MANUAL	36814700			01.00
8909-C TEST BOARD UNIT REFERENCE MANUAL	36816000	A	22	02.00
8909-G TEST BOARD DRAWER REF/CE MANUAL	36828900	A	22	01.50
8909-H TEST BOARD UNIT REFERENCE MANUAL	13797300	B	22	02.30
CE MAN VOL I OF II THEO OF OPER, DIAG, MAINT, MAINT AIDS, PARTS DATA	13799700	C	22	01.20
CE MANUAL VOL. II OF II WIRE LISTS	41600100	D	22	07.55
8987 R/O NIP STATION OPERATORS GUIDE	62079500	02	22	01.00
9008-1 DUAL ACCESS DISK DRIVE CONTROLLER REFERENCE/CE MANUAL	60290900	B	22	09.45
9081 PLUG COMPATIBLE CONTROLLER--LISTED AS FA7A4, FV141				
9082 (23142)				
9100 MAGNETIC TAPE TRANSPORT MAINT. MANUAL ILLUSTRATED PARTS LIST	40814900 40803900		22	04.00 09.00
9103 MAGNETIC TAPE TRANSPORT DIAGRAMS AND WIRE LIST, MOD A REFERENCE MANUAL, MOD A CE MANUAL - PARTS LIST MOD A	40811700 40802100 40805300	C A	22	02.85 04.60 03.60
9110 MAG TAPE TRANSPORT DIAGRAM/WIRE LIST MOD B AND C REFERENCE MANUAL, MOD B AND C	40824600 40806700	2	22	06.80 06.00
9112 MAGNETIC TAPE TRANSPORT MAINT. MANUAL	40822300	B	22	10.00
9113 MAGNETIC TAPE TRANSPORT DIAGRAMS AND WIRE LIST	40818800	2	22	03.00
9114 MAGNETIC TAPE TRANSPORT MAINTENANCE CE MANUAL PARTS LIST	40817000 40826600		22	04.00 01.80
9115 MAGNETIC TAPE TRANSPORT DIAGS, W/L MOD A	40822100	A	22	09.30

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
MAINTENANCE MANUAL	40819700		22	03.50
PARTS LIST	40829900			05.70
9119 MAGNETIC TAPE TRANSPORT MAINTENANCE	40823800	2	22	04.00
DIAGRAMS AND WIRE LIST	40823600	8	22	05.00
PARTS LIST, MOD A	40823700	8		03.95
9120 MAGNETIC TAPE TRANSPORT MAINTENANCE	40820400		22	04.00
DIAGRAMS AND WIRE LIST	40815700	2	22	03.20
PARTS LIST	40868200	A	22	06.60
9125 MAGNETIC TAPE TRANSPORT	40818900		22	04.00
DIAGRAMS AND WIRE LIST MOD A	40821800	3	22	07.05
9125/9135 MAGNETIC TAPE TRANSPORT PARTS LIST	40860100	A	22	10.35
9130 MAGNETIC TAPE TRANSPORT DIAGRAMS AND	40825400	2	22	05.80
WIRE LIST MOD A05 AND UP, B01 AND UP	40806800		3	08.00
REFERENCE MANUAL, MOD A AND B				
9131 MAGNETIC TAPE TRANSPORT DIAGRAMS MOD A/B	40808500		3	03.50
REFERENCE MANUAL, MOD A AND B	40805200	A	3	06.00
ILLUSTRATED PARTS LIST, MOD A AND B	40807100		3	03.50
WIRE LIST MOD A AND B	40808400		3	03.50
9135 MAGNETIC TAPE TRANSPORT MAINTENANCE	40819800	B	22	13.10
DIAGRAMS AND WIRE LIST	40821700	4	22	04.00
9155 MAGNETIC TAPE TRANSPORT CE MAINT MANUAL	40862300	A	22	04.30
9160A/B MAGNETIC TAPE TRANSPORT MAINTENANCE	40813300	2	22	04.00
9165 MAGNETIC TAPE TRANSPORT				
MAINTENANCE MANUAL MOD A	40865000	02	22	01.60
9165/9175 TAPE TRANSPORT PARTS LIST	40863600	A	22	05.60
9170 MAGNETIC TAPE TRANSPORT MAINTENANCE	40818700	A	22	04.60
9175 MAG TAPE TRANSPORT MOD A AND B MAINT MAN.	40865100	2	22	02.10
9180 MAGNETIC TAPE TRANSPORT PARTS LIST MOD A	40868100	B	22	05.55
CE MAINTENANCE MANUAL MODS A AND B	40864600	B	22	13.00
DIAGRAMS, CIRC. DESC., WIRE LIST	41240800	A		04.60
9190-B MAG TAPE TRANSPORT DIAGRAM/WIRE LIST	40826200	A	22	05.40
9200 (CE1A5) CARD READER				
9202 CARD READER				
GENERAL DESC., OPERATION, INSTALLATION,	49596700	B	22	03.00
CHECKOUT, MAINTENANCE CE MANUAL				
THEORY OF OPERATION, DIAGRAMS, WIRE LIST	49596800	B	22	05.80

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.

4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
CE MANUAL				
PARTS LIST CE MANUAL	49596900	B	22	09.35
9236/9244/9286 AIRLINES TERMINAL DISPLAY/ KEYBOARD				
HARDWARE PROGRAMMING MANUAL	62068100		22	02.05
RECEIVE ONLY- NON IMPACT OPERATORS GUIDE	62073800		22	01.00
OPERATORS GUIDE	62067900		22	01.00
ON SITE MAINT MANUAL	62068300		22	02.30
9251 CARD PUNCH SERVICE MANUAL	40808100	7		05.00
9280-A/B (CF507-A/B) CARD READER/PUNCH SUBSYSTEM				
9300 TICKET PRINTER				
GEN DESC, MAINT, PARTS DATA, WIRE LISTS	50577600	A	22	11.10
HARDWARE REF/CE MANUAL				
9301 LINE PRINTER CONTROLLER				
PARTS DATA, DIAGS, W/L, GEN DESC, INSTAL/ CHECKOUT.REF/CE MANUAL	50577900	A	22	15.75
9301 LINE PRINTER EQUIPMENT				
DIAGRAMS MANUAL	50577800	A		29.00
9320 LINE PRINTER PRINCIPLES OF OPERATION REFERENCE MANUAL	50584400	A	22	01.25
PARTS IDENTIFICATION MANUAL	50584600	A	22	02.15
MAINTENANCE, DIAGRAMS, WIRE LIST CE MANUAL	50584500	A	22	04.30
9322 LINE PRINTER MAINTENANCE, DIAGRAMS AND WIRE LIST FIELD SERVICE MANUAL	50583700	C	22	03.70
PARTS LIST PARTS IDENTIFICATION MANUAL	50583800	C	22	01.70
PRINCIPLES OF OPERATIONS REFERENCE MANUAL	50583600	D	22	01.80
LOGIC SCHEMATICS, CIRCUIT BOARDS, TIMING/ WIRING DIAGRAMS FIELD SERVICE MAN. VOL II	91859200	B	34	09.15
50982602/03 EQUIPMENT TYPE CL484C/CL484D INTRODUCTION, OPERATING INSTRUCTIONS				
PRINCIPLES OF OPERATION CE MANUAL				
INTRODUCTION, ASSEMBLY PARTS LISTS, PARTS IDENTIFICATION CE MANUAL	59579300	A	22	02.35
50982602/03 EQUIPMENT TYPE CL484/C/D INSTALL- ATION AND CHECKOUT, MAINT, W/L, DIAGRAMS FSM	59579200	01	22	15.30
59690800/01 EQUIPMENT TYPE CL408-A/B INSTALL. AND CHECKOUT, MAINTENANCE, GLOSSARY FIELD SERVICE MANUAL	91858400	A	22	02.35
INTRODUCTION, OPERATING INSTRUCTIONS, PRINCIPLES OF OPERATION MANUAL	59709100	A	22	04.20
INTRODUCTION, PARTS LIST, USED-ON INDEX CE	91859100	A	22	03.20
INTERCONNECTION DIAGS, PRINT HEAD LOGIC DIAG CONTROLLER LOGIC DIAGS, TIMING DIAGS, FSM II	91858500	A01	34	10.40

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
9340 LINE PRINTER EQUIPMENT PARTS DATA CE MAN. SPECIAL OPTION 68091 INTRO. OPER. PROG. INST. CHKOUT., PRINCIPLES OF OPER, MAINT. DIAGS, W/L, EQ SUM. PARTS DATA CE MANUAL PRINTER EQUIPMENT CE MAN. (USE CL308-A/B)	44895900 44977000	A C	22 22	02.00 02.90
9341 LINE PRINTER W/SPECIAL OPTION 68090 PART 1 CONTROLLER., PART 2 LINE PRINTER EQUIP., PART 3 LINE PRINTER PARTS DATA CE MANUAL	44975600	B	22	15.70
9342 LINE PRINTER EQUIPMENT (CL8P2-A THRU CL8P2-S) INSTALLATION, CHECKOUT, DIAGS, W/L, PARTS DATA, MAINTENANCE CE MANUAL	50579600	A01	22	06.95
9346E LINE PRINTER PRINT HEAD HDWR REF/CE MAN	44982700	B	22	03.70
9346-F LINE PRINTER HEAD MECHANISM (CL8R5-A/D) OPERATIONS, DIAGRAMS, WIRE LIST, MAINTENANCE, PARTS DATA CE MANUAL	50582500	B01	22	03.85
OPERATIONS, DIAGRAMS, WIRE LIST, MAINTENANCE PARTS DATA CE MANUAL	50579100	C	22	05.00
9350 SERIES LINE PRINTER EQ CE MANUAL PARTS DATA	44977600 44981600	A A	22 22	03.40 02.00
9350 LINE PRINTER EQUIP. MODIFIED FOR MSBT GEN DESC, DIAGS, W/L, MATNT. CE MANUAL PARTS DATA CE MANUAL	44983100 44983200	01 01		06.90 02.85
9352 LINE PRINTER CONTROLLER EQUIPMENT W/SPEC. OPTIONS CE MANUAL	44977700	A	22	05.15
INSTALLATION/CHECKOUT DIAGRAMS, WIRE LIST, PARTS DATA CE MANUAL	50581300	C	22	08.35
INSTALLATION/CHECKOUT, MAINT., PARTS DATA W/L, CE MANUAL	50581000	B02	22	08.40
INSTALLATION AND CHECKOUT, DIAGRAMS AND WIRE LISTS, PARTS DATA CE MANUAL	50581400	D	22	05.80
DIAGRAMS, WIRE LIST, PARTS DATA CE MANUAL EQUIPMENT MANUAL	50584800 59579400	C C	22 22	06.00 03.70
LOGIC SCHEMATICS, CIRCUIT BOARDS, WIRING PRINT HEAD MECHANISM - 96 CHARACTER	59707800	A	34	03.50
DIAGRAMS, TIMING DIAGRAMS, FIELD SERVICE MANUAL VOLUME II	59579500	A	22	03.40
FOR TOP LEVEL ASSEMBLY 50709515/16 EQUIPMENT TYPE CL4A9-E/CL4A9-F INSTALLATION AND CKOUT OPER., PRIN. OF OPER., POWER SUPPLY, DIAGS, MAINT, W/L, PARTS DATA HARDWARE REF/CE MAN	59708000	A	22	09.15
9355 LINE PRINTER PRINT MECHANISM HARDWARE REF/CE MANUAL	50580500			04.50

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
OPERATIONS, MAINT, DIAGRAMS, PARTS DATA CE	50581900	DO1	22	06.25
OPERATIONS, MAINTENANCE, DIAGRAMS, PARTS	50584700	A	22	07.90
DATA CE MANUAL				
9360 LINE PRINTER EQUIPMENT PARTS DATA	50578500	A	22	05.00
9361 LINE PRINTER EQUIPMENT PARTS IDENTIFICA-	59577900	A	22	04.80
TION MANUAL				
GEN DESC., MAINT/MAINT AIDS REFERENCE MANUAL	59578000	A	22	04.80
DIAGRAMS AND WIRE LIST FIELD SERVICE MANUAL	59578100	A	22	03.90
9362 PARTS IDENTIFICATION MANUAL	59578900	AD4	22	07.15
FIELD SERVICE MANUAL	59578800	A	22	24.30
CII- JT14A TEST BOX OPERATION MANUAL	76630900		22	02.50
9410-A, 9420-B DUAL DISK STOR DRU. MODS A01-A05	40866500	G	22	03.00
B04-B05 PARTS LIST				
GEN DESC, OPER, INSTAL AND CHECKOUT, MAINT MAN	40864400	D	22	05.65
THEORY OF OPER, DIAGS, MAINT. AIDS, AND W/L	40866400	E	22	05.65
9421 DUAL DISK DRIVE--LISTED AS BK3A1				
9431 DISK STORAGE DRIVE DIAG. AND W/L MAN A12B12	41247500	E	22	02.85
MAINTENANCE MANUAL MODS A12, B12 AND ABOVE	41245900	C	22	07.30
PARTS LIST MODS A12, B12 AND ABOVE	41244300	E	22	01.65
9432 DISK STORAGE DRIVE				
DIAGS AND WIRE LIST MANUAL MODS C, D, G, J, K	40827300	J	22	01.50
DIAGS, CIRC DESC, C/P AND WIRE LIST	41247600	E	22	02.55
MAINTENANCE MANUAL MODS A, B, C, D, G, H	40816900	E	22	06.10
MAINTENANCE MANUAL MODS C12-K12 AND ABOVE	41246000	C	22	06.85
PARTS LIST MODS C12 AND ABOVE, D12 AND ABOVE	41244400	D	22	02.40
F12 AND ABOVE, G12 AND ABOVE, J12 AND ABOVE				
K12 AND ABOVE				
PARTS MANUAL MODS C, D, F, G, J, K	40826500	C	22	02.10
9433-A/B/J/K DIAGRAMS AND WIRE LIST MANUAL	40863100	H	22	05.80
DIAGRAMS AND WIRE LIST MANUALS MOD A12, B12	41247700	E	22	02.00
J12, K12				
PARTS LIST MANUAL MOD A, B, J, K	40826800	D	22	03.20
CE MAINTENANCE MANUAL MODS A THRU G	40826900	F	22	04.10
MAINTENANCE MODS RH1A7-A AND B	41241600	B	22	08.85
9460 DISK STORAGE DRIVE				
PARTS LIST	40828700	B	22	01.30
9461 DISK STORAGE DRIVE				
DIAGRAMS AND WIRE LIST MOD A05/B05 ABOVE	40828900	N	22	05.40
PARTS LIST MODS A05-A11/B05-B11	40829000	C	22	06.55
MAINTENANCE MANUAL MODS A-B	40829100	F	22	05.55
MAINTENANCE MANUAL MODS A12, B12 AND ABOVE	41246800	C	22	04.05
PARTS LIST MODS A12, B12 AND ABOVE	41245200	F	22	02.00

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
DIAGS AND W/L MODS A12,B12 ABOVE, B35 ABOVE	41248400	L	22	01.55
CE MAINTENANCE MANUAL MODS A,B,J,K	41246100	C	22	06.00
MAINTENANCE MAN MODS F12,G12,L12,M12,S12, T12 AND ABOVE	41246200	B	22	02.00
PARTS LIST MODS A12 ABOVE, B12 ABOVE, J12 ABOVE, K12 ABOVE	41244500	D	22	02.00
9433 DISK STORAGE DRIVE--ALSO LISTED AS BJ1A9				
DIAG AND W/L MODS F/G/S/T 12 AND ABOVE	41247800	E	22	02.75
DIAG AND W/L MODS L/M 12 AND ABOVE	70604200	D	22	02.20
PARTS LIST MODS F/G/S/T 11 AND BELOW	40865500	D	22	01.70
PARTS LIST MODS F/G/L/M/S/T 12 AND ABOVE	41244600	D	22	01.80
9434-A/B DISK STORAGE DRIVE PARTS LIST MOD A,B	40827000	B	22	06.50
PARTS LIST MODS A12-B12 AND ABOVE	41244700	D	22	02.00
9441 DISK STORAGE DRIVE				
DIAGS,CIRC DESC,C/P AND W/L MODS B0 AND ABOVE	40828200	G	22	02.55
DIAGRAMS AND WIRE LIST OF MANUAL	70607700	B	22	02.00
9451 DISK STORAGE DRIVE--ALSO LISTED AS BJ1A7				
PART DATA MANUAL	70612200	A	22	01.65
9462-A/B DISK STORAGE DRIVE				
MAINTENANCE MANUAL MODS A12,B12 AND ABOVE	41246900	C	22	04.65
9463 DISK STORAGE DRIVE				
DIAGS,CIRC DESC, C/P AND W/L MODS A10 AND ABOVE, B10 ABOVE	40867100	C	22	05.00
9464 DISK STORAGE DRIVE				
DIAGRAMS, CIRC DESC, C/P,W/L MODS K09/ABOVE	40867600	B	22	06.00
MAINTENANCE MANUAL MODS K09-K11	40868400	D	22	08.70
MAINTENANCE MANUAL MOD A12 AND ABOVE	41247100	C	22	07.45
PARTS LIST MOD K	40868500	C	22	07.30
PARTS LIST MODS K12 AND ABOVE	41245500	D	22	02.00
9465 DISK STORAGE DRIVE--ALSO LISTED AS BJ3A3				
PARTS LIST MOD P-12 AND ABOVE	40860200	D	22	02.05
MAINTENANCE MANUAL MOD P	41240300	B	22	09.00
MAINTENANCE MANUAL MOD P12 AND ABOVE	41247200	C	22	08.10
DIAGRAMS AND WIRE LIST MODS D09 AND ABOVE	41240400	C	22	06.05
PARTS LIST MODS P09-P11	41240500	C	22	04.00
DIAGS,CARD PLACEMENT,W/L MODS P12 AND ABOVE	41248800	E	22	02.20
9468 DISK STORAGE DRIVE--LISTED AS BJ3A1				
9469 DISK STORAGE DRIVE--LISTED AS BJ2A2				
9480-1 MULTIPLE DISK DRIVE--LISTED AS BM1A3, BM1A7, BM1B3				

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
9480-2 MULTIPLE DISK DRIVE--LISTED AS BM1A1, BM1A5, BM1B1				
9481-1 MULTIPLE DISK DRIVE--LISTED AS BM1A4, BM1A6, BM1B4				
9481-2 MULTIPLE DISK DRIVE--LISTED AS BM1A2, BM1B2				
9482 MULTIPLE DISK DRIVE--LISTED AS BM2A1, BM2A2, BM3A2				
9482-1 MULTIPLE DISK DRIVE--LISTED AS BM2A7				
9482-2 MULTIPLE DISK DRIVE--LISTED AS BM2A8, BM2B1, BM2B2				
9486 DISK STORAGE UNIT--LISTED AS BP2A3, BP3A8				
9492/9493 DISK FILE SYSTEM MAINTENANCE MANUAL PARTS LIST MODS A	40829300	E	22	06.70
	40867800	A	22	10.40
9496/9497 DISK FILE GENERAL DESCRIPTION, OPER, INSTALL, CHECKOUT, MAINT, CE MANUAL	40865800	C	22	03.45
9519 (RE4C4) MAGNETIC TAPE TRANSPORT				
9520 (BE4B5) MAGNETIC TAPE TRANSPORT				
9525 (RE4B2) MAGNETIC TAPE TRANSPORT				
9525-13 (RE4B9) MAGNETIC TAPE TRANSPORT				
9525-14 (RE1A3) MAGNETIC TAPE TRANSPORT				
9540 (RE4B3) MAGNETIC TAPE TRANSPORT				
9545 (RE4B1) MAGNETIC TAPE TRANSPORT				
9545-13 (RE4C1) MAGNETIC TAPE TRANSPORT				
9545-14 (RE1A2) MAGNETIC TAPE TRANSPORT				
9560 (RE4A1) MAGNETIC TAPE TRANSPORT				
9565 (RE4A2) MAGNETIC TAPE TRANSPORT				
9565-13 (RE4C2) MAGNETIC TAPE TRANSPORT				
9565-14 (RE2A3) MAGNETIC TAPE TRANSPORT				
9566 (RE4B7) MAGNETIC TAPE TRANSPORT				
9568 (RE2A1) MAGNETIC TAPE TRANSPORT				
9580 (RE4B4) MAGNETIC TAPE TRANSPORT				
9585 (RE4A9) MAGNETIC TAPE TRANSPORT				
9585-11 (BE4B8) MAGNETIC TAPE TRANSPORT				
9585-13 (BE4C7) MAGNETIC TAPE TRANSPORT				
9585-14 (RE2A2) MAGNETIC TAPE TRANSPORT				
9720 DISK FILE--LISTED AS BH1A9 AND BH2A1				
9736 DISK STORAGE UNIT--LISTED AS BR1A1/7/9				
9737 DISK STORAGE UNIT--LISTED AS BR1A8				
9738 DISK STORAGE UNIT--LISTED AS BR1A3				

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover binder that may be used for manuals.
4-Publication division responsible for contents of literature.

TITLE	1	2	3	4
9739 DISK STORAGE UNIT--LISTED AS BR1A4				
9740 DISK STORAGE UNIT--LISTED AS BR1A5, BR2A1				
9741 DISK STORAGE UNIT--LISTED AS BR2A2				
9910 PERIPHERAL EXERCISER GEN DESC, DIAG, MAINT. CE MANUAL	70606600	B	22	03.70
23022/23030/23040/23050 MEMORY SYSTEM SITE PLANNING KIT	83096400	B		01.00
23044 MEMORY SYSTEM SITE PLANNING KIT	83096300			
23065/67 MODEL 1 MEMORY SYSTEM SITE PLANNING KIT	83096200			01.20
14031 TRAIN PRINTER GEN.DESC.,INSTALLATION AND CHECKOUT,OPERATION AND PROGRAMMING,PRINCIPLES OF OPERATION,MAINT/MAINT AIDS CE MANUAL VOL 1	59708200	A01	22	09.10
DIAGRAMS AND WIRE LISTS CE MANUAL VOL 2	59708300	A01	22	07.05
PARTS DATA CE MANUAL VOL 3	59708400	A01	22	10.50
23141 (9081) MULTIPLE DISK SYSTEM REFERENCE MANUAL	70613700	A	22	01.95
23142 (9082) MULTIPLE DISK SYSTEM REF MANUAL SYSTEM ANALYSTS GUIDE	70621300	A	22	03.85
	70622000	A	22	01.30
28211 PRINTER SYSTEMS FORM DESIGN,RIBBON AND ACCESSORIES USERS MAN	97403500	A	22	01.00
PRODUCT INFORMATION MANUAL	97404600	A	22	02.15
28211/14301 AND 28211-21 PRINTER SYSTEMS OPERATORS GUIDE	22265500	A	3	03.90
28211-21 PRINTER SUBSYSTEM LOGIC DIAGRAMS	22273100	G	34	02.60
THEORY OF OPERATIONS	22273000	G	3	13.75
33100 MEMORY SYSTEMS FOR THE IBM SYSTEM 370 SALES REFERENCE GUIDE	15000300		3	06.05
33135 MEMORY SYSTEM SITE PLANNING KIT	75365100	B		02.40
LOGIC DIAGRAMS	75387400	B	34	23.85
THEORY OF OPERATION	75387500			
PRODUCT INFORMATION MANUAL	75401000			
33145 MEMORY SYSTEM				

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover binder that may be used for manuals.

4-Publication division responsible for contents of literature.

TITLE	1	2	3	4
SITE PLANNING KIT	75365200	B		01.00
LOGIC DIAGRAMS	75372900	B	34	27.00
THEORY OF OPERATION	75373000	B	3	09.85
SERVICE MANUAL	75369200		3	12.90
33155-5XX MEMORY SYSTEM				
SITE PLANNING KIT	22264000	B		01.15
THEORY OF OPERATION	75401400	A	3	15.75
LOGIC DIAGRAMS	75401500	A	34	19.00
33155-6XX MEMORY SYSTEM				
SITE PLANNING KIT	75369100	B		03.35
PRODUCT INFORMATION MANUAL	22265400	A		01.00
MAINTENANCE MANUAL	75369600	A	3	12.75
33158 -2XX/3XX/4XX MEMORY SYSTEM				
SITE PLANNING KIT	75385700	A		02.00
THEORY OF OPERATION	75401700	A	3	15.75
LOGIC DIAGRAMS	75401800	A	34	19.00
33159 MEMORY SYSTEM				
SITE PLANNING KIT	22263900	C		02.15
PRODUCT INFORMATION MANUAL	22264800	A		01.00
SERVICE MANUAL	75369800		3	15.75
LOGIC DIAGRAMS	75391300	B	34	25.75
33165-5XX MEMORY SYSTEM				
THEORY OF OPERATION	75402000	A	3	17.25
LOGIC DIAGRAMS	75402100	A	34	19.00
SITE PLANNING KIT	75368900			
33301 MULTIPLE DISK SYSTEM PRODUCT INFOR MAN	70629800		3	00.85
REFERENCE MANUAL	70629900	D	22	06.30
GROUP III MICRODIAGNOSTICS DESCRIPTIONS	70604100	D	22	06.50
GROUP III MICRODIAGNOSTICS USERS MANUAL	70612400	C	22	02.05
TROUBLESHOOTING MANUAL	70608200	C	22	03.50
INSTALLATION CE MANUAL	70608100	G	22	08.75
33301 DISK MEMORY SUBSYSTEM SITE PLANNING KIT	83301400	C		01.00
33301/33302 SUBSYSTEM				
ON-LINE DIAGNOSTICS (COLDS MANUAL)	70602900	D	22	16.35
33302 DISK MEMORY SUBSYSTEM				
SITE PLANNING KIT	70627400		22	01.00
REFERENCE MANUAL	83301500	B	22	08.00
INSTALLATION CE MANUAL	83301600	D	22	03.75
TROUBLESHOOTING MANUAL	83301700	01	22	08.85
34201 MAGNETIC TAPE TRANSPORT				
OPERATORS MANUAL	49752300	A	3	01.10
OPERATORS GUIDE	22263500		3	01.80
MAINTENANCE	22285600		3	22.20

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
LOGIC DIAGRAMS SITE PLANNING KIT USE 38031 MAG TAPE SBSYSTEM PRODUCT MANUAL USE 38031 MAG TAPE SUBSYSTEM	22285700		34	06.80
38031 MAGNETIC TAPE CONTROLLER MAINTENANCE	22285300		3	01.35
LOGIC DIAGRAMS	22285400		34	18.65
TRANSLATOR LISTING	22285500			10.70
38031 MAGNETIC TAPE SUBSYSTEM PRODUCT MANUAL	22263800		3	03.85
SITE PLANNING KIT	75369000			01.50
90100 SYSTEM CONTROLLER COMPUTER SYSTEM REFERENCE MANUAL	60321400	A	22	01.40
INPUT/OUTPUT SPECIFICATIONS MANUAL	60321500	A	22	01.00
90104 (AB103-A, BB328-A, BB329-A) COMPUTATION MODULE REF INFO (USE 90100 REF MAN) CE INFO (USE AB103-A, CATALOG SEC. 1)				
90105-1 (DC118-A) DATA CHANNEL REF INFO (USE 90100 REF MAN) CE INFO (USE AB103-A, CATALOG SEC. 1)				
90106-1 (DC120-A) STORAGE CHANNEL REF INFO (USE 90100 REF MAN) CE INFO (USE AB103-A, CATALOG SEC. 1)				
90107-1 (GL112-A) CONSOLE REF INFO (USE 90100 REF MAN) CE INFO (USE AB103-A, CATALOG SEC. 1)				
90108-1 (BB329-A) MEMORY MODULE REF INFO (USE 90100 REF MAN) CE INFO (USE AB103-A, CATALOG SEC. 1)				
90108-2 (BB328-A) STORAGE INCREMENT REF INFO (USE 90100 REF MAN) CE INFO (USE AB103-A, CATALOG SEC. 1)				
90109-1 (DC119-A) CHARACTER HANDLER REF INFO (USE 90100 REF MAN) CE INFO (USE AB103-A, CATALOG SEC. 1) REF INFO (USE 90100 REF MAN) CE INFO (USE AB103-A, CATALOG SEC. 1) ** REFER ALSO TO VENDOR MANUALS SECTION FOR TELETYPE MANUALS (35KSP)				
90113-1 (CK502-A/B) TELETYPEWRITER ** REFER ALSO TO VENDOR MANUALS SECTION FOR TELETYPE MANUALS (35ASR)				

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.

4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
90114-1 (GH401-A) CABINET REF INFO (USE 90100 REF MAN) CE INFO (USE AB103-A, CATALOG SEC. 1)				
90115-1 (GD104-A, GD105-A, GD106-A) POWER SUPPLY REF INFO (USE 90100 REF MAN) CE INFO (USE AB103-A, CATALOG SEC. 1)				
90115-4 (GE210-A/B) AUXILIARY MOTOR GENERATOR CE INFO (USE 90100 SITE PREPARTION MANUAL - CATALOG SEC. 4)				
90120 PAPER TAPE STATION REFERENCE MANUAL	60324000	A	22	01.15
90121-1 (CE305-A/B) PAPER TAPE READER REF INFO (USE 90120 REF MAN) CE INFO (USE CE305-A/B, CATALOG SEC. 1) ** REFER ALSO TO 370 PAPER TAPE READER MANUALS				
90122-1 (CE305-A/B, GJ102-A) PAPER TAPE READER WITH HANDLER REF INFO (USE 90120 REF MAN) CE INFO (USE CE305-A/B, CATALOG SEC. 1) ** REFER ALSO TO 370 PAPER TAPE READER MANUALS ** REFER ALSO TO VENDOR MANUALS SECTION FOR REMEX PAPER TAPE SPOOLER CE MANUAL				
90123-1 (CF104-A) PAPER TAPE PUNCH REF INFO (USE 90120 REF MAN) CE INFO (USE CE305-A/B, CATALOG SEC. 1)				
90123-2 (CF106-A) PAPER TAPE PUNCH - TUNGSTEN CARBIDE REF INFO (USE 90120 REF MAN) CE INFO (USE CE305-A/B, CATALOG SEC. 1)				
90124-1 (CF104-A, GJ103-A/B) PAPER TAPE PUNCH WITH HANDLER REF INFO (USE 90120 REF MAN) CE INFO (USE CE305-A/B, CATALOG SEC. 1) ** REFER ALSO TO VENDOR MANUALS SECTION FOR REMEX TAPE SPOOLER CE MANUAL				
90124-2 (CF106-A, GJ103-A/B) PAPER TAPE PUNCH -TUNGSTEN CARBIDE- WITH HANDLER REF INFO (USE 90120 REF MAN) CE INFO (USE CE305-A/B, CATALOG SEC. 1) ** REFER ALSO TO VENDOR MANUALS SECTION FOR				

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.

4-Publication division responsi-
ble for contents of literature.

TITLE	1	2	3	4
REMX TAPE SPOOLER CE MANUAL				
90125-1 (CF5A5-A/B/C) PAPER TAPE STATION - COMMON CONTROL REF INFO (USE 90120 REF MAN) CE INFO (USE CE305-A/B, CATALOG SEC. 1)				
90126-1 (CF8A1-A) ENCLOSURE KIT FOR 90125-1 REF INFO (USE 90120 REF MAN) CE INFO (USE CE305-A/B, CATALOG SEC. 1)				
90127-1 (CW123-A) PAPER TAPE PUNCH VALIDATION FFEATURE REF INFO (USE 90120 REF MAN) CE INFO (USE CE305-A/B, CATALOG SEC. 1)				
92411 CRT DISPLAY TERMINAL OPERATORS GUIDE	62034200	01		01.00
HARDWARE PROGRAMMING MANUAL	62061700	02	22	01.00
92412 PRINTER TERMINAL OPERATORS GUIDE	62049500	00		01.00
HARDWARE PROGRAMMING MANUAL (PRELIMINARY)	62074000		22	01.20
92413 CONVERSATIONAL DISPLAY TERMINAL OPERATORS GUIDE	62038000	00		01.00
HARDWARE PROGRAMMING MANUAL	62033500	02	22	01.00
92417/92427 NON-IMPACT PRINTER STATION OPERATORS GUIDE	62073300			01.00
READ ONLY PRINTER PROGRAMMING MANUAL (92417)	62088900	01	22	01.05
READ ONLY PRINTER STATION HARDWARE PROGRAMMING MANUAL (92427)	62122800	01	22	01.00
ON-SITE MAINTENANCE MANUAL (92417)	62089100	01	22	01.20
ON-SITE MAINTENANCE MANUAL (92427)	62122900	01	22	01.05
92424/92425 AIRLINES TERMINAL DISPLAY/KEYBOARD OPERATORS GUIDE	62068000			01.00
ON SITE MAINTENANCE MANUAL	62068400			02.30
HARDWARE PROGRAMMING MANUAL	62068200			02.05
94100 () CORE MEMORY PRODUCT DESCRIPTION MANUAL	60410100	A	22	01.00
THEORY OF OPERATION MANUAL	60410200		22	02.50
CE MANUAL	60405400	A	22	08.95

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.

4-Publication division responsi-
ble for contents of literature.

SECTION 3

PLEASE NOTE:

A number of Software Manuals are listed in more than one location because of the fact that specific software products will run on various operating systems.

Manuals in this section

The format in this section uses a machine line heading with a listing of manuals for each operating system version and the appropriate product set members printed beneath the heading.

TABLE OF ABBREVIATIONS

All Titles for software manuals have been reviewed and standardized. The following table lists all abbreviations and their full wording.

ADB	Applications Development Bulletin
BIN	Binary
BSIPP	Simultaneous Peripheral Processor
COMPAT	Compatible
COMPARATIVE	Used with FORTRAN, notes the similarities and differences among the FORTRAN for 3000 and 6000 machine lines and USASI
EXT	Extended
FTN	FORTAN
FUNCT	Functions
GENERIC	Algol, applicable to all 3/6 machine line
HS	High Speed
IMB	Installation Handbook
LIB	Library
META	Procedure Oriented Source Language Assembler
MP	Memory Protect
MS	Mass Storage
MSIO	Logical Input/Output On Mass Storage
REF	Reference
OP	Operating System
REGINA 1	Linear Programming Package
RESPOND	Multiaccess Subsystem For Remote And/Or Local Ter
SAINT	1401 Simulator And Interpreter
SASY	31/32 Satellite For Standard File Processing-3600
SDPS	Seismic Data Processing System
SFP	Standard File Processor
SIPP	Simultaneous Peripheral Processor, Batch Execution
SMT	Summit
TSORT	Tape Sort
XLAT	Translator

TITLE		1	2	3	4	5
G-15 COMPUTER						
ALGOL/OPERATING MANUAL	60063600				01.00	36
ALGOL/PROGRAMMING MANUAL	60060500				02.05	32
ALGOL/TECHNICAL MANUAL	60060600				04.50	224
ALTRAN/REFERENCE MANUAL	60060300				03.00	160
AUTOCARD PROGRAMMING MANUAL	60153500				03.65	68
AUTOPOINT 24 PROGRAMMING MANUAL	PPT18100				03.05	24
BIT OF MEANING (APG-12591-0761)	60062100			22	01.00	20
CODING MANUAL	60060400				01.00	26
FIXED POINT SCALE (G-15)	60062700				01.00	28
INTERCARD PROGRAMMING MANUAL	60153600		A		03.30	86
INTERCOM 500/PROGRAM MANUAL	60060700				01.50	72
INTERCOM 1000/PROGRAMMING MANUAL	60062200				01.00	32
INTERMAP/PROGRAMMING MANUAL	60060100				03.00	156
G-20 COMPUTER						
GENERAL INFORMATION MANUALS						
BINARY PATCH LOADER (CB-11)	PSB-AG06				01.00	10
BOOTSTRAP CARD PRODUCER VIA CB-11	PSB-AG05				01.00	4
FILE OPERATIONS SYSTEMS (G-20)	PSB-AG01				01.00	20
INTRODUCTION TO PERT	60062000				01.00	12
MAGNETIC TAPE MACPOS (G-20)	PSB-AG02				01.00	30
PERT 2 FOR SNAP 11 VOL 1 (G-20)	PSB-AG09				01.00	15
PERT 2 FOR SNAP 11 VOL 2 (G-20)	PSB-AG09				01.00	20
PERT HANDBOOK	60153800				01.50	76
PIECES OF EIGHT, AN INTRO TO OCTAL SYSTEM	60061600				02.00	44
REVISIONS TO SPACE PROGRAMMING SYSTEM	PSB-AG04				01.00	16
SATELLITE PACKAGE (CB-11)	PSB-AG07				01.00	48
SPACE SYSTEM ARITHMETIC SUBROUTINES	PSB-AG03				01.00	7
TAPE-TO-MT-10 TAPE TRANSLATOR (603)	PSB-AG12				01.00	56
USE OF TAPES WITH THE SPACE SYSTEM	PSB-AG11				01.00	20
FORTRAN/REFERENCE MANUAL	60061200				02.00	108
FORTRAN 11/REFERENCE MANUAL	60054400				03.00	152
FORTRAN-M (SPD-03) (G-20)	60084200				01.50	74
LINEAR PROGRAMMING REF MAN	60054600				04.50	214
PERIPHERAL EQUIP. MAC LANG	60065100				05.35	106
SBAP REFERENCE MANUAL	60061900		A		02.10	32
SCIENTIFIC COMPUTING SYSTEM (G-20/G-20-A)	60054200				01.00	44
SIMULATOR REF MAN (G-20/650)	60060800				01.50	78
SIMULATOR TECHNICAL MAN (G-20/650)	BPT03621				02.75	50
SNAP 11/REF MANUAL	60061500				03.00	144
SORT MERGE/GENERATOR/INFORMATION MANUAL	60054000				01.50	72
SPAR/REFERENCE MANUAL	60054100				05.00	256
PERT/REFERENCE MANUAL (G-20)	60054500				01.50	80
MP-60 COMPUTER SYSTEMS						
	REFERENCE MANUAL	14306500	A	22	04.45	152
COMPASS	REF MANUAL	14061300	B	22	04.30	72

1. Publication number of literature
2. The latest revision level
3. Indicates number of holes punched in manual for use with hard cover ringed binder.

4. Price per manual.
5. Manual page count.

TITLE		1	2	3	4	5
COSY	REF MANUAL	14062100	A	22	01.00	34
PRELIA	REF MANUAL	14062200	A	22	01.00	44
160-B FORMERLY 160						
FORTRAN	GIM	60050500	B		01.00	28
	REFERENCE MANUAL	60050300			02.00	104
	OP PROCEDURE FTN-A	60082500			01.00	8
OSAS/ASSEMBLY	REFERENCE MANUAL	60050100			01.50	72
160-A						
AUTOCOMM	REF MANUAL	60051900	A		01.50	70
FORTRAN	REF MANUAL	60051300	B		02.50	120
INTERFOR	REF MANUAL	60051200			02.50	114
OSAS-A ASSEMBLY	REF MANUAL (SYSTEM)	60050700	C		01.00	52
PERIPHERAL PROC	REF MANUAL	60051700			01.00	36
RT DECODER INST	REF MANUAL	60025100	A		01.00	42
SASY	OPERATORS GUIDE	60171100			01.00	48
SICOM	REF MANUAL	60051500	A		02.50	132
MISCELLANEOUS						
SYSTEMS PROGRAMS FOR THE 160 COMPUTER		60008400		22	08.80	304
CHARACTERISTICS OF 160-A		60019100	C		01.00	20
270 DIGIGRAPHICS SYSTEM						
DIGIGRAPHIC SYSTEM 270 FUNCTION CONTROL		60146400			01.00	56
PROGRAM SPECIFICATIONS						
DIGIGRAPHIC SYSTEM 270 FUNCTION CONTROL		60146500			01.50	84
PROGRAM SPECIFICATIONS (SUPPLEMENT)						
DIGIGRAPHIC SUBSYSTEM FOR 3300 GEN.DESC		60146600	B	22	01.50	74
SYSTEM OPERATION						
DIGIGRAPHIC SUBSYSTEM FOR 3300 (STUDY GUIDE)		60233700	A	22	01.50	78
469 COMPUTER SYSTEM						
ASSEMBLER	REF MAN V1.2	14077300		22	01.50	66
BASIC ARITHMETIC	REF MANUAL	14082200	B	22	02.00	90
PROGRAMMING	REF MANUAL	14065300	B	22	03.00	150
SIMULATOR	REF MAN V1.0B	14082100	D	22	02.00	88
SUBROUTINES						
924-A COMPUTER						
924 ASSEMBLY PROGRAM FOR PAPER TAPE-CM01		60082600			01.00	16
1604-A						
FORTRAN -60	OPERATING GUIDE	60138100			01.00	48
	SOURCE LANGUAGE (PSB)	60138000			02.00	88
1604-C/1604-A FORMERLY 1604/1604A						
ALGOL (AE15)	GIM	60083400			01.00	84
ALGOL (SP002)	GIM	60084100			02.05	44
CODAP-I (PSBAE10)	GIM	60081000			01.00	8

1.Publication number of literature
2.The latest revision level
3.Indicates number of holes punched
in manual for use with hard cover
ringed binder.

4.Price per manual.
5. Manual page count.

TITLE		1	2	3	4	5
	REF MANUAL	60051000			01.00	48
COMPATABILITY		60083600			01.00	10
COSY ASSEMBLY	PSR	60081100	A		01.00	8
COBOL	REF MANUAL	60052100	B		06.00	222
	INTRODUCTION TO	60052000			01.00	60
COM2	REF MANUAL	60051100			01.50	66
COM3	REF MANUAL	60052600			01.50	68
CO-OP MONITOR	REF MANUAL	60051600	B	3	02.00	94
	INSTANT	60056100			01.35	36
	OPERATORS GUIDE	60050900			02.00	92
	PROGRAMMING GUIDE	60050800	A		03.00	150
FTN-60 SP001	GIM	60084000			04.00	190
FORTAN II/63	CONV GUIDE (PSBAE13)	60081300			01.00	12
FORTAN IV/67	CONV GUIDE (AE-15)	60081500			01.00	10
FORTAN 60/62	CONV GUIDE (PS A505)	60080500			01.00	28
FORTAN-62		60050600	A		02.50	116
FORTAN-63		60052900	A	3	04.00	196
LIBEDIT		60080400			01.00	18
PERT		60053900			02.00	96
PERT/TIME/FTN		60139000			01.00	28
SORT		60053500		3	01.50	86
SORT TIMING		60083700			01.00	19
MISCELLANEOUS						
CHARACTERISTICS		60001800	C		02.00	104
COMPUTER CENTER OPERATIONS (MASTER TAPE)		60018200	B		01.00	36
PROGRAMMING SYSTEMS		60052200			01.00	8
PART 2 OPERATION		60003200			05.50	266
1700						
ASSEMBLY SYSTEM (4K)	GIM	60133900	A		01.00	28
	REFERENCE	60171600			01.50	70
	INSTANT	60173700			01.35	28
	AQB	60176500			01.00	34
1700						
MSOS						
	REF MAN V2	60223100	C		05.00	260
	REF MAN V4	60361500	D	22	08.75	460
	DIAGNOSTIC HB V4	60361800	D		03.65	144
	IHR V2.1	60234300	F	22	05.20	118
	THR V4.0	60361600	C	22	06.40	328
	OPERATORS GUIDE V4.0	60373400	A	22	01.50	74
	SYSTEM CHKOUT REF V2	60362200	A		01.00	42
	IMPORT (1700) HS REF	60305700	A	22	02.00	90
MSOS 4	FILE MANAGER V1 REF	39520600	B	22	02.50	110
	ASSEMBLER, MACRO GIM	39519800	B	22	01.00	38
	INSTANT	39520500	A		02.75	82
	GIM	39522400	B	22	01.00	38
	MS/FORTAN VER3-A/R	39519900	A	22	01.00	56
	INSTALLATION HANDBOOK	39520900	A	22	03.00	138
	GENERAL INFO MANUAL					

1. Publication number of literature
2. The latest revision level
3. Indicates number of holes punched
in manual for use with hard cover
ringed binder.

4. Price per manual.
5. Manual page count.

TITLE		1	2	3	4	5
RCOS 2 ASSEMBLER	INSTANT SMALL COMPUTER MAINT. MONITOR V1	39521700	A		01.35	44
	ORDERING BULLETIN V4	39521900	B	22	01.50	76
	REF MANUAL	88997600	A	22	01.50	72
	RFF MAN V2	88948500	A	22	03.50	178
	RELEASE BULLETIN	39520800	A	22	01.25	72
	REF MAN 2.0	88964000	A	22	04.00	198
	FILE MGR UTILITY PROG	88947900	A	22	13.65	74
	OPERATORS GUIDE	88818500	A	22	15.85	94
	GIM	96716700	A	22	02.90	46
	ASSEMBLER, MACRO	60361900	B	22	02.00	88
TIME-SHARE TOTES	CONFIGURATION	60362300	C	22	02.00	98
	COSY/MSOS	60362100	B		01.00	28
	MS FORTRAN	60362000	D	22	04.50	230
	REF MAN V3	60362000	D	22	03.90	130
OLYMPUS 1700 DIAGNOSTIC PACKAGE SOFTWARE		39268100	D	22	03.90	130
SMALL COMPUTER MAINTENANCE MONITOR REF. MAN.		39520200	A	22	01.50	76
UTOPIA 1700 CONSOLE DEBUGGING PKG. SOFTWARE		84797500	C	3	01.50	80
1700						
REDUCED CORE MONITOR						
REDUCED CORE	IHR V1	60282800	A	22	02.50	116
	REF MAN V1	60280600	A	22	01.50	84
1700						
UTILITY SYSTEM						
ASSEMBLER	GIM	60170700		3	01.00	20
	REF MANUAL	60172300			02.00	90
	INSTANT	60173700			01.35	28
	GIM	60133900	A		01.00	28
TAPE FORTRAN	REF MANUAL	60171600			01.50	70
	INSTANT	60173700			01.35	28
	REF MANUAL	60174200		3	02.50	122
	INSTANT	60173700			01.35	28
I/O DRIVERS		60190000			01.00	50
17481430		60234500			01.00	16
SYSTEM BULLETINS						
	SR 8	60194000			02.00	88
	SR 9	60222200			01.00	22
	SR 13	60228500			01.00	20
MISCELLANEOUS						
		SEQ. NO. ONLY				
ANALOG/DIGITAL SYSTEMS GENERAL INFORMATION		60187600			02.00	92
AUTPAN USERS GUIDE V2.0		88762200	C	22	03.00	142
AUTPAN REFERENCE MANUAL V2.0		88762000	B	22	05.50	286
AUTPAN IHR V2.0		88762100	B	22	03.00	158
AUTPAN DACS SOFTWARE REFERENCE MAN V1		39644500	C		07.55	280
AUTPAN IT SYSTEMS MAINTENANCE SPECIFICATIONS VOLS 1 AND 2		39201800	A	22	09.00	512
CARDIO TEST II SOFTWARE OPERATORS GUIDE		39677500	A		01.00	26
DRAFT (VER. 5.1) OCR REFERENCE MANUAL		48143900	F	3	04.50	118
915/919 GRASP (VER. 2.2) OCR SOFTWARE REF MAN		48430100	B	3	03.10	80
955 GRASP (VER. 2.3) OCR SOFTWARE INSTALLATION HANDBOOK		91556200			02.45	22

1. Publication number of literature
2. The latest revision level
3. Indicates number of holes punched in manual for use with hard cover ringed binder.

4. Price per manual.
5. Manual page count.

TITLE		1	2	3	4	5
MEDISCOPE GENERAL INFORMATION MANUAL		60259500		3	01.00	34
MESSAGE ENTRY SYSTEM (MENS) SITE PREPARATION MANUAL		41600000	C	22	01.50	68
PARIMUTUEL WAGERING SYSTEM GIM		59155600	01	22	01.00	42
REMOTE I/O SUBSYSTEM (PRODUCTION CONFIGURATION) HDR. REF./OE MANUAL		39260700	A	22	08.65	482
SETPAN SOFTWARE REFERENCE MANUAL		60259400	B		01.50	60
SHORT OPERATING SYSTEM PROGRAM RULES REF.		60259700	A		03.50	182
SUP-SOFTWARE REFERENCE MANUAL		91637300	01	22	03.30	54
SUP (VER.1.0) SOFTWARE INSTALLATION HANDBOOK		91602400	B		02.50	34
TICKET ISSUING SYSTEM USERS GUIDE		59155100	A		01.00	32
TAPE SCOPE OCR SOFTWARE REF MANUAL		48430010	04	3	03.00	148
1700/SC1701 ASSEMBLER OCR SOFTWARE REF MAN		91634000	A	22	04.00	80
915/919 AN) 955/959 SETUP (VER.1.4) OCR SOFTWARE REFERENCE MANUAL		91674400	A		01.95	30
955 GRASP (VER.2.3) OCR SOFTWARE REFERENCE		48430000	C	3	03.25	38
915/919 GRASP (VER.2.2) OCR SOFTWARE INSTALL.		91529600		3	01.00	42
929 DRIVE(1784) SOFTWARE REF MANUAL		87971800	B	22	04.05	112

3170/3300/3500 COMPUTER SYSTEMS						
* MASTER V4 *						

MASTER						
DIAGNOSTIC HANDBOOK		60415500	C	22	09.75	539
GTM		60134100	B	22	01.00	34
INSTALLATION HANDBOOK		60415300	D	22	08.25	458
INSTANT		60426000	A	22	01.35	102
LTB GEN/MAINT MANUAL (INCLUDES COSY,CUP,GLIB, SYSGEN)		60415400	C	22	07.50	368
OPERATORS GUIDE		60415200	A	22	02.00	108
REFERENCE MANUAL		60415100	C	22	09.75	556
USERS GUIDE		60425700	A	22	05.50	278
UTILITIES REF MANUAL		60418900	B	22	02.00	107
ALGOL REF MANUAL		60371800	C	22	04.00	190
COBOL, ANSI REF MANUAL		60417800	C	22	06.00	305
COBOL, MS REF MANUAL		60192000	B	22	04.00	188
COMPASS REF MANUAL		60236800	C	22	06.40	314
FORTRAN, ANST REF MAN V2		60281400	C	22	04.50	214
FORTRAN, MS REF MAN V1		60236500	B	22	03.50	168
LISA REF MANUAL		60057600	G	22	05.00	254
L-SORT REF MANUAL		60236900	B	22	02.50	122
MS-SORT REF MANUAL		60343500	B	22	01.50	64
MARG-III REF MANUAL		60418000	3	22	01.50	91
USERS MANUAL		60372700	A	22	07.90	416
MOS-III REF MANUAL		60372800	A	22	02.50	136
META REF MANUAL		60282400	E	22	03.50	172
PERT/COST REF MANUAL		60236400	B	22	03.50	164
PERT/TIME REF MANUAL		60132500	A	22	01.50	78
		60131100		22	01.00	58

1.Publication number of literature
2.The latest revision level
3.Indicates number of holes punched in manual for use with hard cover ringed binder.

4.Price per manual.
5. Manual page count.

TITLE		1	2	3	4	5
RESPOND-EXP/TMP REF MANUAL		60372300	B	22	02.00	110
TAPE SORT/MERGE REF MANUAL		60282100	E	22	02.50	118
3170/3300/3500 COMPUTER SYSTEMS						

* MASTER V3 *						

MASTER						
	DIAGNOSTIC HDBK V3	60280800	F	22	09.40	520
	GIM	60134100	B	22	01.00	34
	IHB	60372500	F	22	08.25	460
	INSTANT	60227600	D		01.35	34
	LIBRARY GEN/MAINT	60373100	D	22	07.15	370
	MANUAL (INCLUDES					
	COSY,CUP,GLIB,					
	SYSGEN)					
	OPERATORS GUIDE V3	60281300	E	22	04.00	208
	REF MAN V3	60281000	D	22	09.00	494
	USERS GUIDE V3	60371600	B	22	05.50	266
ALGOL	INSTANT	60134900			01.35	34
	REF MANUAL	60371800	C	22	04.00	190
COBOL, ANSI	GIM	60213500	A	22	01.00	52
	INSTANT	60229500	B		01.35	32
	REF MANUAL	60281100	F	22	08.25	456
COBOL, MS	GIM	60056300		3	02.25	32
	REF MANUAL	60192000	B	22	04.00	188
COMPASS	INSTANT	60176700	B		01.35	20
	REF MANUAL	60236800	C	22	06.40	314
FORTRAN, ANSI	INSTANT	60229300	A		01.35	26
	REF MAN V2	60281400	C	22	04.50	214
FORTRAN, MS	GIM	60055200	C	22	01.00	40
	INSTANT	60131400	E		01.35	20
	REF MANUAL	60057600	G	22	05.00	254
LISA	REF MANUAL	60236900	B	22	02.50	122
L-SORT	REF MANUAL	60343500	A	22	01.50	64
MAPS	REF MAN V2	60372700	A	22	07.90	416
	USERS GUIDE V2	60372800		22	02.50	136
MCS III	REF MANUAL	60282400	E	22	03.50	172
META	GIM	60236000	A	22	01.00	56
	REF MANUAL	60236400	B	22	03.50	164
MS SORT	REF MAN V3	60362400	A	22	02.50	116
PERT COST	GIM	60130000		22	01.00	16
	REF MANUAL	60132500	A	22	01.50	78
	ADV DEV BULLETIN	60179800			01.00	20
PERT TIME	REF MANUAL	60131100		22	01.00	58
	APP DEV BULLETIN	60179700			01.00	14
	APP DEV BULLETIN V2	60172800			01.00	22
TAPE SORT/MERGE	REF MANUAL	60282100	E	22	02.50	118
RESPOND EXP/TMP	REF MANUAL	60372300	B	22	02.00	110
	INSTANT	60227700	A		01.35	36

- 1.Publication number of literature
- 2.The latest revision level
- 3.Indicates number of holes punched in manual for use with hard cover ringed binder.

- 4.Price per manual.
5. Manual page count.

TITLE	1	2	3	4	5
3170/3300/3500 COMPUTER SYSTEMS ***** * MASTER V3,V4 (MISC) * *****					
ANSI FORTRAN REF MAN V1 (FOR MASTER V3,V4)	60236500	B	22	03.50	168
MS SORT V2 (FOR REF MANUAL MASTER V3.0 AND V3.1)	60282200	B	22	02.00	100
L-SORT V1 (FOR REF MANUAL MASTER V3.0 AND V3.1)	60280200	A	22	01.00	28
DCP MARK 4 DIGI- REF MANUAL GRAPHICS (ONLY FOR MASTER V3.0)	60236600	A	22	03.00	156
MAPS REF MAN V1	60281900	B	22	08.25	446
USERS GUIDE V1	60282000	B	22	02.50	120
3170/3300/3500 COMPUTER SYSTEMS ***** * MASTER V2 * *****					
MASTER REF MAN V2	60213600	D	22	07.50	388
DIAGNOSTIC HDBK V2	60206800	B	22	04.50	214
IHR V2	60214000	G	22	08.65	466
OPERATORS GUIDE V2	60178600	B	22	02.50	132
COSY REF MANUAL	60178800	B	22	01.00	36
3100/3150/3170/3200/3300/3500 COMPUTER SYSTEMS ***** * MSOS V5 * *****					
MSOS					
DIAGNOSTIC HANDBOOK	60410900	C	22	05.50	287
INSTANT	60411000	A		01.35	164
IHR	60410800	D	22	06.40	326
OPERATORS GUIDE	60410700	B	22	01.50	108
REF MANUAL	60410600	C	22	07.50	405
ADAPT REF MANUAL	60173400	B	22	02.50	134
ALGOL REF MANUAL	60371800	C	22	04.00	190
COROL, ANSI REF MANUAL	60417900	A	22	05.00	240
COROL, MS REF MANUAL	60191100	C	22	03.50	170
COMPASS REF MANUAL	60236800	C	22	06.40	314
COSY REF MANUAL	60207300	C	22	01.00	48
FORTRAN, ANSI REF MANUAL	60281400	C	22	04.50	214
FORTRAN, MS REF MANUAL	60057600	G	22	05.00	254
LTCM/MSTR/MSOS REF MANUAL	60236900	B	22	02.50	122
REF COST REF MANUAL	60132500	A	22	01.50	78
REF TIME REF MANUAL	60131100		22	01.00	58

1.Publication number of literature
2.The latest revision level
3.Indicates number of holes punched
in manual for use with hard cover
ringed binder.

4.Price per manual.
5. Manual page count.

TITLE		1	2	3	4	5
SAINT	REF MANUAL	60213700	B	22	01.00	46
SORT MERGE	REF MANUAL	60281500	B	22	03.00	158
3100/3150/3170/3200/3300/3500 COMPUTER SYSTEMS						

* MSOS V4 *						

MSOS						
	DIAGNOSTIC HANDBOOK	60236700	D	22	06.75	340
	GIM	60176000		22	01.00	22
	INSTANT	60190300	B		01.35	44
	IHR	60280700	E	22	07.50	410
	OPERATORS GUIDE	60176100	D	22	04.95	168
	REF MANUAL	60173000	F	22	06.75	358
ADAPT	GIM	60135900			01.00	20
	REF MANUAL	60173400	B	22	02.50	134
	INSTANT	60174900			01.35	34
BSIOP	OPERATORS GUIDE	60190200			01.00	28
COBOL	GIM	60056300		3	02.25	32
	REF MANUAL	60172900		3	03.50	176
	INSTANT	60131200	A		01.35	32
	REF MAN V2	60281100	E	22	08.25	456
COBOL, ANSI	REF MANUAL	60191100	C	22	03.50	200
COBOL, MS	REF MANUAL	60236800	C	22	06.40	314
COMPASS	INSTANT	60176700	B		01.35	20
	REF MANUAL	60207300	C		01.00	48
COSY/MSOS/RTS	GIM	60055200	C		01.00	40
FORTPAN	REF MAN V4	60057600	G	22	05.00	254
	INSTANT	60131400	E		01.35	20
FORTPAN, ANSI	REF MAN V2	60281400	C	22	04.50	214
LISA/MSTR/MSOS	REF MANUAL	60236900	B	22	02.50	122
MP	ADR	60192100			01.00	16
MSID	GIM	60189700			01.00	12
	REF MANUAL	60191300	B	3	02.00	112
PEPT COST	GIM	60130000			01.00	16
	REF MANUAL	60132500	A		01.50	78
	ADR V2	60172800			01.00	22
	ADR	60177700			01.00	22
PEPT TIME	REF MANUAL	60131100			01.00	58
	ADR	60177400			01.00	20
RESPOND	GIM	60190400			01.00	16
	REF MANUAL	60192800			01.00	60
	INSTANT	60229900			01.35	32
SAINT	GIM	60132100	A		01.00	20
	REF MANUAL	60213700	B		01.00	46
SOPS	REF MANUAL	60235900			02.00	96
SFP	REF MANUAL	60207200			01.00	36
SIPP	REF MANUAL	60130400	B		01.00	32
SORT/MERGE	REF MANUAL	60281500	B	22	03.00	158
SORT	REF MANUAL	60174100	A	3	01.50	78
TSORT/MERGE	GIM	60055800	A		01.00	20
UTILITY	REF MANUAL	60279400	B	22	01.00	22

1. Publication number of literature
2. The latest revision level
3. Indicates number of holes punched
in manual for use with hard cover
ringed binder.

4. Price per manual.
5. Manual page count.

TITLE		1	2	3	4	5
3100/3150/3170/3200/3300/3500 COMPUTER SYSTEMS						

* REAL TIME SCOPE *						

REAL TIME SCOPE						
	DIAGNOSTIC HANDBOOK	60236700	D	22	06.75	340
	GIM	60134300		3	01.00	22
	IHB	60237000	A		03.50	180
	INSTANT	60191600			01.35	32
	OPERATORS GUIDE	60170200	A	3	01.50	64
	REF MANUAL	60172500			03.10	86
ADAPT	GIM	60135900			01.00	20
	REF MANUAL	60173400	B	22	02.50	134
BSIPP	OPERATORS GUIDE	60190200			01.00	28
COROL	GIM	60056300		3	02.25	32
	REF MANUAL	60132000			03.00	160
	INSTANT	60131200	A		01.35	32
	ADR V2	60137600			01.00	28
COROL, GPTD	GIM	60055100	B		01.00	20
	REF MANUAL	60059300	A		01.50	66
COMPASS	REF MANUAL	60236800	C	22	06.40	314
	INSTANT	60176700	B		01.35	20
COMPASS 32	GIM	60055000	A		01.00	34
COSY/MSOS/RTS	REF MANUAL	60207300	C		01.00	48
FORTAN	GIM	60055200	C		01.00	40
	REF MANUAL	60057600	G	22	05.00	254
	INSTANT	60131400	E		01.35	20
FIN COMPAR 3/6	REF MANUAL	60236100			01.50	86
PERT COST	GIM	60130000			01.00	16
	REF MANUAL	60132500	A		01.50	78
	ADR	60177700			01.00	22
	ADR V2	60172800			01.00	20
PERT TIME	REF MANUAL	60131100			01.00	58
	ADR	60177400			01.00	20
PRT GENERATOR	GIM	60173100			01.00	22
	REF MANUAL	60134700			02.00	102
	INSTANT	60133800			01.35	24
SAINT	GIM	60132100	A		01.00	20
	REF MANUAL	60213700	B		01.00	46
SIPP	REF MANUAL	60170400	B		01.00	32
UTILITY, SCOPE	REF MANUAL	60130200			01.00	26
3100/3150/3200 COMPUTER SYSTEMS						

* TAPE SCOPE *						

TAPE SCOPE						
	ADR, RANDOM DISK OP.	60178300			01.00	32
	GIM	60055400	A		01.00	16
	INSTANT	60189000	A		01.35	36

- 1.Publication number of literature
- 2.The latest revision level
- 3.Indicates number of holes punched in manual for use with hard cover ringed binder.

- 4.Price per manual.
5. Manual page count.

TITLE			1	2	3	4	5
	OPERATORS GUIDE		60059100			01.00	32
	REF MANUAL		60171200			04.50	220
BSIOP	OPERATORS GUIDE		60190200			01.00	28
COBOL	GTM		60056300		3	02.25	32
	REF MANUAL		60132000			03.00	160
	INSTANT		60131200	A		01.35	32
	ADB 42		60137600			01.00	28
COMPASS-32	GIM		60055000	A		01.00	34
	REF MANUAL		60236800	C	22	06.40	314
	INSTANT		60176700	B		01.35	20
COSY/MSOS/RTS	REF MANUAL		60207300	C		01.00	48
FORTRAN	GIM		60055200	C		01.00	40
	REF MANUAL		60057600	G	22	05.00	254
	INSTANT		60131400	E		01.35	20
FTN COMPAR 3/6	REF MANUAL		60236100			01.50	84
PERT COST	GIM		60130000			01.00	16
	REF MANUAL		60132500	A		01.50	78
	ADB V2		60172800			01.00	20
	ADR MSOS		60177700			01.00	22
PERT TIME	GTM		60130000			01.00	16
	REF MANUAL		60131100			01.00	58
	ADR/MSOS		60177400			01.00	20
PEGINA	REF MANUAL		60171800	A	3	01.00	60
REPORT PROG GEN	GIM		60133100			01.00	22
	REF MANUAL		60134700			02.00	102
	INSTANT		60133800			01.35	24
SAINT	GTM		60132100	A		01.00	20
	REF MANUAL		60213700	B		01.00	46
STP2	REF MANUAL		60130400	B		01.00	32
TAPE SORT MERGE	GIM		60055800	A		01.00	20
UTILITY, SCOPE	REF MANUAL		60130200			01.00	26
3100/3150/3200 COMPUTER SYSTEMS							

* BASIC DISK SCOPE *							

BASIC DISK SCOPE							
	REF GUIDE ADR		60175100			01.00	32
COMPASS-32	GIM		60055000	A		01.00	34
COMPASS	REF MANUAL		60236800	C	22	06.40	314
	INSTANT		60176700	B		01.35	20
COSY/MSOS/RTS	REF MANUAL		60207300	C		01.00	48
FORTRAN	GTM		60055200	C		01.00	40
	REF MANUAL		60057600	G	22	05.00	254
	INSTANT		60131400	E		01.35	20
FTN COMPAR 3/6	REF MANUAL		60236100			01.50	84
3100/3150/3200 COMPUTER SYSTEMS							

* DISK SCOPE *							

1.Publication number of literature
2.The latest revision level
3.Indicates number of holes punched
in manual for use with hard cover
ringed binder.

4.Price per manual.
5. Manual page count.

TITLE			1	2	3	4	5
DISK SCOPE							
	REF MANUAL		60171200			04.50	220
	OPERATORS GUIDE		60059100			01.00	32
	INSTANT		60189000	A		01.35	36
COMPASS-32	GIM		60055000	A		01.00	34
COMPASS	REF MANUAL		60236800	C	22	06.40	314
	INSTANT		60176700	B		01.35	20
COSY/MSOS/RTS	REF MANUAL		60207300	C		01.00	48
FORTRAN	GIM		60055200	C		01.00	40
	REF MANUAL		60057600	G	22	05.00	254
	INSTANT		60131400	F		01.35	18
FTN COMPAR 3/6	REF MANUAL		60236100		22	01.50	84
UTILITY SCOPE	REF MANUAL		60130200			01.00	26
3170/3300/3500 COMPUTER SYSTEMS							

* KRONOS IIT *							

KRONOS IIT							
	GIM		41614400	B	22	01.00	26
ASSEMBLE	REF MANUAL		41614800	A		01.00	50
BACKGROUND	REF MANUAL		41615100	A		01.00	22
BASIC	REF MANUAL		41615000			02.00	104
CAL	REF MANUAL		60361100	A		02.00	100
CENTRAL SITE	OPERATORS GUIDE		60342800	A		01.00	48
DEBUG	REF MANUAL		41615300	A		01.00	36
EDIT	REF MANUAL		41614900	A		01.00	52
FORTRAN/FTN	REF MANUAL		41614700	A		03.00	140
GENERAL SYSTEM	USFPS MANUAL		41614600	B	22	01.00	56
GO	REF MANUAL		41615200	A		02.45	28
INSTANT	REF MANUAL		41614500	A		01.35	82
NELIAC	REF MANUAL		60361200	A		02.15	60
3100/3150/3170/3200/3300/3500 COMPUTER SYSTEMS							

* MISCELLANEOUS							

ANALOG MAINT MONITOR (AMM30) SOFTWARE USERS			84763300			03.00	138
MANUAL							
AUTOLOAD UTILITY (3000L) REFERENCE			60130100			01.00	30
BASIC ASSEMBLER REFERENCE (3100/3200/3300)			60057100			01.50	64
BASIC ASSEMBLY PROG GENERAL REFERENCE MAN			60056800			01.00	20
BASIC FORTRAN REFERENCE MANUAL			60172000			02.50	116
BASIC SYSTEM GENERAL INFORMATION			60056800			01.00	20
BASIC II FORTRAN INSTANT (TAPE/SCOPE)			60189000	A		01.35	36
BASIC II FORTRAN REFERENCE MANUAL			60056900		22	01.00	56
BROKERAGE CONTROL OPERATORS GUIDE			59153300	A	22	03.00	148
BROKERAGE CONTROL OPERATORS GUIDE V4.0			59159100	A	22	03.00	162
BROKERAGE CONTROL REFERENCE MANUAL			59153200	A	22	01.50	80
BROKERAGE CONTROL REFERENCE MANUAL V4.0			59159000	A	22	02.00	88
BOP EQUIPMENT BULLETIN			60157500			01.00	28

1. Publication number of literature
2. The latest revision level
3. Indicates number of holes punched
in manual for use with hard cover
ringed binder.

4. Price per manual.
5. Manual page count.

TITLE	1	2	3	4	5
DIGIGRAPHIC SUBSYSTEM FOR 3000 (STUDY)	60233700	A	22	01.50	78
ILP1/INTEGER LINNFAR PROGRAMMING	60084900	A		01.00	32
MASTER/PROFITS 1.0 INSTALLATION PROCEDURES	97400100	A	22	01.00	24
MASTER/OCS MANUAL	59158900	A	22	04.15	154
MASTER USERS UTILITIES REFERENCE MANUAL	00007300	A	22	01.50	76
MSOS ON-LINE CONTROL SUBSYSTEM (OCS) REF MAN	59158800	A	22	06.25	214
MSOS/PROFITS 1.0 INSTALLATION PROCEDURES	59159600	A	22	01.00	22
PARIMUTUEL WAGERING SYSTEM GIM	59155600	01	22	01.00	42
SASY/SATELLITE (3000L) OPERATORS REFERENCE	60133700			01.00	52
SASY/SATELLITE (3600) OPERATORS REFERENCE	60171100			01.00	48
TIME SHARING EQUIPMENT BULLETIN	60156000			01.00	40
3000L COMMUNICATIONS SYS AND EQUIP REF 1	41606600	01	22	02.00	108
3000L TO CYBER 70 - CONVERSION AIDS SYSTEM	19980600	B	22	03.00	140
VERSION 1.0 - FORTRAN CONVERSION FOR					
SCOPE 3.4					
31/32/3300 SYSTEM BULLETIN 61	60236300		3	01.00	16
31/32/33/3500 PRELIS MSOS APPLICATIONS BULL.	60174700		3	01.00	340
31/33/3500 HYBRID LINKAGE SYSTEM	39083500		22	01.00	12
SOFTWARE USERS MANUAL					
31/32/33/3500 REGINA I	60178000			01.00	7
3200 SASY OPERATORS GUIDE	60133700			01.00	52
3200 SCOPE/EXECUTION INTERROGATION PROG	60139300	A	3	01.00	22
3400/3600/3800 COMPUTER SYSTEMS					

* 3400 DRUM SCOPE *					

DRUM SCOPE					
GIM	60131900			01.00	32
REF MANUAL	60170100			04.00	196
OPERATORS GUIDE	60171900			01.00	52
ALGOL INSTANT	60131700			01.35	24
ALGOL-60 GIM	60173300			01.00	20
COROL GIM	60170900			01.00	40
REF MANUAL	60170500	A		05.00	239
INSTANT	60057400	A		01.35	28
COMPASS GIM	60055700	A		01.00	32
3400 BASIC REFERENCE MANUAL	60057900			03.00	144
FORTRAN GIM	60055500	A		01.00	36
REF MANUAL	60132900	A		04.50	220
INSTANT	60057500	B		01.35	24
FTN LIB FUNCT REF MANUAL	60057200			02.00	98
GPTA GIM	60058900			01.00	16
REF MANUAL	60059400	A		01.00	44
PERT TIME/COST REF MANUAL	60059500			02.50	118
TAB (EXTENSION)	60139100			01.00	20
SORT IIT REF MANUAL	60059800	A		01.50	72
UTILITY PACKAGE ADR	60137100			01.00	26
UTILITY COSY ADR	60171500			01.00	12

1.Publication number of literature
2.The latest revision level
3.Indicates number of holes punched
in manual for use with hard cover
ringed binder.

4.Price per manual.
5. Manual page count.

TITLE		1	2	3	4	5
* 3400 TAPE SCOPE *						

TAPF SCOPE						
	GIM	60055600	B		01.00	34
	REF MANUAL	60057800			04.50	228
	OPERATING GUIDE V3	60134200			01.00	56
	INSTANT	60059000	A		01.35	36
	ADB (ADDITION TO REF)	60137200			01.00	20
	ADR (LIB PREPARATION)	60137300			01.00	16
ALGOL	INSTANT	60131700			01.35	24
	ADB	60084800	A		01.50	86
ALGOL-60	GIM	60173300			01.00	20
CEM-4	REF MANUAL	60132300	A		03.35	112
COBOL	GIM	60170900			01.00	40
	REF MANUAL	60170500	A	22	05.00	239
	INSTANT	60057400	A		01.35	28
COMPASS	GIM	60055700	A		01.00	32
	REF MANUAL	60057800	A		04.50	228
	ADR (ADDITION TO REF)	60137200			01.00	20
COMPASS/FTN	MIXED DECKS (PSB)	60137000			01.00	20
FORTRAN	GIM	60055500	A		01.00	36
	REF MANUAL	60132900	A		04.50	220
	REF MANUAL (GENERIC)	60214900	A		03.50	186
	INSTANT	60057500	B		01.35	24
FTN COMPAR 3/6	REF MANUAL	60236100			01.50	84
FTN LIB FUNCT	REF MANUAL	60057200			02.00	98
GRIQ	GIM	60058900			01.00	16
	REF MANUAL	60059400	A		01.00	44
INFOL	GIM	60132400			01.00	16
PERT TIME/COST	REF MANUAL	60059500			02.50	118
	TAR (EXTENSIONS)	60139100			01.00	20
SORT III	REF MANUAL	60059800	A		01.50	72
SORT MERGE	GIM	60058700			01.00	16
UTILITY PACKAGE	ADB	60137100			01.00	26
UTILITY COSY	ADB	60171500			01.00	12
	SR 24 (3400)	60192600			01.00	12
	SR 48 (36/3800)	SR001700			02.65	76
	SR 50 (36/3800)	60192700			01.00	12
	SP 51 (36/3800)	60193600			01.00	38
	SR 52 (36/3800)	60215200			01.00	60
	SR 54 (36/3800)	60279200			01.00	24
3400 SYSTEM	GIM	60058300			01.00	28

* 3600/3800 DRUM SCOPE *						

DRUM SCOPE						
	GIM	60131000			01.00	28
	REF MANUAL	60059200	B	22	04.50	222
	OPERATORS GUIDE V1	60171900			01.00	52
	OPERATORS GUIDE	60175000	A		01.00	54
	INSTANT	60131600	A		01.35	36

1.Publication number of literature
2.The latest revision level
3.Indicates number of holes punched
in manual for use with hard cover
ringed binder.

4.Price per manual.
5. Manual page count.

TITLE			1	2	3	4	5
	ADB (BACKGROUND PRG)		60137900			02.60	26
	ADB (DRUM/TAPE SCOPE)		60137500			01.00	16
ALGOL	INSTANT		60131700			01.35	24
ALGOL-60	GIM		60173300			01.00	20
APT	GIM		60131500			01.00	20
	REF MANUAL	A	60132800			05.00	244
	ADB		60190100			01.00	34
	SUPPLEMENT		60192900			01.50	84
CDC KWIC	ADB		60175300			01.00	32
COM-4	REF MANUAL		60177000			02.00	108
COBOL	GIM		60170900			01.00	40
	REF MANUAL	A	60170500			05.00	239
	INSTANT	A	60057400			01.35	28
COMPASS	GIM		60131800			01.00	36
	REF MANUAL	C	60052500			02.00	102
DISK SORT	GIM		60177300			01.00	16
	REF MANUAL		60189600			01.00	48
FORTRAN	GIM		60053400			01.00	52
	REF MANUAL	A	60132900			04.50	220
	OPERATING GUIDE (PSB)		60138200			01.00	46
	INSTANT	B	60057500			01.35	24
FTN LIB FUNCT	REF MANUAL	B	60056400			02.50	118
FORTRAN	GIM		60132400			01.00	16
	34/38 INFO MAN		60170300			03.00	140
	INSTANT		60173600			01.35	20
FTN COMPAR 3/6	REF MANUAL		60236100			01.50	84
GPIO	REF MANUAL		60130600			02.15	40
MSIO	REF MANUAL	A	60174800			01.00	60
NETWORK FLOW	REF MANUAL		60130500			01.00	52
PERT COST	REF MANUAL		60214800			02.00	92
PERT TIME	REF MANUAL		60170800			01.50	74
PERT TIME/COST	GIM		60170400			01.00	16
SIMSCRIPT	GIM		60133000			01.00	28
	REF MANUAL		60134600			03.00	162
	INSTANT		60133500			01.35	28
SOPT II	GIM		60058600			01.00	20
	REF MANUAL	D	60058500			01.50	78

* 3600/3800 TAPE SCOPE *							

	TAPE SCOPE						
	GIM		60132200	A		01.00	20
	REF MANUAL		60053300	B		05.50	280
	INSTANT		60059000	A		01.35	36
	ADB		60171300	A		01.00	20
ALGOL	INSTANT		60131700			01.35	24
ALGOL-60	GIM		60173300			01.00	20
APT	GIM		60131500			01.00	20
	REF MANUAL	A	60132800			05.00	244
	ADB		60190100			01.00	34
	SUPPLEMENT		60192900			01.50	84

1. Publication number of literature
2. The latest revision level
3. Indicates number of holes punched
in manual for use with hard cover
ringed binder.

4. Price per manual.
5. Manual page count.

TITLE			1	2	3	4	5
CDC KWIC	ADB		60175300			01.00	32
CEM-4	REF MANUAL		60132300	A		02.00	112
COBOL	GIM		60170900			01.00	40
	REF MANUAL		60170500	A		05.00	239
	REV A FOR 36/38 ONLY						
	INSTANT		60057400	A		01.35	28
	EXTENSIONS V2 (PSB)		60138400			01.00	12
	BIN ARITH 3600 COBOL		60083800			01.00	8
COMPASS	GIM		60131800			01.00	36
	REF MANUAL		60052500	C		02.00	102
	INSTANT		60056500	A		01.35	32
DISK SORT	REF MANUAL		60189600			01.00	48
FORTRAN	GIM		60053400			01.00	52
	REF MANUAL		60132900	A		04.50	220
	36/38 INFO REF MAN		60170300			03.00	140
	INSTANT		60173600			01.35	20
	INSTANT		60057500	B		01.35	24
FORTRAN II/3500	CONVERSION GUIDE		60081900	A		01.00	16
FORTRAN 63	CONVERSION GUIDE (PSB)		60082000			01.00	16
FTN LIB FUNCT	REF MANUAL		60056400	B		02.50	118
INFOL	GIM		60132400			01.00	16
	INSTANT		60173600			01.35	20
NETWORK FLOW	REF MANUAL		60130500			01.00	52
OPHELIE	ADB		60172200			02.00	96
PERT COST	REF MANUAL		60214800			02.00	92
PERT TIME	REF MANUAL		60170800			01.50	74
PERT TIME/COST	GIM		60170400			01.00	16
SIMSCRIPT	GIM		60133000			01.00	28
	REF MANUAL		60134600			03.00	162
	INSTANT		60133500			01.35	28
SORT II	GIM		60058600			01.00	20
	REF MANUAL		60058500	D		01.50	78
MISCELLANEOUS							
LIBRARY PREPARATION AND MAINTENANCE FOR			60083500			01.00	24
3600 (CA-11)							
OSAS-A MASTER TAPE (7681)			60138900			01.00	24
SCOPE MESSAGES AND DIAGNOSTICS (CA-03A)			60082400	A	3	01.00	44
SCOPE OPERATING GUIDE VERSION 2.0			60138800			01.00	28
SUMMIT-NRL 3800 SYSTEM							
CDM-4	ADB		60179000			02.00	106
COMPASS	ADB		60177800			02.00	100
DEPINO SYS	ADB		60179500			01.00	28
FORTRAN	REF MANUAL		60177200		22	03.25	100
6000 SERIES OR CYBER 70 MODELS 72,73,74							

* KRONOS V2.1 *							

KRONOS							
	EXPORT/IMPORT REF MAN		59150500	D	22	01.00	32
	GIM		60407100	A	22	01.00	20

1.Publication number of literature
2.The latest revision level
3.Indicates number of holes punched
in manual for use with hard cover
ringed binder.

4.Price per manual.
5. Manual page count.

TITLE		1	2	3	4	5
	IHB	60407500	K	22	09.40	531
	INSTANT	60407200	A		01.35	208
	OPERATORS GUIDE	60407700	D	22	05.00	216
	REF MAN VOL.1 (FOR APPLICATION ANALYST)	60407000	D	22	10.75	618
	REF MAN VOL.2 (FOR SYSTEM ANALYST)	60448200	D	22		
	TERMINAL USER INSTANT	60407800	A		01.35	50
	TEXT EDITOR REF MAN	60408200	B	22	01.50	70
	T-S USERS REF MAN	60407600	C	22	03.00	148
ALGOL	INSTANT V3	60192500	A		01.35	28
	REF MAN V3	60329000	D	22	05.00	240
	REF MAN V4	60384700	A	22	05.00	246
APEX III	REF MANUAL	76070000		22	03.50	244
APL* CYBER	REF MANUAL	19980400	C	22	04.50	204
BASIC	REF MANUAL	19980300	B	22	04.50	232
COBOL	GTM V4	60327800	A	22	01.00	52
	INSTANT V4	60328400	B		01.35	50
	REF MAN V4	60384100	E	22	06.00	598
COMMON UTILITIES	REF MANUAL	60493300	A	3	01.00	32
COMPASS	GIM V3	60343400	A	22	01.00	52
	INSTANT V3	60361000	B		01.35	104
	INSTR CARD V3	60361700	B		00.50	2
	REF MAN V3	60360900	E	22	06.75	356
CYBERLINK INTERCHANGE						
	REF MAN V1	60373300	B	22	01.50	82
	OPERATORS GUIDE	60408400	B	22	01.00	58
EXPORT/IMPORT	REF MANUAL	59150500	D	22	01.00	32
FORTPAN	INSTANT V2.3	60189500	E		01.35	32
	REF MAN V2.3	60174900	F	22	04.50	218
FORTPAN EXT	GTM V4	60327900	A	22	01.00	46
	INSTANT V4	60357900	B		01.35	56
	REF MAN V4	60305600	G	22	09.00	508
	DEBUG GUIDE V4	60329400	B	22	02.00	106
	COMMON LIBRARY MANUAL	60387900	B	22	03.50	166
GPSS V/6000	GTM	84003900	A	3	01.00	94
IGS	LGCT V1 GIM	17322700	B	22	01.20	28
	LGCT V1 REF	17322800	B	22	03.00	40
LOADER	INSTANT	60372200	B		01.35	56
	REF MANUAL	60344200	G	22	04.50	214
MODIFY	INSTANT	60283000	B		01.35	42
	REF MANUAL	60281700	D	22	01.50	78
ON-LINE MAINT	REFERENCE MANUAL	60436600	A	22	02.50	116
PERT/TIME	REF MAN V1.2	60133600	D	22	01.50	76
RECORD MANAGER	CYBER MULTIPLE INDEX PROCESSOR (PSP)	60492900	B	22	01.00	52
	REF MANUAL	60307300	G	22	05.00	254
SIMSCRIPT	GTM V3	60173500	A	22	01.00	24
	REF MAN V3	60358500	E	22	04.00	198
SIMULA	GTM V1	60251900	A	22	01.00	30
	REF MAN V1	60234800	F	22	05.00	242
SORT/MERGE	GTM V4	60342400	A	22	01.00	18
	INSTANT V4	60344400	B		01.35	60

1.Publication number of literature
2.The latest revision level
3.Indicates number of holes punched
in manual for use with hard cover
ringed binder.

4.Price per manual.
5. Manual page count.

TITLE		1	2	3	4	5
	REF MANUAL	60343900	G	22	03.00	146
SYMPLE	REF MANUAL	60328800	C	22	03.00	172
TOTAL	REF MANUAL	76070300		3	03.50	180
TRANSACTION SUBSYSTEM						
	OPERATORS GUIDE	60408000	B	22	01.00	36
	REF MANUAL	60407900	B	22	04.00	200
	TRANEX USERS GUIDE	60436500	A	22		24
T-S FORTRAN	REF MANUAL	60408600	B	22	03.00	144
UPDATE	INSTANT	60360200	A	22	01.35	44
	REF MANUAL	60342500	E	22	02.00	102
8-BIT SUBROUTINE	REF MANUAL	60359400	C	22	03.00	158
6000 SERIES OR CYBER 70 MODELS 72,73,74						

* KRONOS V2.0 *						

KRONOS						
	EXPORT/IMPORT REF MAN	59150500	D		01.00	32
	GIM	59156600	01		01.00	36
	INSTANT	59152100	01		01.35	12
	OPERATORS GUIDE	59151600	A		03.50	186
	REF MANUAL	59150600	C		09.40	514
	TERMINAL USER INSTANT	59152000	B		01.35	24
	TEXT EDITOR REF MAN	59150700	B		01.00	30
	T-S USERS REF MAN	59151300	B		02.00	94
ALGOL	INSTANT V2	60192500	A		01.35	28
APT	GIM V2.2	60172100			01.00	20
	REF MAN V2.2	60174500	C		05.50	270
COBOL	REF MAN V3	60253000	F		07.50	402
	INSTANT V3	60327600	A		01.35	44
COMPASS	REF MAN V2	60279900	D	22	06.75	354
	INSTANT	60282900	B		01.35	96
FORTRAN	REF MAN V2.3	60174900	F	22	04.50	218
	INSTANT V2.3	60189500	E		01.35	32
FORTRAN EXT	INSTANT V3	60305900			01.35	40
FORTRAN TRANSLT	REF MANUAL	59151000	B	22	01.00	26
MODIFY	INSTANT	60283000	B		01.35	42
	REF MANUAL	60281700	D	22	01.50	78
PERT/TIME	REF MAN V1.2	60133600	D	22	01.50	76
SCOPE	INDEXED SEQUENTIAL RM	60305400	E	22	02.50	134
SIMSRIPT	GIM V2	60173500	A	22	01.00	24
SIMULA	GIM V1	60251900	A	22	01.00	30
	REF MAN V1	60234800	F	22	05.00	242
SORT/MERGE	REF MAN V3	60252600	D	22	03.00	146
T-S BASIC	REF MANUAL	59150800	C	22	02.00	90
T-S FORTRAN	REF MANUAL	60408600	B	22	03.00	144
6000 SERIES OR CYBER 70 MODEL 72/73/74						
CYBER 170 MODELS 172,173,174,175						

1.Publication number of literature
2.The latest revision level
3.Indicates number of holes punched
in manual for use with hard cover
ringed binder.

4.Price per manual.
5. Manual page count.

TITLE		1	2	3	4	5
* NOS V1.0 *						

NOS						
	APPLICATIONS PROGRAM-	60436000	A			
	MERS INSTANT					
	BATCH USERS GUIDE	60436300	A	22		
	EXPORT/IMPORT REF	60436200	A	22	01.00	36
	GIM	60435900	A	22	01.00	24
	IHR	60435700	A	22		
	OPERATORS GUIDE	60435600	A	22		
	REF MAN VOL.1 (FOR	60435400	A	22		
	APPLICATION ANALYST)					
	REF MAN VOL.2 (FOR	60445300	A	22		
	SYSTEM ANALYST)					
	SYSTEMS PROGRAMMERS	60449200	A			
	INSTANT					
	TERMINAL USER INSTANT	60435800	A			
	TEXT EDITOR REF	60436100	A	22	01.50	68
	T-S REF	60435500	A	22		
	T-S USERS GUIDE	60436400	A	22		
ALGOL	REF MAN V4	60384700	A	22	05.00	246
APL*CYBER	REFERENCE MANUAL	19980400				
APT IV	GIM	17313200	C	22	01.00	20
	REF MANUAL	17313600	C	22	05.50	286
BASIC	REFERENCE MANUAL	19983900				
COROL	GIM	60327800	A	22	01.00	52
	INSTANT	60328400	B		01.35	50
	REF MAN V4	60384100	E	22	10.50	598
COMMON UTILITIES	REF MANUAL	60493300	A	3	01.00	32
COMPASS	GIM	60343400	A	22	01.00	52
	INSTANT	60361000	B		01.35	104
	INSTRUCTION CARD	60361700	B		00.50	2
	REF MAN V3	60360900	E	22	06.75	356
DDL	REF MANUAL	60359000	B	22	03.50	182
	USERS GUIDE	60384300	A	22	02.00	110
FORTRAN EXT	GIM	60327900	A	22	01.00	46
	GUIDE FOR USERS OF	60385200	A	22	02.50	136
	FORTRAN EXTENDED					
	INSTANT	60357900	B		01.35	56
	REF MAN V4	60305600	G	22	09.00	508
	DEBUG USER GUIDE	60329400	B	22	02.00	106
	COMMON LIBRARY MANUAL	60387900	B	22	03.50	166
GPSS V/6000	GIM	84003900	A		01.00	94
TGS	LOGT V1 GIM	17322700	A	22	01.00	28
	LOGT V1 REF	17322800	B	22	03.00	40
LOADER	INSTANT	60372200	B		01.35	56
	REF MANUAL	60344200	G	22	04.50	214
MODIFY	INSTANT	60283000	B		01.35	42
	REF MANUAL	60281700	D	22	01.50	78
ON-LINE MAINT	REFERENCE MANUAL	60436600	A	22	02.50	116
REPT/TIME	GIM	60133300		22	01.00	16
	REF MANUAL	60133600	D	22	01.50	76
QUERY UPDATE	REF MANUAL	60307500	D	22	02.00	94

1.Publication number of literature
2.The latest revision level
3.Indicates number of holes punched
in manual for use with hard cover
ringed binder.

4.Price per manual.
5. Manual page count.

TITLE		1	2	3	4	5
QU DDL	REF MANUAL V2	60384900	D	22	06.40	290
	MINI USERS GUIDE	60385500	C		01.35	73
	DATA DEFINITION					
	LANGUAGE FOR THE					
RECORD MANAGER	QUERY UPDATE					
	SUB-SCHEMA					
	REFERENCE MANUAL	60359200	C	22	02.00	112
	REF MANUAL	60307300	G	22	05.00	254
SIMSCRIPT	CYBER MULTIPLE INDEX	60492900	B	22	01.00	52
	PROCESSOR (PSB)					
	GIM	60173500	A	22	01.00	24
	REF MAN V3	60358500	E	22	04.00	198
SIMULA	GIM	60251900	A	22	01.00	30
	REF MANUAL	60234800	F	22	05.00	242
	GIM	60342400	A	22	01.00	18
	REF MANUAL	60343900	G	22	03.00	146
SORT MERGE	INSTANT V4	60344400	B		01.35	60
	REF MANUAL	60328800	C	22	03.00	156
	SYMPL					
	TOTAL	76070300		3	03.50	180
TRANSACTION SUBSYSTEM	OPERATORS GUIDE	60408000	B	22	01.00	36
	REF MANUAL	60407900	B	22	04.00	200
	TRANEX USERS GUIDE	60436500	A	22		24
	INSTANT	60360200	A		01.35	44
UPDATE	REF MANUAL	60342500	E	22	02.00	102
	8-BIT SUBROUTINE REF MANUAL	60359400	C	22	03.00	158
	3001L TO CYBER					
	70					
70	CONVERSION AIDS					
	SYSTEM 1.2 FORTRAN	19980600	C	22	03.00	140
	SYSTEM 1.2 COBOL	19980700	B	22	05.50	264
	SYSTEM 1.2 LANGUAGE	19980900	B	22	03.50	178
70	CONVERSION USERS					
	GUIDE					
6000 SERIES OR CYBER 70 MODEL 72,73,74						

* SCOPE V3.4 *						

SCOPE	IHR	60307400	V	22	07.15	230
	REF MANUAL	60307200	H	22	09.00	462
	OPERATORS GUIDE	60327300	F	22	06.40	320
	CONV AIDS PSR	60358200	D	22	01.50	68
ALGOL	USERS GUIDE	60358700	A	22	06.40	320
	REF MAN V3	60329000	D	22	05.00	240
	REF MAN V4	60384700	C	22	05.00	246
	REF MANUAL	59158000	C	22	03.50	172
APEX T	REF MANUAL	59158100	B	22	06.40	318
	REF MANUAL	76070000		22	03.50	244
	REF MANUAL	60172100		22	01.00	20
	GIM	60193100			01.35	40
APEX II	INSTANT					
	REF MANUAL	60174500	C	22	05.50	270
APEX III						
APT						

1.Publication number of literature
2.The latest revision level
3.Indicates number of holes punched
in manual for use with hard cover
ringed binder.

4.Price per manual.
5. Manual page count.

TITLE		1	2	3	4	5
APT IV	GTM	17313200	C	22	01.00	20
	REF MANUAL	17313600	C	22	05.50	286
BASIC	REF MANUAL	19980300	B	22	04.50	232
	REF MANUAL	60306200	C	22	02.00	108
CCP SUPPORT SOFTWARE 1	REF MAN	88988400	A	22	01.00	48
	DIAGNOSTIC HANDBOOK	88988700	A	22	01.00	30
	GTM	88988600	A	22	01.00	34
	MACRO ASSEMBLER REF	88988900	A	22	02.00	102
	MICRO ASSEMBLER REF	88988800	A	22	02.00	102
	PASCAL COMPILER REF	88988500	A	22	01.50	82
COROL	GIM	60327800	A	22	01.00	52
	INSTANT	60328400	B		01.35	50
	REF MAN V4	60384100	E	22	06.00	598
	COMMON UTILITIES REF MANUAL	60493300	A	3	01.00	32
COMPASS	GIM	60343400	A	22	01.00	52
	INSTANT	60361000	B		01.35	104
	INSTRUCTION CARD	60361700	B		00.50	2
	REF MAN V3	60360900	E	22	06.75	356
DDL	REF MANUAL	60359000	B	22	03.50	182
	USERS GUIDE	60384300	A	22	02.00	110
DDS	REF MAN V3	17318900	A	22	01.50	76
EXPORT/IMPORT	HS REF MAN	60235400	D	22	02.00	106
	8231 REF MAN	60189100	A	22	01.00	48
FORM	REF MANUAL	60307000	F	22	02.50	122
FORTRAN	INSTANT	60189500	E		01.35	32
	REF MAN V2.3	60174900	F	22	04.50	218
FORTRAN EXT	GIM	60327900	A	22	01.00	46
	GUIDE FOR USERS OF FORTRAN EXTENDED	60385200	A	22	02.50	136
	INSTANT	60357900	B		01.35	56
	REF MAN V4	60305600	G	22	09.00	508
	DEBUG USER GUIDE	60329400	B	22	02.00	106
	STFT PSB	60358400	A		01.00	26
	COMMON LIBRARY MANUAL	60387900	B	22	03.50	166
	240 SERIES REF MAN	17307300	E	22	02.50	122
TGS	274 SERIES OG	60359800	C	22	02.00	88
	777 VER 2.0 USERS GUIDE/TRAINING MAN	17322500	A	22	02.00	100
	777 VER.2 OPERATORS GUIDE	17322600	B	22	01.00	40
	777 V2 QUICK DRAW PACKAGE REFERENCE	17325100	A	22	01.00	48
	274 SERIES REF MAN	60358800	C	22	03.50	172
	LOGT V1 GIM	17322700	B	22	01.20	28
	LOGT V1 REF	17322800	B	22	03.00	40
	777 3-D V1 REFERENCE	17326500	A	22	02.00	90
	CSSL III REFERENCE	17304400	F	22	04.50	228
	APT/IGS V1 REFERENCE	17310100	B	22	06.75	354
	APT/IGS V1 G.I.M.	17317400	B	22	01.00	20
	777 IGS V2 REFERENCE	17321800	A	22	05.00	254
INTERCOM	REF MANUAL	60307100	E	22	04.00	208
	MUJ PSB	60358300	C	22	01.00	36

1.Publication number of literature
2.The latest revision level
3.Indicates number of holes punched
in manual for use with hard cover
ringed binder.

4.Price per manual.
5. Manual page count.

TITLE		1	2	3	4	5
	INTERACTIVE COMMAND SUMMARY	60384600	D		00.50	2
	INTERACTIVE INTERCOM GUIDE FOR USERS OF FORTRAN EXTENDED	60359700	B	22	03.50	174
	INTERACTIVE PROCEDURE GUIDE	60385600	B		01.35	15
	INTERACTIVE INTERCOM GUIDE FOR USERS OF COBOL	60385700	C	22	03.50	166
	REMOTE BATCH COMMAND SUMMARY	60387400	A		00.50	2
LOADER	INSTANT	60372200	B		01.35	72
	REF MANUAL	60344200	G	22	04.50	222
MARS VI	REF MAN (FULL INV)	17313000	A	22	05.00	262
	REF MAN (PART INV)	60385900	A	22	04.50	226
	REF MANUAL	17305100	A	22	03.00	156
PERT/TIME	GIM	60133300		22	01.00	16
	REF MANUAL	60133600	D	22	01.50	76
QUERY UPDATE	REF MANUAL	60307500	D	22	02.00	94
	REF MAN V2	60384900	D	22	06.40	290
	MTNI USERS GUIDE	60385500	C		01.35	73
QUDDL	REF MANUAL	60327200	D	22	02.00	92
QUDDL	DATA DEFINITION LANGUAGE FOR THE QUERY UPDATE SUB-SCHEMA					
	REFERENCE MANUAL	60359200	C	22	02.00	112
RECORD MANAGER	REF MANUAL	60307300	G	22	05.00	254
	USERS GUIDE	60359600	C	22	07.50	428
	GUIDE FOR USERS OF FORTRAN EXTENDED	60385200	A	22	02.50	136
	GUIDE FOR COBOL USERS	60385300	A	22	03.00	150
	CYBER MULTIPLE INDEX PROCESSOR (PSB)	60492900	B	22	01.00	52
SIMSCRIPT	GIM	60173500	A	22	01.00	24
	REF MAN V3	60358500	E	22	04.00	198
SIMULA	GIM	60251900	A	22	01.00	30
	REF MANUAL	60234800	F	22	05.00	242
SORT MERGE	GIM	60342400	A	22	01.00	18
	REF MANUAL	60343900	G	22	03.00	146
SYMPL	REF MANUAL	60328800	C	22	03.00	156
UPDATE	INSTANT	60360200	A		01.35	44
	REF MANUAL	60342500	E	22	02.00	102
8 BIT SUBROUTINE	REF MANUAL	60359400	C	22	03.00	158
1702 MSOS	OPERATORS GUIDE	60359800	C	22	02.00	88
	EXPORT/IMPORT	60305700	A	22	02.00	90
3000L TO CYBER	CONVERSION AIDS	19980600	C	22	03.00	140
70	SYSTEM 1.0 FORTRAN CONVERSION FOR SCOPE 3.4					
	CONVERSION AIDS SYSTEM 1.0 COBOL	19980700	B	22	05.50	264

1.Publication number of literature
2.The latest revision level
3.Indicates number of holes punched in manual for use with hard cover ringed binder.

4.Price per manual.
5. Manual page count.

TITLE		1	2	3	4	5
CONVERSION FOR SCOPE 3.4 CONVERSION AIDS SYSTEM 1.0 LANGUAGE CONVERSION USER GUIDE		19980900	B	22	03.50	178
6000 SERIES OR CYBER 70 MODEL 72,73,74 ***** * SCOPE V3.3 * ***** SCOPE						
	IHR	60305100	AC	22	09.00	506
	INDEXED SEQ REF MAN	60305400	E	22	02.50	134
	OPERATORS GUIDE	60306400	F	22	03.50	174
	OPHELIE GIM V1	59156800	A	22	01.00	48
	OPHELIE REF V1	59156900	C	22	05.50	270
	OPHELTE/MIXED REF V1	59157000	B	22	01.50	80
	REF MANUAL	60305200	F	22	07.15	376
	USERS GUIDE	60252700	C	22	06.00	302
ALGOL	INSTANT	60192500	A		01.35	28
	REF MAN V3	60329000	D	22	05.00	240
APT	APP DEV BULLETIN	60193100			01.00	40
	GIM	60172100		22	01.00	20
	REF MANUAL	60174500	C	22	05.50	270
APT IV	REF MANUAL	17313600	C	22	05.50	286
BASIC	REF MANUAL	60306200	C	22	02.00	108
COBOL	INSTANT	60327600	A		01.35	44
	REF MANUAL	60253000	E	22	07.50	402
COMPASS	GIM	60174400	C	22	01.00	16
	INSTANT	60191900	B		01.35	26
	INSTANT V2	60282900	B		01.35	96
	REF MANUAL	60190900	C	22	04.00	196
	REF MAN V2	60279900	D	22	06.75	354
CSSL3	USERS GUIDE	17304400	F	22	04.50	228
(CONTINUOUS SYSTEM SIMULATION LANGUAGE III)						
EXPORT/IMPORT	HS REF MAN	60235400	D	22	02.00	106
	HS OG	17303100	A	22	01.50	72
	200 REF MAN	60234600	B	22	01.50	86
	8231 REF MAN	60189100	A	22	01.00	48
FORTPAN	INSTANT	60189500	F		01.35	32
	REF MANUAL	60174900	F	22	04.50	218
FORTPAN EXTENDED	INSTANT	60305900	A		01.35	40
	REF MANUAL	60329100	D	22	05.00	258
	DEBUG USERS GUIDE	60329400	B	22	02.00	106
TGS	240 SERIES REF MAN	17307300	F	22	02.50	122

1.Publication number of literature
2.The latest revision level
3.Indicates number of holes punched
in manual for use with hard cover
ringed binder.

4.Price per manual.
5. Manual page count.

TITLE			1	2	3	4	5
(INTERACTIVE	274	SERIES OG	17303100	A	22	01.50	72
GRAPHICS	274	SERIES GIM	44616700	A	22	01.00	46
SYSTEM)	274	SERIES USER GUIDE	44629300	E	22	03.50	182
	274	SERIES REF MAN	17303600	F	22	04.50	218
INTERCOM		REF MAN V3	60252800	C	22	03.50	184
JOVIAL		REF MANUAL	17302500	A	22	06.00	300
MARS VI		REF MAN (FULL INV)	17313000	A	22	05.00	262
PERT		GIM	60133300		22	01.00	16
PERT/TIME		REF MANUAL	60133600	D	22	01.50	76
SIFT		PROGRAM SYSTEM BULL.	60358400	A		01.00	26
SIMSCRIPT		GIM	60173500	A	22	01.00	24
		REF MAN V3	60358500	E	22	04.00	198
SIMULA		GIM	60251900	A	22	01.00	30
		REF MANUAL	60234800	F	22	05.00	242
SORT/MERGE		REF MANUAL	60252600	E	22	03.00	146
UPDATE		REF MANUAL	60342500	E	22	02.00	102
1700 MSOS		EXPORT/IMPORT	60305700	A	22	02.00	90
MISCELLANEOUS							
CYBER 70 COMPUTER SERIES NUCLEAR CODES MAN			20085400		3	01.20	73
CYBER 70 COMPUTER SYSTEM MODELS 72,73,74			60359800	C	22	02.00	88
6000/1700 COMPUTER SYSTEM 274 INTERACTIVE							
GRAPHICS SYSTEM OPERATORS GUIDE MODELS 72,							
73,74 VERSION 2/6000 V2, MSOS IMPORT HIGH							
SPEED OPERATORS GUIDE 1700 VERSION 1							
6000/CYBER 70 COMPUTER SYSTEMS INTERACTIVE			60359700	A	22	03.50	174
INTERCOM GUIDE FOR USERS OF FORTRAN EXT.							
COROL 35 REFERENCE MANUAL			17308300	A	22	05.50	270
COMMAND GENERAL INFORMATION 6000/CYBER 70			97400300	A	22	01.00	32
DATA HANDLER VERSION 1 REFERENCE MANUAL			17322100	A	22	01.50	63
GRAPHICALLY ORIENTED DESIGN AND ANALYSIS			17317200	C	22	04.00	204
SYSTEM (GODAS) V2 REFERENCE MANUAL							
GIM			17326600	A	22	01.00	40
INTERACTIVE GRAPHICS REF MANUAL V1			44616800	D	22	03.50	186
INTERACTIVE GRAPHICS 274 SYSTEM USERS GUIDE			44629300	D	22	03.50	182
INTERCOM INTERACTIVE PROCEDURE GUIDE			60385600	B		01.35	15
JOVIAL COMPILER REFERENCE MANUAL			17302500	A	22	06.40	328
KRONOS WORKSHOP REFERENCE MANUAL V2.1			97404700	B	22	13.65	810
MARS V1 PART-INVERSION REF MANUAL			17305100	A		03.00	156
MARS V1 PART-INVERSION USERS GUIDE			17308100	A	22	02.50	134
PLATO SUBSYSTEM AUTHORS GUIDE			97404900	01	22	01.50	56
OPERATING GUIDE			97405200	01	22	03.60	117
TUTOR REFERENCE MANUAL			97405100	01	22	04.50	204
USERS GUIDE			97404800	01	22	01.00	15
INSTALLATION HANDBOOK			97405000	01	22	01.00	22
SCOPE INTEGRATED SCHEDULER TUNING GUIDE PSR			60493500	A	22	01.50	66
(CYBER 71/6000 SERIES)							
SCOPE OPERATING SYSTEM SALES HANDBOOK V3.4.1			60425300		22	02.80	155
SCOPE 3.2/3.3 PERM FILE PRESEPVATION BULL.			60327000	A		01.00	26
SORT TIMING PROGRAM			60083700			01.00	19
TRAFFIC GENERAL INFORMATION MANUAL			97405500	B	22	01.50	120

1.Publication number of literature
2.The latest revision level
3.Indicates number of holes punched
in manual for use with hard cover
ringed binder.

4.Price per manual.
5. Manual page count.

TITLE	1	2	3	4	5
6000/CYBER 70 COMMAND BILL OF MATERIAL REFERENCE MANUAL	59159700	B	22	02.50	114
6000/CYBER 70 COMPUTER SYSTEM MULTI-ACCESS RETRIEVAL SYSTEM MARS VT FOR FULL INVERSION REFERENCE MANUAL VERSION 2.1	17313000	A	22	05.00	262
6000/CYBER 70 INTERCOM MULTI-USER JOB CAPABILITY PROGRAMMING SYSTEM BULLETIN FOR TIME-CRITICAL APPLICATIONS GIM	60358300	C	22	01.00	36
6000/CYBER 70 SERIES HIGH-PERFORMANCE SYSTEM	17309700	A	22	02.50	116
6000/CYBER 70 SERIES TIME-CRITICAL SIMULA- TION SYSTEMS GIM MODELS 72/73/74 V3-6000 V4	44629200	C	22	02.00	98
6000 INTERCOM MULTIUSER JOB CAPABILITY PSB VERSION 3	60327400	D	22	01.00	34
6000/240 SERIES INTERACTIVE GRAPHICS SYSTEM REFERENCE MANUAL	17307300	F	22	02.50	122
6000 KWIC APPLICATIONS DEV. BULLETIN	60137700			02.65	28
6000 MIMIC SIMULATION LANGUAGE REFERENCE	44610400	E	22	05.75	152
6000 SCOPE OPERATING SYSTEM TIME CRITICAL MODULE REF V2 (SCOPE 3.3 TO)	17304200	A	22	01.00	42
6000 SEISMIC DATA PROC. SYSTEM REF MANUAL	60342700		22	01.50	66
6000 SEISMIC DATA PROC. SYSTEM IHB	60343000	A	22	01.00	30
64/6500 ASSIST USERS GUIDE	60345100	03	22	02.50	132
64/65/6600 TTY RESPOND REF MAN	60199300	B	22	02.00	112
64/65/6600 TTY RESPOND INSTANT	60191500			01.35	28
7600					

* SCOPE V1.1 *					

SCOPE					
GIM	60280000	A	22	01.00	62
IHR	60282500	A	22	05.50	286
INSTANT	60343100	A		01.35	128
REF MANUAL	60281200	B	22	05.00	254
COMPASS REF MAN V2	60279900	D	22	06.75	354
GIM V2	60279600	A	22	01.00	40
OPU CARD V2	60279700	B		00.50	2
PPU CARD V2	60279800	B		00.50	2
INSTANT V2	60282900	B		01.35	96
FORTRAN EXT REF MANUAL	60329100	D	22	05.00	258
FORTRAN RUN REF MANUAL	60280400	A	22	03.50	172
GIM	60279500		22	01.00	36
MODIFY REF MANUAL	60281700	D	22	01.50	78
INSTANT	60283000	B		01.35	42
MOX REF MANUAL	60237400	A	22	01.00	56
SQM/MCM OPERATORS GUIDE/REF	60372900	A	22	01.50	72
UPDATE INSTANT	60360200	A		01.35	44
REF MANUAL	60342500	E	22	02.00	102

* SCOPE V1.1 STATIONS *					

7611-1 I/O STN OG/REF	60281600	A	22	02.50	134
7611-1 I/O STN INSTNT	60283100			01.35	38

1.Publication number of literature
2.The latest revision level
3.Indicates number of holes punched
in manual for use with hard cover
ringed binder.

4.Price per manual.
5. Manual page count.

TITLE		1	2	3	4	5
CYBER 70/MODEL 76 OR 7600						

* SCOPE V2.1 *						

SCOPE						
	REF MANUAL	60342600	H	22	06.40	322
	USERS GUIDE	60372600	C	22	07.15	366
	DIAGNOSTIC HNOBK	60344100	E	22	02.00	106
	GIM	60342200	B	22	11.00	36
	THR V2.0	60344000	C	22	07.90	424
	IHR V2.1	60426100	C	22	09.40	518
	INSTANT	60344300	B	6	01.35	108
ALGOL	REF MANUAL	60384700	C	22	05.00	246
APEX I	REF MANUAL	59158000	C	22	03.50	172
APEX II	REF MANUAL	59158100	B	22	06.40	318
	GIM	59157900	A	22	01.00	26
APEX III	REF MANUAL	76070000		22	03.50	244
APT IV	REF MANUAL	17313600	C	22	05.50	286
COROL	REF MAN V2	60384200	B	22	09.40	522
	GIM	60327800	A	22	01.00	52
	INSTANT	60328400	B		01.35	50
COMMON UTILITIES	REF MANUAL	60493300	A	3	01.00	32
COMPASS	REF MAN V2	60279900	D	22	16.75	354
	GIM V2	60279600	A	22	01.00	40
	CPU CARD V2	60279700	B		00.50	2
	PPU CARD V2	60279800	B		00.50	2
	INSTANT V2	60282900	B		01.35	96
	REF MAN V3	60360900	E	22	06.75	356
	GIM V3	60343400	A	22	01.00	52
	INST CARD	60361700	B		00.50	2
	INSTANT V3	60361000	B		01.35	104
FORTAN EXT	REF MAN V4.1	60305600	G	22	09.00	508
	GIM	60327900	A	22	01.00	46
	INSTANT	60357900	B		01.35	56
	DEBUG USERS GUIDE	60329400	B	22	02.00	106
	COMMON LIBRARY MANUAL	60387900	A	22	03.00	166
FORTAN RUN	REF MAN V2	60360700	C	22	04.00	210
LOADER	REF MANUAL	60344200	G	22	04.50	222
	INSTANT	60372200	B		01.35	22
ON-LINE MAINT.						
	REF MANUAL	60406200	D	22	01.50	70
RECORD MANAGER	REF MANUAL	60307300	G	22	05.00	254
SIMSRIPT 1.5	REF MAN V2	97400200		22	04.50	214
SAM	OPERATORS GUIDE V2	60361400	A	22	01.50	80
	OPERATORS GUIDE V2	60373800	C	22	02.00	94
SORT/MERGE	REF MANUAL	60343900	G	22	03.00	146
	GIM	60342400	A	22	01.00	18
	INSTANT	60344400	B		01.35	60
SYMBOL	REF MANUAL	60328800	C	22	03.00	156
UPDATE	REF MANUAL	60342500	E	22	02.00	102
	INSTANT	60360200	A		01.35	44

1.Publication number of literature
2.The latest revision level
3.Indicates number of holes punched
in manual for use with hard cover
ringed binder.

4.Price per manual.
5. Manual page count.

TITLE		1	2	3	4	5
* SCOPE V2 STATIONS *						
* AND SUBSYSTEMS *						

6000 STN 3.3	OG/REF MAN	60360400	A	22	03.50	164
6000 STN 3.4	OG/PEF MAN	60343800	D	22	02.50	122
	GTM	60342100	A	22	01.00	20
	INSTANT	60360500	A		01.35	64
7611-1 I/O STN	OG/REF MAN	60343600	C	22	03.00	156
	GTM	60343300	A	22	01.00	24
	INSTANT	60360100	A		01.35	41
7611-2 MAG TAPE	STATION					
	OG/REF MAN	60343700	B	22	01.50	76
	GTM	60342300		22	01.00	20
MAG TAPE SUBSYSTEM						
	REF MANUAL	60403900	C	22	02.50	114
MISCELLANEOUS						
6000/CYBER 70 COMMAND REFERENCE MANUAL		59159800	A	22	04.00	202
FORTPAN COMMON LIBRARY MATHEMATICAL ROUTINES		60387900	A	22		140
8090						
OSAS-A	REF MANUAL	60130900			01.00	52
OSAS-ASSEMBLY SYSTEM		60058200			01.00	46
SIMULTANEOUS PERIPH PROCESS REF		60059900			01.00	32
915 GRASP	OCR REF MANUAL V2.0	48996600			03.65	75
8092						
NIMP	IHR V2.1	87976700	A		06.05	54
	REF MANUAL V2.1	48706201	B	3	05.50	91
TAS	IHR V3.0	87976800	A	22	05.75	54
	REF MANUAL V3.1	48704601	C	3	04.50	33
UTILITY ROUTINE	REF MAN V1.0	48704901	A	3	03.55	56
915 GRASP	IHR V3.0	91661300	A		03.25	42
	REF MAN V2.0	48704800	F	3	02.25	32
915 H/S GRASP	PROGRAMMERS REF V1.0	48707800	B	3	05.00	70
915 KEYPUNCH	REF MAN V2.1	48707900	E	3	01.70	18
	SIMULATOR					
915 LIST PROC.	REF MAN V1.0	48706101	C	3	04.50	75
921 DRIVE	IHR VER 3.1	87976600	A		10.50	28
	REF MAN V3.1	48881400	D	3	05.25	36
921 MONITOR	REF MAN V1.0	91681100	A	22	03.45	46
	IHR	91649500	A		14.85	42

1. Publication number of literature
2. The latest revision level
3. Indicates number of holes punched in manual for use with hard cover ringed binder.

4. Price per manual.
5. Manual page count.

SECTION 4

TITLE	1	2	3	4	5
MISCELLANEOUS MANUALS					
A LIBRARY OF NUCLEAR CODES	60139500			01.25	
A STUDY OF METHODS OF ERROR DETECTION DURING TRANSMISSION OF BINARY INFORMATION	60426500	A	22	01.65	
AIDS - AUTOMATED INTEGRATED DESIGN SYSTEM GENERAL INFORMATION MANUAL	60427900			06.20	
AIDS - GENERAL PURPOSE WIRE WRAP USERS GUIDE	60443100	A	22	06.85	
AIDS - SEMIAUTOMATIC ARTWORK GENERATION USERS GUIDE	60441000	A	22	03.50	
ALPHA REFERENCE MANUAL	14142900	A	22	01.80	
ALPHA 1 COMPUTER SYSTEM - CPU DIAGRAMS MANUAL VOL. 1	14143700	A	34	35.00	
ALPHA 1 COMPUTER SYSTEM GROUND SUPPORT EQUIP. DIAGRAMS MAN. VOL. 2	14143800	A	34	26.20	
ALPHA-1 MIMIC SOFTWARE MANUAL	14155000			01.20	
ALPHA-1 SOFTWARE REFERENCE MAN-ALPHA COMPASS	14123800	A		08.50	
A METHOD OF GENERATING UNIFORM RANDOM NUMBERS (AN APP. REPORT BY W.J.WESTLAKE)	60161200			01.25	
CARE AND HANDLING OF MAGNETIC TAPE	40812300			01.00	
CD CARRIER TRUCKING - ORIENTED TRANSPORTATION APPLICATIONS SOFTWARE GENERAL INFO	97401600	A	22	01.40	
CE ILLUSTRATED TOOL CATALOG	40860000	C	22		
COMMAND SYSTEMS INFORMATION MANUAL	97401500			06.15	
COMMUNICATIONS HANDBOOK	60405100	A	22	01.70	
COMMUNICATIONS SYSTEMS DIVISION TERMINAL UNIT AND DATA SET CE TECH INFO MANUAL	41605200	B	22	03.10	
COMPUTER AIDED MAINTENANCE SCHEDULER (CAMS VERSION 2)					
CE MANUAL	60373500	C	22	02.00	
CORPORATE PHOTOGRAPHY CATALOG	20114600		22		
CYBER 1000 DATA COMMUNICATIONS SYSTEM MANUAL	00007500	A		01.95	
CYBER 1000 DCS GENERAL PROPOSAL TO AIRLINE INDUSTRY	73443000	A		02.35	
CYBER 1000 DCS GENERAL PROPOSAL TO BANKING INDUSTRY	73443100	A		02.10	
CYBER 1000 DCS GENERAL PROPOSAL TO MANUFACTURING	73933300	A		02.35	
CYBERDATA KEY-TO-DISK					
OPERATORS INSTANT	22261900	A		08.40	
SUPERVISORS INSTANT	22262100	A		11.14	
REFERENCE MANUAL	22262200				
970-8 REFERENCE MANUAL	22267300	A	3	01.20	
970-8 CE MANUAL	22264500	A	3	04.40	
970-32 REFERENCE MANUAL	22267200	A	3	02.10	
970-32 CE MANUAL	22264600	A	3	03.00	
970-480 CE MANUAL	22264700	A	3	04.30	
970-480 REFERENCE MANUAL	22267100				
INSTALLATION KIT	22263600				

1.Publication number of literature
2.The latest revision level
3.Indicates number of holes punched in manual for use with hard cover ringed binder.

4.Price per manual.
5. Manual page count.

TITLE	1	2	3	4	5
DIAGNOSTIC CONFIGURATOR/CATALOG	00015000		3		
DIAGNOSTIC CONFIGURATOR CATALOG	60408100	B	22	01.80	
DISK STORAGE UNIT MAINTENANCE AIDS MANUAL	70616800	M	22	07.45	
DISK STORAGE UNIT 84-X,975-X MAINT AIDS CE	70619100	J	22	19.45	
DISK STORAGE UNIT 84X,975X-ENHANCED	70629100	G	22	12.70	
LOGIC CARDS CE MANUAL					
DTL INTEBRID LOGIC GENERAL INFO MANUAL	84785000		3	04.50	
ENGINEERING LOG BOOK	60272100			05.85	
EXTENDED COPE STORAGE DATA PATH AND STOCK	59304600				
SELECT MAINTENANCE AID CHART					
FORMS DESIGN MANUAL	00000200			02.40	
FIELD BULLETIN, POWER RECEPTACLE INSTALL	40816200		22	02.00	
HARDWARE DEVELOPMENT GUIDELINES INFORMATION	60429200	A	3	03.00	
HOW TO HANDPRINT FOR CONTROL DATA OCR READER	48299727			02.25	
KEY TO LOGIC SYMBOLS G.I.M.	88981500	B	22	05.40	
KEY TO LOGIC SYMBOLS - SYSTEM 17	89723700	-	22	04.90	
KEY TO LOGIC SYMBOLS - TTL	60406000	A	22	01.80	
MAGNETIC TAPE TRANSPORT SINGLE CAPSTON HIGH	49751600	A	22	01.75	
PERFORMANCE OPERATORS MANUAL					
MANAGEMENT GUIDE TO EFFECTIVE SELECTION	60426700			01.35	
PROCFSS					
MATH SCIENCE LIBRARY GENERAL INFORMATION MAN	60328900	A		01.00	
MERCHANT USERS MANUAL	13797500			02.15	
MILITARY DISK STORAGE UNIT DESC., THEO OF	14237500		22	20.40	
OPER., DIAGRAMS AND WIRE LIST CE MANUAL					
PARTS SUPPORT FOR THE OEM CUSTOMER	15002900			00.80	
PLANIT AUTHORS GUIDE	59159400		3	08.30	
PLANIT LANGUAGE REFERENCE MANUAL	97401700			13.30	
POSTAL SOURCE DATA COLLECTION SYSTEM	36829400	C	22	02.55	
INSTALLATION MANUAL					
POSTAL SOURCE DATA COLLECTION SYSTEM	13795600	A	22	01.80	
DATA COLLECTION SITE REFERENCE MANUAL					
POSTAL SOURCE DATA COLLECTION SYSTEM	13795700	A	22	01.00	
TELECONCENTRATOR SITE REFERENCE MANUAL					
POSTAL SOURCE DATA COLLECTION SYSTEM	13795500	A	22	02.00	
DATA PROCESSING CENTER SITE REF MANUAL					
POSTAL SOURCE DATA SYSTEM REF MANUAL	13795400	C	22	01.00	
PRODUCT TO EQUIPMENT CROSS REFERENCE MANUAL	60071500	R	3	05.70	
PROFITS REFERENCE MANUAL	59158200	B	22	16.25	
PROFITS OPERATORS GUIDE 3000 PROFITS CRT	59158300	A	22	02.70	
PROFITS AN ON-LINE REAL-TIME ENG/MANUF. SYS	59156000			03.90	
PROGRAM MANAGEMENT HANDBOOK	60408300			20.90	
PROGRAMMING REFERENCE AIDS (CONTAINS	60158600			04.00	
CONVERSION TABLES, CONSTANTS, POWERS AND					
HEXADECIMAL INFORMATION)					
REVOLUTION IN PROGRAMMING	60417000			02.80	
SCOPE 3.1.5	00006300		3	04.85	
SOFTWARE DEVELOPMENT GUIDELINES	60418500			02.60	
QUALITY ASSURANCE MANUAL	60348600			14.55	
SEISMIC DATA PROCESSING SYSTEM REF. MANUAL	44623700	B	22	11.80	
TIME SLOTTED REQUIREMENTS APPLICATION REPORT	97403600			01.60	
TYPIING FOR CONTROL DATA OCR PAGE READERS	48299700			04.05	

1.Publication number of literature
2.The latest revision level
3.Indicates number of holes punched
in manual for use with hard cover
ringed binder.

4.Price per manual.
5. Manual page count.

TITLE	1	2	3	4	5
EDUCATIONAL MANUALS					
AN INTRODUCTION TO BASIC COMPUTER CONCEPTS	44016000			03.70	
AN INTRODUCTION TO INTEGRATED CIRCUITS	60202000			02.55	
BIOLOGY-PHYSIOLOGY APPLIED TO DIGITAL COMPUTERS	22006700			01.25	
FORTRAN AUTOTESTER JOHN WILEY AND SONS, INC., NEW YORK)	60018600			04.75	
FORTRAN TRAINER STUDENT WORKBOOK (BY BRUCE THOMPSON)	44020500			05.15	
FORTRAN TRAINER PART 1 TEACHERS EDITION BY THOMPSON)	44020300			05.85	
FUNCTIONS, FUNCTION MACHINES AND COMPUTERS BY ROBERT L. ALBRECHT	44016800			01.50	
FUNDAMENTAL COMPUTER CONCEPTS BY DR. ROBERT E. SMITH	22008200			02.00	
INTRODUCTION TO DATA COMMUNICATIONS (BASIC SYSTEMS AND HARDWARE)	13798900	C	22	05.95	
MATHEMATICS OF CHEMISTRY AS APPLIED TO DIGITAL COMPUTERS	22006500			01.60	
SECONDARY LEVEL PHYSICS AS APPLIED TO DIGITAL COMPUTERS	22006600			01.25	
STATISTICS APPLIED TO DIGITAL COMPUTERS	22006900			01.00	
TRAINING MANUALS					
160-A TRAINING WORKBOOK (FORMERLY 082666)	60273400			07.50	
160-A FORTRAN TRAINING MANUAL	60165000			04.50	
360 ASSEMBLY LANGUAGE TRAINING MANUAL	60354600	B	3	03.70	
546 SUPPLEMENTAL MANUAL (FORMERLY A-095102)	60238400			01.40	
915 PAGE READER-A PROGRAMMED TEXT VOL. I (FORMERLY 020568)	60241000	A		01.00	
1500 SERIES SYSTEM CODES	76360010			01.90	
1604 TYPE CARDS	60314100			00.75	
1604 PRINTED CIRCUITS (FORMERLY 010367)	60240600			01.40	
1700 COMPUTER MAINTENANCE TRAINING MANUAL, VOL I, 2ND EDITION	60169500	B		03.40	
1700 COMPUTER MAINTENANCE TRAINING MANUAL, VOL II, 2ND EDITION	60169600	A		05.85	
1700 COMPUTER MAINTENANCE TRAINING MANUAL, VOL III	60184900			01.75	
1700 PRINTED CIRCUITS MANUAL	083066A0			12.00	
1700 PROGRAMMING TRAINING MANUAL	60207900	B		07.85	
1728 CARD READER/PUNCH TRAINING MANUAL (FIRST EDITION)	60241400			01.55	
1738 DISK CONTROLLER TRAINING MANUAL (FORMERLY 010268A)	60257900			02.55	
2013 BADGE READER ADAPTER TRAINING MANUAL, TEST EDITION (FORMERLY 041467)	60240400			01.00	
3L00 HARDWARE STUDENT MANUAL	60380500		3	11.85	
3000 PRINTED CIRCUITS (FORMERLY 092166)	60238500			02.25	
3000 TYPE CARDS	60314200			01.00	
3L00 SOFTWARE STUDENT MANUAL	60380400	A	3	01.80	

1. Publication number of literature
2. The latest revision level
3. Indicates number of holes punched
in manual for use with hard cover
ringed binder.

4. Price per manual.
5. Manual page count.

TITLE	1	2	3	4	5
31/32/33/3500 COMPUTER SYSTEM COBOL TRAINING	60314900	C		05.15	
31/32/33/3500 FORTRAN TRAINING MANUAL	60199700	A		06.75	
3100/3200 TRAINING HANDOUTS (FORMERLY 042767)	60258100			03.90	
3100/3200/3300/3500 COMPASS PROGRAMMING TRAINING MANUAL VOLS 1 AND 2	60311500	A		05.40	
3200 TRAINING MANUAL, VOL I, 2ND EDITION, (FORMERLY 020968)	60257700			03.60	
3200 TRAINING MANUAL VOL 2, 2ND EDITION (FORMERLY 021068)	60257800			07.35	
3200/3300 DIFFERENCE COURSE WORKBOOK	01306700			02.20	
3203/3209 STORAGE MODULE TRAINING MANUAL	60143400		22	03.50	
3229 MAG TAPE CONTROLLER TRAINING MANUAL, FIRST EDITION (FORMERLY 021268)	60239200	A		03.00	
3234-A MASS STORAGE CONTROLLER TRAINING SUPPLEMENT	60249400			01.05	
3300 COMPUTER TRAINING MANUAL VOL 1	60158700	A		02.70	
3300 TRAINING MANUAL, VOL II, 2ND EDITION	60158800			07.50	
3312 BUSINESS DATA PROCESSING TRAINING MAN., VOL I, 2ND EDITION (FORMERLY 091566B)	60249900			02.65	
3312 BDP TRAINING MANUAL VOL II, 2ND EDITION (FORMERLY 020568)	60250000			13.40	
3400/3600/3800 COMPASS TRAINING MANUAL, VOLS I, II, III	60166700	B		15.65	
3447-A CARD READER CONTROLLER TRAINING MAN.	60273500			03.40	
3500 BLOCK CONTROL HANDBOOK	60274300			01.05	
3600 COMPUTER MAINTENANCE WORKBOOK	04266700			10.50	
3600/3800 DIFFERENCE TRAINING MANUAL (FORMERLY 032467)	60273600			04.35	
60000 ASCENT/COMPASS PROGRAMMING TRAINING	60183400			04.90	
6000/CYBER 74 COMPUTER MAINTENANCE CHAPTS AND DIAGRAMS FOR TRAINING PURPOSES	60378600		34	08.55	
6000 INTRO. AND PERIPHERAL PROCESSOR TRNG. MANUAL (FORMERLY 020267)	60250400			02.00	
6000 SERIES ASPER/COMPASS PROGRAMMING	60183300			03.65	
6400 CENTRAL PROCESSOR TRAINING MANUAL (FORMERLY 011167)	60257200			04.15	
6600 CENTRAL PROCESSOR TRAINING MANUAL VOL 1 CONTROL AND MEMORY (FORMERLY 020167)	60241300			08.65	
6600 CENTRAL PROCESSOR, VOL II, FUNCTIONAL UNITS (FORMERLY 091466)	60239700			05.80	
6600 COMPUTER WORKBOOK AND TIMING DIAGRAMS (FORMERLY 042167)	60258000			03.80	
6600 STANDARD PERIPHERAL TRAINING MANUAL, TEST EDITION (FORMERLY 092967)	60239500			01.00	
6638 DISK FILE SUBSYSTEM TRAINING SUPPLEMENT	60250800	A		02.10	
6639 DISK CONTROLLER TRAINING MANUAL (FORMERLY 092867)	60273300			01.05	
8092 TELEPROGRAMMER TRAINING MANUAL	60183900			03.50	
ACTIVE ELECTRONICS STUDENT MANUAL (750 HR)	76360015	A	3	06.10	
ACTIVE NETWORKS EXPERIMENTS, REVISED (APL.) (FORMERLY A-012268)	60250500	C	3	01.80	
ACTIVE NETWORKS WORKBOOK, VOL. I	60274100			05.70	

1. Publication number of literature
2. The latest revision level
3. Indicates number of holes punched
in manual for use with hard cover
ringed binder.

4. Price per manual.
5. Manual page count.

TITLE	1	2	3	4	5
(FORMERLY 082866A)					
ACTIVE NETWORKS WORKBOOK, VOL. II	082966A0			03.00	
ACTIVE NETWORKS WORKBOOK, VOL I (REVISED)	60250600			04.45	
(FORMERLY A-012368)					
ACTIVE NETWORKS WORKBOOK, VOL II (REVISED)	60250700			04.80	
(ARL) (FORMERLY A-012468)					
AN INTRODUCTION TO DIGITAL COMPUTERS, VOL 1	60241600			05.80	
(FORMERLY 081866A)					
AN INTRODUCTION TO DIGITAL COMPUTERS,VOL II	60241700			07.15	
(FORMERLY 091266A)					
AN INTRODUCTION TO DIGITAL COMPUTERS,VOL III	60241800			03.40	
(FORMERLY 032367)					
ASSEMBLY LANGUAGE TRAINING MANUAL	60354700		3	06.70	
ASSEMBLY LANGUAGE STUDENT MANUAL	60315100		3	02.75	
ASSEMBLY LANGUAGE TRAINING SUPPLEMENT	60355500			01.80	
BUSINESS APPLICATIONS STUDENT MANUAL	60315200	A		01.00	
BUSINESS CONCEPTS STUDENT MANUAL	60378900		3	02.75	
BUSINESS MATH AND ACCOUNTING STUDENT MANUAL	60355800		3	01.00	
CARD EQUIPMENT STUDENT MANUAL	60313100			01.00	
CDI CAREER EDUCATION STUDENT HANDBOOK (1975)	76360031			01.15	
CENTRAL PROCESSOR SOFTWARE STUDENT MANUAL	60353700			02.05	
CENTRAL PROCESSOR HARDWARE STUDENT MANUAL	60379200	A	3	12.00	
VOL. I-II					
COMMUNICATIONS AND CUSTOMER RELATIONS	60378100		3	01.00	
STUDENT MANUAL					
COMPASS STUDENT MANUAL BOOK I	60313600		3	01.00	
COMPASS STUDENT MANUAL PART II	60314300		3	01.00	
COMPUTER IN CREDIT STUDENT MANUAL	60378400		3	01.00	
COMPUTER SYSTEMS OPERATIONS STUDENT MANUAL	76360011		3	05.20	
COMPUTER TECHNOLOGY HARDWARE WORKBOOK	60241200	A		02.70	
COMPUTER TECHNOLOGY STUDENT MANUAL	60314800	A	3	01.00	
COMPUTER TECHNOLOGY SOFTWARE TRAINING SUPP.	60239600			01.00	
CONTROL DATA INSTITUTE PRODUCT CATALOG	60379000		3	04.05	
CREDIT PRINCIPLES AND PRACTICES I STUDENT	60378200		3	01.00	
MANUAL					
CREDIT PRINCIPLES AND PRACTICES II STUDENT	60378300		3	01.00	
MANUAL					
CYBER 72/73/74 SCOPE SYSTEM MAINTENANCE	76360012		3	05.35	
STUDENT MANUAL					
DATA PROCESSING CONCEPTS STUDENT MANUAL	60353100			01.20	
DATA TERMINALS AND COMMUNICATIONS SYSTEMS	76360023		3	10.10	
DIAGNOSTIC ROUTINES WORKBOOK (FORMERLY	60238700			01.45	
042467)					
DIGITAL COMPUTER OPERATOR	60312700			01.50	
DIGITAL ELECTRONICS STUDENT MANUAL	60353500	C	3	04.10	
DISK DRIVE STUDENT MANUAL	76360002		3	04.35	
ELECTRONICS REVIEW STUDENT MANUAL	60380100		3	02.15	
GLOSSARY FOR INFORMATION PROCESSING	60240700		3	01.60	
(FORMERLY 070367)					
HANDOUTS FOR POSTOFFICE COURSE	07046700			01.95	
INTEGRATED CIRCUITS STUDENT MANUAL	60380000		3	01.30	
INTRO TO DATA PROCESSING (DCO) STUDENT MAN	60354900			02.55	
INTRODUCTION TO CREDIT STUDENT MANUAL	60355700		3	01.00	

1.Publication number of literature
2.The latest revision level
3.Indicates number of holes punched
in manual for use with hard cover
ringed binder.

4.Price per manual.
5. Manual page count.

TITLE	1	2	3	4	5
LINE PRINTER EQUIP. TRAINING MAN 2ND EDITION (FORMERLY 082166)	60257100	C		07.15	
LOGIC CIRCUIT EXPERIMENTS	60238800	A		02.00	
MAGNETIC RECORDING EQUIP.TAPE STUDENT MANUAL	60314400	A		01.00	
MAGNETIC RECORDING EQUIP. DISK STUDENT MAN	60354300	C	3	03.30	
MAGNETIC TAPE-ITS PRINCIPLES AND CERTIF. (FORMERLY 62466)	60256700			01.30	
MAGNETIC TAPE STORAGE TRAINING MANUAL (FORMERLY 081766B)	60239400	C		03.50	
MODEL 33 TELETYPEWRITER TRAINING MANUAL (FORMERLY 060167)	60273900			03.35	
MSOS PROGRAMMING TRAINING MANUAL	60257600			02.20	
OPTICAL CHARACTER RECOGNITION STUDENT MANUAL	60355400		3	01.00	
PASSIVE ELECTRONICS STUDENT MANUAL	60354500	G	3	06.70	
PASSIVE NETWORKS EXPERIMENTS (REVISED ED) (FORMERLY A-010468)	60250200		22	01.15	
PASSIVE NETWORKS WORKBOOK, REVISED, (ARL.) (FORMERLY A-010358 AND 090166B)	60250100			04.60	
PASSIVE NETWORKS WORKBOOK TRAINING SUPP.	60250300			04.05	
PHASE I PROGRAMMING TECHNOLOGY WORKBOOK	04036700			08.70	
PHASE II PROGRAMMING TECHNOLOGY WORKBOOK	04256700			05.60	
PROGRAMMING CONCEPTS WORKBOOK	60274400		3	07.50	
PUNCHED CARD EQUIPMENT STUDENT MANUAL	76360001	C	3	01.10	
PUNCHED CARD EQUIPMENT TRAINING MANUAL	60378700	R	3	05.85	
REPORT PROGRAM GENERATOR STUDENT MANUAL	60379100		3	01.35	
SELECTRIC MAINTENANCE ADMINISTRATION GUIDE	60380200		3	02.50	
SELECTRIC MAINTENANCE STUDENT GUIDE	60380300		3	01.70	
SELECTRIC TYPEWRITER TRAINING MANUAL, SECOND EDITION (FORMERLY 080566B)	60238300			02.40	
SMM3L MONITOR COMMAND AND MEMORY TEST LISTINGS (FORMERLY 030767)	60273800			01.35	
SYSTEM/360 COMPUTER OPERATION (DCO) STUDENT	60355200			01.35	
SYSTEM/360 ASSEMBLY LANGUAGE STUDENT MANUAL	60353000	B	3	07.20	
SYSTEM/360 INSTRUCTIONS	60379300			00.75	
SYSTEMS CONCEPTS STUDENT MANUAL	60353300			01.00	
SYSTEMS DESIGN STUDENT MANUAL	60379500		3	01.25	
UNIT RECORD EQUIPMENT (DCO) STUDENT MANUAL	60355100			04.35	
UTILITIES PROGRAMMING STUDENT MANUAL	60353200			01.00	
UTILITIES STUDENT MANUAL	60313500	A	3	01.00	
VISUAL DISPLAY TRAINING MANUAL	60355300		3	01.20	
VISUAL DISPLAYS / SYSTEMS MAINTENANCE STUDENT MANUAL	76360003		3	01.30	
VISUAL RECORDING EQUIP. STUDENT MANUAL	60313400	A		01.15	
WORK SIMULATION STUDENT MANUAL	60378500		3	01.00	
TECHNICAL REPORTS					
TER01- SOLVING DESIGN PROBLEMS IN GRAPHICAL DIALOGUE	00000021			04.95	
TER02- A GENERALIZED LANGUAGE FOR INFORMAT STORAGE AND RETRIEVAL APPLICATIONS	60175600			01.25	
TER03- USE OF INFOL FOR DOCUMENT AND RETRIEVAL APPLICATIONS	60175700			01.60	

1.Publication number of literature
2.The latest revision level
3.Indicates number of holes punched
in manual for use with hard cover
ringed binder.

4.Price per manual.
5. Manual page count.

TITLE	1	2	3	4	5
TER04- DISPLAY CODED CHARACTER ARITHMETIC ON THE 6000 SERIES	60190500			01.50	
TER05-THE GPL LANGUAGE	60192400			04.00	
TER07- CONVERSATIONAL APT	60222400			07.65	
TER08-COMPUTER SIMULATION-AN INTRODUCTION	60228300			01.70	
TER09- COMPUTERS AND PUBLIC CONCERN	60229700		3	02.90	
TER10-APT/EXPEDITE A CONVERSATIONAL APT SYS FOR THE 6000 COMPUTER WITH 210/211/212 DISPLAY STATION	60234400		3	04.65	
TER-12 PROGRAMMING TECHNICAL REPORT	60235300			01.30	
TER11- THE CHART2 FLOWCHARTING PROGRAM	60234700		3	01.85	
TER14 FUNDAMENTALS OF BASIC TIME SHARING	60252300			01.00	
TER-15 - SIMPL-A SIMULATION PROGRAMMING LANGUAGE. AUTHOR M. MACDOUGALL	60252400			02.00	
TER-16 - PACKED DATA IN FORTRAN EXTENDED UNDER 6000 SCOPE 3.AUTHOR JOHN O. NEUHAUS	60252500			01.45	
TER-17 PROGRAMMING TECHNICAL REPORT	60305800			02.00	
MATHEMATICAL APPROXIMATIONS (TR52)	60070900			08.00	
MATRIX ALGEBRA,GAMMA FUNCTION,ERROR FUNCTION BESSEL FUNCTIONS(TR53)	60071000			02.50	
BINARY ERROR DETECTION BY GENERALIZED PARITY CHECKING (TR54)	60071100		22	02.75	
ARITHMETIC ERRORS AND SINE APPROXIMATIONS (TR56)	60071300			02.20	
LOGIC FOR COMPUTER DESIGNERS AND PROGRAMMERS PART 1 INTRODUCTION TO MATHEMATICAL LOGIC (TR57)	60071400			04.30	
CELLS-BASIC STRUCTURAL UNITS OF DESIGN (TR51	60070800			02.00	
VIDEO LECTURE MANUALS					
VIDEO LECTURE (7600 FEATURES)	00006100			01.80	
VIDEO LECTURE SCOPE 3.1.6 TCS	00006000			05.35	
SCM PUBLICATIONS					
T-330 PROGRAMMING OPER MODE DIAGS,ALIGN PROC POWER SUPPLY SERVICE/INSTR MANUAL	60244400	A	22	10.75	
S-550 SERVICE MANUAL	60242900			04.05	
2816 POINT TO POINT PROGRAMMING MANUAL	60244200	A	22	03.00	
2816 POWER SUPPLY INSTRUCTION MANUAL	60242500	A	22	01.50	
2816 SERVICE MANUAL (ADDENDUM D)	60243000	A	22	05.00	
2816/7816 VERTIPUNCH INSTRUCTION MANUAL	60244600	A	22	04.60	
6615 SERVICE MANUAL	60242000	A	22	17.20	
6615-02 POWER SUPPLY MANUAL	60244300	A	22	02.00	
7816 POINT TO POINT PROGRAMMING MANUAL	60244100	A	22	02.10	
CONTROL UNIT INSTRUCTION MANUAL	60242300	A	22	05.95	
CONTROL UNIT PARTS MANUAL	60243600	B	22	05.20	
CONTROL UNIT SERVICE MANUAL	60243100	A	22	08.40	
CPI SERVICE AND INSTRUCTION MANUAL	60242800			05.00	
DATA PROCESSING PROGRAMMING COURSE	60238700		3	12.25	
T/O TO PUNCH TRANSLATOR SERVICE MANUAL	60243300			05.35	

1.Publication number of literature
2.The latest revision level
3.Indicates number of holes punched in manual for use with hard cover ringed binder.

4.Price per manual.
5. Manual page count.

TITLE	1	2	3	4	5
I/O UNIT PARTS MANUAL	60243400			03.60	
INPUT/OUTPUT INSTRUCTION MANUAL	60242100	A	22	03.60	
PROCESSOR INSTRUCTION MANUAL	60242400	A	22	10.00	
PROCESSOR POWER SUPPLY INSTRUCTION MANUAL	60242600	A	22	01.05	
PROCESSOR SERVICE MANUAL	60241900	A	22	06.50	
READER PARTS MANUAL	60243500	A	22	02.50	
TCR-30 PARTS MANUAL	60243800		22	02.65	
TCR-30 SERVICE AND INSTRUCTION MANUAL	60242700	A	22	08.30	
TOOL LIST	60244000	A	22	01.20	
TYPETRONIC 330 PARTS INFORMATION CE MANUAL	60244900	A	22	02.10	
TYPETRONIC 2816/7816 AUX. FEATURE CONTROL UNIT, PARTS INFORMATION CE MANUAL	60286400	A	22	01.50	
TYPETRONIC 2816/7816 MODEL 02 READER INSTRUCTION MANUAL	60242200	A	22	02.10	
TYPETRONIC 7816 PROCESSOR PARTS CE MANUAL	60244800	A	22	05.20	
TYPETRONIC VERTIPUNCH PARTS MANUAL	60240300		22	02.65	
VERTIPUNCH SERVICE MANUAL	60244500	C		02.50	
SCM (OEM) MANUALS					
024-026 INSTRUCTION MANUAL - IBM	60245300			03.60	
024-026 MAINTENANCE MANUAL - IBM	60245400			04.05	
024-026 PARTS MANUAL - IBM	60245500			03.60	
024-026 REFERENCE MANUAL - IBM	60245200			01.00	
CS100 PARTS CATALOG - BULL CE	60245100			03.00	
HARD COVER BINDERS AND TEMPLATES					
34-RING FOR 11 X 17 DIAGRAM MANUALS					
3/4 IN BINDER	60086900			02.85	
1 1/4 IN BINDER	60087000			04.05	
22-RING FOR 8 1/2 X 11 MANUALS					
3/4 IN BINDER - DARK BLUE W/CDC LOGO	60087200			01.85	
1 1/4 IN BINDER-DARK BLUE W/CDC LOGO	60087400			02.00	
3-RING FOR 8 1/2 X 11 MANUALS					
3/4 IN BINDER-DARK BLUE W/CDC LOGO	60086000			01.50	
1 1/2 IN BINDER - DARK BLUE W/CDC LOGO	60086100			02.30	
2 IN BINDER - DARK BLUE W/CDC LOGO	60087500			02.50	
CYBER 70 1 1/2 3 RING - BUTTERSCOTCH CDC	60088800			02.30	
1700 SERIES 1 1/4 3 RING- BROWN W/CDC LOGO	60088600			03.00	
3000 SERIES 1 1/4 3 RING- ORANGE W/CDC LOGO	60087600			03.00	
6000 SERIES 1 1/4 3 RING LIGHT BLUE W/CDC LOGO	60088500			03.00	
CYBERNET SERVICES-LIGHT BLUE 1 INCH 3 RING	60089100		3	04.00	
CYBERNET SERVICES-LIGHT BLUE 1 1/2 IN 3 RING	60089200		3		
CYBERNET SERVICES LIGHT BLUE 2 INCH 3 RING	60089300		3		
7000 SERIES 1 1/2 3 RING- BROWN W/CDC LOGO	60297200			02.10	

1.Publication number of literature
2.The latest revision level
3.Indicates number of holes punched in manual for use with hard cover ringed binder.

4.Price per manual.
5. Manual page count.

TITLE	1	2	3	4	5
6-RING 3/4 INCH CODE BOOK BINDER-YELLOW	60088700		6	01.70	
PROGRAMMING REPORT SUMMARY BINDER RUST PRESSBOARD 9 X 5 3/4 (METAL FASTENER)	00004600			00.50	
TEMPLATES					
FORM DESIGN AID (915 PAGE READER)	48402800			04.35	
LOGIC TEMPLATE	60085100			03.20	
LOGIC SYMBOLOGY TEMPLATE	62181600			09.25	
LOGIC DRAWING TEMPLATE	82269600			06.60	
PROGRAMMING TEMPLATE	10124300			01.50	
6600 LOGIC TEMPLATE	60113200			03.60	
MOTOR GENERATOR SETS					
GE MANUAL DFS, INSTL, OPR, MAINT AND REF DWGS (ELECTRIC MACH FREQ CONV-SETS PRIOR TO SER 65-1582 EXCEPT SER 65-1557)	60156900	C	22	05.10	
GE MAN-DESC, INSTL, OPR, MAINT AND REF DWGS (ELECTRIC MACHINE FREQ CONV-SER 65-1557, 65-1582 AND ABOVE)	60166800	B	22	09.85	
GE DIAGRAMS MANUAL	60423100	A	22	16.05	
KATO MOTOR GENERATOR SETS (SERIALS 55972 AND ABOVE)					
GEN DESC, OPERATION, INSTALLATION/CHECKOUT, THEORY OF OPERATION, MAINT, PARTS GE MAN. DIAGRAMS MANUAL	60420800	A	22	08.30	
	60419900	A	22	10.20	
REFRIGERATION MANUALS					
TRANE RECIPROCATING REFRIGERATION MANUAL	60240200			09.00	
REFRIGERATION THEORY MAINTENANCE MANUAL	60268100	H	22	06.60	
REFRIGERATION UNITS CORDWOOD MODULES PARTS LIST	60227400	B	22	01.50	
** SEE ALSO GH214-A, GH216-A, GH218-A **					
POWER SUPPLY MANUALS					
AULT POWER SUPPLIES FOR CDC SYSTEMS	60107300	D	22	11.00	
CONTROL DATA POWER SUPPLIES APPLICABLE TO ACTIVE 6000/CYBER SERIES COMPUTING EQUIP. DIAGRAMS, THEORY OF OPERATION, MAINTENANCE AND PARTS DATA GE MANUAL	60427200	A	22	01.50	
CONTROL DATA POWER SUPPLIES APPLICABLE TO ACTIVE 3000 SERIES COMPUTING EQUIPMENT DIAGRAMS, THEORY OF OPERATION, MAINTENANCE AND PARTS DATA GE MANUAL	60427300	A	22	03.35	
CONTROL DATA POWER SUPPLIES APPLICABLE TO INACTIVE COMPUTING EQUIPMENT DIAGRAMS, THEORY OF OPERATION, MAINTENANCE AND PARTS DATA GE MANUAL	60427400	A	22	16.05	

1.Publication number of literature
2.The latest revision level
3.Indicates number of holes punched
in manual for use with hard cover
ringed binder.

4.Price per manual.
5. Manual page count.

TITLE	1	2	3	4	5
DISK FILE HYDRAULIC	40869500	C	22	03.80	
DISK FILE HYDRAULIC POWER SUPPLY GH202-B06 CE MANUAL	41245600	D	22	02.35	
DISK FILE HYDRAULIC POWER SUPPLY CE MANUAL	70615700	B	22	04.30	
PRINTED CIRCUIT MANUALS					
1604 DISK FILE LOGIC MANUAL	40829700	G	22	17.70	
1604 SERIES LOGIC MODULES (TAPE TRANSPORT) OEM CE MANUAL	40827900	E	22	05.90	
CORDWOOD MANUAL VOLUMES 1,2,3	60042700	AY	22	10.00	
DISK STORAGE DRIVE (OEM) 1604 SERIES LOGIC MODULE CE MANUAL	40826700	J	22	07.15	
PRINTED CIRCUIT CARD MODIFICATION PROCEDURES (DRIFT TO MESA)	60041600	A	3	01.25	
VOLS. 1,2 AND 3 (1604 AND 3600 TYPES)	60042900	U	22	13.10	
INTERFID CIRCUITS MANUAL	60201000	A	22	03.15	
SITE PREPARATION MANUALS					
SECTION 1 - GENERAL INFORMATION					
LARGE AND MEDIUM SCALE COMPUTER SYSTEMS INCLUDES INFO FOR 3000, 6000 AND 7000 SYSTEMS	60275100	C	22	01.40	
SMALL SCALE COMPUTER SYSTEMS - INCLUDES INFO FOR 160, 160-A, 1700, SC17 (1770), AND 8090 SYSTEMS	60275200	R	22	03.35	
MINI COMPUTER SYSTEMS	60437000	A	22	02.60	
SECTION 2 SITE PREPARATION AND INSTALLATION INFORMATION (SYSTEM DATA)					
CYBER 70 - MODELS 72/73/74 COMP. SYSTEMS AND CYBER 70 - MODEL 7030 SYSTEMS DATA	60277700	A	22	07.00	
CYBER 70 - MODEL 76 SYSTEMS DATA	60277600	C	22	02.55	
CYBER 170 - MODELS 172/173/174 SYSTEMS DATA	19981400	A	22	04.80	
CYBER 170 - MODEL 175 SYSTEMS DATA	60420100	A	22	03.80	
CYBER 1000 MODELS IMX, PMX, CMX SYS DATA	60418200	A	22	01.40	
MINI COMPUTER SYSTEMS	60437100	A	22	04.70	
SC1700 SYSTEMS DATA SITE PREPARATION MANUAL 732-XX, 733-10, 791-X, 7077-1 AND 7X54/844	60277000	C	22	01.30	
SYSTEMS DATA SITE PREPARATION MANUAL	60277500	A	22	01.95	
8090 SYSTEMS DATA SITE PREPARATION MANUAL	60275500	B	22	01.45	
1700 SYSTEMS DATA SITE PREPARATION MANUAL	60275600	D	22	01.60	
3170 SYSTEMS DATA SITE PREPARATION MANUAL	60277400	A	22	01.30	
3300 SYSTEMS DATA SITE PREPARATION MANUAL	60275900	A	22	01.05	
3500 SYSTEMS DATA SITE PREPARATION MANUAL	60276100	C-E	22	01.15	
6200 SYSTEMS DATA SITE PREPARATION MANUAL	60277300	A	22	01.30	
6400 SYSTEMS DATA SITE PREPARATION MANUAL	60276400	B	22	01.00	
6500 SYSTEMS DATA SITE PREPARATION MANUAL	60276500	R	22	01.00	
6600 SYSTEMS DATA SITE PREPARATION MANUAL	60276600	B	22	01.00	
6700 SYSTEMS DATA SITE PREPARATION MANUAL	60277100	A	22	01.10	
7611-11 SERVICE STATION - SYSTEMS DATA	60277200	A	22	03.25	
2700 SYSTEMS DATA SITE PREPARATION MANUAL	60277800	B	22	06.00	

1.Publication number of literature
2.The latest revision level
3.Indicates number of holes punched
in manual for use with hard cover
ringed binder.

4.Price per manual.
5. Manual page count.

TITLE	1	2	3	4	5
90100 SYSTEMS DATA SITE PREPARATION MANUAL (INCLUDES PRODUCT SPECIFICATION)	60286800	A	22	02.00	
SECTION 3 PERIPHERAL EQUIPMENT DATA SITE PREPARATION MANUAL	60275300	06	22	02.40	
SECTION 3 MINI COMPUTER SYSTEMS	60437200	A	22	05.35	
VENDOR MANUALS					
BENDIX MTA-3 MAGNETIC TAPE ACCESSORY (DRS)	AET05611		3	05.55	
BENDIX PROGRAM PREPARATION ROUTINE TECH MAN	APT45910		3	03.75	
BRVANT DRUM SERVICE MANUAL	60194200				
CALCOMP - MODEL 565 PLOTTER INSTRUCTION MANUAL - (SPECIAL ORDER ITEM-60 DAY DELIVERY) CONTAINS DESC., INSTAL., THEORY OF OP., OPERATING INSTRUCTIONS, MAINTENANCE AND PARTS LIST. (JUNE 1969)	60148100			30.00	
DATA PRODUCTS 5024/810 DISC FILE REFERENCE (SPECIAL ORDER ITEM-VENDOR COST 47.00)	60095600				
DIGITRONICS - MODEL R3000 PERFORATED TAPE READER - CONTAINS INSTALLATION, OPERATION, THEORY OF OP., MAINTENANCE, SCHEMATICS AND WIRING DIAGRAMS	60143200		22	09.75	
DIGITRONICS - MODEL B6090 PERFORATED TAPE HANDLER - CONTAINS DESCRIPTION, INSTAL., OPERATION, THEORY OF OP, MAINT., AND SCHEMATICS	60143100		22	02.70	
GENERAL PRECISION 4440 HIGH SPEED PUNCH MAINTENANCE AND TRAINING	ESD10504		3	10.20	
IBM MODEL 31 MONITOR TYPEWRITER WITH SOROBAN MODIFICATION - REF/INSTRUCTION MANUAL INCLUDES DESCRIPTION, OPERATION, MAINT.	60008300	B	22	07.90	
IBM SELECTRIC SERIES 73 I/O TYPEWRITER REFERENCE MANUAL - INCLUDES MAINT., ADJUSTMENTS, REMOVAL INFO, TIMING CHARTS, WIRING DIAGRAMS, PARTS LIST	60095900	B	22	15.95	
IBM 1311 CE INSTRUCTION MANUAL	60142000			04.35	
IBM 1311 CE MAINTENANCE MANUAL	60152100			03.60	
IBM 1407 CONSOLE INQUIRY CE REFERENCE MANUAL	60142100		22	03.40	
PAPER TAPE PUNCH HANDLER (NCR) CE MANUAL	60297300	A		05.00	
NCR FM-P3 PAPER TAPE PUNCH	60295600	A	22	04.80	
NCR PUNCH MANUAL FM-P2 MX-1027-7	60143600			02.55	
SUPPLEMENT NO.1 TO C.O.C. PAPER TAPE PUNCH (NCR FM-31/P2) (ADDENDUM TO 60143600)	60211600			01.00	
NCR CARD FM-02 (PE) CE MANUAL (REV. 12/67)	60161300	B	22	05.05	
REMEX PAPER TAPE SPOOLER (MODEL RS0502ARB/ S28) CE MANUAL	60207700	B	22	01.90	
GINGER BUSINESS MACHINES LINE PRINTER EQUIPMENT MODELS 53/54/55/56 FIELD SERVICE MANUAL VOL I	59708600	A01	3	02.50	
FIELD SERVICE MANUAL VOL II	59709000	B01	34	08.25	
REFERENCE MANUAL (TRAINING)	59708500	B	3	02.00	
PARTS MANUAL	59708700	D	3	11.45	

1.Publication number of literature
2.The latest revision level
3.Indicates number of holes punched
in manual for use with hard cover
ringed binder.

4.Price per manual.
5. Manual page count.

TITLE	1	2	3	4	5
TALLY PAPER TAPE READER, REF INSTRUCTION	60116900			04.60	
TELETYPE 147624 BRPE PUNCH INSTALLATION	13796300	A		01.00	
TELETYPE PAPER TAPE PUNCH TECH MANUAL BRPE 11(BULLETTN 215B)	60095700			07.50	
TELETYPE PAPER TAPE PUNCH PARTS MANUAL (BRPE-11) (BULLETIN 1154B)	60095800			03.60	
TELETYPE PARTS MANUAL MODELS 32 AND 33 (BULLETIN 1184B)	60144200			05.25	
TELETYPE TECH MANUAL TAPE READER SET (BULLETTN 267B)	41608700			03.60	
TELEX 5403 TRAIN PRINTER DIAGRAMS, W/L CE MANUAL VOLS 1-3	50578700	B		15.30	
DIAGRAMS, W/L, PARTS DATA CL7A2 VOLS 1-3	50581200	B	22	10.65	
5416 TELEX PRINT CART GEN. DFSC., MAINT., THEO.OF OPER., CE MANUAL	50581500	C	22	01.20	
(THE FOLLOWING MANUALS FOR THE ABOVE PRODUCT ARE AVAILABLE ON A SPECIAL ORDER BASIS IN MAX. QTY OF 2 COPIES.ALLOW AT LEAST 3-4 WEEKS FOR PROCESSING AND DELIVERY.)					
AMPEX CDFR-400 TAPE TRANSPORT	60017400				
AMPEX COTM-2 TAPE TRANSPORT	60017500	A			
LONG LINE TRANSMISSION FOR 1604 TYPE I/O CE MANUAL	60013600	A	22	01.40	
(THE FOLLOWING MANUALS FOR THE ABOVE PRODUCT ARE AVAILABLE ON A SPECIAL ORDER BASIS IN MAX. QTY OF 2 COPIES.ALLOW AT LEAST 3-4 WEEKS FOR PROCESSING AND DELIVERY.)					
COMPUTER BUFFER CHANNEL LONG LINE DRIVERS	60123100	A	22	00.75	
COMPUTER NORMAL CHANNEL LONG LINE DRIVERS	60123200	A	22	00.75	
LONG LINE TRANSMISSION FOR 3000 PERIPHERAL CE MANUAL	60317100	A	22	04.50	
MISCELLANEOUS EQUIPMENT MODIFICATIONS (PRIOR TO STANDARD OPT,SPECIAL OPT AND QSE.)					
NCR COMPUTER VOL III DIAGRAMS MANUAL	60010200	A	24	04.60	
(THE FOLLOWING MANUALS FOR THE ABOVE PRODUCT ARE AVAILABLE ON A SPECIAL ORDER BASIS IN MAX. QTY OF 2 COPIES.ALLOW AT LEAST 3-4 WEEKS FOR PROCESSING AND DELIVERY.)					
CONTROL MONITOR C-2539/GTC	60011400				
DATA SELECT UNIT	60021100				
DIGITAL DATA TERMINAL	60105300				
FADE IN DIAGRAMS	60012000				
FADE IN DIAGRAMS(SERIAL 2)	60012700				
THOMPSON-RAMO-WOOLDRIDGE CX/IX400 EXCH.UNIT	60107700				

1.Publication number of literature
2.The latest revision level
3.Indicates number of holes punched
in manual for use with hard cover
ringed binder.

4.Price per manual.
5. Manual page count.

TITLE	1	2	3	4	5
160-A TEST CONSOLE DIAGRAMS	60103600				
162-A TAPE SYNCHRONIZER(PROTOTYPE DIAGRAMS)	60103800				
163-A MAGNETIC TAPE SYSTEM (WEBSTER)	60008600				
164-A TAPE SIGNAL CONDITIONER	60025400				
924-B (SERIAL 3) 77 PASS DIAGRAMS	60109500				
924-B (SERIAL 9) BREAKPOINT SWITCH MOD	60102900				
924-B ITEK MODIFICATION	60109600				
1619X MAGNETIC DISK FILE CONTROLLER DIAG(AIL	60110300				
QSF					
PUBLICATIONS FOR QSF#S ARE NOT STOCKED.THEY ARE AVAILABLE IN QZALIN FORM ONLY. WHEN ORDERING,FURNISH QSE NUMBER AND DESCRIPTION AND ALL AVAILABLE INFO WILL BE SENT.					
STANDARD OPTIONS					
(NOTE 1. INFO FOR THIS OPTION IS INCLUDED IN BASIC MANUALS FOR RESPECTIVE PRODUCT. SEE INDIVIDUAL EQUIPMENT LISTING)					
955 SEQUENTIAL NUMBERING DEVICE OPTION GEN DESC., THEORY OF OPER., DIAGRAMS AND PARTS DATA CE MANUAL	91503500	A	3	03.75	
10001 EIGHT 603 ON 162-1(MAPE 101)	60115800				
10003 1604-B MODIFICATION DIAGRAMS(SEE NOTE 1					
10005 160-A INTERFACE FOR 3206 REFERENCE/ INSTRUCTION (MAPE 223)-SEE NOTE 1					
10006 924/924-A CORE STOR CONVERTS 8K TO 16K SEE NOTE 1					
10007 924/924-A CORE STOR CONVERTS 16K TO 32K (SEE NOTE 1)					
10008 924/924-A CORE STOR CONVERTS 8K TO 32K (SEE NOTE 1)					
10009 1604A/P/C CORE STORAGE CONVERSION 16K TO 32K (SEE NOTE 1)					
10010-A LONG LINE DRIVER	60317100	A	22	04.50	
10012 SPECIAL 501 PRINT DRUM(SLOTTED OH)(SEE NOTE 1)					
10013 3200 CONSOLE FOR 3100 (SEE NOTE 1)					
10015 DUAL MOTOR/GENERATOR SET (NO PUBL NEED OR AVAILABLE FOR THIS OPTION)					
10040-10043 (INFO AVAILABLE IN 1700 DIAGRAMS MANUAL-60152700)					
10099-A SPEED IMPROVEMENT REF/CE MANUAL REF INFO (USE 3300 COMPUTER SYSTEM REF MAN) CE INFO (SEE 3304-A OR 3304-B)	60199800	D	22	02.90	
10103-A CEJ/MEJ FOR 6400/6500 COMPUTERS CE MANUAL	60202100	D	22	01.65	
REF INFO (USE 6000 REFERENCE MANUAL)					
10104-A/B/C/D CENTRAL AND MONITOR EXCHANGE JUMPS FOR 6600 DESC,OPER,PROG,REF MANUAL	60203200	D	22	01.00	

1.Publication number of literature
2.The latest revision level
3.Indicates number of holes punched in manual for use with hard cover ringed binder.

4.Price per manual.
5. Manual page count.

TITLE	1	2	3	4	5
10104-C/D (CE INFO - USE 6613-D CENTRAL MEMORY CE MANUAL - 60246600)					
10115-A REFERENCE MANUAL	60180200	A	22	02.25	
10121 (AT105-A) ACCESS CHANNEL REF INFO (USE 3500 REF MANUAL)					
10123 (AT106-A, AT115-A) MEMORY PROTECT REF/CE INFO (USE AT106-A)					
10124-A 6603 DISK SPEED INCREASE REFERENCE/CE MANUAL	60227500	A	22	01.65	
10126 (GA103-A/B/C, GA104-A/B) TIME BASE SOURCE REFERENCE MANUAL	41600900	B	22	01.50	
10127 (DK502-A) EXPANDED MEMORY OPTION REF INFO (USE 3316-1 REFERENCE MAN.)					
10128 (DK501-A) DUAL MODE OPTION REFERENCE MANUAL	41603000	A	22	01.00	
10169 CENTRAL MEMORY ACCESS PRIORITY FOR					
6400/6500-A/B/C CENTRAL COMP. (USE AT129-A					
6600 SERIALS 1-47 CENT. COMP. (USE AT131-A					
6400/6500/6600-D CENT. COMP. (USE AT130-A)					
10177-1 16K MEMORY INCREMENT FOR					
6415-A/B/C COMPUTER SYSTEM (USE AT142-F)					
6415-D COMPUTER SYSTEM (USE AT142-G)					
AA108-A COMPUTER SYSTEM (USE AT142-B)					
10178-1 32K MEMORY INCREMENT FOR					
6414/6514-A/B/C COMPUTER SYS (USE AT140-F)					
6414/6514-D COMPUTER SYSTEM (USE AT140-H)					
AA105-A COMPUTER SYSTEM (USE AT140-B)					
10179-1 16K MEMORY INCREMENT FOR					
6615-D COMPUTER SYSTEM (USE RR365-B)					
10180-1 32K MEMORY INCREMENT FOR					
6614-A/B/C COMPUTER SYSTEM (USE AT168-G)					
6614-D COMPUTER SYSTEM (USE AT168-J)					
AA103-A COMPUTER SYSTEM (USE AT168-B)					
10194-1 (FV150-A) INTERNAL BCD TO ASCII HOLLERITH CONVERSION KIT FOR THE 3446-A/B CARD PUNCH CONTROLLER					
REF INFO (USE 3446-A/B REF MANUAL)					
CE INFO (USE FV150-A)					
10194-2 (FV149-A) ASCII HOLLERITH TO BCD CONVERSION KIT FOR THE 3447-B CARD READER CONTROLLER					
REF INFO (USE 3248-A REF MANUAL)					
CE INFO (USE FV149-A)					
10256-1 (AF101-B, AF104-A) 3200 BDP OPTION REFERENCE MANUAL	60347700	B	22	09.75	
10256-1 AND 10287-3 OR 10289-1 AND 10256-3 REFERENCE MANUAL	97402600	A	22		
CE INFO (USE AT146-A)					
10256-2 (AF101-B, AF104-B) 3100 BDP INTERFACE OPTION REFERENCE MANUAL	97401800	A	22	01.20	
10256-2 AND 10287-4 OR 10287-2 AND 10256-4					

1. Publication number of literature
2. The latest revision level
3. Indicates number of holes punched in manual for use with hard cover ringed binder.

4. Price per manual.
5. Manual page count.

TITLE	1	2	3	4	5
REFERENCE MANUAL CE INFO (USE AF107-A) 10285-1 () DUAL CHANNEL SWITCH OPTION GENERAL INFO (USE 7054-1) OPERATION AND PROGRAMMING (USE 7054-1) 10287-1 (AF105-A, BT193-A, CD124-A) 3200 ENHANCED BLOCK CONTROL OPTION REFERENCE MANUAL	97402200	A	22	03.85	
10287-2 (3106-A/B, AF106-A, CD124-A) 3100 ENHANCED BLOCK CONTROL OPTION REFERENCE MANUAL	97402400	A	22	03.60	
10293-1/2 (DT194-A, DT196-A) CHANNEL MODIFICATION REF/CE MANUAL	97402000	A	22	01.80	
10308-2 (AT292-A, AT293-A) GO MODE/SDL 10309-1 (AT289-A, AT294-A) GO MODE/SDL-AC104 10309-2 (AT289-A, AT295-A) GO MODE/SDL-AC106 10336-1 (1784) REAL TIME CLOCK REF MANUAL 10339-1 (FA103-A) MASS STORAGE CONTROLLER REF INFO (USE 7639-1)	60406300	A	22	17.00	
10348-1 (AT311-A) DATA CHANNEL CE INFO (USE AA106-A) REF INFO (USE CYBER 76 REF MANUAL PUBLICATION NO. 60367200)	89638800	01	22	01.65	
10348-2 (AT312-A) DATA CHANNEL CE INFO (USE AA106-A) REF INFO (USE CYBER 76 REF MANUAL PUBLICATION NO. 60367200)					
(THE FOLLOWING MANUALS FOR THE ABOVE PRODUCT ARE AVAILABLE ON A SPECIAL ORDER BASIS IN MAX. QTY OF 2 COPIES.ALLOW AT LEAST 3-4 WEEKS FOR PROCESSING AND DELIVERY.) 10078-A 3306 TO 160/160-A INTERFACE REF/CE	60166500	A	22		
SPECIAL OPTIONS					
60002-A 161-S TYPEWRITER UNIT MANUAL MAPE105	60041500				
60006-A 924 SPEED IMPRV.PKG (MAPE 245)	60102200				
60006-A 924-A SPEED IMPROV PKG(MAPE 245)	60102700				
60007 3637 DPUM CONTROLLER CE DIAGRAMS	60184600				
60008-A 8030 POWER FAILURE INTERRUPT(MAPE345	60120400				
60009-A 3256 ERROR CHECKING REF/DIAGRAMS MAN	60122800				
60009-A 3256 LINE PRINTER ECHO CHECK C/P-E/S	60142300				
60014-A 165-2 REFERENCE/INSTP(MAPE 112)	60113300			02.70	
60014/15-A (MAPE 111/114) CE DIAGRAMS	60097200		34	03.00	
60015-A 165-2 REFERENCE/INSTR(MAPE 113)	60113300			02.70	
60016-A 160/160-A EXCHANGE UNIT REF. MANUAL	36812800		22	02.70	
60016-A 160/160-A CARD PL AND EQ SUMMARY	36812900				
60017-A 603/604/606/607 CHAN SWITCH CONSOLE	60105200				
60018-A 603/604/606/607 CHAN SWITCH CONSOLE	60105200				
60022 DATA CHANNEL CONVERTER					

1.Publication number of literature
2.The latest revision level
3.Indicates number of holes punched
in manual for use with hard cover
ringed binder.

4.Price per manual.
5. Manual page count.

TITLE	1	2	3	4	5
CE MANUAL	60390200				
60026 REFERENCE/CE MANUAL	38705100	D	22	04.40	
60028-A/B/C/D/E					
REFERENCE MANUAL	60333700	A	22	01.20	
CE MANUAL	60390300	A		22	
60029 405 CARD READER CONTROLLER REF MANUAL	60333800	A	22	01.00	
CE MANUAL	60390400	A	22		
60031 (CE601-A, CE602-A) 45 COLUMN CARD READ MODIFICATION					
60032-A 3604 DIAGRAMS PAGE 186	60042100	AT	34	08.45	
60064-A REFERENCE/CE MANUAL	60201300			03.10	
60076 CE MANUAL (2321 DATA CELL ADAPTOR FOR 3234 MASS STORAGE SUBSYSTEM)	60197400			06.45	
60118 MAGNETIC TAPE TRANSPORT MAINT, DIAGS.	41240200	B	22	01.45	
60126 3000/7000 DATA CHANNEL ADAPTER	60296900	A	22	08.40	
65005 DATA SET ADAPTER MODULE TESTER REF/ CE MANUAL	41607700	D	22	04.10	
65006 (GK111-A) TAPE EXERCISER SPECIAL OPTION 68091 INTRO. OPER. PROG. INSTL. CHKOUT., PRINCIPLES OF OPER., MAINT. DIAGS, W/L EQ SUM. PARTS DATA CE MANUAL	44977000	C	22	02.90	
65075 (DC401-A) MASS STORAGE EXTENDER					
65102 () BUS PARITY CHECKING CE INFO (USE AT281-A IN SECTION 1)					
(THE FOLLOWING MANUALS FOR THE ABOVE PRODUCT ARE AVAILABLE ON A SPECIAL ORDER BASIS IN MAX. QTY OF 2 COPIES. ALLOW AT LEAST 3-4 WEEKS FOR PROCESSING AND DELIVERY.)					
60013-A 3200 STORAGE MOD CONNECTOR (MAPE 298)	35076500				
60016-B MAINTENANCE SUPPLEMENT	60196100				
60022 DATA CHANNEL CONVERTER					
170 MODIFICATION REFERENCE MANUAL	60334700	A			
1612 MODIFICATION REFERENCE MANUAL	60334800	A			
60028-A/B/C/D/E CE MANUAL	60390300	A			
60029 405 CARD READER CONTROLLER CE MANUAL	60390400	A			
60032-A 3604-A/B BILLABLE TIME METER SUPPL	17632300				
CYBERNET PUBLICATIONS					
6400 KRONOS LIBRARY PROGRAMS	86605900	D	3	07.90	
6000 CYBERNET SCOPE 3.3 REFERENCE MANUAL	86618000		3	07.15	
6600 SCOPE 3.3 LIBRARY ROUTINES	86607700	A	3	01.00	
ADLPIPE-STATIC-THERMAL-DYNAMIC PIPE STRESS ANALYSIS USER INFORMATION MANUAL	86602800	B	3	02.00	
AID 6600 LEARNERS GUIDE SURVEY ANALYSIS WITH QA-PAK-CYBERNET SERVICES	86601800		3	01.50	
ANSYS EXAMPLES MANUAL	76070900		3	10.50	
ANSYS INTRODUCTORY MANUAL	84000900		3	01.50	
ANSYS USER INFORMATION MANUAL	86616800	C	3	15.30	
APT CYBERNET USER INFORMATION MANUAL	84000500	A	3	02.00	

1. Publication number of literature
2. The latest revision level
3. Indicates number of holes punched
in manual for use with hard cover
ringed binder.

4. Price per manual.
5. Manual page count.

TITLE	1	2	3	4	5
APTURN USER INFORMATION MANUAL	84002100		3	05.00	
ATHENA - ON-LINE INTERACTIVE RETRIEVAL/ UPDATE LANGUAGE U.I.M.	76071400	A	3	02.50	
AUTOFLX USER INFORMATION MANUAL	84000800		3	04.90	
AVAS USER INFORMATION MANUAL	00015100	A	3	01.50	
BRIDGE ANALYSIS AND RATING SYSTEM MANUAL	86618500		3	07.50	
CYBERNET SERVICES PROGRAM LIBRARY CATALOG	86616900	A	3	02.00	
CC-TEGAS3 - TEST GENERATION AND SIMULATION SYSTEM USER INFORMATION MANUAL	76070700	A	3	05.00	
CELS USER INFORMATION MANUAL	86612300	B	3	07.15	
CELS PROGRAM ABSTRACTS	86612500		3	01.00	
CENSTAT-CENSUS STATISTICS-GENERAL INFORM- ATION MANUAL	86603700		3	01.00	
CENSTAT TEMPLATE	86613500			00.50	
CIVCO USER INFORMATION MANUAL	86603000	B	3	04.00	
CONTROL 2000 DEMONSTRATION SCRIPT	84003700		3	01.00	
CRYSPAK-CRYSTALLOGRAPHY PACKAGE USER INFO	86605600	A	3	04.50	
CYBER 70/MODEL 76 TERMINAL USERS GUIDE	76072700		3	01.00	
CYBERLOAN GENERAL INFORMATION MANUAL	86616100	A	3	02.25	
CYBERNET/KRONOS 2.0 TO 2.1 CONVERSION GUIDE	84002600		3	02.00	
CYBERNET/KRONOS 2.1 BASIC PROGRAMMING LANGUAGE REFERENCE MANUAL	84001900	A	3	03.00	
CYBERNET/KRONOS 2.1 BATCH AND REMOTE BATCH REFERENCE MANUAL	84000600		3	10.90	
CYBERNET/KRONOS 2.1 TIME-SHARING FORTRAN REFERENCE MANUAL	84001700	B	3	03.00	
CYBERNET/KRONOS COMPILER SUBROUTINE AND SYSTEM UTILITY SUPPLEMENT	84002000	A	3	01.50	
CYBERNET/KRONOS PROCEDURE FILES REFERENCE	84001000	A	3	03.00	
CYBERNET/KRONOS TIME-SHARING USERS REFERENCE	84001800		3	03.00	
CYBERNET/PROSE CALCULUS OPERATIONS MANUAL	84003200	A	3	03.50	
CYBERNET/PROSE DEBUGGING OPERATIONS MANUAL	84003100		3	01.00	
CYBERNET/PROSE PROCEDURAL OPERATIONS MANUAL	84003000	A	3	02.00	
CYBERNET/PROSE SYSTEM GUIDE	84002900	A	3	02.20	
DDO/TRANPLAN USER INFORMATION MANUAL	86615700		3	09.00	
DD-PLOT USER INFORMATION MANUAL	86618400		3	02.50	
DECIDER USER INFORMATION MANUAL	86602900	A	3	01.00	
DISSPLA BEGINNERS USER INFORMATION MANUAL	84001200		3	03.50	
DISSPLA CYBERNET SUPPLEMENT	84001400		3	01.00	
DISSPLA INTERMEDIATE USER INFORMATION MANUAL	84001300		3	03.00	
DISSPLA ADVANCED USER INFORMATION MANUAL	84001500		3	06.40	
EAC/EASE-ELASTIC ANALYSIS FOR STRUCTURAL ENGINEERING-GENERAL INFORMATION MANUAL	86603100	A	3	01.00	
EAC/EASE-ELASTIC ANALYSIS FOR STRUCTURAL ENGINEERING-USER INFORMATION MANUAL	86603200	B	3	02.00	
EAC/EASE-ELASTIC ANALYSIS FOR STRUCTURAL ENGINEERING-DATA CARD DIGEST	86603300	A	3	01.00	
EAC/EASE-2 USER INFORMATION/THEORETICAL MAN	84002700	A	3	03.50	
E/CUBE ENERGY ANALYSIS CYBERNET SERVICE GUIDELINES	86608900	C	3	01.00	
EASE ADDENDUM A-ENGINEERING APPLICATIONS AND PROBLEM SOLUTIONS	86607100		3	02.35	
EASE ADDENDUM B - THEORETICAL REFERENCES	86607200		3	03.90	

1.Publication number of literature
2.The latest revision level
3.Indicates number of holes punched
in manual for use with hard cover
ringed binder.

4.Price per manual.
5. Manual page count.

TITLE	1	2	3	4	5
ELECTRICAL ENGINEERING APPLICATION GUIDE	86619700		3	01.00	
FAAST USER INFORMATION MANUAL	84009800		3	02.50	
FASTIME/LOADFLOW POWER SYSTEM ANALYSIS U.I.M	76071200		3	03.40	
FINITE ELEMENT LEARNERS GUIDE	86616600		3	01.00	
GENERAL ACCOUNTING APPLICATIONS APRIL MINI-MANUAL	86613800			01.35	
GENERAL ACCOUNTING APPLICATIONS GENERAL LEDGER SYSTEMS MINI-MANUAL	86613600			01.35	
GENERAL ACCOUNTING APPLICATIONS PAYROLL MINI-MANUAL	86613700			01.35	
GENERAL PURPOSE SIMULATION SYSTEM GIM	84003900	A	3	02.00	
GENSAP USER INFORMATION MANUAL	86619900	B	3	02.00	
GINA-GENERATE INPUT FOR CDC/NASTRAN UIM	84006700		3	01.00	
IFMS-INTERACTIVE FINANCIAL MODELING SYST.UIM	76070400		3	01.00	
INIS-INTERACTIVE INTERFACE TO SCOPE USERS GUIDE	84002800		3	01.00	
KRONOS TIME-SHARING TUTORIAL MANUAL	86615800	C	3	04.50	
LOADFLOW-POWER SYSTEM PLANNING PROGRAM USER INFORMATION MANUAL	86604600		3	02.00	
MAGEN 6000 USER INFORMATION MANUAL	86604700	A	3	02.00	
MARC I SHADOW/SHADE TERMINAL USERS GUIDE	86607800	A	3	09.50	
MARC II SHADOW/SHADE TERMINAL USERS GUIDE	86607900		3	09.50	
MARC II TERMINAL-EXPORT/IMPORT TERMINAL USER GUIDE OPERATING SYSTEM REFERENCE LIBRARY	86606100	A	3	01.50	
MARC-CDC USER INFORMATION MANUAL VOL 1	17309500	F	3	05.50	
MARC-CDC USER INFORMATION MANUAL VOL II PROGRAM INPUT	17311600	E	3	05.50	
MARC-CDC USER INFORMATION MANUAL VOL III DEMONSTRATION PROBLEMS	17311700	F	3	05.50	
MARS VI REFERENCE MANUAL	76070100		3	04.50	
MATH PROGRAM GENERAL INFORMATION-CYBERNET SERVICES	86614100		3	01.00	
MATH SCIENCE LIBRARY CYBERNET USER GUIDE	86612100		3	01.00	
MEDISHARP GENERAL INFORMATION MANUAL	39771300	A	3	01.50	
MEDISHARP PATIENT ACCOUNTING	86618900		3	03.50	
MTIAS USER INFORMATION MANUAL	86615000	A	3	07.50	
MRI/STARDYNE-FINITE ELEMENT DEMONSTRATION PROBLEMS	84002500		3	01.00	
MRI/STARDYNE-DYNAMIC STRUCTURAL ANALYSIS SYSTEM-USER INFORMATION MANUAL	86603500	D	3	08.65	
MRI/STARDYNE THEORETICAL MANUAL	86616300	A	3	09.75	
NAR/SYSCAP-SYSTEM OF CIRCUIT ANALYSIS PROGRAMS-(DOMESTIC) SOLD IN SETS ONLY	86602000			14.00	
NAR/SYSCAP-SYSTEM OF CIRCUIT ANALYSIS PROGRAMS-(INTERNATIONAL)SOLD IN SETS ONLY	86602300		3	13.80	
NASTRAN APPLICATIONS MANUAL - FRONT MATTER	86616700	K	3	11.10	
NASTRAN-NASA STRUCTURAL ANALYSIS BASIC TRAINING MANUAL	86612600	A	3	02.00	
NASTRAN-GENERAL INFORMATION MANUAL	86614300	A	3	01.00	
NASTRAN-TECHNICAL ARTICLES	86619600		3	01.00	
NETFLOW II-NETWORK FLOW ROUTINE U.I.M.	86604900		3	02.75	
ODD/LP-RAPID LINEAR PROGRAMMING SYSTEM USER INFORMATION MANUAL	86604800		3	01.00	

- 1.Publication number of literature
- 2.The latest revision level
- 3.Indicates number of holes punched
in manual for use with hard cover
ringed binder.

- 4.Price per manual.
5. Manual page count.

TITLE	1	2	3	4	5
PDS/MAGEN - A GENERAL PURPOSE PROBLEM DESCRIPTOR SYSTEM UIM	84009900	A	3	02.50	
PERSONNEL DEMO SCRIPT	84003800		3	01.00	
PIPFLEX USER MANUAL SUPP. CYBERNET SERVICE	86615100		3	01.00	
PMCS USER INFORMATION MANUAL	86615500	D	3	04.00	
PPS IV PROJECT PLANNING SYSTEM GENERAL INFORMATION MANUAL	86608400		3	01.00	
PPS IV PROJECT PLANNING SYSTEM USER INFORMATION MANUAL	86608500	A	3	03.00	
PIPEFLEX-PIPING FLEXIBILITY ANALYSIS-USER INFORMATION MANUAL	86614200		3	01.00	
PIPFLEX-CYBERNET USER INFORMATION MANUAL	84000100	A	3	04.00	
PRICE SCHEDULE FOR CYBERNET SERVICE (FOR CDC USE ONLY)	86608000	C	3	01.00	
PISCES IDL MANUAL A USER INFORMATION MANUAL	86617100	B	3	01.00	
PISCES IDL MANUAL B USER INFORMATION MANUAL	86617200	A	3	03.50	
PISCES IDL MANUAL C USER INFORMATION MANUAL	86617300	B	3	01.50	
PISCES IDL MANUAL D USER INFORMATION MANUAL	86617400	A	3	01.00	
PISCES 2DL MANUAL A USER INFORMATION MANUAL	86617500	A	3	01.00	
PISCES 2DL MANUAL B USER INFORMATION MANUAL	86617600	A	3	03.50	
PISCES 2DL MANUAL C USER INFORMATION MANUAL	86617700	B	3	01.50	
PISCES GEOMETRIC RATIOS USER INFORMATION MAN	86617900		3	02.50	
PI/PLOT-USER INFORMATION MANUAL	86618300		3	01.00	
PLOT 10 TERMINAL CONTROL SYSTEM USER INFO	84002400		3	02.00	
A PRIMER TO QUESTAIRE AND MARKETING RESEARCH DATA PROCESSING TECHNIQUES	86607500	A	3	01.00	
QUESTIONNAIRE ANALYSIS PACKAGE-COMPTRAN LEARNERS GUIDE	86601700		3	01.00	
QUESTIONNAIRE ANALYSIS-MARGINAL LEARNERS GUIDE	86601600		3	01.00	
QUESTIONNAIRE ANALYSIS PACKAGE-GENERAL INFORMATION MANUAL	86604300	A	3	01.00	
QUESTAIRE II GENERAL INFORMATION MANUAL	86604100	A	3	01.00	
QUESTAIRE II USERS INFORMATION MANUAL	86604200	C	3	03.00	
RISK ANALYSIS USERS INFORMATION MANUAL	86604000	A	3	03.15	
SCOPE VERSION 3.3 TO VERSION 3.4 CONVERSION AIDS	84000700		3	01.50	
SCIPLOT USER INFORMATION MANUAL	84000000		3	01.00	
SIMULATORS-1130 (II) SIMULATION OF A MARC II TERMINAL-F/I 200 TERMINAL USER GUIDE	86606200	A	3	03.10	
SPECIAL ADDENDUM FOR EASE (ELASTIC ANALYSIS FOR STRUCTURAL ENGINEERING)	86607000		3	01.00	
SPSS/ON LINE KRONOS VER2.1 U.T.M.	84009600		3	01.00	
SYSCAP TUTORIAL INTRODUCTION GUIDE TO BEGINNER USERS	84000400		3	06.00	
SYSCAP II-SYSTEMS OF CIRCUIT ANALYSIS PROGRAMS USER INFORMATION MANUAL	76070600		3	07.15	
SYSTEM 2000 LEVEL 2 - A MULTI-PURPOSE DATA MANAGEMENT SYSTEM					
DIAGNOSTIC MESSAGE SUPPLEMENT	76074300		3	01.50	
FORTAN PROCEDURAL LANGUAGE SUPPLEMENT	76074600		3	02.00	
IMMEDIATE ACCESS FEATURE SUPPLEMENT	76074400		3	02.00	
REPORT WRITER FEATURE SUPPLEMENT	76074700		3	02.00	

1. Publication number of literature
2. The latest revision level
3. Indicates number of holes punched
in manual for use with hard cover
ringed binder.

4. Price per manual.
5. Manual page count.

TITLE	1	2	3	4	5
USER INFORMATION MANUAL	76074000		3	04.00	
TESS USER INFORMATION MANUAL	86615900		3	05.00	
TESS GENERAL INFORMATION MANUAL	86618200		3	01.00	
TESS-TTY USER INFORMATION MANUAL	84001100		3	01.00	
TOTAL-CDC REFERENCE MANUAL	76070300		3	03.50	
XEDIT - EXTENDED KRONOS TEXT EDITOR U.I.M.	76071000		3	01.50	

STRU-PAK - STRUCTURAL ANALYSIS PACKAGE					
MASTER INSTRUCTION GUIDE	86608600	C	3	01.00	
PROGRAM ABSTRACTS	86608700	B	3	01.00	
** USER INFORMATION MANUALS					
CENSECT - PLANAR SECTION PROPERTIES OF ARBITRARY CROSS SECTIONS	86609000		3	01.00	
STANSECTP - PLANAR SECTION PROPERTIES OF STANDARD CROSS SECTIONS	86609100		3	01.00	
BEAMCOL - BENDING ANALYSIS OF VARIABLE CROSS-SECTION BEAM COLUMNS	86609200	A	3	01.00	
STANBEAM - BENDING ANALYSIS OF VARIABLE CROSS-SECTION BEAMS	86609400	A	3	01.00	
MULTISPAN - BENDING ANALYSIS OF MULTISPAN BEAMS	86609500		3	01.00	
ELASTCOL - ELASTIC STABILITY OF END LOADED COLUMNS	86609300	A	3	01.00	
TNRING - ELASTIC ANALYSIS OF RINGS WITH INPLANE LOADS	86609600	A	3	01.00	
OUTRING - ELASTIC ANALYSIS OF RINGS WITH OUT-OF-PLANE LOADS	86609700		3	01.00	
2DGENFRAME - TWO-DIMENSIONAL GENERAL FRAME ANALYSIS PROGRAM	86609800	B	3	01.00	
2DFSAP-TWO-DIMENSIONAL STRUCTURAL ANALYSIS PROGRAM	86609900	B	3	01.00	
3DFSAP-THREE-DIMENSIONAL STRUCTURAL ANALYSIS PROGRAM	86610000	B	3	01.00	
GRIDSAP - GRID STRUCTURAL ANALYSIS PROGRAM	86610100	A	3	01.00	
2DTSAP - TWO-DIMENSIONAL TRUSS STRUCTURAL ANALYSIS PROGRAM	86610200	B	3	01.00	
3DTSAP -THREE-DIMENSIONAL TRUSS STRUCTURAL ANALYSIS PROGRAM	86610300	B	3	01.00	
CIRCPLAT - BENDING ANALYSIS OF CIRCULAR PLATES	86610400	A	3	01.00	
HUBFLAGI - DESIGN AND ANALYSIS OF BOLTED FLANGE CONNECTIONS-INTEGRAL TYPE	86610500		3	01.00	
STIFFSHELL - BUCKLING OF ORTHOTROPIC SHELLS	86610600		3	01.00	
CRITSPEED - CRITICAL SPEEDS ANALYSIS OF ROTATING SHAFTS	86610700		3	01.00	
2DFMAP - TWO-DIMENSIONAL FRAME MODAL ANALYSIS PROGRAM	86610800	B	3	01.00	
3DFMAP - THREE DIMENSIONAL FRAME MODAL ANALYSIS PROGRAM	86610900	C	3	01.00	
GRIDMAP - GRID MODAL ANALYSIS PROGRAM	86611000	A	3	01.00	

1.Publication number of literature
2.The latest revision level
3.Indicates number of holes punched
in manual for use with hard cover
ringed binder.

4.Price per manual.
5. Manual page count.

TITLE	1	2	3	4	5
2DTMAP - TWO-DIMENSIONAL TRUSS MODAL ANALYSIS PROGRAM	86611100	B	3	01.00	
3DTMAP - THREE-DIMENSIONAL TRUSS MODAL ANALYSIS PROGRAM	86611200	B	3	01.00	
DYNROSS - DYNAMIC RESPONSE OF SIMPLE SYSTEMS	86611300		3	01.00	
SHOCSPEC - SHOCK SPECTRA ANALYSIS OF A SINGLE-DEGREE-OF-FREEDOM SYSTEM	86611400	A	3	01.00	
SINSPONS - SINUSOIDAL RESPONSE OF A MULTI-DEGREE-OF-FREEDOM SYSTEM	86611500	A	3	01.00	
RELSPRING - DESIGN AND ANALYSIS OF RELLEVILLE SPRINGS	86611600	A	3	01.00	
COMSPRING - DESIGN AND ANALYSIS OF HELICAL COMPRESSION SPRINGS	86611700		3	01.00	
TESTRAIN - STRAIN GAGE DATA REDUCTION AND ANALYSIS	86611800		3	01.00	
TORCELL - TORSIONAL ANALYSIS OF SINGLE CELLAR MULTICELLULAR SECTIONS	86611900		3	01.00	
COMPLETE STRU-PAK COLLECTION WITH BINDER AND TABS	86612000		3	21.75	
STRU-PAK PROCESSING COSTS MANUAL	86614000		3	01.00	
SYSTEM 2000 (LEVEL II) MINI-MANUAL	86615600	B		01.35	
TRANPLAN II GENERAL INFORMATION MANUAL	86614400		3	02.50	
S-RAY 70-X-RAY SYSTEM OF CRYSTALLOGRAPHIC PROGRAMS USER INFORMATION PROGRAM	86605700		3	04.65	
ZIPTRAN USER INFORMATION MANUAL	86614600		3	03.25	
LIBRARY OF MATH SUBPROGRAMS - USER INFORMATION MANUAL	86614900	A	3	02.00	

SYSTEMS PROFESSIONAL PACKAGE					
COMPLETE SYSTEMS PROFESSIONAL PACKAGE (INCLUDING BINDER AND TABS)	84006800		3	27.65	
*** USERS GUIDES					
SYSTEMS PROFESSIONAL MASTER USER INFORMATION AND OPERATIONAL INSTRUCTIONS USERS GUIDE	84006900		3	01.00	
CONCRETE COLUMN ULTIMATE STRENGTH DESIGN	84007000		3	01.00	
NON-PRISMATIC CONTINUOUS BEAM DESIGN SERIES	84007100		3	02.50	
RETAINING WALL DESIGN WORKING STRENGTH	84007200		3	01.00	
PRISMATIC CONTINUOUS BEAM DESIGN SERIES	84007300		3	03.00	
PRESTRESSED CONCRETE BEAM DESIGN SERIES	84007400		3	01.00	
FLAT PLATE AND FRAME ANALYSIS AND DESIGN	84007500		3	01.50	
FOOTING DESIGN SERIES-RECTANGULAR OR COMBINED FOOTING DESIGN	84007600		3	01.00	
STEEL COLUMN INVESTIGATION AND DESIGN	84007700		3	01.00	
STEEL BEAM INVESTIGATION AND DESIGN SERIES	84007800		3	01.00	
COMPOSITE STEEL BEAM INVESTIGATION AND D.S.	84007900		3	01.00	
COLUMN BASE PLATE DESIGN	84008000		3	01.00	
WELDED STEEL GIRDER INVESTIGATION AND DESIGN	84008100		3	01.00	
MASONRY, BLOCK OR CONCRETE SHEAR WALL AND PEIP DESIGN	84008200		3	01.00	

1.Publication number of literature
2.The latest revision level
3.Indicates number of holes punched in manual for use with hard cover ringed binder.

4.Price per manual.
5. Manual page count.

TITLE	1	2	3	4	5
MASONRY, BLOCK OR CONCRETE BEARING WALL OF SIGN	84008300		3	01.00	
SAWN TIMBER BEAM DESIGN	84008400		3	01.00	
GLU-LAM TIMBER BEAM DESIGN	84008500		3	01.00	
REGULAR RIGID FRAME ANALYSIS	84008600		3	01.00	
SHEAR WALL-FRAME INTERACTION ANALYSIS	84008700		3	01.00	
MULTI-STORY COLUMN LOAD TAKE-OFF TABULATION	84008800		3	01.00	
SPSTRESS-GENERAL STRUCTURAL SYSTEMS ANALYSIS	84008900		3	02.00	
SIMPLE SPAN BEAM ANALYSIS OPTIONAL CANTILEVR	84009000		3	01.00	
MULTI-STORY WIND OR EARTHQUAKE ROTATIONAL ANALYSIS	84009100		3	02.00	
SMALL RIGID FRAME ANALYSIS	84009200		3	01.00	
DETERMINE TRUSS ANALYSIS	84009300		3	01.00	
THE TWO ITEMS BELOW ARE NOT INCLUDED IN THE COMPLETE PACKAGE AND MUST BE ORDERED SPTLY					
MODIFIED PCA FLAT PLATE, FLAT SLAB, WAFFLE SLAB AND FRAME ANALYSIS AND DESIGN USERS GD	84009400		3	01.50	
SYSTEMS PROFESSIONAL PROGRAMS COST GUIDE USFR COST GUIDE	76070800		3	01.00	

LEAHS PRODUCT DESCRIPTION MANUALS					
LEAHS PHASE III OVERVIEW	84004300		3	01.00	
PWR SEQUENCE OVERVIEW	84004000		3	01.00	
BWR SEQUENCE OVERVIEW	84004200		3	01.00	
PWR BENCHMARKING	84005800		3	01.00	
LEAHS INDIVIDUAL CODE MANUALS					
CHEETAH-P	84004100		3	03.00	
NAIHYDRO-B	84004400		3	01.00	
NAIHYDRO-P	84004500		3	01.00	
FTT	84004600		3	01.00	
SHUFFLE	84004700		3	03.25	
INTREGAL	84004800		3	02.00	
EDIT-C	84004900		3	01.00	
EXPAND	84005000		3	01.00	
PUNCHER-P	84005100		3	01.00	
PD07LEAHS	84005200		3	03.35	
MODEL	84005300		3	01.00	
COPC-BLADE	84005400		3	01.00	
NAI LASER	84005500		3	01.00	
COPC-PTN	84005600		3	01.00	
NAI 3D-P	84005700		3	02.00	
PUNCHER-B	84005900		3	01.00	
DPFFIT	84006000		3	01.00	
CHEETAH-B	84006200		3	01.00	
NAI 3D-B	84006300		3	01.50	

1. Publication number of literature
2. The latest revision level
3. Indicates number of holes punched
in manual for use with hard cover
ringed binder.

4. Price per manual.
5. Manual page count.

TITLE	1	2	3	4	5
***** CYBERNET SERVICES BINDERS					
1 INCH,3 RING,CYBERNET,LIGHT BLUE BINDER	60089100		3	04.00	
1 1/2 INCH,3 RING,CYBERNET,LIGHT BLUE BINDER	60089200		3	04.40	
2 INCH,3 RING,CYBERNET,LIGHT BLUE BINDER	60089300		3	04.70	
4 INCH,NYLON POST,RED,SYSTEMS PROFESSIONAL BINDER	60089400		2P	06.50	

1.Publication number of literature
2.The latest revision level
3.Indicates number of holes punched
in manual for use with hard cover
ringed binder.

4.Price per manual.
5. Manual page count.